

Objective

This tech note outlines the main differences in Open Shortest Path First Version 2 (OSPFv2) support between Cisco® NX-OS Software and Cisco IOS® Software. Sample configurations are included for Cisco NX-OS and Cisco IOS Software for some common features to demonstrate the similarities and differences. Please refer to the [NX-OS documentation on Cisco.com](#) for a complete list of supported features.

OSPF Overview

OSPFv2 is an IETF ([RFC 2328](#)) standards-based dynamic link-state routing protocol used to exchange network reachability within an autonomous system.

Important Cisco NX-OS and Cisco IOS Software Differences

In Cisco NX-OS:

- The OSPF feature supports stateful process restarts and In-Service-Software-Upgrades (ISSU) if two supervisors are present in a chassis.
- OSPF command-line interface (CLI) configuration and verification commands are not available until you enable the OSPF feature with the **feature ospf** command.
- The OSPF protocol requires the Enterprise Services license.
- The OSPF instance can consist of 20 characters, whereas the IOS supports numbers 1 ? 65536.
- Eight equal-cost paths are supported by default. You can configure up to sixteen.
- The default reference bandwidth used in the OSPF cost calculation is 40 Gbps.
- Networks and interfaces are added to an OSPF instance under the interface configuration mode.
- An OSPF area can be configured using decimal or decimal dotted notation, but it is always displayed in decimal dotted notation in the configuration and in the **show** command output.
- Passive interfaces are applied to the interface as opposed to under the OSPF router instance. Loopback interface is considered to be passive by default.
- If a router ID is not manually configured, the loopback 0 IP address is always preferred. If loopback 0 does not exist, Cisco NX-OS selects the IP address for the first loopback interface in the configuration. If no loopback interfaces exist, Cisco NX-OS selects the IP address for the first physical interface in the configuration.
- Neighbor adjacency changes are not logged by default. The **log-adjacency-changes** CLI command is required under the OSPF instance.
- When interface authentication is configured, the OSPF key is encrypted with Data Encryption Standard 3 (3DES) in the configuration. Cisco IOS Software requires the **service password** command.
- The NX-OS does not support distribute-lists used to remove OSPF routes from the routing table. The NX-OS does support inter-area Type-3 LSA/route filtering using the **filter-list** command configured under the OSPF routing instance.
- A route-map is always required when redistributing routes into an OSPF instance. In Cisco IOS Software, a route-map is optional.
- Route redistribution advertises classless and classfull networks by default (no **subnets** option). Cisco IOS Software requires the **subnets** option to redistribute classless networks.
- A VRF instance is configured under an OSPF instance (Numerous VRF instances can be associated to a single OSPF instance). In Cisco IOS Software, a VRF instance is associated to a single OSPF process in a one-to-one relationship.

Things You Should Know

The following list provides some additional facts about Cisco NX-OS that should be helpful when designing, configuring, and maintaining an OSPF network.

- Four OSPF instances can be configured per virtual device context (VDC).
- If you remove the **feature ospf** command, all relevant OSPF configuration information is also removed.
- The **shutdown** command under the OSPF process can be used to disable OSPF while retaining the configuration. Similar functionality can also be applied per interface with the **ip ospf shutdown** command.
- The **show running-config ospf** command displays the current OSPF configuration.
- An OSPF instance can be restarted with the **restart ospf <instance>** Exec command.
- Graceful Restart ([RFC 3623](#)) is enabled by default.
- You cannot configure multiple OSPF instances on the same interface.
- An interface can support multi-area adjacencies using the **multi-area** option with the **ip router ospf** interface command.
- Secondary IP addresses are advertised by default, but can be suppressed per interface with the **ip router ospf <instance> area <#> secondaries none** interface command.
- By default all loopback IP address subnet masks are advertised in an LSA as a /32. The loopback interface command **ip ospf advertise-subnet** can be configured to advertise the primary IP address subnet mask. (This command does not apply to secondary IP addresses. They will still be advertised as a /32.)
- OSPF supports Bidirectional Forwarding Detection (BFD), which can be configured to reduce network convergence time to less than 1 second.
- When you rollover an OSPF authentication key in a combined Cisco NX-OS/Cisco IOS network, you should configure both keys on the Cisco NX-OS router to ensure that there is sufficient overlap between the old key and the new key for a smooth transition to the new key. You should configure the new key as a valid accept key on all the NX-OS and IOS routers before the new key becomes a valid generation key in the keychain. During the overlap period, Cisco NX-OS transmits the new OSPF key and accepts OSPF authenticated packets from both the old key and the new key.
- Maximum prefix thresholds (warning and withdraw) can be configured for redistributed routes using the **redistribute maximum-prefix** routing instance command.

Configuration Comparison

The following sample code shows configuration similarities and differences between the Cisco NX-OS and Cisco IOS Software CLIs. There are two significant differences: Cisco NX-OS allows OSPF to be enabled and disabled globally, and it has a more interface-centric configuration that makes it easier to read.

Cisco IOS CLI

Cisco NX-OS CLI

Enabling the OSPF Feature

feature ospf

Configuring an OSPF Instance and Router ID

router ospf 10

router-id 192.168.1.1

Associating a Network with an OSPF Instance and Area

interface Ethernet2/1

ip address 192.168.10.1/24

ip router ospf 10 area 1

Configuring a Passive Interface

interface Ethernet2/1

ip address 192.168.11.1/24

ip ospf passive-interface

ip router ospf 10 area 0

Configuring Interface Authentication (MD5)

interface Ethernet2/1

ip address 192.168.10.1/24

ip ospf authentication message-digest

ip ospf message-digest-key 1 md5 3
a667d47acc18ea6b

ip router ospf 10 area 1

Configuring a Stub Area with the no summary Option

router ospf 10

area 2 stub no-summary

Creating a Not-So-Stubby Area (NSSA) and Generating a Default Route

router ospf 10

area 3 nssa default-information-originate

Configuring Inter-Area and External Summarization

router ospf 10

area 0 range 159.142.0.0/16 summary-address
172.16.0.0/16

Generating a Default Route (Conditional)

router ospf 10

```
default-information originate
```

Generating a Maximum Metric (Max-Metric) Value

```
router ospf 10
```

```
max-metric router-lsa
```

Configuring Route Redistribution (Permit all Static Routes)

```
router ospf 10
```

```
redistribute static route-map static-to-ospf
```

```
route-map static-to-ospf permit 10
```

Configuring a VRF Instance for OSPF Routing

```
router ospf 10
```

```
vrf customer-a
```

Verification Command Comparison

The following table compares some useful **show** commands for verifying and troubleshooting an OSPFv2 network configuration.

Cisco NX-OS OSPFv2	Cisco IOS Software OSPFv2	Command Description
show ip ospf	show ip ospf	Displays information for all OSPF instances
show ip ospf <instance>	show ip ospf <#>	Displays information for a specific OSPF instance
show ip ospf border-routers	show ip ospf border-routers	Displays a list of border routers
show ip ospf database	show ip ospf database	Displays OSPF database information
show ip ospf interface	show ip ospf interface	Displays all OSPF enabled interfaces and associated status information
show ip ospf interface brief	show ip ospf interface brief	Displays a brief list and status of OSPF enabled interfaces
show ip ospf interface detail	-	Displays additional packet statistics for each interface
show ip ospf lsa-content-changed-list	-	Displays the LSA's that changed content
show ip ospf memory	-	Displays the memory allocated for OSPF
show ip ospf neighbors	show ip ospf neighbor	Displays neighbor-specific information
show ip ospf neighbors detail	show ip ospf neighbor detail	Displays details for each OSPF neighbor
show ip ospf neighbors summary	-	Displays summary information and packet statistics for each OSPF neighbor

Cisco_NX-OS/IOS_OSPF_Comparison

show ip ospf policy statistics	-	Displays redistribution statistics for a specified protocol
show ip ospf request-list	show ip ospf request-list	Displays a list of link-state advertisements (LSAs) that have been requested
show ip ospf retransmission-list	show ip ospf retransmission-list	Displays a list of the link-state retransmission list
show ip ospf route	-	Displays all routes learned through OSPF
show ip ospf statistics	show ip ospf statistics	Displays OSPF LSA statistics
show ip ospf summary-address	show ip ospf summary-address	Displays OSPF summarized networks
show ip ospf traffic	show ip ospf traffic	Displays OSPF related packet counters
show ip ospf virtual-links	show ip ospf virtual-links	Displays OSPF virtual links
show ip ospf vrf	-	Displays information for a specified OSPF VRF instance