

**Main page:** [Cisco Unified MeetingPlace, Release 8.0](#)

**Back to:** [Installation, Upgrade and Migration](#)

**Back to:** [Configuration](#)

- [About Security for the Hardware Media Server](#)
- [About Setting Security Levels While Installing the Hardware Media Server](#)
- [About Maintaining Security on the Hardware Media Server](#)
- [About Security When Upgrading the Hardware Media Server](#)

## Contents

- [1 About Security for the Hardware Media Server](#)
  - ◆ [1.1 Table: Security for the Hardware Media Server](#)
- [2 About Setting Security Levels While Installing the Hardware Media Server](#)
- [3 About Maintaining Security on the Hardware Media Server](#)
- [4 About Security When Upgrading the Hardware Media Server](#)

## About Security for the Hardware Media Server

To maintain security on your Cisco Unified MeetingPlace system, protect the information in [Table: Security for the Hardware Media Server](#).

**Table: Security for the Hardware Media Server**

Parameter	Used for	To change this parameter, see
Administrative password for the Audio Blade  <b>Note:</b> The administrative user name is always <i>admin</i> .	<ul style="list-style-type: none"> <li>• Starting a Telnet session to monitor the Audio Blade.</li> <li>• Retrieving log files using FTP.</li> <li>• Upgrading the Audio Blade software.</li> <li>• Authenticating commands from the Application Server.</li> </ul>	<a href="#">Changing the Password for the Audio Blade</a> in the <a href="#">Setting Initial Values for the Hardware Media Server</a> module
SNMP community names for the Audio Blade	<ul style="list-style-type: none"> <li>• Accessing the Audio Blade from a network management station.</li> <li>• Synchronizing the Application Server and the Audio Blade.</li> </ul>	<a href="#">Adding an Audio Blade to Cisco Unified MeetingPlace</a> in the <a href="#">Changing Values for the Hardware Media Server</a> module

	<ul style="list-style-type: none"> <li>• Uploading and downloading the Audio Blade configuration file.</li> <li>• Accessing the Audio Blade configuration during software upgrades.</li> </ul>	
Administrative user name and password for the Video Blade  <b>Note:</b> This is also called the configuration software user name and password	Controlling Telnet access to the Video Blade.	<a href="#">Changing the Configuration Software User Name and Password for the Video Blade in the Setting Initial Values for the Hardware Media Server</a> module
Administrative user name and password for the Media Server Administration for the Hardware Media Server  <b>Note:</b> This is not the administrative user name and password for the Media Server Administrator (MSA) interface for the Hardware Media Server.	Controlling access to the Media Server Administration for the Hardware Media Server.	<a href="#">Changing the Media Server Administration Password for the Hardware Media Server in the Changing Values for the Hardware Media Server</a> module
Administrative user name and password for the Media Server Administrator (MSA) interface for the Hardware Media Server	Accessing the Media Server Administrator (MSA) interface for the Hardware Media Server, for advanced functions.	<a href="#">Adding and Editing Administrators for the Hardware Media Server in the Configuring the Audio and Video Blades for the Hardware Media Server</a> module

## About Setting Security Levels While Installing the Hardware Media Server

You can set the security level for the Audio Blade and the Video Blade from the console. See the following sections in other chapters for procedures:

- [Changing the Password for the Audio Blade in the Setting Initial Values for the Hardware Media Server](#) module
- [Changing the Configuration Software User Name and Password for the Video Blade in the Setting Initial Values for the Hardware Media Server](#) module
- [Changing the Security Level of the Video Blade in the Setting Initial Values for the Hardware Media Server](#) module

## About Maintaining Security on the Hardware Media Server

You can change security parameters for the Audio Blade using the MSA for the Hardware Media Server. See the following sections for procedures:

- [Changing the Web Server Port for the MSA Interface for the Hardware Media Server in the Configuring the Audio and Video Blades for the Hardware Media Server](#) module

- [Changing the SNMP Values for the Hardware Media Server](#) in the [Configuring the Audio and Video Blades for the Hardware Media Server](#) module
- [Changing the Password for an Installed Audio Blade](#) in the [Changing Values for the Hardware Media Server](#) module

## **About Security When Upgrading the Hardware Media Server**

You can maintain security while upgrading the Hardware Media Server. See [How to Upgrade the Software for the Hardware Media Server](#) in the [Upgrading to Cisco Unified MeetingPlace Release 8.0 from Cisco Unified MeetingPlace Release 7.0](#) module.