

Contents

- [1 Introduction](#)
- [2 Design](#)
- [3 Configuration](#)
- [4 Related show Commands](#)
- [5 Related Information](#)

Introduction

This is the basic config for any ISR router 2800 / 3800 series which runs IOS with CUBE and GK feature set.

Design

The example topology:

Tandberg VT A - H.323 GK zone A - CUBE - H.323 GK zone B - Tandberg VT B

Let assume that Tandberg A is located on Public Internet. And we want to allow it to place calls to Tandberg B, or say MCU on an internal network only through CUBE. Let name the zone A - PUBLICINET-with-IPIPGW And zone B - MCU

We also have to make some assumptions about the dial-plan. Let assume that all endpoints on the internet side will have numbers starting with 00 and all endpoints on internal network will have numbers starting with 2.

00* <-----CUBE-----> 2*

We also assume that CUBE has two IP addresses. One IP should be public IP reachable form internet, and naturally it also should be reachable from inside of your network. In this example the internet will be represented by the subnet 33.33.33.0/24 The internal network can have IP from any private subnet range as 10.x.x.x, 172.x.x.x or 192.x.x.x

33.33.33.0 - CUBE - 10.x.x.x

Configuration

1. First we need to register GW and the video endpoints to the GK and we can run GK feature on the same router if we have IOS with GK feature for example - C2800NM-IPVOICE_IVS-M. The most simple setup will be if we register endpoints with full E164 numbers to their corresponding zones and register the CUBE to the GK in public zone. The CUBE should be registered to the zone where we want to force your endpoints to use CUBE as an access point to your network, so it will be out Public zone with real IP reachable from Public Internet.

!

```
gatekeeper
```

```
zone local PUBLICINET-with-IPIPGW test.com 33.33.33.1 invia PUBLICINET-with-IPIPGW outvia PUBLICINET-with-IPIPGW
zone remote MCU mappets.com 10.52.218.98 1719
no zone subnet PUBLICINET-with-IPIPGW default enable
zone subnet PUBLICINET-with-IPIPGW 33.33.33.1/32 enable
```

Video_Configuration_Examples_for_IPIP_GW_or_CUBE

```
zone subnet PUBLICINET-with-IPIPGW 33.33.33.101/32 enable
zone subnet PUBLICINET-with-IPIPGW 33.33.33.102/32 enable
zone subnet PUBLICINET-with-IPIPGW 33.33.33.0/24 enable
no zone subnet PUBLICINET-with-IPIPGW 172.168.0.0/16 enable
no zone subnet PUBLICINET-with-IPIPGW 192.0.0.0/8 enable
no zone subnet PUBLICINET-with-IPIPGW 10.0.0.0/8 enable
zone prefix MCU 2*
no use-proxy PUBLICINET-with-IPIPGW default inbound-to terminal
no use-proxy PUBLICINET-with-IPIPGW default outbound-from terminal
no shutdown
```

!

To have control over registration - we used "zone subnet" commands. First we need them to disable registration of internal endpoints to the external zone. And we also can use tighter restrictions - if we want to allow only some specific endpoints from internet to register the GK. For example the command "zone subnet PUBLICINET-with-IPIPGW 33.33.33.101/32 enable" will allow to register endpoint with IP 33.33.33.101.

The matching CUBE config will be:

!

```
voice service voip
  allow-connections h323 to h323
```

!

```
interface FastEthernet0/0
  ip address 10.52.218.130 255.255.255.0
```

! This interface is used only for routing, it is not involved in H.323 signaling. !

```
interface FastEthernet0/1.33
  encapsulation dot1Q 333
  ip address 33.33.33.1 255.255.255.0
  h323-gateway voip interface
  h323-gateway voip id PUBLICINET-with-IPIPGW ipaddr 33.33.33.1 1719
  h323-gateway voip h323-id IPIPGW-130
  h323-gateway voip tech-prefix 130
  h323-gateway voip bind srcaddr 33.33.33.1
```

! This interface is used for H.323 signaling, so it have to be reachable for endpoints on the Internet as well as from internal network.

The matching remote GK config(we can run other GK on any other router in the network): !

```
gatekeeper
  zone local MCU mappets.com 10.52.218.98
  zone remote PUBLICINET-with-IPIPGW test.com 33.33.33.1 1719
  zone prefix PUBLICINET-with-IPIPGW 00*
  no use-proxy MCU default inbound-to terminal
  no use-proxy MCU default outbound-from terminal
  no shutdown
```

!

Here we can register any internal H.323 endpoints like Tandberg Video terminals or MCU for conferencing.

Video_Configuration_Examples_for_IPIP_GW_or_CUBE

The final step would be the example of the VOIP dial-peers. Here we configured two dial-peers - but each of them play the role of incoming and outgoing dial-peer at the same time.

!

```
dial-peer voice 2000 voip
destination-pattern 2...
session target ras
incoming called-number 2...
dtmf-relay h245-alphanumeric
codec transparent
no vad
```

!

```
dial-peer voice 1000 voip
destination-pattern 00
session target ras
incoming called-number 00
dtmf-relay h245-alphanumeric
codec transparent
no vad
```

!

The only specific part for video in this whole example is the "codec transparent" command :)

Related show Commands

This section provides information you can use to confirm your configuration is working properly.

Certain show commands are supported by the [Output Interpreter Tool \(registered customers only\)](#), which allows you to view an analysis of show command output.

```
show dial-peer voice summary
show voice call status
```

There also some useful commands to add and they can be used on All routers in production as well:

```
service nagle
service tcp-keepalives-in
service tcp-keepalives-out
service timestamps debug datetime msec
service timestamps log datetime msec
```

!

```
logging message-counter syslog
logging queue-limit 100000
logging buffered 5000000
logging rate-limit 10000
```

Related show Commands

Video_Configuration_Examples_for_IPIP_GW_or_CUBE

no logging console

And some very useful aliases :)

!

```
alias exec c conf t
alias exec r sh run
alias exec i sh ip ro
alias exec ib sh ip int brie
alias exec gs show run | s gatekeeper
alias exec ge sho gatekeeper end
alias exec sg sho gatekeeper
alias exec rs sh run | s
alias exec ri sh run | i
alias exec rb sh run | b
alias exec dp sh run | be dial-p
```

!

Enjoy :)

Related Information

[Technical Support & Documentation - Cisco Systems](#)