Main page: Cisco Unified MeetingPlace, Release 7.0

Contents

- 1 Accessing the Basics Tab
  - 1.1 Procedure
  - 1.2 Table: Cisco Unified MeetingPlace 3545 Media Server Basics Tab Elements
- 2 Viewing Software Version Details
  - 2.1 Procedure
- 3 Setting the Media Server Location
  - 3.1 Procedure

Accessing the Basics Tab

Procedure

1. Do one of the following, in the MSA interface sidebar:
   - Click **Board** (for a Cisco Unified MeetingPlace 3545 Media Server).
   - Click **Device** (for a Cisco Unified MeetingPlace 3515 Media Server).
2. Click the **Basics** tab.

   Table: Cisco Unified MeetingPlace 3545 Media Server Basics Tab Elements describes the elements that appear in the Basics tab for the Media Server.

Note: The descriptions listed are for the Cisco Unified MeetingPlace 3545 Media Server. The descriptions in brackets are for the Cisco Unified MeetingPlace 3515 Media Server.

Table: Cisco Unified MeetingPlace 3545 Media Server Basics Tab Elements

Field	Description
Board [Device] name	Model number of the board [device].
Location	User-configured description about the board [device].
Slot number	Cisco Unified MeetingPlace 3545 Media Server only: Number of the cPCI slot in the Cisco Unified MeetingPlace 3545 Media Server chassis in which this Audio Blade is inserted.
Serial number	Serial number that the factory assigned to the board [device].
Hardware version	Version number of the current hardware configuration.
Software version	First two digits of the version number of the software installed on the board [device].
Date/Time	Date and time that the Audio Blade [Cisco Unified MeetingPlace 3515 Media Server] clock reports.

Viewing Software Version Details

Procedure

1. Do one of the following, in the MSA interface sidebar:
   - Click **Board** (for a Cisco Unified MeetingPlace 3545 Media Server).
   - Click **Device** (for a Cisco Unified MeetingPlace 3515 Media Server).
2. Click the **Basics** tab.
3. Click **Details...**.
   The system displays the Version Details window.

Setting the Media Server Location

You can install the Media Server anywhere on your network including on a remote site. You can describe the current location of the Media Server from the Basics tab.

Procedure

1. Do one of the following, in the MSA interface sidebar:
   - Click **Board** (for a Cisco Unified MeetingPlace 3545 Media Server).
   - Click **Device** (for a Cisco Unified MeetingPlace 3515 Media Server).
2. Click the **Basics** tab.
3. Enter the location information about the Media Server that you want to display in the Location field.
   The field displays up to 23 characters.
4. Click **Upload**.