

## Application\_Extension\_Platform\_1.x\_--\_Uninstalling\_an\_Application

To remove software, perform the following steps.

### Software Uninstall

```
se-Module> software uninstall
```

A numbered list of application packages are displayed on the screen. The number (#) column identifies each add-on package in the list.

### Remove Application

```
se-Module>r number
```

Removes the application.

*number* refers to the number of the application in the numbered list. Take care to choose the correct number that corresponds with your application.

A confirmation question appears: Are you sure? [y/n]: **y**

**Note:** If you answer **n** to this question the application is not uninstalled. Later you can uninstall the application by reentering the original **software uninstall** command.

The Cisco AXP service module automatically reboots, which is a normal occurrence.

Wait until the system reboots and the prompt is redisplayed on the screen.

### Show Software Packages

```
show software packages
```

Shows programs and options that are currently installed. Recently removed applications should not be on the list.

**Return to:** [Application Extension Platform 1.x -- Installing and Uninstalling an Application](#)

**Return to start of Getting Started Guide:** [Cisco AXP Getting Started Guide](#)