

**Main page:** [Cisco Unified MeetingPlace, Release 7.0](#)

**Up one level:** [Reference Information](#)

To find this page, click **Maintenance > SNMP > Notification Destinations > Add New**.

**Table: Field Reference: Add SNMP Notification Destination Page and Edit SNMP Notification Destination Page**

<b>Field</b>	<b>Description</b>
Destination IP address	Restriction: Each notification destination must have a unique IP address.
Port number	The port number for the notification destination.
SNMP version	SNMP version 1 supports only traps. SNMP version 2c supports both traps and inform notification types.
Notification type	Dimmed if you select SNMP version 1.
Security level	<i>Display only.</i> Value is determined by the selected <a href="#">Community string</a> .
Community string	SNMP community string to associate with this notification destination.

**Related Topics**

- [Configuring SNMP on Cisco Unified MeetingPlace](#)