

Main page: [Cisco Unified MeetingPlace, Release 7.0](#)

- [About the Media Server Interfaces](#)
- [Logging in to the Media Server Administration](#)
- [Changing the Media Server Administration Password](#)
- [Adding an Audio Blade to Cisco Unified MeetingPlace](#)
- [Adding an Audio Blade for Redundant Systems](#)
- [Designating the Audio Blade Template](#)
- [Synchronizing Audio Blade Meeting Types with the Template Audio Blade](#)
- [Synchronizing an Audio Blade](#)
- [Synchronizing Audio Blades after Adding a Video Blade](#)
- [Changing the Online and Offline Status of a Blade](#)
- [Changing the Password for an Installed Blade](#)
- [Logging In to the Media Server Administrator](#)