

**Main page:** [Cisco Unified MeetingPlace, Release 7.0](#)

**Up one level:** [Maintenance Page](#)

Cisco Unified MeetingPlace can be configured to call you if a major alarm occurs. When you answer the phone call, you will be provided with the following information:

- Notification that an error has occurred that requires attention.
- A request to view the alarms.
- A request to acknowledge the alarm call.

#### **Restriction**

Pagers cannot be used to receive alarm calls.

#### **Procedure**

1. Log in to the Administration Center.
2. Click **System Configuration > Usage Configuration**.
3. Configure the following fields:
  - ◆ [Call out on major alarm](#) -- Set to **Yes**.
  - ◆ [Phone number to call on alarm](#) -- Enter the system administrator's phone number.
4. Click **Save**.

#### **Related Topics**

- [Usage Configuration Page](#)