

Main page: [Cisco Unified MeetingPlace, Release 7.0](#)

Up one level: [Integration](#)

Procedure

1. Go to <http://<ccm-server>/ccmadmin/main.asp>, where *<ccm-server>* is the fully qualified domain name or IP address of the Cisco Unified Communications Manager server.
2. Log in with your Cisco Unified Communications Manager administrator username and password.
3. Click **Device > Device Settings > Phone Services**.
4. Enter a search parameter then click **Find**.
5. Locate your application in the search results area.
6. Click the name of the IP Phone Service that you want to see.

Related Topics

- [How to Configure Cisco Unified MeetingPlace PhoneView](#)
- [Deleting an IP Phone Service](#)