

**Main page:** [Cisco Unified MeetingPlace, Release 7.0](#)

**Up one level:** [Reference Information](#)

To find this page, click **System Configuration > E-Mail Notifications > Notification Configuration**.

**Table: Field Reference: Notification Configuration Page**

<b>Field</b>	<b>Description</b>
If notification fails retry (times)	Default: 3
Delay between retries (seconds)	Default: 10
If still fails wait before trying again (hours)	Default: 4

**Related Topics**

- [Configuring E-Mail Notification Retries](#)