

**Main page:** [Cisco Unified MeetingPlace, Release 7.0](#)

**Up one level:** [Reference Information](#)

To find this page, click **System Configuration > E-Mail Notifications > Notification Configuration**.

**Table: Field Reference: Notification Configuration Page**

| <b>Field</b>                                    | <b>Description</b> |
|---|--------------------|
| If notification fails retry (times)             | Default: 3         |
| Delay between retries (seconds)                 | Default: 10        |
| If still fails wait before trying again (hours) | Default: 4         |

**Related Topics**

- [Configuring E-Mail Notification Retries](#)