

**Main page:** [Cisco Unified MeetingPlace, Release 7.0](#)

**Up one level:** [Planning Your Deployment](#)

Three factors determine the capacity of your Cisco Unified MeetingPlace Release 7.0 system:

- The amount and type of licenses that you purchase and install.
- How you configure your system.
- The type of hardware that you purchase and install.

This section contains the following information:

- [System Capacity](#)
- [System Capacity Limits for New Deployments](#)
- [System Capacity Quick Reference Tables](#)
- [About Licenses](#)
- [How to Calculate Meeting Configuration Values](#)
- [How to Determine the Type of Hardware for Your System](#)