

Main page: [Cisco Unified MeetingPlace, Release 7.0](#)

Up one level: [Reference Information](#)

To find this page, click **System Configuration > Remote Server Configuration**.

Table: Field Reference: Remote Server Configuration Page

Field	Description
Remote Server Configuration	
See Configuring the Remote Servers	
Auto Answer Parameters	
The Auto-Answer Devices fields were moved to the Meeting Configuration Page in Release 7.0.2.	
Reservationless Single Number Access	
Enable RSNA	Whether or not the Reservationless Single Number Access (RSNA) feature is enabled.
Dial prefix	<i>Reserved for a future release.</i>

Related Topics

- [Configuring Reservationless Single Number Access \(RSNA\) for Cisco Unified MeetingPlace](#)
- [How to Configure Auto-Answer Devices](#)
- [Table: Field Reference: Add Server Configuration Page and Edit Server Configuration Page](#)