

**Main page:** [Cisco Unified MeetingPlace, Release 7.0](#)

**Up one level:** [Reference Information](#)

The following table contains two categories:

- [Fields Exported in All Releases](#)
- [Fields Exported Only in Release 7.0.1](#)

**Note:** In this table, gd means group default and VTP stands for Video Terminal Port.

**Table: Import and Export Data Specifications for Video Terminal Profiles**

Field Name	Description	Size and Type of Value
<b>Fields Exported in All Releases</b>		
videoTermName	See <a href="#">Video terminal name</a> .  Import requirement: This field is required when you add VTPs by import.	0 to 32 alphanumeric characters
videoTermId	Unique value that identifies the VTP in report and export output.  (Release 7.0.1 only) The values for the following fields are identical in each VTP: <ul style="list-style-type: none"> <li>• <a href="#">uid</a></li> <li>• <a href="#">prfnum</a></li> <li>• <a href="#">videoTermId</a></li> </ul> For VTPs that you manually add through the Administration Center, this value is automatically generated by the system.  Import requirements: <ul style="list-style-type: none"> <li>• This field is required whether you are adding or deleting VTPs by import.</li> </ul>	1 to 30 numeric characters

	<ul style="list-style-type: none"> <li>• Do not modify this field from the exported value.</li> <li>• (Release 7.0.1 only) If you import a new VTP, you must enter a unique value that exactly matches what you enter in the <u>uid</u> and <u>prfnum</u> fields.</li> <li>• (Release 7.0.1 only) Make sure that this field contains only numeric characters.</li> </ul>	
videoEndPtAddStr	<p>See <u>Endpoint E.164 number</u>.</p> <p>Import requirement: This field is required when you add VTPs by import.</p> <p>Restriction: Only the following characters are allowed: (),-, and 0-9.</p>	Up to 32 characters
grpname	<p>See <u>Group name</u>.</p> <p>Import requirements:</p> <ul style="list-style-type: none"> <li>• This field is required whether you are adding or deleting user profiles by import.</li> <li>• Do not modify this field from the exported value. If you import a new VTP, enter <b>System</b>.</li> </ul>	1 to 17 alphanumeric characters
grpnum	<p><u>Number</u> of user group.</p> <p>Import requirement: Do not modify this field from the exported value. If you import a new VTP, enter <b>0</b> to indicate the <u>System User Group</u>.</p>	0 to 17 numeric characters
emailaddr	See <u>E-mail address</u> .	0 to 128 alphanumeric characters
tzcode	<p><u>Time zone</u> of the video terminal.</p> <p>Import requirements:</p> <ul style="list-style-type: none"> <li>• The integer value in the import file must match a value defined by Cisco Unified MeetingPlace. Make sure you use a previously exported value.</li> <li>• If the import file contains the <u>tzcode</u> header field, then all user groups in the import file must have a valid entry for the field. For any invalid or blank <u>tzcode</u> values, the associated user group is not imported, and an error is logged.</li> </ul>	0 to 17 ASCII text characters
supportSIPReInvite	See <u>Skip meeting entry voice prompts on outdial</u> .	Yes/No

Table: Import and Export Data Specifications for Video Terminal Profiles

attndprf	See <u>Method of attending</u> .	UserCallsIn/SysFindsUser
rcvnotifs	See <u>Can receive notifications</u> .	Yes/No/gd
rcvattswnotif	See <u>Receive attachments</u> .	Yes/No/gd
preferedCodec	See <u>Preferred codec</u> .  <ul style="list-style-type: none"> <li>• 1-H.261</li> <li>• 2-H.263</li> <li>• 5-H.264</li> <li>• 6-Use default (H.264)</li> </ul>	1/2/5/6
<b>Fields Exported Only in Release 7.0.1</b>		
fnm	<u>Video terminal name</u> that appears in the participant list and in reports. The system copies this value from the <u>videoTermName</u> field.  Import requirement: Do not modify this field from the exported value. If you import a new VTP, enter the same text that you enter in the <u>videoTermName</u> field.	0 to 32 alphanumeric characters
uid  prfnum	Unique value that identifies the VTP in report and export output.  The values for the following fields are identical in each VTP:  <ul style="list-style-type: none"> <li>• <u>uid</u></li> <li>• <u>prfnum</u></li> <li>• <u>videoTermId</u></li> </ul> For VTPs that you manually add through the Administration Center, this value is automatically generated by the system.  Import requirements:  <ul style="list-style-type: none"> <li>• This field is required whether you are adding or deleting VTPs by import.</li> <li>• Do not modify this field from the exported value. If you import a new VTP, you must enter a unique value that exactly matches what you enter in the <u>prfnum</u> and <u>videoTermId</u> fields.</li> </ul>	1 to 30 numeric characters
phnum	See <u>Endpoint E.164 number</u> .	0 to 32 alphanumeric characters
abbprmts	<i>Not supported</i> .  Import requirement: Do not modify this field from	-

Table: Import and Export Data Specifications for Video Terminal Profiles

	the exported value. If you import a new profile, enter <b>gd</b> .	
anndpart	See <u>Departure announcement</u> .  Import requirement: Do not modify this field from the exported value. If you import a new VTP, enter <b>gd</b> .	Beep+ name/Beep only/ Silent/gd
annentry	See <u>Entry announcement</u> .  Import requirement: Do not modify this field from the exported value. If you import a new VTP, enter <b>Beep only</b> .	Beep+ name/Beep only/ Silent/gd
pwdreq	<i>Not supported.</i>  Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
screntry	<i>Not supported.</i>  Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Yes</b> .	-
uactive	<i>Not supported.</i>  Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>EndUser</b> .	-
utype	<i>Not supported.</i>  Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
ndial	<i>Not supported.</i>  Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	-
shrtmnus	<i>Not supported.</i>  Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
pwdonoutdial	<i>Not supported.</i>  Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
whocanattnd	<i>Not supported.</i>	-

Table: Import and Export Data Specifications for Video Terminal Profiles

	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
whocanlstn	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Anyone</b> .	
canrecord	<i>Not supported.</i>	
recordmtgs	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	
ODXLatTableNum	<i>Not supported.</i>	
MaxImmedMtgsPerDay	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
DayOfLastImmedMtg	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, leave this field blank.	
NumImmedMtgsOnThatDay	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>0</b> .	
site	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>0</b> .	
sndnotifs	<i>Not supported.</i>	
autodistatts	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	
dfltnotifprio	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile,	

Table: Import and Export Data Specifications for Video Terminal Profiles

	enter <b>gd</b> .	
sndnotifonmtgch	<i>Not supported.</i>	
sndinvlstwnotif	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
sndmtgpwdwnotif		
playattlstfifo	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	-
schedprefunitonly	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Yes</b> .	-
autostrtrcrd	<i>Not supported.</i>	
disablerollcall	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
schedhomesiteonly	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Yes</b> .	-
concurrentquestions	<i>Not supported.</i>	
announceqarr	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	-
announceqdep		
fqnadisable	<i>Not supported.</i>	
ftellpartpos		
fadvanceinfo	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
fautoproenabled		
fstartpeopleinwr	<i>Not supported.</i>	-

Table: Import and Export Data Specifications for Video Terminal Profiles

groupulallowed	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
privateulallowed		
meetingcategory		
numdataparts		
chatclienttype		
fallowdataconf	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
fchatsession	<i>Not supported.</i>	
fismtgseminartype	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	-
fallowguestview	<i>Not supported.</i>	
qnanotify	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	-
fCanInviteRemoteServers	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	-
1stSearch	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Main phone</b> .	-
2ndSearch	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Alternate phone</b> .	-
3rdSearch	<i>Not supported.</i>	-

Table: Import and Export Data Specifications for Video Terminal Profiles

	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Pager</b> .	
canallowguestoutdial	<i>Not supported.</i>	
allowguestoutdial	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
VLanguage	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>English (US)</b> .	
fEndMtgWarn	<i>Not supported.</i>	
fMtgExtendPrompts	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
CanChangeMtgID	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	
RsvnlessCnfg	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>0</b> .	
RsvnlessCnfgGD	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>254</b> .	
AllowVideoSched	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
AllowInternetAccess	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile,	

Table: Import and Export Data Specifications for Video Terminal Profiles



	enter <b>No</b> .	
VideoEndPtBandwidth	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
bountyUser	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>TRUE</b> .	
isLocalUser	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Yes</b> .	
EmailFormat	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>txt</b> .	
ReserveVoiceLicenses	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
LockedProfileTime	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>0</b> .	
CanReserveVideoPorts	<i>Not supported.</i>	
PreferVideo	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
PreferDataConf	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>Yes</b> .	
FRsvnlessAllowInternetAcc	<i>Not supported.</i>	

Table: Import and Export Data Specifications for Video Terminal Profiles

	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	
FStartPeopleInWR	<i>Not supported.</i>	
attendMode	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
attendPasswdRequired	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>No</b> .	
announceQArr	<i>Not supported.</i>	
videoTypes	<i>Not supported.</i>	
mtgEntryMode	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
dataConfClientType		
allowVideoSched	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
endpointType	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>4</b> .	
FVideoMCUOnly	<i>Not supported.</i>	
videoAttPref	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>gd</b> .	
videoTermClass	<i>Not supported.</i> Import requirement: Do not modify this field from the exported value. If you import a new profile, leave this field blank.	
attPref	<i>Not supported.</i>	

Table: Import and Export Data Specifications for Video Terminal Profiles

	Import requirement: Do not modify this field from the exported value. If you import a new profile, enter <b>1</b> .	
rcvNMaskEn	See <u>Can receive notifications</u> .	<ul style="list-style-type: none"> <li>• 0-No</li> <li>• 1-Yes</li> <li>• gd</li> </ul>

**Related Topics**

- Exporting Video Terminal Profiles
- Adding or Editing Video Terminal Profiles by Import
- Deleting Video Terminal Profiles by Import