

Main page: [Cisco Unified MeetingPlace Express, Release 2.x](#)

Next page: [About Logging in to the Cisco Unified MeetingPlace Express Application as a System Administrator](#)

There are several different ways to interact with Cisco Unified MeetingPlace Express, including the following:

Contents

- [1 End-User Interfaces](#)
- [2 Administration Center](#)
- [3 Console](#)
- [4 Command-Line Interface \(CLI\)](#)

End-User Interfaces

End users use the End-User Interface and Microsoft Outlook on the web, the telephone user interface (TUI), and the Cisco Unified MeetingPlace Express Phone View to schedule and attend meetings, and to perform other meeting-related tasks. For complete information about end-user functionality, see the User Guide for Cisco Unified MeetingPlace Express Release 2.x and the User Guide for Microsoft Outlook Operating with Cisco Unified MeetingPlace Express Release 2.x here:

http://www.cisco.com/en/US/products/ps6533/products_user_guide_list.html.

Administration Center

The Administration Center is a web-based interface for system administrators. Here they can configure, maintain, and customize the Cisco Unified MeetingPlace Express application. For complete information about the Administration Center, see [Getting Started in the Administration Center](#).

Console

System administrators may occasionally need to configure advanced network features and can use the console for this. For information about using the console, see [Logging in to the CLI Using the Console](#).

Command-Line Interface (CLI)

The Command-Line Interface (CLI) is used to run certain commands. Most of the functionality performed by these commands have been built in to the Cisco Unified MeetingPlace Express Administration Center so that a system administrator can perform the same functions without using the CLI. For information about using the CLI, see [Logging in to the CLI](#).