

**Main page:** [Cisco Unified MeetingPlace Express, Release 2.x](#)

**Previous page:** [Page References](#)

This page is used to export a system configuration, which consists of the following information: usage configuration, meeting configuration, H.323 call configuration, SIP call configuration, ad hoc meeting configuration, dial configuration, and media parameter configuration.

This file can be used if you need to replace your hardware or reinstall the complete Cisco Unified MeetingPlace Express system.