

**Main page:** [Cisco Unified MeetingPlace Express, Release 2.x](#)

**Previous page:** [Page References](#)

The Maintenance page leads to other pages with configuration options listed in the following table.

**Table: Maintenance Area Configuration Options and Pages**

| Option  | Administration Center Pages                         |
|---|---|
| <a href="#">Importing Data into Cisco Unified MeetingPlace Express</a>                            | <a href="#">About This Page: Import</a>             |
| <a href="#">How To Export Data</a>  | <a href="#">About This Page: Export Information</a> |
| <a href="#">How to Work With SNMP</a>   | <a href="#">About This Page: SNMP Configuration</a> |
| <a href="#">Installing and Managing Licenses on the Cisco Unified MeetingPlace Express System</a> | <a href="#">About This Page: Manage Licenses</a>    |
| <a href="#">Sending E-Mail Blasts</a>   | <a href="#">Field Reference: E-Mail Blast</a>       |
| <a href="#">Cleaning Up Unused Voice Files in the Database</a>                                    | <a href="#">Field Reference: File Cleanup</a>       |
| <a href="#">How to Customize Voice Prompts</a>  | <a href="#">Field Reference: Custom Prompts</a>     |