

Main page: [Cisco Unified MeetingPlace Express, Release 2.x](#)

Previous page: [Page References](#)

This page is used to export information about meeting participants who joined or left a Cisco Unified MeetingPlace Express meeting during a specified range of dates. Topics in this section include:

- [Field Reference: Meeting Participant Join Leave Information](#)
- [Output Fields of the Meeting Participant Join Leave Information Page](#)

Field Reference: Meeting Participant Join Leave Information

Table: Fields on the Meeting Participant Join Leave Information Page

Field	Description	Value
Destination	Destination of the exported information. For descriptions, restrictions, and recommendations for each option, see the How To Export Data .	Screen/File/Printer Default: Screen
Include field header names	Whether or not to include the field header names in the exported file.	No/Yes Default: Yes
Start date	Earliest date for which you want to export meeting participant join leave information.	Format: mm/dd/yyyy Default: yesterday's date
End date	Latest date for which you want to export meeting participant join leave information.	Format: mm/dd/yyyy Default: today's date

Output Fields of the Meeting Participant Join Leave Information Page

Field	Description
PartID	Meeting participant ID.
UserID	Username used to log in to Cisco Unified MeetingPlace Express from a workstation (not from a phone).
ConfNum	Unique number used by the local audio mixer to identify the voice meeting. This value is different from the meeting ID displayed to end users.
MeetingID	

	Meeting ID, which uniquely identifies the meeting. If you do not specify one, the system automatically assigns your phone number as the meeting ID.
gmStartDate	The date that the user entered the meeting.
gmStartTime	The time that the user entered the meeting.
gmEndDate	The date that the user left the meeting.
gmEndTime	The time that the user left the meeting.
Device	Device and port number used to join the meeting: <ul style="list-style-type: none"> • 4081-4082: web port • all other values: voice port
nIncDigits	The number of DNIS digits that were received from the PBX.
IncDigits	The actual string of DNIS digits received from the PBX. Can be up to 24 digits.
AttachmentID	Not supported.
nANIDigits	The number of ANI digits that were received from the PBX.
ANIDigits	The actual string of ANI digits received from the PBX. Can be up to 24 digits.