

Cisco\_Unified\_MeetingPlace\_Express,\_Release\_2.x\_--\_About\_This\_Page:\_SMA\_Disable\_SSL

**Main page:** [Cisco Unified MeetingPlace Express, Release 2.x](#)

**Previous page:** [Page References](#)

This page is used to disable SSL on the secondary server in Cisco Unified MeetingPlace Express.