

**Main page:** [Cisco Unified MeetingPlace Express, Release 2.x](#)

**Previous page:** [Page References](#)

This page is used to display, add, edit, and delete SNMP community strings.

Field	Description
Community string name	The name of the SNMP community string. Click the underlined name of the SNMP community string to edit it.
Access privileges	The level of access for this SNMP community string. Access privileges provide security by restricting the ability to alter the Cisco Unified MeetingPlace Express system.  Allowable access privileges for the community strings are: <ul style="list-style-type: none"><li>• Read only</li><li>• Read write</li><li>• Read write notify</li><li>• Notify only</li><li>• None</li></ul>

**Related Topics**

- [Adding and Editing an SNMP Community String](#)
- [Displaying and Deleting an SNMP Notification Destination](#)