

**Main page:** [Cisco Unified MeetingPlace Express, Release 2.x](#)

**Previous page:** [Page References](#)

Field	Description	Values
Event date	The date of the event for which you want system information.	<ul style="list-style-type: none"> <li>• Date in the format MM/DD/YYYY</li> <li>• Click ... to choose a date.</li> </ul> Default: today's date
Approximate event time	The approximate hour and minute of the event for which you want system information.	Hour: 00 - 23 Minute: 00 - 59 Default: current time
Log capture window	The number of minutes before and after the approximate event time for which you want system information.	0 - 1400 Default: 60
Name of person to contact	The name of the person to contact with information about the event.	Any text string. Default: blank
Phone number of person to contact	The phone number of the person to contact with information about the event.	Any text string. Default: blank
E-mail address of person to contact	The e-mail address of the person to contact with information about the event.	Any text string. Default: blank
Event scenario	The steps that produced the event.	Any text. Default: blank
Observed results	What you observed when the event happened.	Any text. Default: blank
Expected results	What you expected to observe when the event happened.	Any text.

		Default: blank
--	--	----------------

**Related Topics**

- [Viewing the System Information Capture \(Infocap\) Log](#)