

Cisco_Unified_MeetingPlace_Release_6.1_--_Raw_Data_Export_Specifications

[Cisco Unified MeetingPlace Release 6.1](#) > [Cisco Unified MeetingPlace Audio Server](#) > [Maintaining](#) > [Running Reports](#) > [About Raw Data Reports](#)

The following raw report data specifications are used for exporting data from MeetingTime to a spreadsheet or database program.

See the following sections:

- [Raw Profile Information Data](#)
- [Raw Group Information Data](#)
- [Raw Meeting Details Information Data](#)
- [Raw Meeting Participant Information Data](#)
- [Raw Meeting Outdial \(Users\) Information Data](#)
- [Raw Meeting Outdial \(Servers\) Information Data](#)
- [Raw Meeting Attachment Information](#)
- [Raw System Outdial Information Data](#)
- [Raw Scheduling Failures](#)
- [Raw Participant Join Leave Information](#)

For a description of each raw data report, see the [About Raw Data Reports](#).