

The following examples are typical translation tables for a customer with two port groups, one connected to a PBX (port group 0) and the second port group (port group 1) connected to a Central Office.

- [Example 1: Port Group 1, PBX](#)
- [Example 2: Port Group 1, Central Office, No Flash or Positive Answer Supervision](#)

Example 1: Port Group 1, PBX

Port group 0 connected to the PBX.

From	To	Port Group	DestType	Comment
0\{R?}	200\1	0	GENERIC	Call the company attendant. If a wait for answer is requested, include it at the end.
!\{R?}	!\,200\1	0	GENERIC	Allow all flash transfers. Wait two seconds after a flash transfer before dialing. If a wait for answer is requested, include it at the end.
2..R?	\0	ANYGROUP	GENERIC	Allow calls to all internal extensions with and without waiting for an answer. Can use any port in any port group.
!\{2..R?}	!\,\1	0	GENERIC	Allow all flash transfers to internal extensions. Add a four second delay after a flash transfer before dialing.
9,*011.*	0	BLOCK	GENERIC	Block all international calls.
9,*10.*	0	BLOCK	GENERIC	Block all calls using a long distance carrier.
9,*1?900.*	0	BLOCK	GENERIC	Block all calls to the 900 area code.
9,*1?976.*	0	BLOCK	GENERIC	Block all calls to the 976 area code or office code.
9,*1?...976....	0	BLOCK	GENERIC	Block all calls to the 976 office code regardless of the area code.
9,*1?.....R?	\0	0	GENERIC	Accept all calls to the local area code.
9,*1?.....R?	\0	0	GENERIC	Accept all calls to all area codes.

Example 2: Port Group 1, Central Office, No Flash or Positive Answer Supervision

Port group 1 is connected to the Central Office. No flash (making the phone go on and off hook fast) is allowed on port group 1. No positive answer supervision.

From	To	Port Group	DestType	Comment
------	----	------------	----------	---------

Cisco_Unified_MeetingPlace_Release_6.1_-_Translation_Table_Examples

0R	9887200R,,	1	GENERIC	Call the company attendant. Ports in group 1 do not have positive answer supervision, so wait four seconds before playing the first prompt.
0	9887200	1	GENERIC	Call the company attendant. Do not wait four seconds before playing the first prompt.
2..R	9887\0,,	1	GENERIC	Call local extensions when going over the network. Wait four seconds before playing the first prompt.
2..	9887\0	1	GENERIC	Call local extensions when going over the network. Do not wait four seconds before playing the first prompt.
011.*	0	BLOCK	GENERIC	Block all international calls.
10.*	0	BLOCK	GENERIC	Block all calls using a long distance carrier.
1?900	0	BLOCK	GENERIC	Block all calls to the 900 area code.
1?976.*	0	BLOCK	GENERIC	Block all calls to the 976 area code or office code.
1?...976....	0	BLOCK	GENERIC	Block all calls to the 976 office code regardless of the area code.
1?.....R	\0,,	1	GENERIC	Accept all calls to the local area code. Wait four seconds before playing the first prompt.
1?.....	\0	1	GENERIC	Accept all calls to the local area code.
1?212.....R	\0,,	1	GENERIC	Accept calls only to the 212 area code. Wait four seconds before playing the first prompt.
1?212.....	\0	1	GENERIC	Accept calls to the 212 area code.