

**Main page:** [Cisco Unified Presence, Release 7.x](#)

**Previous Topic**

- [Deployment of Cisco Unified Presence](#)
- [User and Device Configuration on Cisco Unified Communications Manager](#)
- [Configuring the Presence Service Parameter](#)
- [How to Configure the SIP Trunk and SIP Trunk Security Profile on Cisco Unified Communications Manager](#)
- [Verifying That the Required Services are Running on Cisco Unified Communications Manager](#)