

**Main page:** [Cisco Unified Presence, Release 7.x](#)

**Previous Topic**

- [Configuring the Cisco IP PhoneMessenger Service](#)

Before you configure Cisco IP PhoneMessenger, make sure that you have configured the following:

- Configured the Cisco Unified Communications Manager server for integration with Cisco Unified Presence
- Configured the Cisco Unified Presence server for deployment in the network.

**Related Topics**

- [Configuring Cisco Unified Communications Manager for Integration with Cisco Unified Presence](#)
- [Configuring a Cisco Unified Presence Server for Deployment in the Network](#)
- [Getting More Information](#)