

Main page: [Cisco Unified Presence, Release 7.x](#)

This module describes the configuration steps for integrating Cisco Unified Presence with Microsoft Office Communications Server or Microsoft Live Communications Server for Microsoft Office Communicator (MOC) call control.

Note: This module describes the procedure for integrating Cisco Unified Presence with Microsoft Office Communications Server (OCS). Use this module as a guide for setting up this integration between Cisco Unified Presence and Microsoft Live Communications Server (LCS).

Software Requirements

- Cisco Unified Presence Server (Release 6.X or Release 7.X)
- Cisco Unified Communications Manager Server Version 6.X, 7.x or 8.x
- Microsoft Office Communications (OCS) 2007 Server Standard or Enterprise
- Microsoft Live Communications (LCS) 2005 Server, Standard or Enterprise
- Microsoft Office Communicator (MOC)
- Microsoft Windows Server
- (Optional) Cisco CSS 11500 Content Services Switch

For this integration it is assumed that you have the following installed and configured:

- A Cisco Unified Presence server that is set up and configured as described in the *Deployment Guide for Cisco Unified Presence*.
- The Cisco Unified Presence server must be correctly deployed with a Cisco Unified Communications Manager (CUCM) server as described in the *Deployment Guide for Cisco Unified Presence*.
- A Microsoft OCS or LCS server that is set up and configured as per the requirements defined in the Microsoft documentation.