

**Main page:** [Cisco Unity Express -- REST PI Service Operations](#)

**Previous page:** [Cisco Unity Express -- DNS Configuration REST PI Service Operation](#)

**Next page:** [Cisco Unity Express -- License Information REST PI Service Operation](#)

**Search the Cisco Unity Express documentation on the DocWiki:**

Loading

---


## Contents

- [1 System Information](#)
  - ◆ [1.1 Classes](#)
    - ◇ [1.1.1 SystemInfo](#)
  - ◆ [1.2 Resources](#)

## System Information

### Classes

**Figure 18: System Information**



### SystemInfo

<b>Class Name</b>	SystemInfo
<b>Extends From</b>	ManagedBaseElement

Cisco\_Unity\_Express\_--\_System\_Information\_REST\_Pi\_Service\_Operation

<b>Description</b>	System DNS configuration settings		
<b>XML Namespace</b>	http://sysinfo.model.rest.aesop.cisco.com		
<b>Field Name</b>	<b>Type</b>	<b>Constraints</b>	<b>Comments</b>
chasisSerial	String		Chasis serial number
chasisType	String		Chasis type
memorySize	Integer		Memory size of the module (MB)
moduleSerial	String		Module serial number
moduleType	String		Module type
upTime	Long		System up time (seconds)

**Resources**

Resource URI	Operation	Input	Return Value
/system/info	GET (read system information)		SystemInfo