

**Main page:** [Cisco Unity Express -- REST PI Service Operations](#)

**Previous page:** [Cisco Unity Express -- DNS Configuration REST PI Service Operation](#)

**Next page:** [Cisco Unity Express -- License Information REST PI Service Operation](#)

**Search the Cisco Unity Express documentation on the DocWiki:**

Loading

---


## Contents

- [1 System Information](#)
  - ◆ [1.1 Classes](#)
    - ◊ [1.1.1 SystemInfo](#)
  - ◆ [1.2 Resources](#)

## System Information

### Classes

**Figure 18: System Information**



### SystemInfo

<b>Class Name</b>	SystemInfo
<b>Extends From</b>	ManagedBaseElement

## Cisco\_Unity\_Express\_--\_System\_Information\_REST\_PI\_Service\_Operation

Description	System DNS configuration settings		
XML Namespace	http://sysinfo.model.rest.aesop.cisco.com		
Field Name	Type	Constraints	Comments
chassisSerial	String		Chassis serial number
chassisType	String		Chassis type
memorySize	Integer		Memory size of the module (MB)
moduleSerial	String		Module serial number
moduleType	String		Module type
upTime	Long		System up time (seconds)

### Resources

Resource URI	Operation	Input	Return Value
/system/info	GET (read system information)		SystemInfo