

Exec Command Differences

The following table lists the **debug** commands that are in FWSM software but not in ASA software.

[show no] debug acl optimization
[show no] debug aging
[show no] debug control-plane
[show no] debug ip bgp
[show no] debug npc
[show no] debug pc-lu
[show no] debug pisa
[show no] debug resource partition
[show no] debug route-inject
[show no] debug route-monitor
[show no] debug route-np
[show no] debug RM-NP-counter
[show no] debug session
[show no] debug ssl