

Switch Transfer Is Not Going to the Gateway Defined in the Gatekeeper Zone Prefix Command

Problem Summary	Switch Transfer is not going to the Gateway defined in the Gatekeeper zone prefix command.
Error Message	None.
Possible Cause	The IP address of the outbound Gateway, which is registered with a DNS name, is used in the zone prefix.
Recommended Action	Use the same name of the outbound Gateway in zone prefix. To verify the outbound Gatekeeper priority list, do the following: <ol style="list-style-type: none"> 1. Enter the show Gatekeeper gw-type-prefix command in the Gatekeeper CLI. 2. Enter the show Gatekeeper end command in the Gatekeeper CLI and verify that H323 ID used by egress gateway/endpoint to register with Gatekeeper is used in the Zone prefix configuration of Gatekeeper.
Release	Release 7.0(2)
Associated CDETS #	None.