

## Error When Adding a Dial-Peer

<b>Problem Summary</b>	When adding a dial-peer, an error message is issued and the dial-peer is not added.
<b>Error Message</b>	Could not add peer.
<b>Possible Cause</b>	This message implies that the amount of memory required to add the dial-peer is not available.
<b>Recommended Action</b>	Use the <b>show memory</b> command to verify the available free memory. If the available free memory is > 0, then the logging buffer is taking up all available memory. In this case, adjust the amount of memory used by the log buffer by changing the value of logging buffered <numeric value>. The recommended value for this setting is between 10 - 20% of the total Gateway memory.
<b>Release</b>	Release 7.0(2)
<b>Associated CDETS #</b>	None.