

Error When Adding a Dial-Peer

Problem Summary	When adding a dial-peer, an error message is issued and the dial-peer is not added.
Error Message	Could not add peer.
Possible Cause	This message implies that the amount of memory required to add the dial-peer is not available.
Recommended Action	Use the show memory command to verify the available free memory. If the available free memory is > 0, then the logging buffer is taking up all available memory. In this case, adjust the amount of memory used by the log buffer by changing the value of logging buffered <numeric value>. The recommended value for this setting is between 10 - 20% of the total Gateway memory.
Release	Release 7.0(2)
Associated CDETS #	None.