

This chapter provides CLR (clear) commands for the Cisco ONS 15454 SDH and Cisco ONS 15600 SDH.

Contents

- 1
CLR-COND-SECU
 - ◆ 1.1
Usage
Guidelines
 - ◆ 1.2
Category
 - ◆ 1.3
Security
 - ◆ 1.4
Input
Format
 - ◆ 1.5
Input
Example
 - ◆ 1.6
Input
Parameters

CLR-COND-SECU

(Cisco ONS 15454 SDH and ONS 15600 SDH) The Clear Security Condition (CLR-COND-SECU) command clears the specified standing condition.

Usage Guidelines

In Software Release 6.0 and later, only the INTRUSION-PSWD parameter value is supported.

Category

Security

Security

Superuser

Input Format

CLR-COND-SECU:[<TID>]::<CTAG>[::<SECUALMTYPE>];

Input Example

CLR-COND-SECU:CISCO::123::INTRUSION-PSWD:

Input Parameters

<code><SECUALMTYPE></code>	(Optional) Secure alarm type. Defaults to INTRUSION-PSWD. The parameter type is
----------------------------------	---------------------------------------------------------------------------------

ONS_SDH_TL1_Command_Guide_R8.5.1_--_CLR_Commands

	SECUALMTYPE, which is the security alarm type.
<ul style="list-style-type: none">• INTRUSION-BSWD	Condition raised after an invalid password is used during login. Condition is raised only if the password is used a specified number of times.