

This chapter provides clear (CLR) commands for the Cisco ONS 15454, Cisco ONS 15310-CL, Cisco ONS 15310-MA, and Cisco ONS 15600.

Contents

- 1
 - CLR-COND-SECU
 - ◆ 1.1
 - Usage
 - Guidelines
 - ◆ 1.2
 - Category
 - ◆ 1.3
 - Security
 - ◆ 1.4
 - Input
 - Formats
 - ◆ 1.5
 - Input
 - Examples
 - ◆ 1.6
 - Input
 - Parameters

CLR-COND-SECU

(Cisco ONS 15454, ONS 15327, ONS 15310-CL, ONS 15310-MA, ONS 15600) The Clear Security Condition (CLR-COND-SECU) command clears the specified standing condition.

Usage Guidelines

In Software Release 6.0 and later, only the INTRUSION-PSWD parameter value is supported.

Category

Security

Security

Superuser

Input Formats

```
CLR-COND-SECU:[<TID>]::<CTAG>[::<SECUALMTYPE>];
```

Input Examples

```
CLR-COND-SECU:CISCO::123::INTRUSION-PSWD:
```

Input Parameters

<SECUALMTYPE>	Secure alarm type. Defaults to INTRUSION-PSWD. The parameter type is security alarm type (SECUALMTYPE).
<ul style="list-style-type: none"> • INTRUSION-PSWD 	Condition raised after an invalid password is used during login. Condition is raised only if the password is used a specified number of times.