

QuickTime does not playback G.729 recording, but status bar keep moving

Problem Summary	QuickTime <i>appears</i> to start playing a G.729 audio recording. The QuickTime slider bar continues to move along as if it were actually playing the file. But you do not hear any sound.
Error Message	None.
Possible Cause	QuickTime does not support playback of G.729 Audio.
Recommended Action	Use an alternate player which supports this codec, if available.
Release	Releases 8.5(1), 8.5(2), 8.5(3), 8.5(4), 9.0(1)
Associated CDETS #	CSCtk11000