

Barge in does not work and results in an error

Problem Summary	Barge in does not work and results in an error
Error Message	None.
Possible Cause	The Barge In feature uses conference functionality.
Recommended Action	From the CallManager configuration, check that the conference bridge is configured correctly and that it has been started. Also try to make a regular conference call. If Hardphones are available, try to make a conference call from the IP hardphone (will indicate if the conference bridge is not available).
Release	Release 7.5(x)
Associated CDETS #	None.