

**Barge in does not work and results in an error**

<b>Problem Summary</b>	Barge in does not work and results in an error
<b>Error Message</b>	None.
<b>Possible Cause</b>	The Barge In feature uses conference functionality.
<b>Recommended Action</b>	From the CallManager configuration, check that the conference bridge is configured correctly and that it has been started. Also try to make a regular conference call. If Hardphones are available, try to make a conference call from the IP hardphone (will indicate if the conference bridge is not available).
<b>Release</b>	Release 7.5(x)
<b>Associated CDETS #</b>	None.