

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

The following are the supported devices for Prime Collaboration 10.0 Assurance - Advanced. See [Cisco Prime Collaboration Assurance Guide - Standard, 10.0](#) for supported devices for Prime Collaboration 10.0 Assurance - Standard

### Contents

- [1 Supported Software Versions](#)
- [2 Cisco Endpoints](#)
- [3 Cisco Infrastructure Devices](#)
- [4 Cisco Network Devices](#)
- [5 Third-party Endpoints](#)
- [6 Third-party Network Devices](#)

### Supported Software Versions

Device	Software Versions
Analog Gateway	-
Cisco Unified Communications Manager	8.0 - 10.0
Cisco Unified Communications Manager Business Edition	8.0 - 9.0
Cisco Unified Communications Manager Express	8.0 - 9.5
Cisco Unified Presence (Cisco Unified Communications Manager IM and Presence)	8.0 - 10.0
Cisco Unified Contact Center Enterprise	8.0 - 10.0
Cisco Unified Contact Center Express	8.0 - 10.0
Cisco Unity Connection	8.0 - 10.0
Cisco Unity	8.0 - 8.6
Cisco Unity Express	8.0 - 9.0
Cisco Emergency Responder	1.0 - 10.0
Cisco Expert Advisor	7.2 - 7.6
Finesse	9.0 - 9.1
Mediasense	9.0 - 10.0

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Unified Customer Voice Portal	8.0 - 10.0
Cisco Unified MeetingPlace Enterprise	7.0 - 8.6
Cisco Unified MeetingPlace Express	2.0 - 2.1
Cisco Personal Assistant	1.3 - 1.4
Cisco IP phones (89xx, 99xx)	all software versions
Cisco Unified Personal Communicator	1.1 - 8.6
Cisco IP Communicator	1.2 - 8.6
Cisco TelePresence Manager (CTS-Manager)	1.7 ? 1.9
Cisco TelePresence Management Suite (Cisco TMS)	13.0 ? 14.3 New features supported in 14.1, 14.2, and 14.3 are not supported. The Cisco TMS 14.2 and 14.3 versions are supported through <a href="#">Cisco Prime Collaboration 10.0 Assurance and Analytics Service Pack 1</a> .
Cisco TelePresence Multipoint Switch	1.7 ? 1.10
Cisco MCU	4.1 ? 4.4
Cisco TelePresence Video Communication Server (Cisco VCS)	6.0 ? 8.1 The Cisco VCS 8.1 version is supported through <a href="#">Cisco Prime Collaboration 10.0 Assurance and Analytics Service Pack 1</a> .
Cisco TelePresence Video Communication Server Expressway (Cisco VCS Expressway)	6.0 - 8.0
Cisco Telepresence Server	2.1 ? 3.1 For 3.0 and 3.1, support is available for the Standalone operation mode (locally managed mode); the Flexible operation mode (remotely managed mode) is not supported.
Cisco TelePresence MSE Supervisor	2.1 ? 2.3
Cisco Telepresence Conductor	1.1 - 2.1 Note: Only the Cisco TelePresence Conductor with Cisco VCS (Policy Service) deployment is supported. Cisco TelePresence Conductor with Cisco VCS

	(B2BUA) and Cisco TelePresence Conductor with Cisco Unified CM deployments are not supported.
Cisco TelePresence System	1.7 ? 1.9.3
<ul style="list-style-type: none"> <li>• Cisco Codec EX series</li> <li>• Cisco TelePresence System Integrator C Series</li> <li>• Cisco TelePresence MX Series</li> <li>• Cisco TelePresence System Profile Series</li> <li>• Cisco TelePresence SX20 Quick Set</li> <li>• Cisco TX 9000 series</li> </ul>	<ul style="list-style-type: none"> <li>• EX series: TC 4.2 - 7.0; TE 6.0</li> <li>• C, MX, and SX series: TC 4.2 - 7.0</li> <li>• TX series: TX 6.0</li> </ul> <p>The TC 6.3 and 7.0 versions are supported through <a href="#">Cisco Prime Collaboration 10.0 Assurance and Analytics Service Pack 1</a>.</p> <p>Note: MSI based features are not supported because of the limitations in the device software. MSI credential verification fails for these software images in Prime Collaboration Assurance.</p>
Cisco TelePresence System MXP series	9.1
Cisco IP Video Phone E20	TE 4.0 - 6.0
Cisco Jabber Video for Telepresence (Movi)	all software versions.
Cisco Cius	all software versions.
Wireless	-
Network devices (routers and switches)	-
Border Element, Gatekeeper, H323 Gateway, SIP Gateway, MGCP Gateway, SRST Device, Voice Gateway	IOS 12.x or later
Polycom VSX series	2.5 - 3.0 (for HDX series)
Polycom HDX series	9.0 (for VSX series)
Third party devices	-

## Cisco Endpoints

Device Group	Device Series	Device Name	SystemObjectID
--------------	---------------	-------------	----------------

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

TelePresence	Cisco TelePresence System	Cisco TelePresence 1000	1.3.6.1.4.1.9.1.800
TelePresence	Cisco TelePresence System	Cisco TelePresence 1000	1.3.6.1.4.1.9.1.801
TelePresence	Cisco TelePresence System	Cisco TelePresence 1000	1.3.6.1.4.1.9.1.1003
Cisco Codec C Series	Cisco Codec C Series	ciscoC20	1.3.6.1.4.1.9.1.c20
Cisco Codec C Series	Cisco Codec C Series	ciscoC40	1.3.6.1.4.1.9.1.c40
Cisco Codec C Series	Cisco Codec C Series	ciscoC60	1.3.6.1.4.1.9.1.c60
Cisco Codec C Series	Cisco Codec C Series	ciscoC90	1.3.6.1.4.1.9.1.c90
Cisco Codec C Series	Cisco Codec C Series	ciscoEX60	1.3.6.1.4.1.9.1.ex60
Cisco Codec C Series	Cisco Codec C Series	ciscoEX90	1.3.6.1.4.1.9.1.ex90
Cisco Codec C Series	Cisco Codec C Series	ciscoMX200	1.3.6.1.4.1.9.1.mx200
Cisco Codec C Series	Cisco Codec C Series	ciscoMX300	1.3.6.1.4.1.9.1.mx300
Cisco Codec C Series	Cisco Codec C Series	ciscoProfile42-C20	1.3.6.1.4.1.9.1.p42c20
Cisco Codec C Series	Cisco Codec C Series	ciscoProfile42-C40	1.3.6.1.4.1.9.1.p42c40
Cisco Codec C Series	Cisco Codec C Series	ciscoProfile42-C60	1.3.6.1.4.1.9.1.p42c60
Cisco Codec C Series	Cisco Codec C Series	ciscoProfile52	1.3.6.1.4.1.9.1.p52
Cisco Codec C Series	Cisco Codec C Series	ciscoProfile52-Dual	1.3.6.1.4.1.9.1.p52dual
Cisco Codec C Series	Cisco Codec C Series	ciscoProfile65	1.3.6.1.4.1.9.1.p65
Cisco Codec C Series	Cisco Codec C Series	ciscoProfile65-Dual	1.3.6.1.4.1.9.1.p65dual
Cisco TelePresence SX20	Cisco Codec C Series	ciscoSX20	1.3.6.1.4.1.9.1.sx20
Cisco Cius	Cisco Cius	ciscoCius	1.3.6.1.4.1.9.1.cius
Cisco Jabber	Cisco Jabber	ciscoJabber	1.3.6.1.4.1.9.1.ciscojabber
Cisco Phone	Cisco Phone	ciscoPhone	1.3.6.1.4.1.9.1.phone
		ciscoCTS1000	1.3.6.1.4.1.9.1.cts1000

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco TelePresence System	Cisco TelePresence System		
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS1100	1.3.6.1.4.1.9.1.cts1100
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS1300	1.3.6.1.4.1.9.1.cts1300
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS1310	1.3.6.1.4.1.9.1.cts1310
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS1400	1.3.6.1.4.1.9.1.cts1400
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS3000	1.3.6.1.4.1.9.1.cts3000
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS3010	1.3.6.1.4.1.9.1.cts3010
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS3200	1.3.6.1.4.1.9.1.cts3200
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS3210	1.3.6.1.4.1.9.1.cts3210
Cisco TelePresence System	Cisco TelePresence System	ciscoCTS500	1.3.6.1.4.1.9.1.cts500
Cisco TelePresence System	Cisco TelePresence System	ciscoTX9000	1.3.6.1.4.1.9.1.tx9000
Cisco TelePresence System	Cisco TelePresence System	ciscoTX9200	1.3.6.1.4.1.9.1.tx9200
Cisco TelePresence E20	Cisco TelePresence System	ciscoE20	1.3.6.1.4.1.5596.160.6.4.1
Cisco Unified IP Phones	-	Cisco 12 SP	
Cisco Unified IP Phones	-	Cisco 12 SP+	
Cisco Unified IP Phones	-	Cisco 30 SP+	
Cisco Unified IP Phones	-	Cisco 30 VIP	

Cisco Unified IP Phones	-	Cisco 3905
Cisco Unified IP Phones	-	Cisco 3911
Cisco Unified IP Phones	-	Cisco 6901
Cisco Unified IP Phones	-	Cisco 6911
Cisco Unified IP Phones	-	Cisco 6921
Cisco Unified IP Phones	-	Cisco 6941
Cisco Unified IP Phones	-	Cisco 6945
Cisco Unified IP Phones	-	Cisco 6951
Cisco Unified IP Phones	-	Cisco 6961
Cisco Unified IP Phones	-	Cisco 7821
Cisco Unified IP Phones	-	Cisco 7841
Cisco Unified IP Phones	-	Cisco 7845
Cisco Unified IP Phones	-	Cisco 7861
Cisco Unified IP Phones	-	Cisco 7902
Cisco Unified IP Phones	-	Cisco 7905
Cisco Unified IP Phones	-	Cisco 7906
Cisco Unified IP Phones	-	Cisco 7910
Cisco Unified IP Phones	-	Cisco 7911
Cisco Unified IP Phones	-	Cisco 7912
Cisco Unified IP Phones	-	Cisco 7920
Cisco Unified IP Phones	-	Cisco 7921
Cisco Unified IP Phones	-	Cisco 7925
Cisco Unified IP Phones	-	Cisco 7926

Cisco Unified IP Phones	-	Cisco 7931
Cisco Unified IP Phones	-	Cisco 7935
Cisco Unified IP Phones	-	Cisco 7936
Cisco Unified IP Phones	-	Cisco 7937
Cisco Unified IP Phones	-	Cisco 7940
Cisco Unified IP Phones	-	Cisco 7941
Cisco Unified IP Phones	-	Cisco 7941G-GE
Cisco Unified IP Phones	-	Cisco 7942
Cisco Unified IP Phones	-	Cisco 7945
Cisco Unified IP Phones	-	Cisco 7960
Cisco Unified IP Phones	-	Cisco 7961
Cisco Unified IP Phones	-	Cisco 7961G-GE
Cisco Unified IP Phones	-	Cisco 7962
Cisco Unified IP Phones	-	Cisco 7965
Cisco Unified IP Phones	-	Cisco 7970
Cisco Unified IP Phones	-	Cisco 7971
Cisco Unified IP Phones	-	Cisco 7971G-GE
Cisco Unified IP Phones	-	Cisco 7975
Cisco Unified IP Phones	-	Cisco 7985
Cisco Unified IP Phones	-	Cisco 8831
Cisco Unified IP Phones	-	Cisco 8941
Cisco Unified IP Phones	-	Cisco 8942
Cisco Unified IP Phones	-	Cisco 8945

Cisco Unified IP Phones	-	Cisco 8961
Cisco Unified IP Phones	-	Cisco 8962
Cisco Unified IP Phones	-	Cisco 9945
Cisco Unified IP Phones	-	Cisco 9965
Cisco Unified IP Phones	-	Cisco 9971
Cisco Unified IP Phones	-	Cisco 9951
Cisco Desktop Collaboration Experience	-	Cisco DX650
-	-	Cisco Dual Mode for Android
-	-	Cisco Dual Mode for iPhone
-	-	Cisco IP Communicator
-	-	Cisco Unified Client Services Framework
-	Cisco Unified Personal Communicator	

## Cisco Infrastructure Devices

Product Series	Product Name	System OID
Cisco Call Manager	Cisco Unified Communications Manager	1.3.6.1.4.1.9.1.cucm
Cisco MCU	Cisco MSE 8050 (Supervisor)	1.2.826.0.1.4616240.1.7.8050
Cisco MCU	Cisco MCU MSE 8420	1.2.826.0.1.4616240.1.1.8420
Cisco MCU	Cisco MCU MSE 8510	1.2.826.0.1.4616240.1.1.8510
Cisco MCU	Cisco MCU 4200	1.2.826.0.1.4616240.1.1.4200
Cisco MCU	Cisco MCU 4201	1.2.826.0.1.4616240.1.1.4201
Cisco MCU	Cisco MCU 4203	1.2.826.0.1.4616240.1.1.4203
Cisco MCU	Cisco MCU 4205	1.2.826.0.1.4616240.1.1.4205
Cisco MCU	Cisco MCU 4210	1.2.826.0.1.4616240.1.1.4210
Cisco MCU	Cisco MCU 4215	1.2.826.0.1.4616240.1.1.4215



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco MCU	Cisco MCU 4220	1.2.826.0.1.4616240.1.1.4220
Cisco MCU	Cisco MCU 4500	1.2.826.0.1.4616240.1.1.4500
Cisco MCU	Cisco MCU 4501	1.2.826.0.1.4616240.1.1.4501
Cisco MCU	Cisco MCU 4505	1.2.826.0.1.4616240.1.1.4505
Cisco MCU	Cisco MCU 4510	1.2.826.0.1.4616240.1.1.4510
Cisco MCU	Cisco MCU 4515	1.2.826.0.1.4616240.1.1.4515
Cisco MCU	Cisco MCU 4520	1.2.826.0.1.4616240.1.1.4520
Cisco MCU	Cisco MCU 5310	1.3.6.1.4.1.9.1.1540
Cisco Telepresence Conductor	Cisco Telepresence Conductor	1.3.6.1.4.1.5596.180.6.4.1
Cisco TelePresence Manager	Cisco CTS Manager	1.3.6.1.4.1.9.1.ctsman
Cisco TMS	Cisco TMS	1.3.6.1.4.1.311.1.1.3.1.2
Cisco TPS	Cisco Telepresence Server MSE 8710	1.2.826.0.1.4616240.1.1.8710
Cisco TPS	Cisco Telepresence Server 7010	1.2.826.0.1.4616240.1.1.7010
Cisco TPS ISDN Gateway MSE 8000 Series	Cisco TelePresence ISDN GW MSE 8321	1.2.826.0.1.4616240.1.3.8321
Cisco TPS ISDN Gateway MSE 8000 Series	Cisco TelePresence ISDN GW MSE 8310	1.2.826.0.1.4616240.1.3.8310
Cisco TPS ISDN Gateway	Cisco TelePresence ISDN GW 3421	1.2.826.0.1.4616240.1.3.3421
Cisco TPS ISDN Gateway	Cisco TelePresence ISDN GW 3241	1.2.826.0.1.4616240.1.3.3241
Cisco CTX	Cisco Telepresence Exchange Server	1.3.6.1.4.1.9.1.587
Cisco VCS	Cisco VCS	1.3.6.1.4.1.9.1.vcs
Cisco 7800 Series Media Convergence Servers	MCS7816H	1.3.6.1.4.1.9.1.900
	MCS7828H	1.3.6.1.4.1.9.1.901
	MCS7825H	1.3.6.1.4.1.9.1.583
	MCS7835H	1.3.6.1.4.1.9.1.584
	MCS7845H	1.3.6.1.4.1.9.1.586
	MCS7815 I	1.3.6.1.4.1.9.1.582
	MCS7835 I	1.3.6.1.4.1.9.1.585
	MCS7845 I	1.3.6.1.4.1.9.1.587
	MCS7855 I	1.3.6.1.4.1.9.1.588
	MCS7865 I	1.3.6.1.4.1.9.1.589
	MCS7825 I	1.3.6.1.4.1.9.1.746
	MCS7816 I	1.3.6.1.4.1.9.1.898
MCS7828 I	1.3.6.1.4.1.9.1.899	

Cisco Unified Border Element (CUBE)	Cisco 2800 Series ISR	?
	Cisco 2900 Series ISR	?
	Cisco 3800 Series ISR	?
	Cisco 3900 Series ISR	?
	Cisco 7200VXR Routers	?
	Cisco 7301 Routers	?
	Cisco AS5350XM Universal Gateway	?
	Cisco AS5400XM Universal Gateway	?
Cisco Unified Client Services Framework (CUCSF) Client	?	?
Cisco Unified Communications 500 Series for Small Business	UC520s8U4FXO	1.3.6.1.4.1.9.1.878
	UC520s8U4FXOW	1.3.6.1.4.1.9.1.879
	UC520s8U2BRI	1.3.6.1.4.1.9.1.880
	UC520s8U2BRIW	1.3.6.1.4.1.9.1.881
	UC520s16U4FXO	1.3.6.1.4.1.9.1.882
	UC520s16U4FXOW	1.3.6.1.4.1.9.1.883
	UC520s16U2BRI	1.3.6.1.4.1.9.1.884
	UC520s16U2BRIW	1.3.6.1.4.1.9.1.885
	UC520m32U8FXO	1.3.6.1.4.1.9.1.886
	UC520m32U4BRI	1.3.6.1.4.1.9.1.888
	UC520m48U12FXO	1.3.6.1.4.1.9.1.890
	UC520m48U6BRI	1.3.6.1.4.1.9.1.892
	UC520m48U1T1E1F	1.3.6.1.4.1.9.1.894
	UC520m48U1T1E1B	1.3.6.1.4.1.9.1.895
Cisco Unified Communications Integration for Microsoft Office Communicator	?	?
Cisco Unified Communications Manager	?	?
Cisco Unified Communications Manager Business Edition	?	?
Cisco Unified Communications Manager Express	?	?

Cisco Unified Contact Center Enterprise Edition	?	1.3.6.1.4.1.9.1.693
Cisco Unified Contact Center Express Edition	?	?
Cisco Unified Customer Voice Portal	?	?
Cisco Expert Advisor	?	?
Cisco Unified MeetingPlace Enterprise	?	1.3.6.1.4.1.9.9.733
Cisco Unified MeetingPlace Express	?	?
Cisco Unified Personal Communicator	?	?
Cisco Unified Presence Server	?	?
Cisco Unified SIP Proxy	NME	1.3.6.1.4.1.9.1.1406
	SM	1.3.6.1.4.1.9.1.1150
Cisco Emergency Responder	?	?
Cisco Personal Assistant	?	?
Cisco Unity	?	?
Cisco Unity Connection	?	?
Cisco Unity Express	?	?
Media Sense	?	?
Finesse	?	?
Cisco NAM software (Versions - 4.x, 5.0, 5.1, and 5.1 (2) )	?	?
<p>Cisco NAM hardware:</p> <p>1. Cisco NAM 2200 Series Appliances</p> <ul style="list-style-type: none"> <li>• NAM2204-RJ45</li> <li>• NAM2204-SFP</li> <li>• NAM2220</li> </ul> <p>2. Cisco Catalyst 6500 and Cisco 7600 Series; Cisco Integrated Services Routers (Branch Routers)</p> <ul style="list-style-type: none"> <li>• NME-NAM-80S</li> </ul>	?	?

<ul style="list-style-type: none"> <li>• NME-NAM-120S</li> <li>• WS-SVC-NAM-1</li> <li>• WS-SVC-NAM-2</li> <li>• WS-SVC-NAM-1-250S</li> <li>• WS-SVC-NAM-2-250S</li> <li>• NM-NAM (Supported with NAM 4.0 only. NAM 4.1 and 4.2 are not supported on NM-NAM.)</li> </ul>		
Cisco 1040 Sensor (Binary Image file name - SvcMonAB2_102.img)	?	?

## Cisco Network Devices

Device Group	Device Series	Device Name	SystemObjectID
Cisco UCS Series	Cisco UCS Series Servers	Cisco UCS 6120XP 20-Port Fabric Interconnect	1.3.6.1.4.1.9.12.3.1.3.847
Cisco UCS Series	Cisco UCS Series Servers	Cisco UCS 6140XP 40-Port Fabric Interconnect	1.3.6.1.4.1.9.12.3.1.3.899
Cisco UCS Series	Cisco UCS Series Servers	Cisco UCS 6248UP 48-Port Fabric Interconnect	1.3.6.1.4.1.9.12.3.1.3.1062
Cisco UCS Series	Cisco UCS Series Servers	Cisco UCS 6296UP 96-Port Fabric Interconnect	1.3.6.1.4.1.9.12.3.1.3.1063
Universal Gateways and Access Servers	Cisco 2500 Series Access Servers	Cisco 2509 Access Server	1.3.6.1.4.1.9.1.153
Universal Gateways and Access Servers	Cisco 2500 Series Access Servers	Cisco 2510 Access Server	1.3.6.1.4.1.9.1.26
Universal Gateways and Access Servers	Cisco 2500 Series Access Servers	Cisco 2511 Access Server	1.3.6.1.4.1.9.1.154
Universal Gateways and Access Servers	Cisco 2500 Series Access Servers	Cisco 2512 Access Server	1.3.6.1.4.1.9.1.28

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Universal Gateways and Access Servers	Cisco AS5200 Series Universal Access Servers	Cisco AS5201 Universal Access Server	1.3.6.1.4.1.9.1.109
Universal Gateways and Access Servers	Cisco AS5300 Series Universal Gateways	Cisco AS5350 Universal Gateway	1.3.6.1.4.1.9.1.313
Universal Gateways and Access Servers	Cisco AS5300 Series Universal Gateways	Cisco AS5300 Access Server	1.3.6.1.4.1.9.1.162
Universal Gateways and Access Servers	Cisco AS5300 Series Universal Gateways	Cisco AS5350XM Universal Gateway	1.3.6.1.4.1.9.1.679
Universal Gateways and Access Servers	Cisco AS5400 Series Universal Gateways	Cisco AS5400 Universal Gateway	1.3.6.1.4.1.9.1.274
Universal Gateways and Access Servers	Cisco AS5400 Series Universal Gateways	Cisco AS5400XM Universal Gateway	1.3.6.1.4.1.9.1.668
Universal Gateways and Access Servers	Cisco AS5800 Series Universal Gateways	Cisco AS5800 Access Server	1.3.6.1.4.1.9.1.188
Universal Gateways and Access Servers	Cisco AS5800 Series Universal Gateways	Cisco AS5850 Universal Gateway	1.3.6.1.4.1.9.1.308
Universal Gateways and Access Servers	Other Access Devices	TerminalServer	1.3.6.1.4.1.9.1.2
Content Networking	Cisco 500 Series Cache Engines	Cisco 500 Cache Engine	1.3.6.1.4.1.9.1.240
Content Networking	Cisco 500 Series Cache Engines	Cisco 500 Cache Engine	1.3.6.1.4.1.9.1.9
Content Networking	Cisco 500 Series Cache Engines	Cisco 500 Cache Engine	1.3.6.1.4.1.9.1.244
Content Networking	Cisco Micro Webservers	Cisco Micro Webserver 200	1.3.6.1.4.1.9.1.176
Content Networking	Cisco 4600 Series Content Distribution Manager	Cisco 4650 Content Distribution Manager	1.3.6.1.4.1.9.1.487

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Content Networking	Cisco 4600 Series Content Distribution Manager	Cisco 4630 Content Distribution Manager	1.3.6.1.4.1.9.1.486
Content Networking	Cisco 500 Series Content Engines	Cisco 507 Content Engine	1.3.6.1.4.1.9.1.409
Content Networking	Cisco 500 Series Content Engines	Cisco 507 AV Content Engine	1.3.6.1.4.1.9.1.432
Content Networking	Cisco 500 Series Content Engines	Cisco 560 Content Engine	1.3.6.1.4.1.9.1.410
Content Networking	Cisco 500 Series Content Engines	Cisco 560 Content Engine	1.3.6.1.4.1.9.1.433
Content Networking	Cisco 500 Series Content Engines	Cisco 590 Content Engine	1.3.6.1.4.1.9.1.411
Content Networking	Cisco 500 Series Content Engines	Cisco 510 Content Engine	1.3.6.1.4.1.9.1.505
Content Networking	Cisco 500 Series Content Engines	Cisco 565 Content Engine	1.3.6.1.4.1.9.1.491
Content Networking	Cisco 500 Series Content Engines	Cisco 566 Content Engine	1.3.6.1.4.1.9.1.596
Content Networking	Cisco 500 Series Content Engines	Cisco 501 Content Engine	1.3.6.1.4.1.9.1.612
Content Networking	Cisco 600 Series Content Engines	Cisco 611 Content Engine	1.3.6.1.4.1.9.1.708
Content Networking	Cisco 600 Series Content Engines	Cisco 674 Content Engine	1.3.6.1.4.1.9.1.996
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-274 Wide Area Application Engine	1.3.6.1.4.1.9.1.987
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-474 Wide Area Application Engine	1.3.6.1.4.1.9.1.986
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-511 Wide Area Application Engines	1.3.6.1.4.1.9.1.595
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-511 Wide Area Application Engines	1.3.6.1.4.1.9.1.681
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-511 Wide Area Application Engines	1.3.6.1.4.1.9.1.785
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-512 Wide Area Application Engine	1.3.6.1.4.1.9.1.759
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-512 Wide Area Application Engine	1.3.6.1.4.1.9.1.776

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-574 Wide Area Application Engine	1.3.6.1.4.1.9.1.985
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-611 Wide Area Application Engine	1.3.6.1.4.1.9.1.786
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-612 Wide Area Application Engine	1.3.6.1.4.1.9.1.757
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-612 Wide Area Application Engine	1.3.6.1.4.1.9.1.761
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-612 Wide Area Application Engine	1.3.6.1.4.1.9.1.777
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-674 Wide Area Application Engine	1.3.6.1.4.1.9.1.957
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-7326 Wide Area Application Engine	1.3.6.1.4.1.9.1.787
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-7341 Wide Area Application Engine	1.3.6.1.4.1.9.1.907
Content Networking	Cisco Wide Area Application Engine (WAE) Appliances	Cisco WAE-7371 Wide Area Application Engine	1.3.6.1.4.1.9.1.908
Content Networking	Cisco 7300 Series Content Engines	Cisco 7320 Content Engine	1.3.6.1.4.1.9.1.412
Content Networking	Cisco 7300 Series Content Engines	Cisco 7305 Content Engine	1.3.6.1.4.1.9.1.504
Content Networking	Cisco 7300 Series Content Engines	Cisco 7325 Content Engine	1.3.6.1.4.1.9.1.492
Content Networking	Cisco 7300 Series Content Engines	Cisco 7306 Content Engine	1.3.6.1.4.1.9.1.600
Content Networking	Cisco 7300 Series Content Engines	Cisco 7326 Content Engine	1.3.6.1.4.1.9.1.601
Content Networking	Cisco 7300 Series Content Engines	Cisco 7341 Content Engine	1.3.6.1.4.1.9.1.982
Content Networking	Cisco 7300 Series Content Engines	Cisco 7371 Content Engine	1.3.6.1.4.1.9.1.983
Content Networking	Cisco DistributedDirector	Cisco DistributedDirector 4700M	1.3.6.1.4.1.9.1.50
Content Networking	Cisco CSS 11000 Series Content Services Switches	Cisco CSS 11050 Content Services Switch	1.3.6.1.4.1.2467.4.4
			1.3.6.1.4.1.9.9.368.4.4

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Content Networking	Cisco CSS 11000 Series Content Services Switches	Cisco CSS 11050 Content Services Switch	
Content Networking	Cisco CSS 11000 Series Content Services Switches	Cisco CSS 11100 Content Services Switch	1.3.6.1.4.1.2467.4.1
Content Networking	Cisco CSS 11000 Series Content Services Switches	Cisco CSS 11150 Content Services Switch	1.3.6.1.4.1.2467.4.3
Content Networking	Cisco CSS 11000 Series Content Services Switches	Cisco CSS 11150 Content Services Switch	1.3.6.1.4.1.9.9.368.4.3
Content Networking	Cisco CSS 11000 Series Content Services Switches	Cisco CSS 11800 Content Services Switch	1.3.6.1.4.1.2467.4.2
Content Networking	Cisco CSS 11000 Series Content Services Switches	Cisco CSS 11800 Content Services Switch	1.3.6.1.4.1.9.9.368.4.2
Content Networking	Cisco 4400 Series Content Routers	Cisco 4450 Content Router	1.3.6.1.4.1.9.1.532
Content Networking	Cisco 4400 Series Content Routers	Cisco 4430 Content Router	1.3.6.1.4.1.9.1.531
Content Networking	Cisco CSS 11500 Series Content Services Switches	Cisco CSS 11506 Content Services Switch	1.3.6.1.4.1.2467.4.6
Content Networking	Cisco CSS 11500 Series Content Services Switches	Cisco CSS 11506 Content Services Switch	1.3.6.1.4.1.9.9.368.4.6
Content Networking	Cisco CSS 11500 Series Content Services Switches	Cisco CSS 11503 Content Services Switch	1.3.6.1.4.1.2467.4.5
Content Networking	Cisco CSS 11500 Series Content Services Switches	Cisco CSS 11503 Content Services Switch	1.3.6.1.4.1.9.9.368.4.5
Content Networking	Cisco CSS 11500 Series Content Services Switches	Cisco CSS 11501 Content Services Switch	1.3.6.1.4.1.2467.4.7
Content Networking	Cisco CSS 11500 Series Content Services Switches	Cisco CSS 11501 Content Services Switch	1.3.6.1.4.1.9.9.368.4.7
Content Networking	Cisco ACE GSS 4400 Series Global Site Selector Appliances	Cisco GSS 4480,4490,4491,4492R Global Site Selector	1.3.6.1.4.1.9.1.517
Content Networking	Cisco ACE GSS 4400 Series Global Site Selector Appliances	Cisco GSS 4490 Global Site Selector	1.3.6.1.4.1.9.1.518



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Content Networking	Cisco ACE GSS 4400 Series Global Site Selector Appliances	Cisco GSS 4491 Global Site Selector	1.3.6.1.4.1.9.1.519
Cisco Interfaces and Modules	Cisco Interface Cards	Cisco Intrusion Prevention System Advanced Integration Module	1.3.6.1.4.1.9.12.3.1.9.2.213
Cisco Interfaces and Modules	Cisco Interface Cards	Cisco Intrusion Prevention System Network Module	1.3.6.1.4.1.9.12.3.1.9.2.180
Cisco Interfaces and Modules	Cisco Interface Cards	Cisco 3205 Wireless Mobile Interface Card (WMIC)	1.3.6.1.4.1.9.1.819
Cisco Interfaces and Modules	Cisco Interface Cards	Cisco 3202 Wireless Mobile Interface Card (WMIC)	1.3.6.1.4.1.9.1.667
Cisco Interfaces and Modules	Cisco Services-Ready Engine (SRE) Modules	Application Extension Platform for SRE	1.3.6.1.4.1.9.1.1280
Cisco Interfaces and Modules	Cisco Services-Ready Engine (SRE) Modules	Application Extension Platform for SRE	1.3.6.1.4.1.9.1.1281
Cisco Interfaces and Modules	Cisco Services-Ready Engine (SRE) Modules	Application Extension Platform for SRE	1.3.6.1.4.1.9.1.1282
Cisco Interfaces and Modules	Cisco Services-Ready Engine (SRE) Modules	Application Extension Platform for SRE	1.3.6.1.4.1.9.1.1283
Cisco Interfaces and Modules	Cisco Services-Ready Engine (SRE) Modules	Application Extension Platform for SRE	1.3.6.1.4.1.9.1.1284
Cisco Interfaces and Modules	Cisco Services-Ready Engine (SRE) Modules	Cisco Wide Area Application Services (WAAS) Modules for SRE	1.3.6.1.4.1.9.1.1212
Cisco Interfaces and Modules	Cisco Services-Ready Engine (SRE) Modules	Cisco Wide Area Application Services (WAAS) Modules for SRE	1.3.6.1.4.1.9.1.1213
Cisco Interfaces and Modules	Cisco Application Extension Platform Modules and Interface Cards	Cisco Application Extension Platform Network Module Enhanced	1.3.6.1.4.1.9.1.1151

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Interfaces and Modules	Cisco Application Extension Platform Modules and Interface Cards	Cisco Application Extension Platform Network Module Enhanced	1.3.6.1.4.1.9.1.1288
Cisco Interfaces and Modules	Cisco Application Extension Platform Modules and Interface Cards	Cisco Application Extension Platform Network Module Enhanced	1.3.6.1.4.1.9.1.1289
Cisco Interfaces and Modules	Cisco Application Extension Platform Modules and Interface Cards	Cisco Application Extension Platform Network Module Enhanced	1.3.6.1.4.1.9.1.1290
Cisco Interfaces and Modules	Cisco Application Extension Platform Modules and Interface Cards	Cisco Application Extension Platform Advanced Integration Module	1.3.6.1.4.1.9.1.1152
Cisco Interfaces and Modules	Cisco Application Extension Platform Modules and Interface Cards	Cisco Application Extension Platform Advanced Integration Module 2	1.3.6.1.4.1.9.1.1153
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer 2 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1048
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer 2 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1051
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer 2 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1052
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer 2 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1055
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1049
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1050
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1053
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1054

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1056
Cisco Interfaces and Modules	Cisco Ethernet Switching Network Modules	Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1057
Cisco Interfaces and Modules	Cisco Service Control Engines	Cisco SCE 2020 Service Control Engine	1.3.6.1.4.1.9.1.684
Cisco Interfaces and Modules	Cisco Service Control Engines	Cisco SCE 8000 Service Control Engine	1.3.6.1.4.1.9.1.913
Cisco Interfaces and Modules	Cisco Service Control Engines	Cisco SCE 1000 Series Service Control Engine	1.3.6.1.4.1.9.1.683
Cisco Interfaces and Modules	Cisco Interface Cards	Cisco Intrusion Prevention System Advanced Integration Module	1.3.6.1.4.1.9.12.3.1.9.2.213
Cisco Interfaces and Modules	Cisco Interface Cards	Cisco Intrusion Prevention System Network Module	1.3.6.1.4.1.9.12.3.1.9.2.180
Cisco Interfaces and Modules	Cisco Interface Cards	Cisco 3205 Wireless Mobile Interface Card (WMIC)	1.3.6.1.4.1.9.1.819
Cisco Interfaces and Modules	Cisco Interface Cards	Cisco 3202 Wireless Mobile Interface Card (WMIC)	1.3.6.1.4.1.9.1.667
Cisco Interfaces and Modules	Cisco Voice Modules and Interface Cards	Cisco Unity Express Network Module	1.3.6.1.4.1.9.1.622
Cisco Interfaces and Modules	Cisco Voice Modules and Interface Cards	Cisco Unity Express Network Module	1.3.6.1.4.1.9.1.711
Cisco Interfaces and Modules	Cisco Voice Modules and Interface Cards	Cisco Unity Express Network Module	1.3.6.1.4.1.9.1.866
Cisco Interfaces and Modules	Cisco Voice Modules and Interface Cards	Cisco Unity Express Advanced Integration Module	1.3.6.1.4.1.9.1.623
Cisco Interfaces and Modules	Cisco Voice Modules and Interface Cards	Cisco Unity Express Advanced Integration Module	1.3.6.1.4.1.9.1.867
Cisco Interfaces and Modules	Cisco Voice Modules and Interface Cards	Cisco Unity Express Advanced Integration Module	1.3.6.1.4.1.9.1.868
			1.3.6.1.4.1.9.1.1150

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Interfaces and Modules	Cisco Voice Modules and Interface Cards	Cisco Unified SIP Proxy SM-SRE	
Cisco Interfaces and Modules	Cisco Voice Modules and Interface Cards	Cisco Unified SIP Proxy NME	1.3.6.1.4.1.9.1.1406
Cisco Interfaces and Modules	Cisco IGX Universal Router Modules	Cisco IGX Universal Router Module 2FE	1.3.6.1.4.1.9.1.374
Cisco Interfaces and Modules	Cisco IGX Universal Router Modules	Cisco IGX Universal Router Module 2FE-2V	1.3.6.1.4.1.9.1.375
Cisco Interfaces and Modules	Cisco Network Modules	Cisco 2600,2800,3700,3800 Series 16-Port EtherSwitch Service Module	1.3.6.1.4.1.9.1.663
Cisco Interfaces and Modules	Cisco Network Modules	Cisco 2600,2800,3700,3800 Series 16-Port EtherSwitch Service Module	1.3.6.1.4.1.9.1.702
Cisco Interfaces and Modules	Cisco Network Modules	Cisco 2600,3600,3700 Series Content Engine Modules	1.3.6.1.4.1.9.1.454
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Catalyst 6000 Multilayer Switch Feature Card MSFC2	1.3.6.1.4.1.9.1.301
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Catalyst 6000 Series Supervisor Module with MSFC	1.3.6.1.4.1.9.1.258
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Catalyst 6000 Multilayer Switch Feature Card MSFC3	1.3.6.1.4.1.9.1.557
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Catalyst 5000 RSM	1.3.6.1.4.1.9.1.168
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Catalyst 5500 RSM	1.3.6.1.4.1.9.1.257
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Catalyst 6000 Series Switches MSM	1.3.6.1.4.1.9.1.256
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Catalyst 6000 Access Gateway line card	1.3.6.1.4.1.9.1.573
Cisco Interfaces	Cisco Network Modules	Cisco IDS Access Router Network Module	1.3.6.1.4.1.9.1.654

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

and Modules			
Cisco Interfaces and Modules	Cisco Network Modules	Cisco 2800,3800 Series 23-Port EtherSwitch Service Module	1.3.6.1.4.1.9.1.664
Cisco Interfaces and Modules	Cisco Network Modules	Cisco 2800,3800 Series 23-Port EtherSwitch Service Module	1.3.6.1.4.1.9.1.703
Cisco Interfaces and Modules	Cisco Network Modules	Cisco 2851,3800 Series 24-Port EtherSwitch (with Stackwise Connectors) Service Module	1.3.6.1.4.1.9.1.665
Cisco Interfaces and Modules	Cisco Network Modules	Cisco 2851,3800 Series 48-Port EtherSwitch Service Module	1.3.6.1.4.1.9.1.666
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Wide Area Application Services Network Module(NME-WAE-502)	1.3.6.1.4.1.9.1.823
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Wide Area Application Services Network Module(NME-WAE-502)	1.3.6.1.4.1.9.1.1161
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Wide Area Application Services Network Module(NME-WAE-502)	1.3.6.1.4.1.9.1.1162
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Wide Area Application Services Network Module(NME-WAE-502)	1.3.6.1.4.1.9.1.1209
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Wide Area Application Services Network Module(NME-WAE-502)	1.3.6.1.4.1.9.1.1210
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Wide Area Application Services Network Module(NME-WAE-502)	1.3.6.1.4.1.9.1.1211
Cisco Interfaces and Modules	Cisco Network Modules	Cisco Wide Area Application Services Network Module(NME-WAE-522)	1.3.6.1.4.1.9.1.1211
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor Virtual Sensor	1.3.6.1.4.1.9.1.1437
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor Virtual Sensor	1.3.6.1.4.1.9.1.1438

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor Virtual Sensor	1.3.6.1.4.1.9.1.1439
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor Virtual Sensor	1.3.6.1.4.1.9.1.1440
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor	1.3.6.1.4.1.9.1.1232
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor	1.3.6.1.4.1.9.1.1233
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor	1.3.6.1.4.1.9.1.1234
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor	1.3.6.1.4.1.9.1.1235
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Content Switching Module with SSL	1.3.6.1.4.1.9.1.524
Cisco Interfaces and Modules	Cisco Services Modules	SAMI	1.3.6.1.4.1.9.1.744
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series SSL Services Module	1.3.6.1.4.1.9.1.554
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ACE Application Control Engine Module	1.3.6.1.4.1.9.1.730
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ACE Application Control Engine Module	1.3.6.1.4.1.9.1.1291
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ACE Application Control Engine Module	1.3.6.1.4.1.9.1.1231
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ACE 4710 Application Control Engine	1.3.6.1.4.1.9.1.824
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Branch Routers Series Network Analysis Module (NME-NAM)	1.3.6.1.4.1.9.1.826
Cisco Interfaces and Modules	Cisco Services Modules	Router RPM	1.3.6.1.4.1.9.1.457
Cisco Interfaces and Modules	Cisco Services Modules	Router RPM	1.3.6.1.4.1.9.1.199

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Interfaces and Modules	Cisco Services Modules	Router RPM	1.3.6.1.4.1.9.1.440
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module	1.3.6.1.4.1.9.1.662
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module	1.3.6.1.4.1.9.1.655
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module	1.3.6.1.4.1.9.1.944
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention Security Services Card	1.3.6.1.4.1.9.1.1039
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention Security Services Card	1.3.6.1.4.1.9.1.1010
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention Security Services Card	1.3.6.1.4.1.9.1.1085
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention Security Services Card	1.3.6.1.4.1.9.1.1086
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series Firewall Services Module	1.3.6.1.4.1.9.1.522
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series Firewall Services Module Security Context	1.3.6.1.4.1.9.1.674
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series Firewall Services Module System Context	1.3.6.1.4.1.9.1.767
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series Wireless LAN Services Module	1.3.6.1.4.1.9.1.599
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series Intrusion Detection System (IDS-2) Services Module	1.3.6.1.4.1.9.1.653
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series Intrusion Detection System (IDS-2) Services Module Virtual Sensor	1.3.6.1.4.1.9.1.815
			1.3.6.1.4.1.9.1.817

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module Virtual Sensor	
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module Virtual Sensor	1.3.6.1.4.1.9.1.816
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module Virtual Sensor	1.3.6.1.4.1.9.1.943
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ONS Radio Access Network (RAN) Service Module	1.3.6.1.4.1.9.1.772
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor	1.3.6.1.4.1.9.1.1232
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor	1.3.6.1.4.1.9.1.1233
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor	1.3.6.1.4.1.9.1.1234
Cisco Interfaces and Modules	Cisco Services Modules	Cisco ASA 5585 IPS Security Services Processor	1.3.6.1.4.1.9.1.1235
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series ASA Services Module	1.3.6.1.4.1.9.1.1277
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series ASA Services Module Security Context	1.3.6.1.4.1.9.1.1275
Cisco Interfaces and Modules	Cisco Services Modules	Cisco Catalyst 6500 Series ASA Services Module System Context	1.3.6.1.4.1.9.1.1276
Cisco Interfaces and Modules	Cisco Service Control Engines	Cisco SCE 2020 Service Control Engine	1.3.6.1.4.1.9.1.684
Cisco Interfaces and Modules	Cisco Service Control Engines	Cisco SCE 8000 Service Control Engine	1.3.6.1.4.1.9.1.913
Cisco Interfaces and Modules	Cisco Service Control Engines	Cisco SCE 1000 Series Service Control Engine	1.3.6.1.4.1.9.1.683
Cisco Interfaces and Modules	Network Analysis Modules	6380-NAM	1.3.6.1.4.1.9.5.1.3.1.1.2.223



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Interfaces and Modules	Network Analysis Modules	WS-SVC-NAM-1	1.3.6.1.4.1.9.5.1.3.1.1.2.914
Cisco Interfaces and Modules	Network Analysis Modules	WS-SVC-NAM-2	1.3.6.1.4.1.9.5.1.3.1.1.2.291
Cisco Interfaces and Modules	Network Analysis Modules	WS-SVC-NAM-3	1.3.6.1.4.1.9.1.1029
Cisco Interfaces and Modules	Network Analysis Modules	Cisco Catalyst 6500 Series Network Analysis Module (NAM-3)	1.3.6.1.4.1.9.12.3.1.9.29.175
Cisco Interfaces and Modules	Network Analysis Modules	Cisco Catalyst 6500 Series Network Analysis Module (NAM-3)	1.3.6.1.4.1.9.1.1529
Cisco Interfaces and Modules	Network Analysis Modules	Cisco Nexus 1000V NAM VSB	1.3.6.1.4.1.9.1.1214
Cisco Interfaces and Modules	Network Analysis Modules	Cisco WAAS NAM Virtual Blade	1.3.6.1.4.1.9.1.1169
Cisco Interfaces and Modules	Network Analysis Modules	Cisco 2600,3660,3700 Series NAM	1.3.6.1.4.1.9.1.562
Cisco Interfaces and Modules	Network Analysis Modules	Cisco Catalyst 4000 Series NAM	1.3.6.1.4.1.9.1.575
Cisco Interfaces and Modules	Network Analysis Modules	Cisco NAM 2204 Appliance	1.3.6.1.4.1.9.1.1032
Cisco Interfaces and Modules	Network Analysis Modules	Cisco NAM 2220 Appliance	1.3.6.1.4.1.9.1.1033
Cisco Interfaces and Modules	Network Analysis Modules	Cisco Prime NAM 2304 Appliance	1.3.6.1.4.1.9.1.1527
Cisco Interfaces and Modules	Network Analysis Modules	Cisco Prime NAM 2320 Appliance	1.3.6.1.4.1.9.1.1528
Cisco Interfaces and Modules	Network Analysis Modules	Cisco SM-SRE Network Analysis Module	1.3.6.1.4.1.9.1.1314
Cisco Interfaces and Modules	Netflow Generation Agent	Cisco Netflow Generation Agent (NGA) 3140	1.3.6.1.4.1.9.1.1539
Cisco Interfaces and Modules	NetScout Probes	NetScout Model 8221	1.3.6.1.4.1.141.1.1.8221

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cisco Interfaces and Modules	NetScout Probes	NetScout Model 8241ET	1.3.6.1.4.1.141.1.1.8241
Cisco Interfaces and Modules	NetScout Probes	NetScout Model 8243ET	1.3.6.1.4.1.141.1.1.8243
Cisco Interfaces and Modules	NetScout Probes	Netscout Model 8912ET	1.3.6.1.4.1.141.1.1.8912
DSL and Long Reach Ethernet (LRE)	DSL	Cisco 6200 Series IP DSL Switches	1.3.6.1.4.1.9.1.192
DSL and Long Reach Ethernet (LRE)	Cisco 600 Series Modems	Cisco 626 ADSL Modem	1.3.6.1.4.1.9.1.329
DSL and Long Reach Ethernet (LRE)	Cisco 600 Series Modems	Cisco 627 ADSL Modem	1.3.6.1.4.1.9.1.330
DSL and Long Reach Ethernet (LRE)	Cisco 600 Series Modems	Cisco 633 SDSL Digital Service Unit	1.3.6.1.4.1.9.1.331
DSL and Long Reach Ethernet (LRE)	Cisco Catalyst 2900 Series LRE XL Switches	Cisco Catalyst 2912 LRE XL Switch	1.3.6.1.4.1.9.1.370
DSL and Long Reach Ethernet (LRE)	Cisco Catalyst 2900 Series LRE XL Switches	Cisco Catalyst 2924 LRE XL Switch	1.3.6.1.4.1.9.1.369
DSL and Long Reach Ethernet (LRE)	Cisco Catalyst 2900 Series LRE XL Switches	Cisco Catalyst 2908 XL Switch	1.3.6.1.4.1.9.1.170
DSL and Long Reach Ethernet (LRE)	Cisco 6000 Series IP DSL Switches	Cisco 6015 IP DSL Switch	1.3.6.1.4.1.9.1.299
DSL and Long Reach Ethernet (LRE)	Cisco 6000 Series IP DSL Switches	Cisco 6130 IP DSL Switch	1.3.6.1.4.1.9.1.252
DSL and Long Reach Ethernet (LRE)	Cisco 6000 Series IP DSL Switches	Cisco 6160 IP DSL Switch	1.3.6.1.4.1.9.1.297

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

DSL and Long Reach Ethernet (LRE)	Cisco 6000 Series IP DSL Switches	Cisco 6260 IP DSL Switch	1.3.6.1.4.1.9.1.253
DSL and Long Reach Ethernet (LRE)	Cisco Catalyst 2950 LRE Series Switches	Cisco Catalyst 2950 8 LRE Switch	1.3.6.1.4.1.9.1.483
DSL and Long Reach Ethernet (LRE)	Cisco Catalyst 2950 LRE Series Switches	Cisco Catalyst 2950 24 LRE Switch	1.3.6.1.4.1.9.1.482
Optical Networking	Metro Core	Cisco Metro 1500 Series (MAN DWDM)	1.3.6.1.4.1.2544.1.3
Optical Networking	Metro Core	Cisco ONS 15454	1.3.6.1.4.1.3607.1.20.10.10
Optical Networking	Cisco ONS 15400 Series	Cisco ONS 15454 M6 Multiservice Transport Platform (MSTP)	1.3.6.1.4.1.3607.1.20.10.70
Optical Networking	Cisco ONS 15500 Series	Cisco ONS 15540 ESP Extended Services Platform	1.3.6.1.4.1.9.1.406
Optical Networking	Cisco ONS 15500 Series	Cisco ONS 15540 ESP Extended Services Platform	1.3.6.1.4.1.9.1.481
Optical Networking	Cisco ONS 15500 Series	Cisco ONS 15530 DWDM Multiservice Aggregation Platform	1.3.6.1.4.1.9.1.460
Optical Networking	Cisco ONS 15500 Series	Cisco ONS 15530 DWDM Multiservice Aggregation Platform	1.3.6.1.4.1.9.1.461
Optical Networking	Cisco ONS 15500 Series	Cisco ONS 15530 DWDM Multiservice Aggregation Platform	1.3.6.1.4.1.9.1.462
Optical Networking	Cisco ONS 15500 Series	Cisco ONS 15501-DC	1.3.6.1.4.1.1869.11.11.5.1
Optical Networking	Cisco ONS 15500 Series	Cisco ONS 15501-AC	1.3.6.1.4.1.1869.11.11.5.3
Optical Networking	Cisco ONS 15300 Series	Cisco ONS 15305 Multiservice Customer Access Platform	1.3.6.1.4.1.7546.1.4.1.1.3
Routers	Cisco 1800 Series Routers	Cisco 1841,1841VE Integrated Services Router	1.3.6.1.4.1.9.1.620
Routers	Cisco 1800 Series Routers	Cisco 1841,1841VE Integrated Services Router	1.3.6.1.4.1.9.1.1369
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.902

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.903
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.904
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.905
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.939
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.940
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.990
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.991
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.992
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.993
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.994
Routers	Cisco 1800 Series Routers	Cisco 1861,1861W Integrated Services Router	1.3.6.1.4.1.9.1.995
Routers	Cisco 1800 Series Routers	Cisco 1805,1805EJ Integrated Services Router	1.3.6.1.4.1.9.1.981
Routers	Cisco 1800 Series Routers	Cisco 1801,1801W,1801WM Integrated Services Router	1.3.6.1.4.1.9.1.638
Routers	Cisco 1800 Series Routers	Cisco 1801,1801W,1801WM Integrated Services Router	1.3.6.1.4.1.9.1.783
Routers	Cisco 1800 Series Routers	Cisco 1802 Integrated Services Router	1.3.6.1.4.1.9.1.639
Routers	Cisco 1800 Series Routers	Cisco 1803,1803W Integrated Services Router	1.3.6.1.4.1.9.1.640
Routers	Cisco 1800 Series Routers	Cisco 1811,1811W Integrated Services Router	1.3.6.1.4.1.9.1.641
Routers	Cisco 1800 Series Routers	Cisco 1812,1812W Integrated Services Router	1.3.6.1.4.1.9.1.642
Routers	Cisco 1800 Series Routers	Cisco 1861E Integrated Services Router	1.3.6.1.4.1.9.1.1339
Routers	Cisco 1800 Series Routers	Cisco 1861E Integrated Services Router	1.3.6.1.4.1.9.1.1340
Routers	Cisco 1800 Series Routers	Cisco 1861E Integrated Services Router	1.3.6.1.4.1.9.1.1341
Routers	Cisco 1800 Series Routers	Cisco 1861E Integrated Services Router	1.3.6.1.4.1.9.1.1342

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 1800 Series Routers	Cisco 1861E Integrated Services Router	1.3.6.1.4.1.9.1.1343
Routers	Cisco 1800 Series Routers	Cisco 1861E Integrated Services Router	1.3.6.1.4.1.9.1.1344
Routers	CSM Generic Router	Cisco Generic Integrated Services Router	1.0.0.0.0.0.0.1
Routers	CSM Generic Router	Cisco Generic Aggregation Services Router	1.0.0.0.0.0.0.2
Routers	Cisco 5900 Series Embedded Services Routers	Cisco 5915 Embedded Service Router	1.3.6.1.4.1.9.1.1355
Routers	Cisco 5900 Series Embedded Services Routers	Cisco 5915 Embedded Service Router	1.3.6.1.4.1.9.1.1356
Routers	Cisco 5900 Series Embedded Services Routers	Cisco 5940 Embedded Services Router	1.3.6.1.4.1.9.1.1163
Routers	Cisco 5900 Series Embedded Services Routers	Cisco 5940 Embedded Services Router	1.3.6.1.4.1.9.1.1164
Routers	Cisco 2800 Series Integrated Services Routers	Cisco 2801 Integrated Services Router	1.3.6.1.4.1.9.1.619
Routers	Cisco 2800 Series Integrated Services Routers	Cisco 2811VE Integrated Services Router	1.3.6.1.4.1.9.1.576
Routers	Cisco 2800 Series Integrated Services Routers	Cisco 2811VE Integrated Services Router	1.3.6.1.4.1.9.1.1370
Routers	Cisco 2800 Series Integrated Services Routers	Cisco 2821 Integrated Services Router	1.3.6.1.4.1.9.1.577
Routers	Cisco 2800 Series Integrated Services Routers	Cisco 2851 Integrated Services Router	1.3.6.1.4.1.9.1.578
Routers	Cisco 3800 Series Integrated Services Routers	Cisco 3825 Integrated Services Router	1.3.6.1.4.1.9.1.543
Routers	Cisco 3800 Series Integrated Services Routers	Cisco 3845 Integrated Services Router	1.3.6.1.4.1.9.1.544
Routers	Cisco 3800 Series Integrated Services Routers	Cisco 3825 NOVPN Integrated Services Router	1.3.6.1.4.1.9.1.1103
Routers	Cisco 3800 Series Integrated Services	Cisco 3845 NOVPN Integrated Services Router	1.3.6.1.4.1.9.1.1102

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Routers		
Routers	Cisco AGSPlus Routers	Cisco AGSPlus Router	1.3.6.1.4.1.9.1.11
Routers	Cisco 3000 Series Routers	Cisco 3000 Router	1.3.6.1.4.1.9.1.6
Routers	Cisco 3100 Series Routers	Cisco 3101 Router	1.3.6.1.4.1.9.1.32
Routers	Cisco 3100 Series Routers	Cisco 3102 Router	1.3.6.1.4.1.9.1.33
Routers	Cisco 3100 Series Routers	Cisco 3103 Router	1.3.6.1.4.1.9.1.34
Routers	Cisco 3100 Series Routers	Cisco 3104 Router	1.3.6.1.4.1.9.1.35
Routers	Cisco 7000 Series Routers	Cisco 7000 Router	1.3.6.1.4.1.9.1.8
Routers	Cisco 7000 Series Routers	Cisco 7010 Router	1.3.6.1.4.1.9.1.12
Routers	Cisco 6400 Series Broadband Aggregators	Cisco 6400 Broadband Aggregator	1.3.6.1.4.1.9.1.180
Routers	Cisco 6400 Series Broadband Aggregators	Cisco 6400 Broadband Aggregator	1.3.6.1.4.1.9.1.211
Routers	Cisco 6400 Series Broadband Aggregators	Cisco 6400 Broadband Aggregator	1.3.6.1.4.1.9.1.464
Routers	Cisco 1000 Series Routers	Cisco 1000 Router	1.3.6.1.4.1.9.1.40
Routers	Cisco 1000 Series Routers	Cisco 1003 Router	1.3.6.1.4.1.9.1.41
Routers	Cisco 1000 Series Routers	Cisco 1004 Router	1.3.6.1.4.1.9.1.44
Routers	Cisco 1000 Series Routers	Cisco 1005 Router	1.3.6.1.4.1.9.1.49
Routers	Cisco 1000 Series Routers	Cisco 1020 Router	1.3.6.1.4.1.9.1.43
Routers	Cisco 12000 Series Routers	Cisco 12004 Router	1.3.6.1.4.1.9.1.181
Routers	Cisco 12000 Series Routers	Cisco 12006 Router	1.3.6.1.4.1.9.1.590
Routers	Cisco 12000 Series Routers	Cisco 12008 Router	1.3.6.1.4.1.9.1.182
Routers	Cisco 12000 Series Routers	Cisco 12010 Router	1.3.6.1.4.1.9.1.348
Routers	Cisco 12000 Series Routers	Cisco 12012 Router	1.3.6.1.4.1.9.1.173

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 12000 Series Routers	Cisco 12016 Router	1.3.6.1.4.1.9.1.273
Routers	Cisco 12000 Series Routers	Cisco 12410 Router	1.3.6.1.4.1.9.1.394
Routers	Cisco 12000 Series Routers	Cisco 12416 Router	1.3.6.1.4.1.9.1.385
Routers	Cisco 12000 Series Routers	Cisco 12406 Router	1.3.6.1.4.1.9.1.388
Routers	Cisco 12000 Series Routers	Cisco 12404 Router	1.3.6.1.4.1.9.1.423
Routers	Cisco 12000 Series Routers	Cisco 12816 Router	1.3.6.1.4.1.9.1.477
Routers	Cisco 12000 Series Routers	Cisco 12810 Router	1.3.6.1.4.1.9.1.478
Routers	Cisco 1400 Series Routers	Cisco 1401 Router	1.3.6.1.4.1.9.1.206
Routers	Cisco 1400 Series Routers	Cisco 1417 Router	1.3.6.1.4.1.9.1.250
Routers	Cisco 1600 Series Routers	Cisco 1601 Router	1.3.6.1.4.1.9.1.113
Routers	Cisco 1600 Series Routers	Cisco 1602 Router	1.3.6.1.4.1.9.1.114
Routers	Cisco 1600 Series Routers	Cisco 1603 Router	1.3.6.1.4.1.9.1.115
Routers	Cisco 1600 Series Routers	Cisco 1604 Router	1.3.6.1.4.1.9.1.116
Routers	Cisco 1600 Series Routers	Cisco 1605 Router	1.3.6.1.4.1.9.1.172
Routers	Cisco 1700 Series Modular Access Routers	Cisco 1701 ADSL Security Access Router	1.3.6.1.4.1.9.1.550
Routers	Cisco 1700 Series Modular Access Routers	Cisco 1711 Security Access Router	1.3.6.1.4.1.9.1.538
Routers	Cisco 1700 Series Modular Access Routers	Cisco 1712 Security Access Router	1.3.6.1.4.1.9.1.539
Routers	Cisco 1700 Series Modular Access Routers	Cisco 1720 Modular Access Router	1.3.6.1.4.1.9.1.201
Routers	Cisco 1700 Series Modular Access Routers	Cisco 1750 Modular Access Router	1.3.6.1.4.1.9.1.216
Routers	Cisco 1700 Series Modular Access Routers	Cisco 1751 Modular Access Router	1.3.6.1.4.1.9.1.326

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 1700 Series Modular Access Routers	Cisco 1710 Security Access Router	1.3.6.1.4.1.9.1.200
Routers	Cisco 1700 Series Modular Access Routers	Cisco 1760 Modular Access Router	1.3.6.1.4.1.9.1.416
Routers	Cisco 1700 Series Modular Access Routers	Cisco 1721 Modular Access Router	1.3.6.1.4.1.9.1.444
Routers	Cisco 2500 Series Routers	Cisco 2500 Router	1.3.6.1.4.1.9.1.13
Routers	Cisco 2500 Series Routers	Cisco 2506 Router	1.3.6.1.4.1.9.1.22
Routers	Cisco 2500 Series Routers	Cisco 2508 Router	1.3.6.1.4.1.9.1.24
Routers	Cisco 2500 Series Routers	Cisco 2501 Router	1.3.6.1.4.1.9.1.17
Routers	Cisco 2500 Series Routers	Cisco 2501 Router	1.3.6.1.4.1.9.1.165
Routers	Cisco 2500 Series Routers	Cisco 2501 Router	1.3.6.1.4.1.9.1.166
Routers	Cisco 2500 Series Routers	Cisco 2502 Router	1.3.6.1.4.1.9.1.18
Routers	Cisco 2500 Series Routers	Cisco 2502 Router	1.3.6.1.4.1.9.1.167
Routers	Cisco 2500 Series Routers	Cisco 2503 Router	1.3.6.1.4.1.9.1.19
Routers	Cisco 2500 Series Routers	Cisco 2504 Router	1.3.6.1.4.1.9.1.20
Routers	Cisco 2500 Series Routers	Cisco 2505 Router	1.3.6.1.4.1.9.1.21
Routers	Cisco 2500 Series Routers	Cisco 2507 Router	1.3.6.1.4.1.9.1.23
Routers	Cisco 2500 Series Routers	Cisco 2513 Router	1.3.6.1.4.1.9.1.29
Routers	Cisco 2500 Series Routers	Cisco 2514 Router	1.3.6.1.4.1.9.1.30
Routers	Cisco 2500 Series Routers	Cisco 2515 Router	1.3.6.1.4.1.9.1.31
Routers	Cisco 2500 Series Routers	Cisco 2516 Router	1.3.6.1.4.1.9.1.42
Routers	Cisco 2500 Series Routers	Cisco 2520 Router	1.3.6.1.4.1.9.1.70
Routers	Cisco 2500 Series Routers	Cisco 2521 Router	1.3.6.1.4.1.9.1.71
Routers		Cisco 2522 Router	1.3.6.1.4.1.9.1.72



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Cisco 2500 Series Routers		
Routers	Cisco 2500 Series Routers	Cisco 2523 Router	1.3.6.1.4.1.9.1.73
Routers	Cisco 2500 Series Routers	Cisco 2524 Router	1.3.6.1.4.1.9.1.74
Routers	Cisco 2500 Series Routers	Cisco 2525 Router	1.3.6.1.4.1.9.1.75
Routers	Cisco 2500 Series Routers	Cisco 2517 Router	1.3.6.1.4.1.9.1.67
Routers	Cisco 2500 Series Routers	Cisco 2518 Router	1.3.6.1.4.1.9.1.68
Routers	Cisco 2500 Series Routers	Cisco 2519 Router	1.3.6.1.4.1.9.1.69
Routers	Cisco 2500 Series Routers	Cisco 2509 Router	1.3.6.1.4.1.9.1.25
Routers	Cisco 2500 Series Routers	Cisco 2511 Router	1.3.6.1.4.1.9.1.27
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2610 Multiservice Platform	1.3.6.1.4.1.9.1.185
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2610 Multiservice Platform	1.3.6.1.4.1.9.1.418
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2610 Multiservice Platform	1.3.6.1.4.1.9.1.466
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2611 Multiservice Platform	1.3.6.1.4.1.9.1.186
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2611 Multiservice Platform	1.3.6.1.4.1.9.1.419
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2611 Multiservice Platform	1.3.6.1.4.1.9.1.467
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2612 Multiservice Platform	1.3.6.1.4.1.9.1.187
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2613 Multiservice Platform	1.3.6.1.4.1.9.1.195
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2620 Multiservice Platform	1.3.6.1.4.1.9.1.208
Routers	Cisco 2600 Series Multiservice	Cisco 2620 Multiservice Platform	1.3.6.1.4.1.9.1.468

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Platforms		
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2621 Multiservice Platform	1.3.6.1.4.1.9.1.209
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2621 Multiservice Platform	1.3.6.1.4.1.9.1.469
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2650 Multiservice Platform	1.3.6.1.4.1.9.1.319
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2650 Multiservice Platform	1.3.6.1.4.1.9.1.470
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2651 Multiservice Platform	1.3.6.1.4.1.9.1.320
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2651 Multiservice Platform	1.3.6.1.4.1.9.1.471
Routers	Cisco 2600 Series Multiservice Platforms	Cisco 2691 Multiservice Platform	1.3.6.1.4.1.9.1.413
Routers	Cisco MWR 2900 Series Mobile Wireless Routers	Cisco MWR 2941-DC Mobile Wireless Router	1.3.6.1.4.1.9.1.1014
Routers	Cisco MWR 2900 Series Mobile Wireless Routers	Cisco MWR 2941-DC Mobile Wireless Router	1.3.6.1.4.1.9.1.1215
Routers	Cisco 3200 Series Mobile Access Routers	Cisco 3251 Mobile Access Router Card	1.3.6.1.4.1.9.1.479
Routers	Cisco 3200 Series Mobile Access Routers	Cisco 3220 Mobile Access Router	1.3.6.1.4.1.9.1.553
Routers	Cisco 3200 Series Mobile Access Routers	Cisco 3201 Wireless Mobile Interface card	1.3.6.1.4.1.9.1.581
Routers	Cisco 3200 Series Mobile Access Routers	Cisco 3270 Rugged Router	1.3.6.1.4.1.9.1.689
Routers	Cisco 3200 Series Mobile Access Routers	Cisco 3270 Rugged Router	1.3.6.1.4.1.9.1.690
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3620 Multiservice Platform	1.3.6.1.4.1.9.1.122
Routers	Cisco 3600 Series	Cisco 3620 Multiservice	1.3.6.1.4.1.9.1.123

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Multiservice Platforms	Platform	
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3640 Multiservice Platform	1.3.6.1.4.1.9.1.110
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3640 Multiservice Platform	1.3.6.1.4.1.9.1.189
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3660 Multiservice Platform	1.3.6.1.4.1.9.1.205
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3661 Multiservice Platform	1.3.6.1.4.1.9.1.338
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3661 Multiservice Platform	1.3.6.1.4.1.9.1.339
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3662 Telco Versatile DCN Access Platform	1.3.6.1.4.1.9.1.340
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3662 Telco Versatile DCN Access Platform	1.3.6.1.4.1.9.1.341
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3662 Telco Versatile DCN Access Platform	1.3.6.1.4.1.9.1.342
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3662 Telco Versatile DCN Access Platform	1.3.6.1.4.1.9.1.343
Routers	Cisco 3600 Series Multiservice Platforms	Cisco 3631 Central Office Access Router	1.3.6.1.4.1.9.1.425
Routers	Cisco 600 Series DSL Customer Premises Equipment Routers	Cisco 673 SDSL DSL Router	1.3.6.1.4.1.9.1.332
Routers	Cisco 600 Series DSL Customer Premises Equipment Routers	Cisco 675 ADSL Router	1.3.6.1.4.1.9.1.333
Routers	Cisco 600 Series DSL Customer Premises Equipment Routers	Cisco 675 ADSL Router	1.3.6.1.4.1.9.1.334
Routers	Cisco 600 Series DSL Customer Premises Equipment Routers	Cisco 676 ADSL Router	1.3.6.1.4.1.9.1.335

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 600 Series DSL Customer Premises Equipment Routers	Cisco 677 ADSL Router	1.3.6.1.4.1.9.1.336
Routers	Cisco 600 Series DSL Customer Premises Equipment Routers	Cisco 677 ADSL Router	1.3.6.1.4.1.9.1.363
Routers	Cisco 600 Series DSL Customer Premises Equipment Routers	Cisco 678 ADSL Router	1.3.6.1.4.1.9.1.337
Routers	Cisco 700 Series ISDN Access Routers	Cisco 761 ISDN Access Router	1.3.6.1.4.1.9.1.98
Routers	Cisco 700 Series ISDN Access Routers	Cisco 762 ISDN Access Router	1.3.6.1.4.1.9.1.99
Routers	Cisco 700 Series ISDN Access Routers	Cisco 772 ISDN Access Router	1.3.6.1.4.1.9.1.127
Routers	Cisco 700 Series ISDN Access Routers	Cisco 775 ISDN Access Router	1.3.6.1.4.1.9.1.128
Routers	Cisco 700 Series ISDN Access Routers	Cisco 776 ISDN Access Router	1.3.6.1.4.1.9.1.129
Routers	Cisco 700 Series ISDN Access Routers	Cisco 751 ISDN Access Router	1.3.6.1.4.1.9.1.81
Routers	Cisco 700 Series ISDN Access Routers	Cisco 752 ISDN Access Router	1.3.6.1.4.1.9.1.82
Routers	Cisco 700 Series ISDN Access Routers	Cisco 753 ISDN Access Router	1.3.6.1.4.1.9.1.83
Routers	Cisco 700 Series ISDN Access Routers	Cisco 765 ISDN Access Router	1.3.6.1.4.1.9.1.102
Routers	Cisco 700 Series ISDN Access Routers	Cisco 766 ISDN Access Router	1.3.6.1.4.1.9.1.103
Routers	Cisco 700 Series ISDN Access Routers	Cisco 771 ISDN Access Router	1.3.6.1.4.1.9.1.126
Routers	Cisco 7200 Series Routers	Cisco 7202 Router	1.3.6.1.4.1.9.1.194
Routers		Cisco 7204 Router	1.3.6.1.4.1.9.1.125

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Cisco 7200 Series Routers		
Routers	Cisco 7200 Series Routers	Cisco 7204VXR Router	1.3.6.1.4.1.9.1.223
Routers	Cisco 7200 Series Routers	Cisco 7206 Router	1.3.6.1.4.1.9.1.108
Routers	Cisco 7200 Series Routers	Cisco 7206VXR Router	1.3.6.1.4.1.9.1.222
Routers	Cisco 7200 Series Routers	Cisco 7201 Router	1.3.6.1.4.1.9.1.821
Routers	Cisco 7500 Series Routers	Cisco 7505 Router	1.3.6.1.4.1.9.1.48
Routers	Cisco 7500 Series Routers	Cisco 7506 Router	1.3.6.1.4.1.9.1.47
Routers	Cisco 7500 Series Routers	Cisco 7507 Router	1.3.6.1.4.1.9.1.45
Routers	Cisco 7500 Series Routers	Cisco 7507 Router	1.3.6.1.4.1.9.1.288
Routers	Cisco 7500 Series Routers	Cisco 7507 Router	1.3.6.1.4.1.9.1.290
Routers	Cisco 7500 Series Routers	Cisco 7513 Router	1.3.6.1.4.1.9.1.46
Routers	Cisco 7500 Series Routers	Cisco 7513 Router	1.3.6.1.4.1.9.1.289
Routers	Cisco 7500 Series Routers	Cisco 7513 Router	1.3.6.1.4.1.9.1.291
Routers	Cisco 7500 Series Routers	Cisco 7576 Router	1.3.6.1.4.1.9.1.204
Routers	Cisco 7600 Series Routers	Cisco 7609 Router	1.3.6.1.4.1.9.1.509
Routers	Cisco 7600 Series Routers	Cisco 7609 Router	1.3.6.1.4.1.9.5.55
Routers	Cisco 7600 Series Routers	Cisco 7603 Router	1.3.6.1.4.1.9.1.401
Routers	Cisco 7600 Series Routers	Cisco 7603 Router	1.3.6.1.4.1.9.5.53
Routers	Cisco 7600 Series Routers	Cisco 7603 Router	1.3.6.1.4.1.9.1.862
Routers	Cisco 7600 Series Routers	Cisco 7604 Router	1.3.6.1.4.1.9.1.658
Routers	Cisco 7600 Series Routers	Cisco 7606 Router	1.3.6.1.4.1.9.1.402
Routers	Cisco 7600 Series Routers	Cisco 7606 Router	1.3.6.1.4.1.9.5.54
Routers	Cisco 7600 Series Routers	Cisco 7613 Router	1.3.6.1.4.1.9.5.60

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 7600 Series Routers	Cisco 7613 Router	1.3.6.1.4.1.9.1.528
Routers	Cisco 7600 Series Routers	Cisco 7609S Router	1.3.6.1.4.1.9.1.864
Routers	Cisco 7600 Series Routers	Cisco 7606-S Router	1.3.6.1.4.1.9.1.863
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1384
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1385
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1386
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1387
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1388
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1389
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1378
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1379
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1380
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1381
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1382
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1383
Routers	Cisco 800 Series Routers	Cisco 887VA-W Integrated Services Router	1.3.6.1.4.1.9.1.1375
Routers	Cisco 800 Series Routers	Cisco 887VA-W Integrated Services Router	1.3.6.1.4.1.9.1.1376
Routers	Cisco 800 Series Routers	Cisco 887VA-W Integrated Services Router	1.3.6.1.4.1.9.1.1377
Routers	Cisco 800 Series Routers	Cisco 886VA-W Integrated Services Router	1.3.6.1.4.1.9.1.1374
Routers	Cisco 800 Series Routers	Cisco 866VAE Integrated Services Router	1.3.6.1.4.1.9.1.1359
Routers	Cisco 800 Series Routers	Cisco 866VAE Integrated Services Router	1.3.6.1.4.1.9.1.1360
Routers	Cisco 800 Series Routers	Cisco 866VAE Integrated Services Router	1.3.6.1.4.1.9.1.1361
Routers	Cisco 800 Series Routers	Cisco 867VAE Integrated Services Router	1.3.6.1.4.1.9.1.1358

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 800 Series Routers	Cisco 802 ISDN Router	1.3.6.1.4.1.9.1.213
Routers	Cisco 800 Series Routers	Cisco 802 ISDN Router	1.3.6.1.4.1.9.1.295
Routers	Cisco 800 Series Routers	Cisco 851,851W Integrated Services Router	1.3.6.1.4.1.9.1.566
Routers	Cisco 800 Series Routers	Cisco 857,857W Integrated Services Router	1.3.6.1.4.1.9.1.567
Routers	Cisco 800 Series Routers	Cisco 871,871W Integrated Services Router	1.3.6.1.4.1.9.1.571
Routers	Cisco 800 Series Routers	Cisco 878,878W Integrated Services Router	1.3.6.1.4.1.9.1.570
Routers	Cisco 800 Series Routers	Cisco 876,876W Integrated Services Router	1.3.6.1.4.1.9.1.568
Routers	Cisco 800 Series Routers	Cisco 877,877W Integrated Services Router	1.3.6.1.4.1.9.1.569
Routers	Cisco 800 Series Routers	Cisco 877,877W Integrated Services Router	1.3.6.1.4.1.9.1.782
Routers	Cisco 800 Series Routers	Cisco 803 ISDN Router	1.3.6.1.4.1.9.1.214
Routers	Cisco 800 Series Routers	Cisco 804 ISDN Router	1.3.6.1.4.1.9.1.215
Routers	Cisco 800 Series Routers	Cisco 804 ISDN Router	1.3.6.1.4.1.9.1.296
Routers	Cisco 800 Series Routers	Cisco 805 Serial Router	1.3.6.1.4.1.9.1.245
Routers	Cisco 800 Series Routers	Cisco 826 ADSL Router	1.3.6.1.4.1.9.1.321
Routers	Cisco 800 Series Routers	Cisco 826 ADSL Router	1.3.6.1.4.1.9.1.322
Routers	Cisco 800 Series Routers	Cisco 827 ADSL Router	1.3.6.1.4.1.9.1.284
Routers	Cisco 800 Series Routers	Cisco 827-4V ADSL Router	1.3.6.1.4.1.9.1.270
Routers	Cisco 800 Series Routers	Cisco 806 Broadband Router	1.3.6.1.4.1.9.1.384
Routers	Cisco 800 Series Routers	Cisco 828 G.SHDSL Router	1.3.6.1.4.1.9.1.382
Routers	Cisco 800 Series Routers	Cisco 827 H ADSL Router	1.3.6.1.4.1.9.1.446
Routers	Cisco 800 Series Routers	Cisco 801 ISDN Router	1.3.6.1.4.1.9.1.212
Routers	Cisco 800 Series Routers	Cisco 811 ISDN Router	1.3.6.1.4.1.9.1.395
Routers	Cisco 800 Series Routers	Cisco 813 ISDN Router	1.3.6.1.4.1.9.1.396

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 800 Series Routers	Cisco 831 Ethernet Broadband Router	1.3.6.1.4.1.9.1.497
Routers	Cisco 800 Series Routers	Cisco 836 ADSL over ISDN Broadband Router	1.3.6.1.4.1.9.1.499
Routers	Cisco 800 Series Routers	Cisco 837 ADSL Broadband Router	1.3.6.1.4.1.9.1.495
Routers	Cisco 800 Series Routers	Cisco 861,861W Integrated Services Router G2	1.3.6.1.4.1.9.1.834
Routers	Cisco 800 Series Routers	Cisco 877 Integrated Services Router	1.3.6.1.4.1.9.1.782
Routers	Cisco 800 Series Routers	Cisco 815 Integrated Services Router	1.3.6.1.4.1.9.1.733
Routers	Cisco 800 Series Routers	Cisco 881,881W Integrated Services Router G2	1.3.6.1.4.1.9.1.837
Routers	Cisco 800 Series Routers	Cisco 881,881W Integrated Services Router G2	1.3.6.1.4.1.9.1.838
Routers	Cisco 800 Series Routers	Cisco 881,881W Integrated Services Router G2	1.3.6.1.4.1.9.1.1371
Routers	Cisco 800 Series Routers	Cisco 881,881W Integrated Services Router G2	1.3.6.1.4.1.9.1.1372
Routers	Cisco 800 Series Routers	Cisco 881,881W Integrated Services Router G2	1.3.6.1.4.1.9.1.1373
Routers	Cisco 800 Series Routers	Cisco 881,881W Integrated Services Router G2	1.3.6.1.4.1.9.1.1600
Routers	Cisco 800 Series Routers	Cisco 881SRST,881SRSTW Integrated Services Router G2	1.3.6.1.4.1.9.1.840
Routers	Cisco 800 Series Routers	Cisco 886,886W Integrated Services Router G2	1.3.6.1.4.1.9.1.842
Routers	Cisco 800 Series Routers	Cisco 886,886W Integrated Services Router G2	1.3.6.1.4.1.9.1.843
Routers	Cisco 800 Series Routers	Cisco 886SRST,886SRSTW Integrated Services Router G2	1.3.6.1.4.1.9.1.846
Routers	Cisco 800 Series Routers	Cisco 887,887W Integrated Services	1.3.6.1.4.1.9.1.847



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

		Routers G2	
Routers	Cisco 800 Series Routers	Cisco 887,887W Integrated Services Routers G2	1.3.6.1.4.1.9.1.848
Routers	Cisco 800 Series Routers	Cisco 887,887W Integrated Services Routers G2	1.3.6.1.4.1.9.1.1105
Routers	Cisco 800 Series Routers	Cisco 887V Integrated Services Router G2	1.3.6.1.4.1.9.1.1040
Routers	Cisco 800 Series Routers	Cisco 887V Integrated Services Router G2	1.3.6.1.4.1.9.1.1138
Routers	Cisco 800 Series Routers	Cisco 887V Integrated Services Router G2	1.3.6.1.4.1.9.1.1139
Routers	Cisco 800 Series Routers	Cisco 888,888W,888GW Integrated Services Router G2	1.3.6.1.4.1.9.1.852
Routers	Cisco 800 Series Routers	Cisco 888,888W,888GW Integrated Services Router G2	1.3.6.1.4.1.9.1.853
Routers	Cisco 800 Series Routers	Cisco 888ESRST,888ESRSTW Integrated Services Router G2	1.3.6.1.4.1.9.1.1100
Routers	Cisco 800 Series Routers	Cisco 888E,888EW Integrated Services Router G2	1.3.6.1.4.1.9.1.1096
Routers	Cisco 800 Series Routers	Cisco 888E,888EW Integrated Services Router G2	1.3.6.1.4.1.9.1.1097
Routers	Cisco 800 Series Routers	Cisco 888E,888EW Integrated Services Router G2	1.3.6.1.4.1.9.1.1098
Routers	Cisco 800 Series Routers	Cisco 888E,888EW Integrated Services Router G2	1.3.6.1.4.1.9.1.1394
Routers	Cisco 800 Series Routers	Cisco 888E,888EW Integrated Services Router G2	1.3.6.1.4.1.9.1.1099
Routers	Cisco 800 Series Routers	Cisco 888EA Integrated Services Router G2	1.3.6.1.4.1.9.1.1542
Routers	Cisco 800 Series Routers	Cisco 888SRST,888SRSTW Integrated Services Router G2	1.3.6.1.4.1.9.1.851
Routers	Cisco 800 Series Routers	Cisco 888SRST,888SRSTW Integrated Services Router	1.3.6.1.4.1.9.1.856

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

		G2	
Routers	Cisco 800 Series Routers	Cisco 866 Integrated Services Router	1.3.6.1.4.1.9.1.835
Routers	Cisco 800 Series Routers	Cisco 867,867W Integrated Services Router G2	1.3.6.1.4.1.9.1.836
Routers	Cisco 800 Series Routers	Cisco 891,891W Integrated Services Router G2	1.3.6.1.4.1.9.1.857
Routers	Cisco 800 Series Routers	Cisco 892,892W Integrated Services Router G2	1.3.6.1.4.1.9.1.858
Routers	Cisco 800 Series Routers	Cisco 892F,892FW Integrated Services Router	1.3.6.1.4.1.9.1.1249
Routers	Cisco 800 Series Routers	Cisco 885 Integrated Services Router	1.3.6.1.4.1.9.1.859
Routers	Cisco 800 Series Routers	Cisco 885 Integrated Services Router	1.3.6.1.4.1.9.1.861
Routers	Cisco 800 Series Routers	Cisco 887VA M Integrated Services Router G2	1.3.6.1.4.1.9.1.1271
Routers	Cisco 800 Series Routers	Cisco 886VA,886VAG Integrated Services Router G2	1.3.6.1.4.1.9.1.1273
Routers	Cisco 800 Series Routers	Cisco 886VA,886VAG Integrated Services Router G2	1.3.6.1.4.1.9.1.1390
Routers	Cisco 800 Series Routers	Cisco 881W,881WD Integrated Services Router	1.3.6.1.4.1.9.1.1566
Routers	Cisco 800 Series Routers	Cisco 881W,881WD Integrated Services Router	1.3.6.1.4.1.9.1.1567
Routers	Cisco 800 Series Routers	Cisco C896VA Integrated Services Router	1.3.6.1.4.1.9.1.1627
Routers	Cisco 800 Series Routers	Cisco C897VA Integrated Services Router	1.3.6.1.4.1.9.1.1622
Routers	Cisco 800 Series Routers	Cisco C897VA Integrated Services Router	1.3.6.1.4.1.9.1.1623
Routers	Cisco 800 Series Routers	Cisco C897VAW Integrated Services Router	1.3.6.1.4.1.9.1.1624
Routers	Cisco 800 Series Routers	Cisco C897VAW Integrated Services Router	1.3.6.1.4.1.9.1.1625
Routers	Cisco 800 Series Routers	Cisco C897VAW Integrated Services Router	1.3.6.1.4.1.9.1.1626
Routers	Cisco 800 Series Routers	Cisco C898EA Integrated Services Router	1.3.6.1.4.1.9.1.1621
Routers			1.3.6.1.4.1.9.1.1274

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Cisco 800 Series Routers	Cisco 887VA Integrated Services Router G2	
Routers	Cisco 800 Series Routers	Cisco 887VA Integrated Services Router G2	1.3.6.1.4.1.9.1.1391
Routers	Cisco 800 Series Routers	Cisco 887VA Integrated Services Router G2	1.3.6.1.4.1.9.1.1392
Routers	Cisco 800 Series Routers	Cisco 887VA Integrated Services Router G2	1.3.6.1.4.1.9.1.1393
Routers	Cisco 800 Series Routers	Cisco 887VA Integrated Services Router G2	1.3.6.1.4.1.9.1.1601
Routers	Cisco 800 Series Routers	Cisco 887VA Integrated Services Router G2	1.3.6.1.4.1.9.1.1602
Routers	Cisco 800 Series Routers	Cisco Catalyst 6500 Series ASA Services Module Security Context	1.3.6.1.4.1.9.1.1275
Routers	Cisco 800 Series Routers	Cisco 880 3G Integrated Services Router G2	1.3.6.1.4.1.9.1.1299
Routers	Cisco 800 Series Routers	Cisco 880 3G Integrated Services Router G2	1.3.6.1.4.1.9.1.1395
Routers	Cisco 800 Series Routers	Cisco 880 3G Integrated Services Router G2	1.3.6.1.4.1.9.1.1396
Routers	Cisco 800 Series Routers	Cisco 880 3G Integrated Services Router G2	1.3.6.1.4.1.9.1.1397
Routers	Cisco 800 Series Routers	Cisco 880 3G Integrated Services Router G2	1.3.6.1.4.1.9.1.1398
Routers	Cisco 800 Series Routers	Cisco 880 3G Integrated Services Router G2	1.3.6.1.4.1.9.1.1399
Routers	Cisco 800 Series Routers	Cisco 880 3G Integrated Services Router G2	1.3.6.1.4.1.9.1.1400
Routers	Cisco 800 Series Routers	Cisco 887VA-W Integrated Services Router G2	1.3.6.1.4.1.9.1.1375
Routers	Cisco 800 Series Routers	Cisco 887VA-W Integrated Services Router G2	1.3.6.1.4.1.9.1.1376
Routers	Cisco 800 Series Routers	Cisco 887VA-W Integrated Services Router G2	1.3.6.1.4.1.9.1.1377
Routers	Cisco 800 Series Routers	Cisco 886VA-W Integrated Services Router G2	1.3.6.1.4.1.9.1.1374
Routers	Cisco 800 Series Routers	Cisco 867VAE Integrated Services Router	1.3.6.1.4.1.9.1.1358
Routers	Cisco 800 Series Routers	Cisco 867VAE Integrated Services Router	1.3.6.1.4.1.9.1.1360
Routers			1.3.6.1.4.1.9.1.1272

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Cisco 800 Series Routers	Cisco 867VAE Integrated Services Router	
Routers	Cisco 800 Series Routers	Cisco 866VAE Integrated Services Router	1.3.6.1.4.1.9.1.1359
Routers	Cisco 800 Series Routers	Cisco 866VAE Integrated Services Router	1.3.6.1.4.1.9.1.1361
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1378
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1379
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1380
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1381
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1382
Routers	Cisco 800 Series Routers	Cisco 819 Non-Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1383
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1384
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1385
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1386
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1387
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1388
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1389
Routers	Cisco 800 Series Routers	Cisco 819 Hardened Integrated Services Router	1.3.6.1.4.1.9.1.1575
Routers	Cisco 800 Series Routers	Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services Router	1.3.6.1.4.1.9.1.1570
Routers	Cisco 800 Series Routers	Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services Router	1.3.6.1.4.1.9.1.1571
Routers	Cisco 800 Series Routers	Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services Router	1.3.6.1.4.1.9.1.1572
Routers	Cisco 800 Series Routers	Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services	1.3.6.1.4.1.9.1.1573

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

		Router	
Routers	Cisco 800 Series Routers	Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services Router	1.3.6.1.4.1.9.1.1574
Routers	Cisco 800 Series Routers	Cisco C892FSP Integrated Services Router	1.3.6.1.4.1.9.1.1620
Routers	Cisco 800 Series Routers	Cisco 812 3G Integrated Services Router	1.3.6.1.4.1.9.1.1578
Routers	Cisco 800 Series Routers	Cisco 812 CiFi Integrated Services Router	1.3.6.1.4.1.9.1.1579
Routers	Cisco 800 Series Routers	Cisco 812 CiFi Integrated Services Router	1.3.6.1.4.1.9.1.1580
Routers	Cisco 800 Series Routers	Cisco 812 CiFi Integrated Services Router	1.3.6.1.4.1.9.1.1581
Routers	Cisco 800 Series Routers	Cisco 812 CiFi Integrated Services Router	1.3.6.1.4.1.9.1.1582
Routers	Cisco Small Business 100 Series Routers	Cisco Small Business 101 Series Routers	1.3.6.1.4.1.9.1.627
Routers	Cisco Small Business 100 Series Routers	Cisco Small Business 106 Series Routers	1.3.6.1.4.1.9.1.628
Routers	Cisco Small Business 100 Series Routers	Cisco Small Business 107 Series Routers	1.3.6.1.4.1.9.1.629
Routers	Cisco 10000 Series Routers	Cisco 10008 Router	1.3.6.1.4.1.9.1.438
Routers	Cisco 10000 Series Routers	Cisco 10005 Router	1.3.6.1.4.1.9.1.437
Routers	Cisco MC3810 Multiservice Access Concentrators	Cisco MC3810-V Access Concentrator	1.3.6.1.4.1.9.1.157
Routers	Cisco MC3810 Multiservice Access Concentrators	Cisco MC3810-V3 Access Concentrator	1.3.6.1.4.1.9.1.286
Routers	Cisco SOHO 70 Series Routers	Cisco SOHO 77 ADSL Router	1.3.6.1.4.1.9.1.353
Routers	Cisco SOHO 70 Series Routers	Cisco SOHO 76 ADSL Router	1.3.6.1.4.1.9.1.354
Routers	Cisco SOHO 70 Series Routers	Cisco SOHO 71 Broadband Router	1.3.6.1.4.1.9.1.463
Routers	Cisco SOHO 70 Series Routers	Cisco SOHO 77 H ADSL Router	1.3.6.1.4.1.9.1.447
Routers	Cisco SOHO 70 Series Routers	Cisco SOHO 78 G.SHDSL Router	1.3.6.1.4.1.9.1.383

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco SOHO 90 Series Secure Broadband Routers	Cisco SOHO 91 Ethernet Broadband Router	1.3.6.1.4.1.9.1.498
Routers	Cisco SOHO 90 Series Secure Broadband Routers	Cisco SOHO 96 ADSL over ISDN Secure Broadband Routers	1.3.6.1.4.1.9.1.500
Routers	Cisco SOHO 90 Series Secure Broadband Routers	Cisco SOHO 97 ADSL Broadband Router	1.3.6.1.4.1.9.1.496
Routers	Cisco 7400 Series Routers	Cisco 7401 Application Specific Router	1.3.6.1.4.1.9.1.403
Routers	Cisco 7300 Series Routers	Cisco 7304 Router	1.3.6.1.4.1.9.1.439
Routers	Cisco 7300 Series Routers	Cisco 7301 Router	1.3.6.1.4.1.9.1.476
Routers	Cisco 10700 Series Routers	Cisco 10720 Router	1.3.6.1.4.1.9.1.397
Routers	Cisco 3700 Series Multiservice Access Routers	Cisco 3725 Multiservice Access Router	1.3.6.1.4.1.9.1.414
Routers	Cisco 3700 Series Multiservice Access Routers	Cisco 3745 Multiservice Access Router	1.3.6.1.4.1.9.1.436
Routers	Cisco MWR 1900 Mobile Wireless Routers	Cisco 1900 Mobile Wireless Edge Router	1.3.6.1.4.1.9.1.398
Routers	Cisco MWR 1900 Mobile Wireless Routers	Cisco MWR 1941-DC Mobile Wireless Edge Router	1.3.6.1.4.1.9.1.520
Routers	Cisco MWR 1900 Mobile Wireless Routers	Cisco MWR 1941-DC-A Mobile Wireless Edge Router	1.3.6.1.4.1.9.1.732
Routers	Cisco Carrier Routing System	Cisco CRS-1 16-Slot Single-Shelf System	1.3.6.1.4.1.9.1.613
Routers	Cisco Carrier Routing System	Cisco CRS-1 8-Slot Single-Shelf System	1.3.6.1.4.1.9.1.643
Routers	Cisco Carrier Routing System	Cisco CRS-1 4-Slot Single-Shelf System	1.3.6.1.4.1.9.1.822
Routers	Cisco 5700 Series Routers	Cisco 5720 Integrated Encryption Router	1.3.6.1.4.1.9.1.820
Routers	Cisco 5700 Series Routers	Cisco 5740 Integrated Encryption Router	1.3.6.1.4.1.9.1.833
Routers	Cisco 5700 Series Routers	Cisco 5750 Integrated Encryption Router	1.3.6.1.4.1.9.1.731
Routers	Other Routers	Cisco GatewayServer	1.3.6.1.4.1.9.1.1
Routers	Other Routers	Cisco Trouter	1.3.6.1.4.1.9.1.3

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Other Routers	Cisco ProtocolTranslator	1.3.6.1.4.1.9.1.4
Routers	Other Routers	Cisco IGS-L, IGS-R	1.3.6.1.4.1.9.1.5
Routers	Other Routers	Cisco Router 2000	1.3.6.1.4.1.9.1.10
Routers	Other Routers	Cisco Router 2102	1.3.6.1.4.1.9.1.15
Routers	Other Routers	Cisco Router 2202	1.3.6.1.4.1.9.1.16
Routers	Other Routers	Cisco 3200 Series 3202	1.3.6.1.4.1.9.1.36
Routers	Other Routers	Cisco 3200 Series 3204	1.3.6.1.4.1.9.1.37
Routers	Other Routers	Cisco 4500 Series 4500	1.3.6.1.4.1.9.1.14
Routers	Other Routers	Cisco AccessProRC	1.3.6.1.4.1.9.1.38
Routers	Other Routers	Cisco AccessProEC	1.3.6.1.4.1.9.1.39
Routers	Other Routers	Cisco ODS FDDI Network Controller	1.3.6.1.4.1.50.7
Routers	Other Routers	Cisco 10000 Series C10400	1.3.6.1.4.1.9.1.272
Routers	Other Routers	Cisco Optical Regenerator	1.3.6.1.4.1.9.1.254
Routers	Other Routers	Cisco MWAM	1.3.6.1.4.1.9.12.3.1.9.17.39
Routers	Other Routers	Cisco MWAM	1.3.6.1.4.1.9.1.621
Routers	Cisco ASR 901 Series Aggregation Services Routers	Cisco ASR 901-12C-F-D Router	1.3.6.1.4.1.9.1.1521
Routers	Cisco ASR 901 Series Aggregation Services Routers	Cisco ASR 901-12C-FT-D Router	1.3.6.1.4.1.9.1.1522
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 9001 Router	1.3.6.1.4.1.9.1.1639
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 9010 Router	1.3.6.1.4.1.9.1.1017
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 9006 Router	1.3.6.1.4.1.9.1.1018
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 1002 Router	1.3.6.1.4.1.9.1.923
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 1001 Router	1.3.6.1.4.1.9.1.1165
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 1004 Router	1.3.6.1.4.1.9.1.924
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 1006 Router	1.3.6.1.4.1.9.1.925
Routers			1.3.6.1.4.1.9.1.1116

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 1002 Fixed Router	
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 1002-X Router	1.3.6.1.4.1.9.1.1525
Routers	Cisco ASR 1000 Series Aggregation Services Routers	Cisco ASR 1013 Router	1.3.6.1.4.1.9.1.1166
Routers	Cisco ASR 9000 Series Aggregation Services Routers	Cisco ASR 9010 Router	1.3.6.1.4.1.9.1.1017
Routers	Cisco ASR 9000 Series Aggregation Services Routers	Cisco ASR 9006 Router	1.3.6.1.4.1.9.1.1018
Routers	Cisco ASR 9000 Series Aggregation Services Routers	Cisco ASR 9001 Router	1.3.6.1.4.1.9.1.1639
Routers	Cisco ASR 903 Series Aggregation Services Routers	Cisco ASR 903 Router	1.3.6.1.4.1.9.1.1441
Routers	Cisco ASR 901 Series Aggregation Services Routers	Cisco ASR 901-12C-F-D Router	1.3.6.1.4.1.9.1.1521
Routers	Cisco ASR 901 Series Aggregation Services Routers	Cisco ASR 901-12C-FT-D Router	1.3.6.1.4.1.9.1.1522
Routers	Cisco 1900 Series Integrated Services Routers	Cisco 1941 Integrated Services Router G2	1.3.6.1.4.1.9.1.1047
Routers	Cisco 1900 Series Integrated Services Routers	Cisco 1941W Integrated Services Router G2	1.3.6.1.4.1.9.1.1095
Routers	Cisco 1900 Series Integrated Services Routers	Cisco 1941W Integrated Services Router G2	1.3.6.1.4.1.9.1.1172
Routers	Cisco 1900 Series Integrated Services Routers	Cisco 1941W Integrated Services Router G2	1.3.6.1.4.1.9.1.1173
Routers	Cisco 1900 Series Integrated Services Routers	Cisco 1941W Integrated Services Router G2	1.3.6.1.4.1.9.1.1174
Routers	Cisco 1900 Series Integrated Services Routers	Cisco 1941W Integrated Services Router G2	1.3.6.1.4.1.9.1.1220
Routers	Cisco 1900 Series Integrated Services Routers	Cisco 1905 Serial Integrated Services Router G2	1.3.6.1.4.1.9.1.1192



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Routers	Cisco 1900 Series Integrated Services Routers	Cisco 1921 Integrated Services Router G2	1.3.6.1.4.1.9.1.1191
Routers	Cisco 2900 Series Integrated Services Routers G2	Cisco 2951 Integrated Services Router G2	1.3.6.1.4.1.9.1.1043
Routers	Cisco 2900 Series Integrated Services Routers G2	Cisco 2911 Integrated Services Router G2	1.3.6.1.4.1.9.1.1045
Routers	Cisco 2900 Series Integrated Services Routers G2	Cisco 2921 Integrated Services Router G2	1.3.6.1.4.1.9.1.1044
Routers	Cisco 2900 Series Integrated Services Routers G2	Cisco 2901 Integrated Services Router G2	1.3.6.1.4.1.9.1.1046
Routers	Cisco 2000 Series Connected Grid Routers	Cisco 2010 Connected Grid Router	1.3.6.1.4.1.9.1.1253
Routers	Cisco 2000 Series Connected Grid Routers	Cisco 2010 Connected Grid Router	1.3.6.1.4.1.9.1.1526
Routers	Cisco 3900 Series Integrated Services Routers G2	Cisco 3945 Integrated Services Router G2	1.3.6.1.4.1.9.1.1041
Routers	Cisco 3900 Series Integrated Services Routers G2	Cisco 3925 Integrated Services Router G2	1.3.6.1.4.1.9.1.1042
Routers	Cisco 3900 Series Integrated Services Routers G2	Cisco 3945E Integrated Services Router G2	1.3.6.1.4.1.9.1.1145
Routers	Cisco 3900 Series Integrated Services Routers G2	Cisco 3925E Integrated Services Router G2	1.3.6.1.4.1.9.1.1144
Routers	Cisco 1000 Voice Series Routers	CSR1000V	1.3.6.1.4.1.9.1.1537
Routers	Cisco 4400 Series Integrated Services Routers	Cisco 4451 Series Integrated Services Router	1.3.6.1.4.1.9.1.1707
Routers	Cisco 4400 Series Integrated Services Routers	Cisco 4452 Series Integrated Services Router	1.3.6.1.4.1.9.1.1708
Switches and Hubs	Cisco Catalyst 2100 Series Switches	Cisco Catalyst 2100 Switch	1.3.6.1.4.1.437.1.1.3.3.2
Switches and Hubs	Cisco Catalyst 2360 Series Switches	Cisco Catalyst 2360-48TD-S	1.3.6.1.4.1.9.1.1292
Switches and Hubs	Cisco Catalyst 4500-X Series	Cisco Catalyst 4500X-16 SFP+ Switch	1.3.6.1.4.1.9.1.1605

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Switches		
Switches and Hubs	Cisco Catalyst 4500-X Series Switches	Cisco Catalyst 4500X-32 SFP+ Switch	1.3.6.1.4.1.9.1.1606
Switches and Hubs	Cisco Catalyst 2928 Series Switches	Cisco Catalyst 2928-24TC-C Switch	1.3.6.1.4.1.9.1.1328
Switches and Hubs	Cisco Catalyst 2928 Series Switches	Cisco Catalyst C2928-24LT-C Switch	1.3.6.1.4.1.9.1.1330
Switches and Hubs	Cisco Catalyst 2928 Series Switches	Cisco Catalyst C2928-48TC-C Switch	1.3.6.1.4.1.9.1.1329
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SG300-28P 28-Port Gigabit PoE Managed Switch	1.3.6.1.4.1.9.6.1.83.28.2
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SF300-08 8-Port 10/100 Managed Switch	1.3.6.1.4.1.9.6.1.82.8.4
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SF302-08 8-Port 10/100 Managed Switch with Gigabit Uplinks	1.3.6.1.4.1.9.6.1.82.8.1
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SF302-08MP 8-Port 10/100 Max PoE Managed Switch with Gigabit Uplinks	1.3.6.1.4.1.9.6.1.82.8.3
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SF302-08P 8-Port 10/100 PoE Managed Switch with Gigabit Uplinks	1.3.6.1.4.1.9.6.1.82.8.2
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SF300-24 24-Port 10/100 Managed Switch with Gigabit Uplinks	1.3.6.1.4.1.9.6.1.82.24.1
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SF300-24P 24-Port 10/100 PoE Managed Switch with Gigabit Uplinks	1.3.6.1.4.1.9.6.1.82.24.2
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SF300-48 48-Port 10/100 Managed Switch with Gigabit Uplinks	1.3.6.1.4.1.9.6.1.82.48.1
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SF300-48P 48-Port 10/100 PoE Managed Switch with Gigabit Uplinks	1.3.6.1.4.1.9.6.1.82.48.2
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SG300-10 10-Port Gigabit Managed Switch	1.3.6.1.4.1.9.6.1.83.10.1
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SG300-10MP 10-Port Gigabit Max-PoE Managed Switch	1.3.6.1.4.1.9.6.1.83.10.3

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SG300-10P 10-Port Gigabit PoE Managed Switch	1.3.6.1.4.1.9.6.1.83.10.2
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SG300-20 20-Port Gigabit Managed Switch	1.3.6.1.4.1.9.6.1.83.20.1
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SG300-28 28-Port Gigabit Managed Switch	1.3.6.1.4.1.9.6.1.83.28.1
Switches and Hubs	Cisco Small Business 300 Series Managed Switches	Cisco SG300-52 52-Port Gigabit Managed Switch	1.3.6.1.4.1.9.6.1.83.52.1
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SF500-24 24-Port 10/100 Stackable Managed Switch	1.3.6.1.4.1.9.6.1.80.24.1
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SF500-24 24-Port 10/100 POE Stackable Managed Switch	1.3.6.1.4.1.9.6.1.80.24.2
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SF500-48 48-Port 10/100 Stackable Managed Switch	1.3.6.1.4.1.9.6.1.80.48.1
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SF500-48P 48P-Port 10/100 POE Stackable Managed Switch	1.3.6.1.4.1.9.6.1.80.48.2
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SG500-28 28-port Gigabit Stackable Managed Switch	1.3.6.1.4.1.9.6.1.81.28.1
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SG500-28P 28-port Gigabit POE Stackable Managed Switch	1.3.6.1.4.1.9.6.1.81.28.2
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SG500-52 52-port Gigabit Stackable Managed Switch	1.3.6.1.4.1.9.6.1.81.52.1
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SG500-52P 52-port Gigabit POE Stackable Managed Switch	1.3.6.1.4.1.9.6.1.81.52.2
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SG500X-24 24-Port Gigabit with 4-Port 10-Gigabit Stackable Managed Switch	1.3.6.1.4.1.9.6.1.85.24.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SG500X-24P 24-Port Gigabit POE with 4-Port 10-Gigabit Stackable Managed Switch	1.3.6.1.4.1.9.6.1.85.24.2
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SG500X-48 48-Port Gigabit with 4-Port 10-Gigabit Stackable Managed Switch	1.3.6.1.4.1.9.6.1.85.48.1
Switches and Hubs	Cisco Small Business 500 Series Stackable Managed Switches	Cisco SG500X-48P 48-Port Gigabit POE with 4-Port 10-Gigabit Stackable Managed Switch	1.3.6.1.4.1.9.6.1.85.48.2
Switches and Hubs	Cisco 2500 Series Connected Grid Switches	Cisco CGS-2520-24TC Connected Grid Switch	1.3.6.1.4.1.9.1.1245
Switches and Hubs	Cisco 2500 Series Connected Grid Switches	Cisco CGS-2520-16S-8PC Connected Grid Switch	1.3.6.1.4.1.9.1.1246
Switches and Hubs	Cisco ME 3600X Series Ethernet Access Switches	Cisco ME 3600X-24FS-M Switch	1.3.6.1.4.1.9.1.1250
Switches and Hubs	Cisco ME 3600X Series Ethernet Access Switches	Cisco ME 3600X-24TS-M Switch	1.3.6.1.4.1.9.1.1251
Switches and Hubs	Cisco Catalyst 2100 Series Switches	Cisco Catalyst 2100 Switch	1.3.6.1.4.1.437.1.1.3.3.2
Switches and Hubs	Cisco 1220 Etherswitch Series	Cisco 1220 Etherswitch	1.3.6.1.4.1.9.5.19
Switches and Hubs	Cisco Catalyst 1200 Series Switches	1200	1.3.6.1.4.1.9.5.5
Switches and Hubs	Cisco Catalyst 1200 Series Switches	1220	1.3.6.1.4.1.9.5.27
Switches and Hubs	Cisco Workgroup Concentrators	Cisco WS-C1100 CDDI,FDDI Workgroup Concentrator	1.3.6.1.4.1.9.5.4
Switches and Hubs	Cisco Workgroup Concentrators	Cisco WS-C1100 CDDI,FDDI Workgroup Concentrator	1.3.6.1.4.1.9.5.1
Switches and Hubs	Cisco Workgroup Concentrators	Cisco WS-C1400 Workgroup Concentrator	1.3.6.1.4.1.9.5.6
Switches and Hubs	Cisco Workgroup Concentrators	Cisco 1000 Workgroup Concentrator	1.3.6.1.4.1.9.5.3
Switches and Hubs	Cisco Lightstream ATM Switches	Cisco LightStream 1010 ATM Switches	1.3.6.1.4.1.9.5.11
Switches and Hubs	Cisco Lightstream	Cisco LightStream 1010	1.3.6.1.4.1.9.1.107

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Hubs	ATM Switches	ATM Switches	
Switches and Hubs	Cisco Lightstream ATM Switches	Cisco LightStream 1015 ATM Switches	1.3.6.1.4.1.9.1.164
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560-24PS Switch	1.3.6.1.4.1.9.1.563
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560-48PS Switch	1.3.6.1.4.1.9.1.564
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560G-24PS Switch	1.3.6.1.4.1.9.1.614
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560G-24TS Switch	1.3.6.1.4.1.9.1.615
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560-24TS Switch	1.3.6.1.4.1.9.1.633
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560G-48PS Switch	1.3.6.1.4.1.9.1.616
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560G-48TS Switch	1.3.6.1.4.1.9.1.617
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560-48TS Switch	1.3.6.1.4.1.9.1.634
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst C3560-8PC-S Switch	1.3.6.1.4.1.9.1.1466
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst C3560-12PC-S Switch	1.3.6.1.4.1.9.1.1465
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560-8PC Compact Switch	1.3.6.1.4.1.9.1.797
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560-12PC-S Compact Switch	1.3.6.1.4.1.9.1.1015
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560V2-24DC Switch	1.3.6.1.4.1.9.1.1019
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560V2-24TS Switch	1.3.6.1.4.1.9.1.1020
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560V2-24PS Switch	1.3.6.1.4.1.9.1.1021
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560V2-48TS Switch	1.3.6.1.4.1.9.1.1024
Switches and Hubs	Cisco Catalyst 3560 Series Switches	Cisco Catalyst 3560V2-48PS Switch	1.3.6.1.4.1.9.1.1025
Switches and Hubs	Cisco Catalyst 3560-C Series Switches	Cisco Catalyst 3560CG-8PC-S Compact Switch	1.3.6.1.4.1.9.1.1317
Switches and Hubs	Cisco Catalyst 3560-C Series Switches	Cisco Catalyst 3560CG-8TC-S Compact Switch	1.3.6.1.4.1.9.1.1318
Switches and Hubs	Cisco Catalyst 3560-C Series	Cisco Catalyst 3560CPD-8PT-S Compact	1.3.6.1.4.1.9.1.1368

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Switches	Switch	
Switches and Hubs	Cisco Catalyst 3560-C Series Switches	Cisco Catalyst 3560C-12PC-S Switch	1.3.6.1.4.1.9.1.1465
Switches and Hubs	Cisco Catalyst 2960-C Series Switches	Cisco Catalyst 2960CPD-8TT-L Switch	1.3.6.1.4.1.9.1.952
Switches and Hubs	Cisco Catalyst 2960-C Series Switches	Cisco Catalyst 2960CPD-8TT-L Switch	1.3.6.1.4.1.9.1.1278
Switches and Hubs	Cisco Catalyst 2960-C Series Switches	Cisco Catalyst 2960CPD-8PT-L Switch	1.3.6.1.4.1.9.1.1315
Switches and Hubs	Cisco Catalyst 2960-C Series Switches	Cisco Catalyst 2960CG-8TC-L Compact Switch	1.3.6.1.4.1.9.1.1316
Switches and Hubs	Cisco Catalyst 2960-C Series Switches	Cisco Catalyst 2960C-8PC-L Switch	1.3.6.1.4.1.9.1.1366
Switches and Hubs	Cisco Catalyst 2960-C Series Switches	Cisco Catalyst 2960C-12PC-L Switch	1.3.6.1.4.1.9.1.1367
Switches and Hubs	Cisco Catalyst 2960-C Series Switches	Cisco Catalyst 2960C-8TC-L Switch	1.3.6.1.4.1.9.1.1365
Switches and Hubs	Cisco Catalyst 2960-C Series Switches	Cisco Catalyst 2960C-8TC-S Switch	1.3.6.1.4.1.9.1.1364
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco SM-ES3-16-P	1.3.6.1.4.1.9.1.1049
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module	1.3.6.1.4.1.9.1.1057
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco SM-ES3-24-P	1.3.6.1.4.1.9.1.1053
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco SM-ES3G-16-P	1.3.6.1.4.1.9.1.1050
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco SM-ES3G-24-P	1.3.6.1.4.1.9.1.1054
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco Catalyst 3560E-24TD-E,S Switch	1.3.6.1.4.1.9.1.793

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco Catalyst 3560E-48TD-E,S Switch	1.3.6.1.4.1.9.1.794
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco Catalyst 3560E-24PD-E,S Switch	1.3.6.1.4.1.9.1.795
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco Catalyst 3560E-48PD-E,S Switch	1.3.6.1.4.1.9.1.796
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco Catalyst 3560E-12D-S,E Switch	1.3.6.1.4.1.9.1.930
Switches and Hubs	Cisco Catalyst 3560-E Series Switches	Cisco Catalyst 3560E-12SD-E,S Switch	1.3.6.1.4.1.9.1.956
Switches and Hubs	Cisco Catalyst 3560-X Series Switches	Cisco Catalyst 3560X-24T-L,S Switch	1.3.6.1.4.1.9.1.1226
Switches and Hubs	Cisco Catalyst 3560-X Series Switches	Cisco Catalyst 3560X-48T-L,S Switch	1.3.6.1.4.1.9.1.1227
Switches and Hubs	Cisco Catalyst 3560-X Series Switches	Cisco Catalyst 3560X-24P-L,S Switch	1.3.6.1.4.1.9.1.1228
Switches and Hubs	Cisco Catalyst 3560-X Series Switches	Cisco Catalyst 3560X-48PF-L,S Switch	1.3.6.1.4.1.9.1.1229
Switches and Hubs	Cisco Catalyst 3750 Metro Series Switches	Cisco Catalyst 3750 Metro 24-DC Switch	1.3.6.1.4.1.9.1.574
Switches and Hubs	Cisco Catalyst 3750-E Series Switches	Cisco Catalyst 3750E-24TD-E,S Switch	1.3.6.1.4.1.9.1.789
Switches and Hubs	Cisco Catalyst 3750-E Series Switches	Cisco Catalyst 3750E-48TD-E,S Switch	1.3.6.1.4.1.9.1.790
Switches and Hubs	Cisco Catalyst 3750-E Series Switches	Cisco Catalyst 3750E-48PD-E,S Switch	1.3.6.1.4.1.9.1.791
Switches and Hubs	Cisco Catalyst 3750-E Series Switches	Cisco Catalyst 3750E-24PD-E,S Switch	1.3.6.1.4.1.9.1.792
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco 3750 Stackable Switches	1.3.6.1.4.1.9.1.516
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-24PS Switch	1.3.6.1.4.1.9.1.602
Switches and Hubs	Cisco Catalyst 3750	Cisco Catalyst	1.3.6.1.4.1.9.1.603

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Hubs	Series Switches	3750G-48PS Switch	
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-24TS-1U Switch	1.3.6.1.4.1.9.1.624
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750-24FS Switch	1.3.6.1.4.1.9.1.656
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750-24PS Switch	1.3.6.1.4.1.9.1.536
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750-24TS Switch	1.3.6.1.4.1.9.1.513
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750-48PS Switch	1.3.6.1.4.1.9.1.535
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-16TD Switch	1.3.6.1.4.1.9.1.591
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-48TS Switch	1.3.6.1.4.1.9.1.604
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-12S-SD Switch	1.3.6.1.4.1.9.1.688
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-12S Switch	1.3.6.1.4.1.9.1.530
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-24WS Switch	1.3.6.1.4.1.9.1.778
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-24WS Switch	1.3.6.1.4.1.9.1.779
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-24 Switch	1.3.6.1.4.1.9.1.511
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-48 Switch	1.3.6.1.4.1.9.1.512
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750G-24T Switch	1.3.6.1.4.1.9.1.514
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750V2-24TS Switch	1.3.6.1.4.1.9.1.1022
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750V2-24PS Switch	1.3.6.1.4.1.9.1.1023
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750V2-48TS Switch	1.3.6.1.4.1.9.1.1026
Switches and Hubs	Cisco Catalyst 3750 Series Switches	Cisco Catalyst 3750V2-48PS Switch	1.3.6.1.4.1.9.1.1027
Switches and Hubs	Cisco Catalyst 3750-X Series Switches	Cisco Catalyst 3750X-24T-L,S Switch	1.3.6.1.4.1.9.1.1222
Switches and Hubs	Cisco Catalyst 3750-X Series Switches	Cisco Catalyst 3750X-48T-L,S Switch	1.3.6.1.4.1.9.1.1223
Switches and Hubs	Cisco Catalyst 3750-X Series Switches	Cisco Catalyst 3750X-24P-L,S Switch	1.3.6.1.4.1.9.1.1224



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 3750-X Series Switches	Cisco Catalyst 3750X-48PF-L,S Switch	1.3.6.1.4.1.9.1.1225
Switches and Hubs	Cisco Catalyst 3750-X Series Switches	Cisco Catalyst 3750X-24S-S Switch	1.3.6.1.4.1.9.1.1404
Switches and Hubs	Cisco Catalyst 3750-X Series Switches	Cisco Catalyst 3750X-12S-S Switch	1.3.6.1.4.1.9.1.1405
Switches and Hubs	Cisco 2500 Series Connected Grid Switches	Cisco CGS-2520-24TC Connected Grid Switch	1.3.6.1.4.1.9.1.1245
Switches and Hubs	Cisco 2500 Series Connected Grid Switches	Cisco CGS-2520-16S-8PC Connected Grid Switch	1.3.6.1.4.1.9.1.1246
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Switch Module 3012 for IBM BladeCenter	1.3.6.1.4.1.9.1.999
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Switch Module 3012 for IBM BladeCenter	1.3.6.1.4.1.9.1.1000
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3020 for HP	1.3.6.1.4.1.9.1.748
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3030 for Dell	1.3.6.1.4.1.9.1.749
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3032 for Dell M1000E	1.3.6.1.4.1.9.1.920
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3040 for FSC	1.3.6.1.4.1.9.1.784
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Stack of CBS3100 switch modules	1.3.6.1.4.1.9.1.946
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Switch Module 3110G for IBM BladeCenter	1.3.6.1.4.1.9.1.909
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Switch Module 3110G for IBM BladeCenter	1.3.6.1.4.1.9.1.910
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Switch Module 3110X for IBM BladeCenter	1.3.6.1.4.1.9.1.947
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Switch Module 3110X for IBM BladeCenter	1.3.6.1.4.1.9.1.911

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Switch Module 3110X for IBM BladeCenter	1.3.6.1.4.1.9.1.912
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3120X for HP	1.3.6.1.4.1.9.1.948
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3120X for HP	1.3.6.1.4.1.9.1.919
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3120G for HP	1.3.6.1.4.1.9.1.918
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3125G for HP	1.3.6.1.4.1.9.1.1001
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3125X for HP	1.3.6.1.4.1.9.1.1002
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3130X for Dell M1000E	1.3.6.1.4.1.9.1.949
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3130X for Dell M1000E	1.3.6.1.4.1.9.1.922
Switches and Hubs	Cisco Catalyst Blade Switch 3000 Series	Cisco Catalyst Blade Switch 3130G for Dell M1000E	1.3.6.1.4.1.9.1.921
Switches and Hubs	Cisco 1500 Series Micro Hubs	MicroHub 1503	1.3.6.1.4.1.9.1.160
Switches and Hubs	Cisco 1500 Series Micro Hubs	MicroHub 1502	1.3.6.1.4.1.9.1.161
Switches and Hubs	Cisco 1538 Series Micro Hubs	Cisco 1538M Micro Hub	1.3.6.1.4.1.9.1.224
Switches and Hubs	Cisco Catalyst 1600 Series Switches	Cisco Catalyst 1600 Switch	1.3.6.1.4.1.9.5.8
Switches and Hubs	Cisco Catalyst 1600 Series Switches	Cisco Catalyst 1600 Switch	1.3.6.1.4.1.9.5.9
Switches and Hubs	Cisco Catalyst 1900 Series Switches	Cisco Catalyst 1912 C A Switch	1.3.6.1.4.1.9.1.175
Switches and Hubs	Cisco Catalyst 1900 Series Switches	Cisco Catalyst 1924 A Switch	1.3.6.1.4.1.9.5.18
Switches and Hubs	Cisco Catalyst 1900 Series Switches	Cisco Catalyst 1924 A Switch	1.3.6.1.4.1.9.5.16
Switches and Hubs	Cisco Catalyst 1900 Series Switches	Cisco Catalyst 1900 C	1.3.6.1.4.1.9.5.28
Switches and Hubs	Cisco Catalyst 1900 Series Switches	Cisco Catalyst 1900 L	1.3.6.1.4.1.9.5.31

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 2800 Series Switches	Cisco Catalyst 2800 Switch	1.3.6.1.4.1.437.1.1.3.3.3
Switches and Hubs	Cisco Catalyst 2800 Series Switches	Cisco Catalyst 2820 Modular Ethernet Switch	1.3.6.1.4.1.9.5.20
Switches and Hubs	Cisco Catalyst 2900 Series Switches	Cisco Catalyst 2948G-GE-TX Switch	1.3.6.1.4.1.9.5.62
Switches and Hubs	Cisco Catalyst 2900 Series Switches	Cisco Catalyst 2926 Switch	1.3.6.1.4.1.9.5.35
Switches and Hubs	Cisco Catalyst 2900 Series Switches	Cisco Catalyst 2948G-L2 Switch	1.3.6.1.4.1.9.5.42
Switches and Hubs	Cisco Catalyst 2900 Series Switches	Cisco Catalyst 2980G-A Switch	1.3.6.1.4.1.9.5.51
Switches and Hubs	Cisco Catalyst 2900 Series Switches	Cisco Catalyst 2980G-A Switch	1.3.6.1.4.1.9.5.49
Switches and Hubs	Cisco Catalyst 2900 Series XL Switches	Cisco Catalyst 2912 XL Switch	1.3.6.1.4.1.9.1.219
Switches and Hubs	Cisco Catalyst 2900 Series XL Switches	Cisco Catalyst 2924C XL Switch	1.3.6.1.4.1.9.1.184
Switches and Hubs	Cisco Catalyst 2900 Series XL Switches	Cisco Catalyst 2924C XL Switch	1.3.6.1.4.1.9.1.218
Switches and Hubs	Cisco Catalyst 2900 Series XL Switches	Cisco Catalyst 2924 XL Switch	1.3.6.1.4.1.9.1.183
Switches and Hubs	Cisco Catalyst 2900 Series XL Switches	Cisco Catalyst 2924 XL Switch	1.3.6.1.4.1.9.1.217
Switches and Hubs	Cisco Catalyst 2900 Series XL Switches	Cisco Catalyst 2924M XL Switch	1.3.6.1.4.1.9.1.220
Switches and Hubs	Cisco Catalyst 2900 Series XL Switches	Cisco Catalyst 2912MF XL Switch	1.3.6.1.4.1.9.1.221
Switches and Hubs	Cisco Catalyst 2900 Series XL Switches	Cisco Catalyst 2916M XL Switch	1.3.6.1.4.1.9.1.171
Switches and Hubs	Cisco Catalyst 2918 Series Switches	Cisco Catalyst 2918-24TT-C Switch	1.3.6.1.4.1.9.1.965
Switches and Hubs	Cisco Catalyst 2918 Series Switches	Cisco Catalyst 2918-24TC-C Switch	1.3.6.1.4.1.9.1.966
Switches and Hubs	Cisco Catalyst 2918 Series Switches	Cisco Catalyst 2918-48TT-C Switch	1.3.6.1.4.1.9.1.967
Switches and Hubs	Cisco Catalyst 2918 Series Switches	Cisco Catalyst 2918-48TC-C Switch	1.3.6.1.4.1.9.1.968
Switches and Hubs	Cisco Catalyst 2928 Series Switches	Cisco Catalyst 2928-24TC-C Switch	1.3.6.1.4.1.9.1.1328
Switches and Hubs	Cisco Catalyst 2928 Series Switches	Cisco Catalyst C2928-24LT-C Switch	1.3.6.1.4.1.9.1.1330
Switches and Hubs	Cisco Catalyst 2928 Series Switches	Cisco Catalyst C2928-48TC-C Switch	1.3.6.1.4.1.9.1.1329
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48FPD-L Switch	1.3.6.1.4.1.9.1.1258

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48LPD-L Switch	1.3.6.1.4.1.9.1.1259
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48TD-L Switch	1.3.6.1.4.1.9.1.1260
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-24PS-L Switch	1.3.6.1.4.1.9.1.1265
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-K9-M Switch	1.3.6.1.4.1.9.1.1208
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-24TS-L Switch	1.3.6.1.4.1.9.1.1267
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48TS-S Switch	1.3.6.1.4.1.9.1.1256
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-24TC Switch	1.3.6.1.4.1.9.1.694
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-24TT Switch	1.3.6.1.4.1.9.1.716
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-48TC Switch	1.3.6.1.4.1.9.1.695
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-48TT Switch	1.3.6.1.4.1.9.1.717
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960G-24TC Switch	1.3.6.1.4.1.9.1.696
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960G-48TC Switch	1.3.6.1.4.1.9.1.697
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-8TC Compact Switch	1.3.6.1.4.1.9.1.798
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960G-8TC Compact Switch	1.3.6.1.4.1.9.1.799
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-24-S Switch	1.3.6.1.4.1.9.1.929
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-24TC-S Switch	1.3.6.1.4.1.9.1.928
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-48TC-S Switch	1.3.6.1.4.1.9.1.927
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-24PC-L Switch	1.3.6.1.4.1.9.1.950
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-24LT-L Switch	1.3.6.1.4.1.9.1.951
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960PD-8TT-L Compact Switch	1.3.6.1.4.1.9.1.952
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-8TC-S Compact Switch	1.3.6.1.4.1.9.1.1006
			1.3.6.1.4.1.9.1.1005

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-48TT-S Switch	
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-48PST-L Switch	1.3.6.1.4.1.9.1.1016
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-24LC-S Switch	1.3.6.1.4.1.9.1.1146
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-24PC-S Switch	1.3.6.1.4.1.9.1.1147
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960-48PST-S Switch	1.3.6.1.4.1.9.1.1148
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48TD-L Switch	1.3.6.1.4.1.9.1.1260
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S	1.3.6.1.4.1.9.1.1208
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-24TD-L Switch	1.3.6.1.4.1.9.1.1262
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48FPD-L Switch	1.3.6.1.4.1.9.1.1258
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48LPD-L Switch	1.3.6.1.4.1.9.1.1259
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-24PD-L Switch	1.3.6.1.4.1.9.1.1261
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48TS-L Switch	1.3.6.1.4.1.9.1.1266
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-24TS-L Switch	1.3.6.1.4.1.9.1.1267
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48TS-S Switch	1.3.6.1.4.1.9.1.1256
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-24TS-S Switch	1.3.6.1.4.1.9.1.1257
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48FPS-L Switch	1.3.6.1.4.1.9.1.1263
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-48LPS-L Switch	1.3.6.1.4.1.9.1.1264
Switches and Hubs	Cisco Catalyst 2960 Series Switches	Cisco Catalyst 2960S-24PS-L Switch	1.3.6.1.4.1.9.1.1265
Switches and Hubs	Cisco Catalyst 3000 Series Switches	Cisco Catalyst 3000 Switch	1.3.6.1.4.1.9.5.10
Switches and Hubs	Cisco Catalyst 3000 Series Switches	Cisco Catalyst 3100 Switch	1.3.6.1.4.1.9.5.23
Switches and Hubs	Cisco Catalyst 3000 Series Switches	Cisco Catalyst 3200 Switch	1.3.6.1.4.1.9.5.15
Switches and Hubs	Cisco Catalyst 3550 Series Switches	Cisco Catalyst 3550 12T Switch	1.3.6.1.4.1.9.1.368
Switches and Hubs	Cisco Catalyst 3550 Series Switches	Cisco Catalyst 3550 12G Switch	1.3.6.1.4.1.9.1.431

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 3550 Series Switches	Cisco Catalyst 3550 24 Switch	1.3.6.1.4.1.9.1.366
Switches and Hubs	Cisco Catalyst 3550 Series Switches	Cisco Catalyst 3550 24 DC SMI Switch	1.3.6.1.4.1.9.1.452
Switches and Hubs	Cisco Catalyst 3550 Series Switches	Cisco Catalyst 3550 48 Switch	1.3.6.1.4.1.9.1.367
Switches and Hubs	Cisco Catalyst 3550 Series Switches	Cisco Catalyst 3550 24 FX SMI Switch	1.3.6.1.4.1.9.1.453
Switches and Hubs	Cisco Catalyst 3550 Series Switches	Cisco Catalyst 3550 24 PWR Switch	1.3.6.1.4.1.9.1.485
Switches and Hubs	Cisco Catalyst 3500 Series XL Switches	Cisco Catalyst 3508G XL Switch	1.3.6.1.4.1.9.1.246
Switches and Hubs	Cisco Catalyst 3500 Series XL Switches	Cisco Catalyst 3512 XL Switch	1.3.6.1.4.1.9.1.247
Switches and Hubs	Cisco Catalyst 3500 Series XL Switches	Cisco Catalyst 3524 XL Switch	1.3.6.1.4.1.9.1.248
Switches and Hubs	Cisco Catalyst 3500 Series XL Switches	Cisco Catalyst 3524 PWR XL Switch	1.3.6.1.4.1.9.1.287
Switches and Hubs	Cisco Catalyst 3500 Series XL Switches	Cisco Catalyst 3548 XL Switch	1.3.6.1.4.1.9.1.278
Switches and Hubs	Cisco Catalyst 3900 Series Switches	Cisco Catalyst 3900 Switch	1.3.6.1.4.1.9.5.33
Switches and Hubs	Cisco Catalyst 3900 Series Switches	Cisco Catalyst 3920 Switch	1.3.6.1.4.1.9.5.37
Switches and Hubs	Cisco Catalyst 4000 Series Switches	Cisco Catalyst 4604 Access Gateway	1.3.6.1.4.1.9.1.318
Switches and Hubs	Cisco Catalyst 4000 Series Switches	Cisco Catalyst 4003 Switch	1.3.6.1.4.1.9.5.40
Switches and Hubs	Cisco Catalyst 4000 Series Switches	Cisco Catalyst 4006 Switch	1.3.6.1.4.1.9.5.46
Switches and Hubs	Cisco Catalyst 4000 Series Switches	Cisco Catalyst 4006 Switch	1.3.6.1.4.1.9.1.448
Switches and Hubs	Cisco Catalyst 4000 Series Switches	Cisco Catalyst 4006 Switch	1.3.6.1.4.1.9.1.300
Switches and Hubs	Cisco Catalyst 4000 Series Switches	Cisco Catalyst 4912G Switch	1.3.6.1.4.1.9.5.41
Switches and Hubs	Cisco Catalyst 4000 Series Switches	Cisco Catalyst 4000 Switch	1.3.6.1.4.1.9.1.7
Switches and Hubs	Cisco Catalyst G-L3 Series Switches	Cisco Catalyst C2948G-L3 Ethernet Switch	1.3.6.1.4.1.9.1.275
Switches and Hubs	Cisco Catalyst G-L3 Series Switches	Cisco Catalyst C2948G-L3 Ethernet Switch	1.3.6.1.4.1.9.1.386
Switches and Hubs	Cisco Catalyst G-L3 Series	Cisco Catalyst 4908G-L3 Switch	1.3.6.1.4.1.9.1.298

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Switches		
Switches and Hubs	Cisco Catalyst G-L3 Series Switches	Cisco Catalyst 4908G-L3 Switch	1.3.6.1.4.1.9.1.387
Switches and Hubs	Cisco Catalyst G-L3 Series Switches	Cisco Catalyst 4840G Switch	1.3.6.1.4.1.9.1.312
Switches and Hubs	Cisco Catalyst G-L3 Series Switches	Cisco IE-3010-24TC Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1320
Switches and Hubs	Cisco IE 3000 Series Switches	Cisco IE 3000-4TC Industrial Ethernet Switch	1.3.6.1.4.1.9.1.958
Switches and Hubs	Cisco IE 3000 Series Switches	Cisco IE 3000-8TC Industrial Ethernet Switch	1.3.6.1.4.1.9.1.959
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-4TS Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1468
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-4T Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1469
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-4TS-G Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1470
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-4T-G Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1471
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-8TC Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1472
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-8TC-G Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1473
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-16TC Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1474
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-16TC-G Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1475
Switches and Hubs	Cisco IE 2000 Series Switches	Cisco IE 2000-16TC-G-X Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1520
Switches and Hubs	Cisco Catalyst 5000 Series Switches	Cisco Catalyst 5000 Switch	1.3.6.1.4.1.9.5.7
Switches and Hubs	Cisco Catalyst 5000 Series Switches	Cisco Catalyst 5002 Switch	1.3.6.1.4.1.9.5.29
Switches and Hubs	Cisco Catalyst 5500 Series Switches	Cisco Catalyst 5500 Switch	1.3.6.1.4.1.9.5.17
Switches and Hubs	Cisco Catalyst 5500 Series Switches	Cisco Catalyst 5505 Switch	1.3.6.1.4.1.9.5.34
Switches and Hubs	Cisco Catalyst 5500 Series Switches	Cisco Catalyst 5509 Switch	1.3.6.1.4.1.9.5.36
Switches and Hubs	Cisco Catalyst 6000 Series Switches	Cisco Catalyst 6006 Switch	1.3.6.1.4.1.9.1.280
Switches and Hubs	Cisco Catalyst 6000 Series Switches	Cisco Catalyst 6006 Switch	1.3.6.1.4.1.9.5.38

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 6000 Series Switches	Cisco Catalyst 6009 Switch	1.3.6.1.4.1.9.1.281
Switches and Hubs	Cisco Catalyst 6000 Series Switches	Cisco Catalyst 6009 Switch	1.3.6.1.4.1.9.5.39
Switches and Hubs	Cisco Catalyst 6000 Series Switches	Cisco Catalyst 6000 Switch	1.3.6.1.4.1.9.1.241
Switches and Hubs	Cisco Catalyst 8500 Series Multiservice Switch Routers	Cisco Catalyst 8510 MSR Switch	1.3.6.1.4.1.9.1.230
Switches and Hubs	Cisco Catalyst 8500 Series Multiservice Switch Routers	Cisco Catalyst 8540 MSR Switch	1.3.6.1.4.1.9.1.202
Switches and Hubs	Cisco Catalyst 8500 Series Multiservice Switch Routers	Cisco Catalyst 8515 MSR Switch	1.3.6.1.4.1.9.1.231
Switches and Hubs	Cisco Catalyst 8500 Series Multiservice Switch Routers	Cisco Catalyst 8515 CSR Switch	1.3.6.1.4.1.9.1.196
Switches and Hubs	Cisco 1548 Series Micro Switch	Cisco 1548M Micro Switch	1.3.6.1.4.1.9.1.225
Switches and Hubs	Cisco BPX 8600 Series Switches	Cisco BPX 8650 IP,ATM Multiservice Switch	1.3.6.1.4.1.9.1.238
Switches and Hubs	Cisco BPX 8600 Series Switches	Cisco BPX 8680 IP,ATM Multiservice Switch	1.3.6.1.4.1.9.1.239
Switches and Hubs	Cisco BPX 8600 Series Switches	Cisco BPX 8620 Switch	1.3.6.1.4.1.9.1.237
Switches and Hubs	Cisco BPX 8600 Series Switches	Cisco BPX Switch	1.3.6.1.4.1.351.100
Switches and Hubs	Cisco IGX 8400 Series Switches	Cisco IGX 8410 Multiservice Switch	1.3.6.1.4.1.9.1.232
Switches and Hubs	Cisco IGX 8400 Series Switches	Cisco IGX 8420 Multiservice Switch	1.3.6.1.4.1.9.1.233
Switches and Hubs	Cisco IGX 8400 Series Switches	Cisco IGX 8430 Multiservice Switch	1.3.6.1.4.1.9.1.234
Switches and Hubs	Cisco IGX 8400 Series Switches	Cisco IGX 8450 SES Multiservice Switch	1.3.6.1.4.1.9.1.235
Switches and Hubs	Cisco MGX 8200 Series Edge Concentrators	Cisco MGX 8220 Edge Concentrator	1.3.6.1.4.1.351.110
Switches and Hubs	Cisco MGX 8200 Series Edge Concentrators	Cisco MGX 8230 Edge Concentrator	1.3.6.1.4.1.9.1.304
Switches and Hubs	Cisco MGX 8200 Series Edge Concentrators	Cisco MGX 8240 Private Line Gateway	1.3.6.1.4.1.9.1.311
Switches and Hubs	Cisco MGX 8200 Series Edge	Cisco MGX 8250 Edge Concentrator	1.3.6.1.4.1.9.1.305



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Concentrators		
Switches and Hubs	Cisco 8110 Series Broadband Network Termination Units	Cisco 8110 Broadband Network Termination Unit	1.3.6.1.4.1.9.1.349
Switches and Hubs	Cisco MGX 8800 Series Switches	Cisco MGX 8850 Multiservice Switch	1.3.6.1.4.1.9.1.228
Switches and Hubs	Cisco MGX 8800 Series Switches	Cisco MGX 8850 Voice Gateway	1.3.6.1.4.1.351.130
Switches and Hubs	Cisco MGX 8800 Series Switches	Cisco MGX 8830 ATM Multiservice Switch	1.3.6.1.4.1.9.1.229
Switches and Hubs	Cisco MGX 8800 Series Switches	Cisco MGX 8830 ATM Multiservice Switch	1.3.6.1.4.1.9.1.458
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6506 Switch	1.3.6.1.4.1.9.1.282
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6506 Switch	1.3.6.1.4.1.9.5.45
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6509 Switch	1.3.6.1.4.1.9.5.44
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6509 Switch	1.3.6.1.4.1.9.1.283
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6509-NEB Switch	1.3.6.1.4.1.9.5.47
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6509-NEB Switch	1.3.6.1.4.1.9.1.310
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6509-NEB-A Switch	1.3.6.1.4.1.9.1.534
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6509-NEB-A Switch	1.3.6.1.4.1.9.5.61
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6513 Switch	1.3.6.1.4.1.9.5.50
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6513 Switch	1.3.6.1.4.1.9.1.400
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6503 Switch	1.3.6.1.4.1.9.5.56
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6503 Switch	1.3.6.1.4.1.9.1.449
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6504-E Switch	1.3.6.1.4.1.9.5.64
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6504-E Switch	1.3.6.1.4.1.9.1.657
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Virtual Switching System	1.3.6.1.4.1.9.1.896
Switches and Hubs	Cisco Catalyst 6500 Series Switches	Cisco Catalyst 6509-V-E Switch	1.3.6.1.4.1.9.1.832
Switches and Hubs	Cisco Catalyst 4200 Series Switches	Cisco Catalyst 4224 Access Gateway Switch	1.3.6.1.4.1.9.1.399

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 2350 Series Switches	Cisco Catalyst 2350-48TD-S Switch	1.3.6.1.4.1.9.1.1104
Switches and Hubs	Cisco Catalyst 2940 Series Switches	Cisco Catalyst 2940-8TF Switch	1.3.6.1.4.1.9.1.542
Switches and Hubs	Cisco Catalyst 2940 Series Switches	Cisco Catalyst 2940-8TT Switch	1.3.6.1.4.1.9.1.540
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950T 24 Switch	1.3.6.1.4.1.9.1.359
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950T 24 Switch	1.3.6.1.4.1.9.1.360
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950 12 Switch	1.3.6.1.4.1.9.1.323
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950 24 Switch	1.3.6.1.4.1.9.1.324
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950C 24 Switch	1.3.6.1.4.1.9.1.325
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950G 24 EI DC Switch	1.3.6.1.4.1.9.1.472
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950SX 24 Switch	1.3.6.1.4.1.9.1.480
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950SX 48 SI Switch	1.3.6.1.4.1.9.1.560
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2955S 12 Switch	1.3.6.1.4.1.9.1.508
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950T 48 SI Switch	1.3.6.1.4.1.9.1.559
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950G 12 EI Switch	1.3.6.1.4.1.9.1.427
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950G 24 EI Switch	1.3.6.1.4.1.9.1.428
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2950G 48 EI Switch	1.3.6.1.4.1.9.1.429
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2955C 12 Switch	1.3.6.1.4.1.9.1.489
Switches and Hubs	Cisco Catalyst 2950 Series Switches	Cisco Catalyst 2955T 12 Switch	1.3.6.1.4.1.9.1.488
Switches and Hubs	Cisco Catalyst 2970 Series Switches	Cisco Catalyst 2970G-24T Switch	1.3.6.1.4.1.9.1.527
Switches and Hubs	Cisco Catalyst 2970 Series Switches	Cisco Catalyst 2970G-24TS Switch	1.3.6.1.4.1.9.1.561
Switches and Hubs	Cisco Catalyst 2975 Series Switches	Cisco Catalyst 2975 Switch	1.3.6.1.4.1.9.1.1067
Switches and Hubs	Cisco Catalyst 2975 Series Switches	Cisco Catalyst 2975 Switch	1.3.6.1.4.1.9.1.1068
Switches and Hubs	Cisco MGX 8900 Series Switches	Cisco MGX 8950 Multiservice Switch	1.3.6.1.4.1.9.1.315

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4507RE Switch	1.3.6.1.4.1.9.1.1286
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4510RE Switch	1.3.6.1.4.1.9.1.1287
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4503 Switch	1.3.6.1.4.1.9.5.58
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4503 Switch	1.3.6.1.4.1.9.1.503
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4506 Switch	1.3.6.1.4.1.9.5.59
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4506 Switch	1.3.6.1.4.1.9.1.502
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4507R Switch	1.3.6.1.4.1.9.1.501
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4510R Switch	1.3.6.1.4.1.9.1.537
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4506-E Switch	1.3.6.1.4.1.9.1.875
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4510R-E Switch	1.3.6.1.4.1.9.1.877
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4503-E Switch	1.3.6.1.4.1.9.1.874
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4507R-E Switch	1.3.6.1.4.1.9.1.876
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4507R plus E Switch	1.3.6.1.4.1.9.1.1286
Switches and Hubs	Cisco Catalyst 4500 Series Switches	Cisco Catalyst 4510R plus E Switch	1.3.6.1.4.1.9.1.1287
Switches and Hubs	Cisco Catalyst 4900 Series Switches	Cisco Catalyst 4948 Switch	1.3.6.1.4.1.9.1.626
Switches and Hubs	Cisco Catalyst 4900 Series Switches	Cisco Catalyst 4948 10 Gigabit Ethernet Switch	1.3.6.1.4.1.9.1.659
Switches and Hubs	Cisco Catalyst 4900 Series Switches	Cisco Catalyst 4900M Switch	1.3.6.1.4.1.9.1.917
Switches and Hubs	Cisco Catalyst 4900 Series Switches	Cisco Catalyst 4928 10 Gigabit Ethernet Switch	1.3.6.1.4.1.9.1.1004
Switches and Hubs	Cisco Catalyst 4900 Series Switches	Cisco Catalyst 4948E Ethernet Switch	1.3.6.1.4.1.9.1.1178
Switches and Hubs	Cisco Catalyst 4900 Series Switches	Cisco Catalyst 4948E-F Switch	1.3.6.1.4.1.9.1.1327
Switches and Hubs	Cisco ME 3600X Series Ethernet Access Switches	Cisco ME 3600X-24FS-M Switch	1.3.6.1.4.1.9.1.1250
Switches and Hubs	Cisco ME 3600X Series Ethernet Access Switches	Cisco ME 3600X-24TS-M Switch	1.3.6.1.4.1.9.1.1251

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco IE 3010 Series Switches	Cisco IE-3010-16S-8PC Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1319
Switches and Hubs	Cisco IE 3010 Series Switches	Cisco IE-3010-24TC Industrial Ethernet Switch	1.3.6.1.4.1.9.1.1320
Switches and Hubs	Cisco ME 3800X Series Carrier Ethernet Switch Routers	Cisco ME 3800X-24FS-M Switch Router	1.3.6.1.4.1.9.1.1252
Switches and Hubs	Cisco Catalyst 8500 Series Campus Switch Routers	Cisco Catalyst 8510 CSR Switch	1.3.6.1.4.1.9.1.190
Switches and Hubs	Cisco Catalyst 8500 Series Campus Switch Routers	Cisco Catalyst 8540 CSR Switch	1.3.6.1.4.1.9.1.203
Switches and Hubs	Cisco ME 2400 Series Ethernet Access Switches	Cisco ME 2400-24TS-A Switch	1.3.6.1.4.1.9.1.734
Switches and Hubs	Cisco ME 2400 Series Ethernet Access Switches	Cisco ME 2400-24TS-D Switch	1.3.6.1.4.1.9.1.735
Switches and Hubs	Cisco ME 3400 Series Ethernet Access Switches	Cisco ME 3400-24TS-A Switch	1.3.6.1.4.1.9.1.736
Switches and Hubs	Cisco ME 3400 Series Ethernet Access Switches	Cisco ME 3400-24TS-D Switch	1.3.6.1.4.1.9.1.737
Switches and Hubs	Cisco ME 3400 Series Ethernet Access Switches	Cisco ME 3400G-12CS-A Switch	1.3.6.1.4.1.9.1.780
Switches and Hubs	Cisco ME 3400 Series Ethernet Access Switches	Cisco ME 3400G-12CS-D Switch	1.3.6.1.4.1.9.1.781
Switches and Hubs	Cisco ME 3400 Series Ethernet Access Switches	Cisco ME 3400G-2CS-A Switch	1.3.6.1.4.1.9.1.825
Switches and Hubs	Cisco ME 3400 Series Ethernet Access Switches	Cisco ME 3400-24FS-A Switch	1.3.6.1.4.1.9.1.873
Switches and Hubs	Cisco ME 4900 Series Ethernet Switches	Cisco ME 4924-10GE Switch	1.3.6.1.4.1.9.1.788
Switches and Hubs	Cisco ME 3400E Series Ethernet Access Switches	Cisco ME 3400EG-2CS-A Switch	1.3.6.1.4.1.9.1.1007
Switches and Hubs	Cisco ME 3400E Series Ethernet Access Switches	Cisco ME 3400EG-12CS-M Switch	1.3.6.1.4.1.9.1.1008

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco ME 3400E Series Ethernet Access Switches	Cisco ME 3400E-24TS-M Switch	1.3.6.1.4.1.9.1.1009
Switches and Hubs	Cisco ME 6500 Series Ethernet Switches	Cisco ME 6524GS-8S Ethernet Switch	1.3.6.1.4.1.9.1.719
Switches and Hubs	Cisco ME 6500 Series Ethernet Switches	Cisco ME 6524TS-8S Ethernet Switch	1.3.6.1.4.1.9.1.720
Switches and Hubs	Cisco Pro Series	Cisco Pro 761	1.3.6.1.4.1.9.1.88
Switches and Hubs	Cisco Pro Series	Cisco Pro 762	1.3.6.1.4.1.9.1.89
Switches and Hubs	Cisco Pro Series	Cisco Pro 771	1.3.6.1.4.1.9.1.143
Switches and Hubs	Cisco Pro Series	Cisco Pro 772	1.3.6.1.4.1.9.1.144
Switches and Hubs	Cisco Pro Series	Cisco Pro 775	1.3.6.1.4.1.9.1.145
Switches and Hubs	Cisco Pro Series	Cisco Pro 765	1.3.6.1.4.1.9.1.92
Switches and Hubs	Cisco Pro Series	Cisco Pro 766	1.3.6.1.4.1.9.1.93
Switches and Hubs	Cisco Pro Series	Cisco Pro 1003	1.3.6.1.4.1.9.1.51
Switches and Hubs	Cisco Pro Series	Cisco Pro 1004	1.3.6.1.4.1.9.1.52
Switches and Hubs	Cisco Pro Series	Cisco Pro 1005	1.3.6.1.4.1.9.1.53
Switches and Hubs	Cisco Pro Series	Cisco Pro 1601	1.3.6.1.4.1.9.1.117
Switches and Hubs	Cisco Pro Series	Cisco Pro 1602	1.3.6.1.4.1.9.1.118
Switches and Hubs	Cisco Pro Series	Cisco Pro 1603	1.3.6.1.4.1.9.1.119
Switches and Hubs	Cisco Pro Series	Cisco Pro 1604	1.3.6.1.4.1.9.1.120
Switches and Hubs	Cisco Pro Series	Cisco Pro 2500PCE	1.3.6.1.4.1.9.1.55
Switches and Hubs	Cisco Pro Series	Cisco Pro 2501	1.3.6.1.4.1.9.1.56
Switches and Hubs	Cisco Pro Series	Cisco Pro 2502	1.3.6.1.4.1.9.1.130
Switches and Hubs	Cisco Pro Series	Cisco Pro 2503	1.3.6.1.4.1.9.1.57
	Cisco Pro Series	Cisco Pro 2504	1.3.6.1.4.1.9.1.131

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs			
Switches and Hubs	Cisco Pro Series	Cisco Pro 2505	1.3.6.1.4.1.9.1.58
Switches and Hubs	Cisco Pro Series	Cisco Pro 2506	1.3.6.1.4.1.9.1.132
Switches and Hubs	Cisco Pro Series	Cisco Pro 2507	1.3.6.1.4.1.9.1.59
Switches and Hubs	Cisco Pro Series	Cisco Pro 2508	1.3.6.1.4.1.9.1.133
Switches and Hubs	Cisco Pro Series	Cisco Pro 2509	1.3.6.1.4.1.9.1.60
Switches and Hubs	Cisco Pro Series	Cisco Pro 2510	1.3.6.1.4.1.9.1.134
Switches and Hubs	Cisco Pro Series	Cisco Pro 2511	1.3.6.1.4.1.9.1.61
Switches and Hubs	Cisco Pro Series	Cisco Pro 2512	1.3.6.1.4.1.9.1.135
Switches and Hubs	Cisco Pro Series	Cisco Pro 2513	1.3.6.1.4.1.9.1.136
Switches and Hubs	Cisco Pro Series	Cisco Pro 2514	1.3.6.1.4.1.9.1.62
Switches and Hubs	Cisco Pro Series	Cisco Pro 2515	1.3.6.1.4.1.9.1.137
Switches and Hubs	Cisco Pro Series	Cisco Pro 2516	1.3.6.1.4.1.9.1.63
Switches and Hubs	Cisco Pro Series	Cisco Pro 2517	1.3.6.1.4.1.9.1.138
Switches and Hubs	Cisco Pro Series	Cisco Pro 2518	1.3.6.1.4.1.9.1.139
Switches and Hubs	Cisco Pro Series	Cisco Pro 2519	1.3.6.1.4.1.9.1.64
Switches and Hubs	Cisco Pro Series	Cisco Pro 2521	1.3.6.1.4.1.9.1.65
Switches and Hubs	Cisco Pro Series	Cisco Pro 2520	1.3.6.1.4.1.9.1.104
Switches and Hubs	Cisco Pro Series	Cisco Pro 2522	1.3.6.1.4.1.9.1.105
Switches and Hubs	Cisco Pro Series	Cisco Pro 2523	1.3.6.1.4.1.9.1.140
Switches and Hubs	Cisco Pro Series	Cisco Pro 2524	1.3.6.1.4.1.9.1.106
Switches and Hubs	Cisco Pro Series	Cisco Pro 2525	1.3.6.1.4.1.9.1.141
Switches and Hubs	Cisco Pro Series	Cisco Pro 4500	1.3.6.1.4.1.9.1.66

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Cisco Pro Series	Cisco Pro 4700	1.3.6.1.4.1.9.1.142
Switches and Hubs	Cisco Pro Series	Cisco Pro 751	1.3.6.1.4.1.9.1.76
Switches and Hubs	Cisco Pro Series	Cisco Pro 752	1.3.6.1.4.1.9.1.77
Switches and Hubs	Cisco Pro Series	Cisco Pro 753	1.3.6.1.4.1.9.1.78
Switches and Hubs	Cisco Pro Series	Cisco Pro Workgroup Switch 1420	1.3.6.1.4.1.9.5.21
Switches and Hubs	Cisco Pro Series	Cisco Pro Workgroup Switch 1601	1.3.6.1.4.1.9.5.25
Switches and Hubs	Cisco Pro Series	Cisco Pro Workgroup Switch 1800	1.3.6.1.4.1.9.5.24
Switches and Hubs	Cisco Pro Series	Cisco Pro Workgroup Switch 2200	1.3.6.1.4.1.9.5.13
Switches and Hubs	Cisco Pro Series	Cisco Pro 3116	1.3.6.1.4.1.9.1.149
Switches and Hubs	Unified Computing	Cisco UCS 6140XP 40-Port Fabric Interconnect	1.3.6.1.4.1.9.12.3.1.3.899
Switches and Hubs	Unified Computing	Cisco UCS 6120XP 20-Port Fabric Interconnect	1.3.6.1.4.1.9.12.3.1.3.847
Switches and Hubs	Data Center Switches	Cisco Nexus 7000 9-Slot Switch	1.3.6.1.4.1.9.12.3.1.3.932
Switches and Hubs	Data Center Switches	Cisco Nexus 3048 Switch	1.3.6.1.4.1.9.12.3.1.3.1106
Switches and Hubs	Data Center Switches	Cisco Nexus 3064 Switch	1.3.6.1.4.1.9.12.3.1.3.1060
Switches and Hubs	Data Center Switches	Cisco Nexus 3064 Switch	1.3.6.1.4.1.9.12.3.1.3.1105
Switches and Hubs	Data Center Switches	Cisco Nexus 5010 Switch	1.3.6.1.4.1.9.12.3.1.3.798
Switches and Hubs	Data Center Switches	Cisco Nexus 5020 Switch	1.3.6.1.4.1.9.12.3.1.3.719
Switches and Hubs	Data Center Switches	Cisco Nexus 5020 Switch	1.3.6.1.4.1.9.12.3.1.3.720
Switches and Hubs	Data Center Switches	Cisco Nexus 5020T Switch	1.3.6.1.4.1.9.12.3.1.3.936
Switches and Hubs	Data Center Switches	Cisco Nexus 5548 O2 32X10GE	1.3.6.1.4.1.9.12.3.1.3.1084
Switches and Hubs	Data Center Switches	Cisco Nexus 7000 10-Slot Switch	1.3.6.1.4.1.9.12.3.1.3.612
Switches and Hubs	Data Center Switches	Cisco Nexus 7000 18-Slot Switch	1.3.6.1.4.1.9.12.3.1.3.777

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Data Center Switches	Cisco Nexus 1000V Series Switches	1.3.6.1.4.1.9.12.3.1.3.840
Switches and Hubs	Data Center Switches	Cisco Nexus 1010 Virtual Services Appliance	1.3.6.1.4.1.9.12.3.1.3.907
Switches and Hubs	Data Center Switches	Cisco Nexus 4001I Switch Module for IBM BladeCenter	1.3.6.1.4.1.9.12.3.1.3.903
Switches and Hubs	Data Center Switches	Cisco Nexus 4005I Switch Module for IBM BladeCenter	1.3.6.1.4.1.9.12.3.1.3.930
Switches and Hubs	Data Center Switches	Cisco Nexus 5548P Switch	1.3.6.1.4.1.9.12.3.1.3.1008
Switches and Hubs	Data Center Switches	Cisco Nexus 5548UP Switch	1.3.6.1.4.1.9.12.3.1.3.1084
Switches and Hubs	Data Center Switches	Cisco Nexus 5596UP Switch	1.3.6.1.4.1.9.12.3.1.3.1038
Switches and Hubs	Data Center Switches	Cisco Nexus 3064 Switch	1.3.6.1.4.1.9.12.3.1.3.1060
Switches and Hubs	Data Center Switches	Cisco Nexus 3064 Switch	1.3.6.1.4.1.9.12.3.1.3.1105
Switches and Hubs	Data Center Switches	Cisco Nexus 3048 Switch	1.3.6.1.4.1.9.12.3.1.3.1106
Switches and Hubs	Data Center Switches	Cisco Nexus 3016 Switch	1.3.6.1.4.1.9.12.3.1.3.1107
Switches and Hubs	Data Center Switches	Cisco Nexus 7000 9-Slot Switch	1.3.6.1.4.1.9.12.3.1.3.932
Switches and Hubs	Cisco FastHub 100 Series Hubs	FastHub 116T	1.3.6.1.4.1.9.1.150
Switches and Hubs	Cisco FastHub 100 Series Hubs	FastHub 116C	1.3.6.1.4.1.9.1.151
Switches and Hubs	Cisco FastHub 100 Series Hubs	FastHub 100	1.3.6.1.4.1.9.1.226
Switches and Hubs	Cisco FastHub 200 Series Hubs	FastHub 216T	1.3.6.1.4.1.9.1.169
Switches and Hubs	Cisco FastHub 300 Series Hubs	FastHub 316C	1.3.6.1.4.1.9.1.148
Switches and Hubs	Cisco FastHub 300 Series Hubs	FastHub 316T	1.3.6.1.4.1.9.1.147
Switches and Hubs	Cisco FastHub Series Hubs	FastHubBMMTX	1.3.6.1.4.1.9.1.177
Switches and Hubs	Cisco FastHub Series Hubs	FastHubBMMFX	1.3.6.1.4.1.9.1.178
Switches and Hubs	Other Switches and Hubs	Adapter Card	1.3.6.1.4.1.9.5.2
Switches and Hubs	Other Switches and Hubs	Catalyst WSC2900	1.3.6.1.4.1.9.5.12



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Switches and Hubs	Other Switches and Hubs	Catalyst WSC3001	1.3.6.1.4.1.9.5.26
Switches and Hubs	Other Switches and Hubs	Cisco IGXSes	1.3.6.1.4.1.9.1.243
Switches and Hubs	Other Switches and Hubs	CPW1220i	1.3.6.1.4.1.9.5.30
Switches and Hubs	Other Switches and Hubs	DCD	1.3.6.1.4.1.9.5.22
Switches and Hubs	Other Switches and Hubs	ESStack	1.3.6.1.4.1.9.5.14
Switches and Hubs	Other Switches and Hubs	TSSStack	1.3.6.1.4.1.9.5.32
Switches and Hubs	Other Switches and Hubs	WSC1900 Lite Fx	1.3.6.1.4.1.9.5.175
Switches and Hubs	Other Switches and Hubs	Cisco FastHub 1116	1.3.6.1.4.1.9.1.152
Switches and Hubs	Other Switches and Hubs	Cisco Intelligent Gigabit Ethernet Switch Module for IBM eServer BladeCenter	1.3.6.1.4.1.9.1.592
Switches and Hubs	Other Switches and Hubs	Cisco Intelligent Gigabit Ethernet Switch Module for IBM eServer BladeCenter	1.3.6.1.4.1.9.1.660
Switches and Hubs	Other Switches and Hubs	Cisco Gigabit Ethernet Switch Module	1.3.6.1.4.1.11.2.3.7.11.33.3.1.1
Switches and Hubs	Cisco Catalyst 3850 Series Ethernet Stackable Switch	Cisco Catalyst 3850 48P 10/100/1000 PoE+ Ports Layer 2/Layer 3 Ethernet Stackable Switch	1.3.6.1.4.1.9.1.1641
Switches and Hubs	Cisco Catalyst 3850 Series Ethernet Stackable Switch	Cisco Catalyst 3850 24P 10/100/1000 PoE+ Ports Layer 2/Layer 3 Ethernet Stackable Switch	1.3.6.1.4.1.9.1.1642
Switches and Hubs	Cisco Catalyst 3850 Series Ethernet Stackable Switch	Cisco Catalyst 3850 48 10/100/1000 PoE+ Ports Layer 2/Layer 3 Ethernet Stackable Switch	1.3.6.1.4.1.9.1.1643
Switches and Hubs	Cisco Catalyst 3850 Series Ethernet Stackable Switch	Cisco Catalyst 3850 24 10/100/1000 PoE+ Ports Layer 2/Layer 3 Ethernet Stackable Switch	1.3.6.1.4.1.9.1.1644
Video and Content Delivery	Cisco RF Gateway Series	Cisco RF Gateway 10	1.3.6.1.4.1.9.1.931
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7120 Router	1.3.6.1.4.1.9.1.259

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7120 Router	1.3.6.1.4.1.9.1.260
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7120 Router	1.3.6.1.4.1.9.1.261
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7120 Router	1.3.6.1.4.1.9.1.262
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7120 Router	1.3.6.1.4.1.9.1.263
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7120 Router	1.3.6.1.4.1.9.1.264
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7140 Router	1.3.6.1.4.1.9.1.265
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7140 Router	1.3.6.1.4.1.9.1.266
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7140 Router	1.3.6.1.4.1.9.1.267
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7140 Router	1.3.6.1.4.1.9.1.268
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7140 Router	1.3.6.1.4.1.9.1.269
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7140 Router	1.3.6.1.4.1.9.1.276
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7140 Router	1.3.6.1.4.1.9.1.277
Security and VPN	Cisco 7100 Series VPN Routers	Cisco 7160 VPN Router	1.3.6.1.4.1.9.1.358
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 506 Firewall	1.3.6.1.4.1.9.1.389
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 515 Firewall	1.3.6.1.4.1.9.1.390
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 515 Firewall Security Context	1.3.6.1.4.1.9.1.678
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 520 Firewall	1.3.6.1.4.1.9.1.391
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 525 Firewall	1.3.6.1.4.1.9.1.392
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 525 Firewall Security Context	1.3.6.1.4.1.9.1.676
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 535 Firewall	1.3.6.1.4.1.9.1.393
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 535 Firewall Security Context	1.3.6.1.4.1.9.1.675
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 501 Firewall	1.3.6.1.4.1.9.1.417
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 515E Firewall	1.3.6.1.4.1.9.1.451

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 515E Firewall Security Context	1.3.6.1.4.1.9.1.677
Security and VPN	Cisco PIX 500 Series Firewalls	Cisco PIX 506E Firewall	1.3.6.1.4.1.9.1.450
Security and VPN	Cisco PIX 500 Series Firewalls	PIX Firewall	1.3.6.1.4.1.9.1.227
Security and VPN	Cisco VPN 5000 Series Concentrators	VPN 500x Concentrator	1.3.6.1.4.1.255.1.1
Security and VPN	Cisco VPN 3000 Series Concentrators	Cisco VPN 30xx Concentrator	1.3.6.1.4.1.3076.1.2.1.1.1.1
Security and VPN	Cisco VPN 3000 Series Concentrators	Cisco VPN 30xx Concentrator	1.3.6.1.4.1.3076.1.2.1.1.1.2
Security and VPN	Cisco VPN 3000 Series Concentrators	Cisco VPN 30xx Concentrator	1.3.6.1.4.1.3076.1.2.1.1.2.1
Security and VPN	Cisco VPN 3000 Series Concentrators	Cisco VPN 30xx Concentrator	1.3.6.1.4.1.3076.1.2.1.1.3.1
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4210 Sensor	1.3.6.1.4.1.9.1.645
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4215 Sensor	1.3.6.1.4.1.9.1.646
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4220 Sensor	1.3.6.1.4.1.9.1.741
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4230 Sensor	1.3.6.1.4.1.9.1.742
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4235 Sensor	1.3.6.1.4.1.9.1.647
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4240 Sensor	1.3.6.1.4.1.9.1.648
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4250 Sensor	1.3.6.1.4.1.9.1.649
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4250 XL Sensor	1.3.6.1.4.1.9.1.651
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4255 Sensor	1.3.6.1.4.1.9.1.652
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4260 Sensor	1.3.6.1.4.1.9.1.743
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4215 Virtual Sensor	1.3.6.1.4.1.9.1.807
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4235 Virtual Sensor	1.3.6.1.4.1.9.1.808
			1.3.6.1.4.1.9.1.812

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4240 Virtual Sensor	
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4250 Virtual Sensor	1.3.6.1.4.1.9.1.809
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4250 SX Virtual Sensor	1.3.6.1.4.1.9.1.810
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IDS 4250 XL Virtual Sensor	1.3.6.1.4.1.9.1.811
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4255 Virtual Sensor	1.3.6.1.4.1.9.1.813
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4260 Virtual Sensor	1.3.6.1.4.1.9.1.814
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4270 Sensor	1.3.6.1.4.1.9.1.830
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4270 Virtual Sensor	1.3.6.1.4.1.9.1.831
Security and VPN	Cisco IPS 4200 Series Sensors	Cisco IPS 4250 SX Sensor	1.3.6.1.4.1.9.1.650
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.1202
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.1203
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.1204
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.1205
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.1198
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.1199
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.1200
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.1201
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance	1.3.6.1.4.1.9.1.1194
Security and VPN	Cisco ASA-5500 Series Adaptive	Cisco ASA-5585 Adaptive Security Appliance	1.3.6.1.4.1.9.1.1195

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Security Appliances		
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance	1.3.6.1.4.1.9.1.1196
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance	1.3.6.1.4.1.9.1.1197
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5510 Adaptive Security Appliance	1.3.6.1.4.1.9.1.669
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5510 Adaptive Security Appliance	1.3.6.1.4.1.9.12.3.1.3.447
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5510 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.773
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5520 Adaptive Security Appliance	1.3.6.1.4.1.9.1.670
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5520 Adaptive Security Appliance	1.3.6.1.4.1.9.12.3.1.3.448
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5520 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.671
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5540 Adaptive Security Appliance	1.3.6.1.4.1.9.1.672
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5540 Adaptive Security Appliance	1.3.6.1.4.1.9.12.3.1.3.449
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5540 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.673
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5560 Adaptive Security Appliance	1.3.6.1.4.1.9.12.3.1.3.454
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5550 Adaptive Security Appliance	1.3.6.1.4.1.9.1.753
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5550 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.763
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5505 Adaptive Security Appliance	1.3.6.1.4.1.9.1.745
Security and	Cisco ASA-5500	Cisco ASA-5505 Adaptive	1.3.6.1.4.1.9.12.3.1.3.560

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

VPN	Series Adaptive Security Appliances	Security Appliance	
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5580 Adaptive Security Appliance	1.3.6.1.4.1.9.1.914
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance	1.3.6.1.4.1.9.1.1194
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance	1.3.6.1.4.1.9.1.1195
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance	1.3.6.1.4.1.9.1.1196
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance	1.3.6.1.4.1.9.1.1197
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.1198
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.1199
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.1200
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.1201
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.1202
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.1203
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.1204
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5585 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.1205
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5580 Adaptive Security Appliance Security Context	1.3.6.1.4.1.9.1.915
Security and VPN	Cisco ASA-5500 Series Adaptive Security Appliances	Cisco ASA-5580 Adaptive Security Appliance System Context	1.3.6.1.4.1.9.1.916

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Security and VPN	IDS Management	Cisco Threat Response	
Network Management	Other Network Management Products	Cisco Cluster Management Suite	
Network Management	Other Network Management Products	Cisco CNS Configuration Engine	
Network Management	Other Network Management Products	CiscoWorks Auto Update Server	
Network Management	CiscoWorks Wireless LAN Solution Engine	CiscoWorks 1105 for Wireless LAN Solution Engine	1.3.6.1.4.1.9.1.459
Network Management	CiscoWorks Wireless LAN Solution Engine	CiscoWorks 1130 for Wireless LAN Solution Engine	1.3.6.1.4.1.9.1.630
Network Management	CiscoWorks Wireless LAN Solution Engine	CiscoWorks 1030 for Wireless LAN Solution Engine	1.3.6.1.4.1.9.1.631
Network Management	CiscoWorks Wireless LAN Solution Engine	CiscoWorks 1132 for Wireless LAN Solution Engine	1.3.6.1.4.1.9.1.712
Network Management	CiscoWorks Wireless LAN Solution Engine	CiscoWorks 1133 for Wireless LAN Solution Engine	1.3.6.1.4.1.9.1.752
Network Management	CiscoWorks Wireless LAN Solution Engine	Cisco Wireless LAN Solution Engine S20	1.3.6.1.4.1.9.1.709
Network Management	Cisco SwitchProbes	Cisco SwitchProbe	1.3.6.1.4.1.141.1.1.7500
Network Management	Cisco SwitchProbes	Cisco SwitchProbe	1.3.6.1.4.1.141.1.1.7211
Network Management	Cisco SwitchProbes	Cisco SwitchProbe	1.3.6.1.4.1.141.1.1.7221
Network Management	Cisco SwitchProbes	Cisco SwitchProbe	1.3.6.1.4.1.141.1.1.8400
Network Management	Cisco SwitchProbes	Cisco SwitchProbe	1.3.6.1.4.1.141.1.1.7302
Network Management	CiscoWorks Hosting Solution Engine	Cisco 1105 for Hosting Solution Engine	1.3.6.1.4.1.9.1.405
Network Management	CiscoWorks	CiscoWorks Monitoring Center for Security	
Network Management	CiscoWorks	CiscoWorks Management Center for Cisco Security Agents	

Network Management	CiscoWorks	CiscoWorks Management Center for Cisco Security Agents 4.0	
Broadband Cable	Cisco CVA120 Series Cable Voice Adapters	Cisco CVA122E Cable Voice Adapter	1.3.6.1.4.1.9.1.371
Broadband Cable	Cisco uBR7200 Series Universal Broadband Routers	Cisco uBR7223 Universal Broadband Router	1.3.6.1.4.1.9.1.210
Broadband Cable	Cisco uBR7200 Series Universal Broadband Routers	Cisco uBR7246 Universal Broadband Router	1.3.6.1.4.1.9.1.179
Broadband Cable	Cisco uBR7200 Series Universal Broadband Routers	Cisco uBR7246VXR Universal Broadband Router	1.3.6.1.4.1.9.1.271
Broadband Cable	Cisco uBR7225VXR Universal Broadband Routers	Cisco uBR7225VXR Universal Broadband Router	1.3.6.1.4.1.9.1.827
Broadband Cable	Cisco uBR900 Series Cable Access Routers	Cisco uBR904 Cable Access Router	1.3.6.1.4.1.9.1.191
Broadband Cable	Cisco uBR900 Series Cable Access Routers	Cisco uBR905 Cable Access Router	1.3.6.1.4.1.9.1.351
Broadband Cable	Cisco uBR900 Series Cable Access Routers	Cisco uBR914 Cable Data Service Unit	1.3.6.1.4.1.9.1.294
Broadband Cable	Cisco uBR900 Series Cable Access Routers	Cisco uBR924 Cable Access Router	1.3.6.1.4.1.9.1.255
Broadband Cable	Cisco uBR900 Series Cable Access Routers	Cisco uBR925 Cable Access Router	1.3.6.1.4.1.9.1.316
Broadband Cable	Cisco uBR7100 Series Universal Broadband Routers	Cisco uBR7100 Universal Broadband Router	1.3.6.1.4.1.9.1.309
Broadband Cable	Cisco uBR7100 Series Universal Broadband Routers	Cisco uBR7114 Universal Broadband Router	1.3.6.1.4.1.9.1.346
Broadband Cable	Cisco uBR7100 Series Universal Broadband Routers	Cisco uBR7114E Universal Broadband Router	1.3.6.1.4.1.9.1.347
Broadband Cable	Cisco uBR7100 Series Universal Broadband Routers	Cisco uBR7111 Universal Broadband Router	1.3.6.1.4.1.9.1.344
Broadband Cable	Cisco uBR7100 Series Universal	Cisco uBR7111E Universal Broadband	1.3.6.1.4.1.9.1.345



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Broadband Routers	Router	
Broadband Cable	Cable Modem Termination Systems (CMTS)	Cisco uBR10012 Universal Broadband Router	1.3.6.1.4.1.9.1.317
Storage Networking	Cisco SN 5400 Series Storage Routers	Cisco SN 5428 Storage Router	1.3.6.1.4.1.9.1.475
Storage Networking	Cisco SN 5400 Series Storage Routers	Cisco SN 5420 Storage Router	1.3.6.1.4.1.9.1.407
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9506 Multilayer Director Switch	1.3.6.1.4.1.9.12.3.1.3.375
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9509 Multilayer Director Switch	1.3.6.1.4.1.9.12.3.1.3.376
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9513 Multilayer Director Switch	1.3.6.1.4.1.9.12.3.1.3.377
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9216 Multilayer Fabric Switch	1.3.6.1.4.1.9.1.521
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9216 Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.380
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9216A Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.442
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9132 Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.462
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9116 Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.463
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9216i Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.472
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9120 Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.414
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9140 Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.411
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9124 Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.587
Storage	Cisco MDS 9000	Cisco MDS 9124e	1.3.6.1.4.1.9.12.3.1.3.606

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Networking	Series Multilayer Switches	Multilayer Fabric Switch	
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9222i Multiservice Modular Switch	1.3.6.1.4.1.9.12.3.1.3.651
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9134 Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.616
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS IBM Blade Switch	1.3.6.1.4.1.9.12.3.1.3.601
Storage Networking	Cisco MDS 9000 Series Multilayer Switches	Cisco MDS 9148 Multilayer Fabric Switch	1.3.6.1.4.1.9.12.3.1.3.841
Voice and Telephony	Virtual Machine	VMware Virtual Machine for Cisco Unified Communications Applications	1.3.6.1.4.1.9.1.1348
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7815I Media Convergence Server	1.3.6.1.4.1.9.1.582
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7825H Media Convergence Server	1.3.6.1.4.1.9.1.583
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7825I Media Convergence Server	1.3.6.1.4.1.9.1.746
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7835H Media Convergence Server	1.3.6.1.4.1.9.1.584
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7835I Media Convergence Server	1.3.6.1.4.1.9.1.585
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7845H Media Convergence Server	1.3.6.1.4.1.9.1.586
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7845I Media Convergence Server	1.3.6.1.4.1.9.1.587
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7855I Media Convergence Server	1.3.6.1.4.1.9.1.588
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 7865I Media Convergence Server	1.3.6.1.4.1.9.1.589
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco MCS 7828-I3 Unified Communications Manager Business Edition	1.3.6.1.4.1.9.1.899

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

		Appliance	
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco MCS 7816-I3	1.3.6.1.4.1.9.1.898
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco MCS 7816-H3	1.3.6.1.4.1.9.1.900
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco MCS 7828-H3 Unified Communications Manager Business Edition Appliance	1.3.6.1.4.1.9.1.901
Voice and Telephony	Cisco 7800 Series Media Convergence Servers	Cisco 78xx Media Convergence Server	
Voice and Telephony	Conferencing	Cisco Unified MeetingPlace	1.3.6.1.4.1.9.9.733
Voice and Telephony	Cisco IAD2400 Series Integrated Access Devices	Cisco IAD2420 Integrated Access Device	1.3.6.1.4.1.9.1.362
Voice and Telephony	Cisco IAD2400 Series Integrated Access Devices	Cisco IAD2431 Series Integrated Access Device	1.3.6.1.4.1.9.1.546
Voice and Telephony	Cisco IAD2400 Series Integrated Access Devices	Cisco IAD2431 Series Integrated Access Device	1.3.6.1.4.1.9.1.547
Voice and Telephony	Cisco IAD2400 Series Integrated Access Devices	Cisco IAD2431 Series Integrated Access Device	1.3.6.1.4.1.9.1.548
Voice and Telephony	Cisco IAD2400 Series Integrated Access Devices	Cisco IAD2431 Series Integrated Access Device	1.3.6.1.4.1.9.1.549
Voice and Telephony	Cisco IAD2400 Series Integrated Access Devices	Cisco IAD2430 Integrated Access Device	1.3.6.1.4.1.9.1.54
Voice and Telephony	Cisco IAD2400 Series Integrated Access Devices	Cisco IAD2430 Integrated Access Device	1.3.6.1.4.1.9.1.545
Voice and Telephony	Cisco IAD2400 Series Integrated Access Devices	Cisco IAD2435 Integrated Access Device	1.3.6.1.4.1.9.1.962
Voice and Telephony	Cisco IAD880 Series Integrated Access Devices	Cisco IAD881,IAD881W Integrated Access Device	1.3.6.1.4.1.9.1.839
Voice and Telephony	Cisco IAD880 Series Integrated Access Devices	Cisco IAD881,IAD881W Integrated Access Device	1.3.6.1.4.1.9.1.841
Voice and Telephony	Cisco IAD880	Cisco IAD886,IAD886W	1.3.6.1.4.1.9.1.844

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Telephony	Series Integrated Access Devices	Integrated Access Device	
Voice and Telephony	Cisco IAD880 Series Integrated Access Devices	Cisco IAD886,IAD886W Integrated Access Device	1.3.6.1.4.1.9.1.845
Voice and Telephony	Cisco IAD880 Series Integrated Access Devices	Cisco IAD887,IAD887W Integrated Access Device	1.3.6.1.4.1.9.1.849
Voice and Telephony	Cisco IAD880 Series Integrated Access Devices	Cisco IAD887,IAD887W Integrated Access Device	1.3.6.1.4.1.9.1.850
Voice and Telephony	Cisco IAD880 Series Integrated Access Devices	Cisco IAD888,IAD888W Integrated Access Device	1.3.6.1.4.1.9.1.854
Voice and Telephony	Cisco IAD880 Series Integrated Access Devices	Cisco IAD888,IAD888W Integrated Access Device	1.3.6.1.4.1.9.1.855
Voice and Telephony	Cisco DPA 7600 Series Gateways	Cisco DPA 7630 Voice Mail Gateway	1.3.6.1.4.1.9.1.365
Voice and Telephony	Cisco DPA 7600 Series Gateways	Cisco DPA 7610 Voice Mail Gateway	1.3.6.1.4.1.9.1.381
Voice and Telephony	Cisco VG200 Series Gateways	Cisco VG248 48-Port Analog Phone Gateway	1.3.6.1.4.1.9.1.404
Voice and Telephony	Cisco VG200 Series Gateways	Cisco VG224 Voice Gateway	1.3.6.1.4.1.9.1.558
Voice and Telephony	Cisco VG200 Series Gateways	Cisco VG200 Voice Gateway	1.3.6.1.4.1.9.1.279
Voice and Telephony	Cisco VG200 Series Gateways	Cisco VG202 Analog Voice Gateway	1.3.6.1.4.1.9.1.964
Voice and Telephony	Cisco VG200 Series Gateways	Cisco VG204 Analog Voice Gateway	1.3.6.1.4.1.9.1.963
Voice and Telephony	Cisco VG300 Series Gateways	Cisco VG350 Analog Voice Gateway	1.3.6.1.4.1.9.1.1557
Voice and Telephony	Cisco ICS 7700 Series Integrated Communication Systems	Cisco ICS 7750 Integrated Communication System	1.3.6.1.4.1.9.1.302
Voice and Telephony	Cisco ICS 7700 Series Integrated Communication Systems	Cisco ICS 7750 Integrated Communication System	1.3.6.1.4.1.9.1.303
Voice and Telephony	Cisco ICS 7700 Series Integrated Communication Systems	Cisco ICS 7750 Integrated Communication System	1.3.6.1.4.1.9.1.314
Voice and Telephony	Cisco ICS 7700 Series Integrated	Cisco ICS 7750 Integrated Communication System	1.3.6.1.4.1.9.1.456

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Communication Systems		
Voice and Telephony	Call Control	Cisco CallManager	1.3.6.1.4.1.311.1.1.3.1.1
Voice and Telephony	Call Control	Cisco CallManager	1.3.6.1.4.1.311.1.1.3.1.2
Voice and Telephony	Call Control	Cisco CallManager	1.3.6.1.4.1.311.1.1.3.1.3
Voice and Telephony	Call Control	Cisco CallManager	1.3.6.1.4.1.99.1.1.3.28
Voice and Telephony	Call Control	Cisco CallManager	1.3.6.1.4.1.9.1.1348
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.878
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.879
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.880
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.881
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.882
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.883
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.884
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.885
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.886
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.888
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.890
Voice and Telephony	Call Control	Cisco Unified Communications 500	1.3.6.1.4.1.9.1.892

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

		Series for Small Business	
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.894
Voice and Telephony	Call Control	Cisco Unified Communications 500 Series for Small Business	1.3.6.1.4.1.9.1.895
Voice and Telephony	Customer Contact		
Voice and Telephony	Voice Applications	MeetingPlace Express	1.3.6.1.4.1.9.1.710
Server Fabric Switches	Cisco SFS 3000 Series Multifabric Server Switches	Cisco SFS 3012 Multifabric Server Switch	1.3.6.1.4.1.6203.3
Server Fabric Switches	Cisco SFS 3000 Series Multifabric Server Switches	Cisco SFS 3012 Multifabric Server Switch	1.3.6.1.4.1.6203.20
Server Fabric Switches	Cisco SFS 3000 Series Multifabric Server Switches	Cisco SFS 3504 Multifabric Server Switch	1.3.6.1.4.1.6203.16
Server Fabric Switches	Cisco SFS 7000 Series InfiniBand Server Switches	Cisco SFS 7008 InfiniBand Server Switch	1.3.6.1.4.1.6203.18
Server Fabric Switches	Cisco SFS 7000 Series InfiniBand Server Switches	Cisco SFS 7000 InfiniBand Server Switch	1.3.6.1.4.1.6203.17
Server Fabric Switches	Cisco SFS 7000 Series InfiniBand Server Switches	Cisco SFS 7000D InfiniBand Server Switch	1.3.6.1.4.1.6203.19
Server Fabric Switches	IBM BladeCenter InfiniBand Switch	Cisco BladeCenterH	1.3.6.1.4.1.6203.15
Autonomous AP	Cisco Aironet 3500 Series	Cisco Aironet 3500 Access Point	1.3.6.1.4.1.9.1.1124
Autonomous AP	Cisco Aironet 3500 Series	Cisco Aironet 3500 Access Point	1.3.6.1.4.1.9.1.1125
Autonomous AP	Cisco Aironet 340 Series	Cisco Aironet 340 Access Points	1.3.6.1.4.1.9.1.379
Autonomous AP	Cisco Aironet 350 Series	Cisco Aironet 350 Access Points	1.3.6.1.4.1.9.1.380
Autonomous AP	Cisco Aironet 350 Series	Cisco Aironet 350 Access Points	1.3.6.1.4.1.9.1.552
Autonomous AP	Cisco 800 Series Access Points	Cisco AP801agn Access Point	1.3.6.1.4.1.9.1.988
Autonomous AP	Cisco 800 Series Access Points	Cisco AP801gn Access Point	1.3.6.1.4.1.9.1.989
Autonomous AP	Cisco Aironet 1100 Series	Cisco Aironet 1100 Series Access Point	1.3.6.1.4.1.9.1.507

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Autonomous AP	Cisco Aironet 1100 Series	Cisco Aironet 1130 Series Access Point	1.3.6.1.4.1.9.1.618
Autonomous AP	Cisco Aironet 1140 Series	Cisco Aironet 1140 Access Point	1.3.6.1.4.1.9.1.1034
Autonomous AP	Cisco Aironet 1140 Series	Cisco Aironet 1140 Access Point	1.3.6.1.4.1.9.1.1035
Autonomous AP	Cisco Aironet 1200 Series	Cisco Aironet 1200 Access Point	1.3.6.1.4.1.9.1.474
Autonomous AP	Cisco Aironet 1200 Series	Cisco Aironet 1210 Access Point	1.3.6.1.4.1.9.1.525
Autonomous AP	Cisco Aironet 1240 AG Series	Cisco Aironet 1240 AG Access Point	1.3.6.1.4.1.9.1.685
Autonomous AP	Cisco Aironet 1250 Series	Cisco Aironet 1250 Series Access Point	1.3.6.1.4.1.9.1.758
Autonomous AP	Cisco Aironet 1400 Series	BR1410	1.3.6.1.4.1.9.1.533
Autonomous AP	Cisco Aironet 1400 Series	Aironet BR 1430	1.3.6.1.4.1.9.1.1031
Autonomous AP	Cisco Aironet 1300 Series	Aironet BR1300	1.3.6.1.4.1.9.1.565
Autonomous AP	Cisco Aironet 1040 Series	Cisco Aironet 1040	1.3.6.1.4.1.9.1.1270
Autonomous AP	Cisco Aironet 1040 Series	Cisco Aironet 1040	1.3.6.1.4.1.9.1.1269
Autonomous AP	Cisco Aironet 1260 Series	Cisco Aironet 1260	1.3.6.1.4.1.9.1.1248
Autonomous AP	Cisco Aironet 1260 Series	Cisco Aironet 1260	1.3.6.1.4.1.9.1.1247
Autonomous AP	Cisco Aironet 2600I Series	Cisco Aironet 2600I Access Point	1.3.6.1.4.1.9.1.1647
Autonomous AP	Cisco Aironet 2600E Series	Cisco Aironet 2600E	1.3.6.1.4.1.9.1.1659
Autonomous AP	Cisco Aironet 3500I Series	Cisco Aironet 3500I Access Point	1.3.6.1.4.1.9.1.1124
Autonomous AP	Cisco Aironet 3500E Series	Cisco Aironet 3500E	1.3.6.1.4.1.9.1.1125
Autonomous AP	Cisco Aironet 3600I Series	Cisco Aironet 3600I Access Point	1.3.6.1.4.1.9.1.1662
Autonomous AP	Cisco Aironet 3600I Series	Cisco Aironet 3600I Access Point	1.3.6.1.4.1.9.1.1661
Autonomous AP	Cisco Aironet 1550 Series	Cisco Aironet 1550 Access Point	1.3.6.1.4.1.9.1.1664
Autonomous AP	Cisco Aironet 1550 Series	Cisco Aironet 1550 Access Point	1.3.6.1.4.1.9.1.1665
Unified AP	Cisco 5212 Series Unified Access	Cisco 5212 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Points		
Unified AP	Cisco 5312 Series Unified Access Points	Cisco 5312 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.2
Unified AP	Cisco MIMO Series Unified Access Points	Cisco MIMO Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.3
Unified AP	Cisco UNKNOWN Series Unified Access Points	Cisco UNKNOWN Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.4
Unified AP	Cisco 1100 Series Unified Access Points	Cisco 1100 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.5
Unified AP	Cisco 1130 Series Unified Access Points	Cisco 1130 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.6
Unified AP	Cisco 1240 Series Unified Access Points	Cisco 1240 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.7
Unified AP	Cisco 1200 Series Unified Access Points	Cisco 1200 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.8
Unified AP	Cisco 1310 Series Unified Access Points	Cisco 1310 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.9
Unified AP	Cisco 1500 Series Unified Access Points	Cisco 1500 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.10
Unified AP	Cisco 1250 Series Unified Access Points	Cisco 1250 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.11
Unified AP	Cisco 1505 Series Unified Access Points	Cisco 1505 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.12
Unified AP	Cisco 3201 Series Unified Access Points	Cisco 3201 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.13
Unified AP	Cisco 1520 Series Unified Access Points	Cisco 1520 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.14
Unified AP	Cisco 801GN Series Unified Access Points	Cisco 801GN Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.15
Unified AP	Cisco 1140 Series Unified Access Points	Cisco 1140 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.16
Unified AP	Cisco 801AGN	Cisco 801AGN Unified	1.3.6.1.4.1.14179.2.2.1.1.22.17



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Series Unified Access Points	Access Point	
Unified AP	Cisco 3500I Series Unified Access Points	Cisco 3500I Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.18
Unified AP	Cisco 3500E Series Unified Access Points	Cisco 3500E Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.19
Unified AP	Cisco 1260 Series Unified Access Points	Cisco 1260 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.20
Unified AP	Cisco 1040 Series Unified Access Points	Cisco 1040 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.21
Unified AP	Cisco 1550 Series Unified Access Points	Cisco 1550 Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.22
Unified AP	Cisco 602I Series Unified Access Points	Cisco 602I Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.23
Unified AP	Cisco 3500P Series Unified Access Points	Cisco 3500P Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.24
Unified AP	Cisco 802GN Series Unified Access Points	Cisco 802GN Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.25
Unified AP	Cisco 802AGN Series Unified Access Points	Cisco 802AGN Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.26
Unified AP	Cisco 3600I Series Unified Access Points	Cisco 3600I Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.27
Unified AP	Cisco 3600E Series Unified Access Points	Cisco 3600E Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.28
Unified AP	Cisco 2600I Series Unified Access Points	Cisco 2600I Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.29
Unified AP	Cisco 2600E Series Unified Access Points	Cisco 2600E Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.30
Unified AP	Cisco 1600I Series Unified Access Points	Cisco 1600I Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.32
Unified AP	Cisco 1600E Series Unified Access Points	Cisco 1600E Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.33

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Unmanaged AP	Cisco Unmanaged Series Unified Access Points	Cisco Unmanaged Unified Access Point	1.3.6.1.4.1.14179.2.2.1.1.22.999
Wireless Controller	Cisco 2000 Series Wireless LAN Controllers	Cisco 2006 Wireless LAN Controller	1.3.6.1.4.1.14179.1.1.4.2
Wireless Controller	Cisco 2100 Series Wireless LAN Controllers	Cisco 2106 Wireless LAN Controller	1.3.6.1.4.1.9.1.828
Wireless Controller	Cisco 2100 Series Wireless LAN Controllers	Cisco 2106 Wireless LAN Controller	1.3.6.1.4.1.9.1.818
Wireless Controller	Cisco 4400 Series Wireless LAN Controllers	Cisco 4404 Wireless LAN Controller	1.3.6.1.4.1.14179.1.1.4.4
Wireless Controller	Cisco 4400 Series Wireless LAN Controllers	Cisco 4404 Wireless LAN Controller	1.3.6.1.4.1.14179.1.1.4.3
Wireless Controller	Cisco 4400 Series Wireless LAN Controllers	Cisco 4404 Wireless LAN Controller	1.3.6.1.4.1.14179.1.1.4.5
Wireless Controller	Cisco 4400 Series Wireless LAN Controllers	Cisco 4402 Wireless LAN Controller	1.3.6.1.4.1.9.1.747
Wireless Controller	Cisco WiSM Series Controller	Cisco WiSM Controller	1.3.6.1.4.1.14179.1.1.4.4
Wireless Controller	Cisco 5500 Series Wireless LAN Controllers	Cisco 5508 Wireless LAN Controller	1.3.6.1.4.1.9.1.1069
Wireless Controller	Cisco 2500 Series Wireless LAN Controller	Cisco 2504 Wireless LAN Controller	1.3.6.1.4.1.9.1.1279
Wireless Controller	Cisco Catalyst 6500 Series WLSM	Cisco WiSM2 Controller	1.3.6.1.4.1.9.1.1293
Wireless Controller	Cisco SRE 700 Series Wireless Controllers	Cisco SRE 700 Wireless Controller	1.3.6.1.4.1.9.1.1230
Wireless Controller	Cisco Flex 7500 Series Wireless LAN Controller	Cisco Flex 7510 Wireless LAN Controller	1.3.6.1.4.1.9.1.1295
Wireless Controller	Cisco 8500 Series Wireless LAN Controller	Cisco Flex 8500 Wireless LAN Controller	1.3.6.1.4.1.9.1.1615
Wireless Controller	Cisco VIRTUAL Series Wireless LAN Controller	Cisco Virtual Wireless LAN Controller	1.3.6.1.4.1.9.1.1631
Wireless	Cisco 5760 Series	Cisco 5760 Wireless LAN	1.3.6.1.4.1.9.1.1645

Controller	Wireless LAN Controller	Controller	
Cisco MXP Series	Cisco MXP Series	Cisco MXP 1000	1.3.6.1.4.1.9.1.mxp1000
Cisco MXP Series	Cisco MXP Series	Cisco MXP 150	1.3.6.1.4.1.9.1.mxp1000
Cisco MXP Series	Cisco MXP Series	Cisco MXP 1500	1.3.6.1.4.1.9.1.mxp1000
Cisco MXP Series	Cisco MXP Series	Cisco MXP 1700	1.3.6.1.4.1.9.1.mxp1000
Cisco MXP Series	Cisco MXP Series	Cisco MXP 3000	1.3.6.1.4.1.9.1.mxp1000
Cisco MXP Series	Cisco MXP Series	Cisco MXP 6000	1.3.6.1.4.1.9.1.mxp1000
Cisco MXP Series	Cisco MXP Series	Cisco MXP95Edge	1.3.6.1.4.1.5596.10.6.4.1
Cisco MXP Series	Cisco MXP Series	Cisco Profile 52 6000MXP	1.3.6.1.4.1.9.1.p52.6000mxp

## Third-party Endpoints

Device Series	Device Name	SystemObjectID
Polycom TelePresence System	Polycom	1.3.6.1.4.1.2684.1.1

## Third-party Network Devices

Device Series	Device Group	SystemObjectID
3Com	SuperStack TR Advanced RMON Agent Version F3.10.0	1.3.6.1.4.1.141.1.1.6010
3Com	DSSS Access Point	1.3.6.1.4.1.388.1.4
3Com	LinkBuilder FDDI	1.3.6.1.4.1.43.1.8.6
3Com	SuperStack II Hub 10	1.3.6.1.4.1.43.1.8.5
3Com	SuperStack II PS Hub 40	1.3.6.1.4.1.43.10.27.4.1
3Com	SuperStack TR Advanced RMON Agent Version F3.10.0	1.3.6.1.4.1.260.1.100
3Com	NA	1.3.6.1.4.1.43.1.4.11
3Com	NA	1.3.6.1.4.1.43.1.4.20
3Com	CoreBuilder-9000 (L3 Blade)	1.3.6.1.4.1.43.1.9.13.1.2.1
3Com	CoreBuilder-9000 (L3 Blade)	1.3.6.1.4.1.43.1.9.13.1.2.4
3Com	CoreBuilder-9000 (L3 Blade)	1.3.6.1.4.1.43.1.9.13.1.2.5
3Com	HiPer Access Router	1.3.6.1.4.1.429.2.19
3Com	3824	1.3.6.1.4.1.43.1.8.39

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

3Com	NA	1.3.6.1.4.1.114.1.3.3.2.3
3Com	NA	1.3.6.1.4.1.43.1.8.13
3Com	3Com Switch 4210 PWR 9-Port	1.3.6.1.4.1.43.1.16.4.3.46
3Com	3ComSuperStackII	1.3.6.1.4.1.43.10.27.4.1.2.1
3Com	5500G-EI 24-Port Sw	1.3.6.1.4.1.43.1.16.4.3.7
3Com	5500G-EI 48-Port	1.3.6.1.4.1.43.1.16.4.3.8
3Com	8810 10 Slot Chassis	1.3.6.1.4.1.43.1.16.4.3.40
3Com	8814 14 Slot Chassis	1.3.6.1.4.1.43.1.16.4.3.41
3Com	AccessBuilder 6218-JX	1.3.6.1.4.1.135.28
3Com	ATM Expansion Module	1.3.6.1.4.1.43.1.9.15.2
3Com	CoreBuilder 3500	1.3.6.1.4.1.114.2.1.1.1.1.9
3Com	CoreBuilder 3500	1.3.6.1.4.1.43.1.16.1.1.1.1
3Com	CoreBuilder 5000	1.3.6.1.4.1.49.2.3.24
3Com	CoreBuilder 6012	1.3.6.1.4.1.114.1.3.2.1.1.8
3Com	CoreBuilder-3900	1.3.6.1.4.1.43.1.16.2.2.1.2
3Com	Corebuilder7000 ATM	1.3.6.1.4.1.43.1.12.1
3Com	CoreBuilder7000 ATM	1.3.6.1.4.1.43.1.12.4
3Com	CoreBuilder-9000 (EME)	1.3.6.1.4.1.43.1.9.13.3.1
3Com	CoreBuilder-9000 (L2 Blade)	1.3.6.1.4.1.43.1.9.13.1.1.2
3Com	CoreBuilder-9000 (L2 Blade)	1.3.6.1.4.1.43.1.9.13.1.1.4
3Com	CoreBuilder-9000 (L2 Blade)	1.3.6.1.4.1.43.1.9.13.1.1.6
3Com	CoreBuilder-9000 (L2 Blade)	1.3.6.1.4.1.43.1.9.13.1.1.7
3Com	CoreBuilder-9000 (L2 Fabric)	1.3.6.1.4.1.43.1.9.13.1.3.2
3Com	CoreBuilder9000 ATM	1.3.6.1.4.1.43.1.9.13.2.2.1
3Com	CoreBuilder-9400	1.3.6.1.4.1.43.1.16.1.2.1.1
3Com	Lanplex 2500	1.3.6.1.4.1.114.1.3.3.1.7
3Com	Lanplex 2500	1.3.6.1.4.1.114.1.4.8.2.1.7
3Com	Lanplex 2500	1.3.6.1.4.1.8888.1.4.8.2.1.7
3Com	Office Connect	1.3.6.1.4.1.43.1.4.32
3Com	SuperStack 3	1.3.6.1.4.1.43.10.27.4.1.2.4
3Com	SuperStack 3900-24	1.3.6.1.4.1.43.1.16.2.2.1.1
3Com	SuperStack II Switch	1.3.6.1.4.1.43.1.8.24
3Com	SuperStack3	1.3.6.1.4.1.43.10.27.4.1.2.11
3Com	SuperStack3	1.3.6.1.4.1.43.10.27.4.1.2.5
3Com	SuperStackII 3000	1.3.6.1.4.1.43.1.8.22
3Com	SuperStackII 3300	1.3.6.1.4.1.43.10.27.4.1.2.2
3Com	SuperStackII Advanced RPS	1.3.6.1.4.1.43.1.13.1
3Com	SuperStackII Desktop Switch SW Version:2.10	1.3.6.1.4.1.43.1.8.29

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

3Com	SuperStackII Switch 4300	1.3.6.1.4.1.43.1.8.38
3Com	SuperStackII Switch 9300	1.3.6.1.4.1.43.1.16.2.2.2.1
A3com	4500	1.3.6.1.4.1.43.1.16.4.3.23
Acgate	Octel-200 Voice Mail System	1.3.6.1.4.1.662.1.1.7.28.4.0.0
Adtran	NetVanta 1224	1.3.6.1.4.1.664.1.525
Adtran	Smart16e_controller	1.3.6.1.4.1.664.1.34
Adtran	916	1.3.6.1.4.1.664.1.781
Adtran	616 IAD	1.3.6.1.4.1.664.1.493
Adtran	908E	1.3.6.1.4.1.664.1.835
Adtran	924E	1.3.6.1.4.1.664.1.816
Adtran	924eL1	1.3.6.1.4.1.664.1.996
Adtran	924eL2	1.3.6.1.4.1.664.1.988
Adtran	924eL2	1.3.6.1.4.1.664.1.994
Adtran	924eL2	1.3.6.1.4.1.664.1.997
Adtran	Atlas 830	1.3.6.1.4.1.664.1.430
Adtran	MX2800	1.3.6.1.4.1.664.1.198
Adtran	NetVanta 1224ST	1.3.6.1.4.1.664.1.526
Adtran	NetVanta 1224ST	1.3.6.1.4.1.664.1.742
Adtran	NetVanta 1224ST PoE	1.3.6.1.4.1.664.1.743
Adtran	Netvanta 3205	1.3.6.1.4.1.664.1.466
Adtran	Netvanta_1224STR	1.3.6.1.4.1.664.1.583
Adtran	Netvanta_3305	1.3.6.1.4.1.664.1.467
Adtran	Netvanta_4350	1.3.6.1.4.1.664.1.586
Adtran	Netvanta_5305	1.3.6.1.4.1.664.1.578
Adtran	TA3000	1.3.6.1.4.1.664.1.245
Adtran	1524ST	1.3.6.1.4.1.664.1.760
Adtran	T3SU-300-AC	1.3.6.1.4.1.664.1.170
Adva	FSP 2000	1.3.6.1.4.1.2544.1.7.1.1
Adva	FPS150CCf-825	1.3.6.1.4.1.18022.1.15
AFL	FNT3824	1.3.6.1.4.1.167.19
AI	Ai-198 (CLC) card	1.3.6.1.4.1.539.2.198
Aironet	BR500E	1.3.6.1.4.1.551.2.1.77
AKCP	sensorProbe8	1.3.6.1.4.1.3854.1.2.2.1.1
Alcatel	Alcatel Voice Device	1.3.6.1.4.1.637.64.4400.1.1.10
Alcatel	7700	1.3.6.1.4.1.6486.800.1.1.2.1.3.1.5
Alcatel	PizzaPort	1.3.6.1.4.1.800.3.1.1.7
Alcatel	7450 ESS	1.3.6.1.4.1.6527.1.6.1
Alcatel	7450 SR12	1.3.6.1.4.1.6527.1.6.3
Alcatel	7750 SR1	1.3.6.1.4.1.6527.1.3.1
Alcatel	7750 SR12	1.3.6.1.4.1.6527.1.3.3

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Alcatel	7750 SR7	1.3.6.1.4.1.6527.1.3.4
Alcatel	6600	1.3.6.1.4.1.6486.800.1.1.2.1.3.1.1
Alcatel	6700	1.3.6.1.4.1.6486.800.1.1.2.1.3.1.2
Alcatel	7800	1.3.6.1.4.1.6486.800.1.1.2.1.1.1.2
Alcatel	8800	1.3.6.1.4.1.6486.800.1.1.2.1.2.1.1
Alcatel	OMNI Switch	1.3.6.1.4.1.800.3.1.1.1
Alcatel	OmniAccess-408	1.3.6.1.4.1.800.3.1.1.11
Alcatel	OmniStack 1024	1.3.6.1.4.1.800.3.1.1.8
Alcatel	OmniStack 6024	1.3.6.1.4.1.800.3.1.1.9
Alcatel	OmniStack-LS-6200	1.3.6.1.4.1.6486.800.1.1.2.2.4.1.3
Alcatel	OmniSwitch	1.3.6.1.4.1.800.3.1.1.2
Alcatel	OmniSwitch 6248	1.3.6.1.4.1.6486.800.1.1.2.2.4.1.4
Alcatel	OmniSwitch 6624	1.3.6.1.4.1.6486.800.1.1.2.1.3.1.4
Alcatel	OmniSwitch 6850	1.3.6.1.4.1.6486.800.1.1.2.1.7.1.16
Alcatel	OmniSwitch 6850	1.3.6.1.4.1.6486.800.1.1.2.1.7.1.5
Alcatel	OmniSwitch-6848	1.3.6.1.4.1.6486.800.1.1.2.1.6.1.7
Alcatel	OmniSwitch-6850	1.3.6.1.4.1.6486.800.1.1.2.1.7.1.10
Alcatel	Omniswitch-6850-P48X	1.3.6.1.4.1.6486.800.1.1.2.1.7.1.8
Alcatel	OmniSwitch-7700	1.3.6.1.4.1.6486.800.1.1.2.1.1.1.1
Alcatel	Omniswitch-9700	1.3.6.1.4.1.6486.800.1.1.2.1.8.1.4
Alcatel	OS9800	1.3.6.1.4.1.6486.800.1.1.2.1.8.1.2
Alcatel	PR-2200 Gigabit Switch Router	1.3.6.1.4.1.3003.2.2.2.2
Alcatel	PR-5200 Gigabit Switch Router	1.3.6.1.4.1.3003.2.2.2.1
Allen Bradley PLC	1756-ENET	1.3.6.1.4.1.95.1.5
Allied Telesis	AT-RP48	1.3.6.1.4.1.207.1.14.65
Allied Telesyn	AT-3624TR	1.3.6.1.4.1.207.1.2.1
Allied Telesyn	AT8016FSC	1.3.6.1.4.1.207.1.4.79
Allied_Telesyn	AT-8724XL-DC NEBS	1.3.6.1.4.1.207.1.14.48
Allied_Telesyn	AT-8012M	1.3.6.1.4.1.207.1.4.86
Allied_Telesyn	AT-8724XL	1.3.6.1.4.1.207.1.14.30
Allied_Telesyn	AT-RP24i	1.3.6.1.4.1.207.1.14.20
Allied_Telesyn	Rapier 24i DC/NE	1.3.6.1.4.1.207.1.14.47
AlliedTelesis	8350GB	1.3.6.1.4.1.207.1.4.74
Alpha	AlphaServer 4100	1.3.6.1.4.1.36.2.15.13.6.2
Alteon	180e	1.3.6.1.4.1.1872.1.5
Alteon	ACEdirector 2	1.3.6.1.4.1.1872.1.4
Alteon	ACEdirector 3	1.3.6.1.4.1.1872.1.6
Alteon	Switched Firewall	1.3.6.1.4.1.1872.2.3.3.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Alvarion	Alvarion BreezeAccess	1.3.6.1.4.1.12394.4.3.1
Alvarion	BreezeACCESS VL	1.3.6.1.4.1.12394.4.1.4
Ancor	Fibre Channel Switch	1.3.6.1.4.1.1663.1.1.1.1.7
Anda	ER2200	1.3.6.1.4.1.3812.1.2.5
Anda	EE4000	1.3.6.1.4.1.3812.1.2.4
APC	NA	1.3.6.1.4.1.318.1.3.2.10
APC	NA	1.3.6.1.4.1.318.1.3.2.11
APC	NA	1.3.6.1.4.1.318.1.3.2.8
APC	NA	1.3.6.1.4.1.318.1.3.4.1
APC	AP605	1.3.6.1.4.1.318.1.3.2.9
APC	AP605	1.3.6.1.4.1.318.1.3.3.2
APC	AP605	1.3.6.1.4.1.318.1.3.5.1
APC	AP9605	1.3.6.1.4.1.318.1
APC	AP9606	1.3.6.1.4.1.318.1.3.2.12
APC	smartUPS	1.3.6.1.4.1.318.1.3.2
APC	Smart-UPS RT 5000 XL	1.3.6.1.4.1.318.1.3.2.13
APC	UPS	1.3.6.1.4.1.318.1.3.2.7
Applied Innovations	AI-194	1.3.6.1.4.1.539.2.194.7.4
Applied Innovations	AI193TX	1.3.6.1.4.1.539.2.193.7.10
Applied Innovations	AI196	1.3.6.1.4.1.539.2.196.7.2.1.0
Applied Innovations	AI294	1.3.6.1.4.1.629.1.1.7
Applied Innovations	AI296	1.3.6.1.4.1.539.2.7
Applied Innovations	AIscout2	1.3.6.1.4.1.539.2.18
Arrowpoint	CSS 11000	1.3.6.1.4.1.2467.4.2
ArrowPoint	CSS 11050	1.3.6.1.4.1.2467.4.3
Aruba	2400e	1.3.6.1.4.1.14823.1.1.7
Aruba	800	1.3.6.1.4.1.14823.1.1.3
Aruba	2400	1.3.6.1.4.1.14823.1.1.2
Aruba	3600	1.3.6.1.4.1.14823.1.1.17
Aruba	5000	1.3.6.1.4.1.14823.1.1.1
Aruba	6000	1.3.6.1.4.1.14823.1.1.4
Aruba	800-4	1.3.6.1.4.1.14823.1.1.9
Aruba	AP 61	1.3.6.1.4.1.14823.1.2.4
Aruba	AP 65	1.3.6.1.4.1.14823.1.2.14
ArubaNetworks	AP70	1.3.6.1.4.1.14823.1.2.5
ASCEND	NA	1.3.6.1.4.1.529.1.2.5
ASCEND	NA	1.3.6.1.4.1.529.1.2.6
ASCEND	NA	1.3.6.1.4.1.529.1.3.5
ASCEND	NA	1.3.6.1.4.1.529.1.3.7
ASCEND	Max 3000	1.3.6.1.4.1.529.1.2.9

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

ASCEND	Max-1800	1.3.6.1.4.1.529.1.2.2
ASCEND	Max-2000	1.3.6.1.4.1.529.1.2.3
Avaya	AP-8	1.3.6.1.4.1.11898.2.4.12
Avaya	s8700m	1.3.6.1.4.1.6889.1.8.1.49
Avaya	G700 Media Gateway	1.3.6.1.4.1.6889.1.9
Avaya	IP_OFFICE_401	1.3.6.1.4.1.6889.1.2.1.5.4
Avaya	IP_Phone_4610	1.3.6.1.4.1.6889.1.69.1.7
Avaya	IP_Phone_4612	1.3.6.1.4.1.6889.1.69.1.2
Avaya	IP_Phone_4612	1.3.6.1.4.1.6889.1.69.1.6
Avaya	IP_Phone_4624	1.3.6.1.4.1.6889.1.69.1.1
Avaya	IP600	1.3.6.1.4.1.1751.1.49
Avaya	ipOffice	1.3.6.1.4.1.6889.1.2.1.2.2
Avaya	S8300 Media Server	1.3.6.1.4.1.6889.1.8.1.50
Avaya	s8500	1.3.6.1.4.1.6889.1.5.1
Avaya	s8500	1.3.6.1.4.1.6889.1.8.1.52
Avaya	s8700i	1.3.6.1.4.1.6889.1.8.1.51
Avaya	Security Gateway Model 200 3DES ENCRYPTION	1.3.6.1.4.1.1866.1.14
Avaya	Security Gateway Model 203	1.3.6.1.4.1.1866.1.17
Avaya	Security Gateway Model 208 3DES ENCRYPTION (Standard),	1.3.6.1.4.1.1866.1.18
Avaya	SG5X Security Gateway	1.3.6.1.4.1.1866.1.12
Avaya	VPN Service Unit Model 100 3DES ENCRYPTION	1.3.6.1.4.1.1866.1.6
Avaya	VPN Service Unit Model 10000 3DES ENCRYPTION (Standard)	1.3.6.1.4.1.1866.1.11
Avaya	VSU-2000	1.3.6.1.4.1.1866.1.10
Avaya	VSU-5000	1.3.6.1.4.1.1866.1.7
Avaya	G250	1.3.6.1.4.1.6889.1.8.1.0.5
Avaya	G350	1.3.6.1.4.1.6889.1.45.103.2
Avaya	G250-DS1	1.3.6.1.4.1.6889.1.45.103.6
Avaya	P333R	1.3.6.1.4.1.81.17.2.13
Avaya	C360	1.3.6.1.4.1.81.17.1.19
Avaya	C363	1.3.6.1.4.1.81.17.2.17
Avaya	C460	1.3.6.1.4.1.6889.1.45.103.1
Avaya	Carrier	1.3.6.1.4.1.6889.1.8.1.0.2
Avaya	G250-ANALOG	1.3.6.1.4.1.6889.1.45.103.4
Avaya	G250-BRI	1.3.6.1.4.1.6889.1.45.103.5
Avaya	G250-DCP	1.3.6.1.4.1.6889.1.45.103.7



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Avaya	G350	1.3.6.1.4.1.6889.1.8.1.0.3
Avaya	G700	1.3.6.1.4.1.6889.1.8.1.0.4
Avaya	PortNetwork	1.3.6.1.4.1.6889.1.8.1.0.1
Avici	TSR IPriori	1.3.6.1.4.1.2474.2.1
Avocent Corporation	DSR2020	1.3.6.1.4.1.10418.7.1.10
Avocent Corporation	DSR4020	1.3.6.1.4.1.10418.7.1.11
Avocent Corporation	A2000R	1.3.6.1.4.1.10418.3.1.6
BATM	T4 Ethernet Switch	1.3.6.1.4.1.738.1.5.100.1.1.1
BATM	T5C 24T Routing Switch	1.3.6.1.4.1.738.1.5.100.1.1.7
Bay	BayStackVersion 1.0.0	1.3.6.1.4.1.930.1.3
Bay	Token Ring Bridge s3000Trb	1.3.6.1.4.1.45.1.3.8
Bay	5000	1.3.6.1.4.1.45.3.13.1
Bay	5000	1.3.6.1.4.1.45.3.21.1
Bay	2715SA TokenRing	1.3.6.1.4.1.45.3.19.1
Bay	2715-trNMM	1.3.6.1.4.1.45.3.9.1
Bay	281X-enetNMM	1.3.6.1.4.1.45.3.12.1
Bay	281XSA-enetNMM	1.3.6.1.4.1.45.3.14.1
Bay	291X-FDDI-NMM	1.3.6.1.4.1.45.3.10.1
Bay	3000-FDDI-NMM	1.3.6.1.4.1.45.3.2.3
Bay	3030-trNMM	1.3.6.1.4.1.45.3.3.2
Bay	5000-tokNMM	1.3.6.1.4.1.45.3.13.2
Bay	5310A/SA	1.3.6.1.4.1.45.3.17.1
Bay	5510 TokenRing	1.3.6.1.4.1.45.3.17.2
Bay	5616A/SA	1.3.6.1.4.1.45.3.13.6
Bay	5910S	1.3.6.1.4.1.45.3.13.3
Bay	BayStack 100	1.3.6.1.4.1.45.3.26.1
Bay	BayStack 200	1.3.6.1.4.1.45.3.31.1
Bay	BayStack 200	1.3.6.1.4.1.45.3.33.1
Bay	BayStack Ethernet	1.3.6.1.4.1.45.3.22.1
Bay	Ethernet NMM 281XSA	1.3.6.1.4.1.45.3.1
Bay	Ethernet NMM 331XS	1.3.6.1.4.1.45.3.2.1
Bay	NMM 331XA	1.3.6.1.4.1.45.3.27.1
Bay	NMM 331XA	1.3.6.1.4.1.45.3.3.1
Bay	Token Ring NNM 351X	1.3.6.1.4.1.45.3.2.2
Bay	Probe	1.3.6.1.4.1.442.1.1.1.9.2
Bay	RMON Probe	1.3.6.1.4.1.569.1.1.1.1
Bay	RMON Probe	1.3.6.1.4.1.569.1.1.1.3
Bay	RMON Probe	1.3.6.1.4.1.569.1.1.2.2
Bay	RMON Probe	1.3.6.1.4.1.569.1.1.3.2
Bay	RMON Probe	1.3.6.1.4.1.569.1.1.4.2

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Bay	RMON Probe	1.3.6.1.4.1.569.1.1.4.3
Bay	Router	1.3.6.1.4.1.18.3
Bay	28115	1.3.6.1.4.1.45.3.15.1
Bay	28200	1.3.6.1.4.1.45.3.28.1
Bay	58000	1.3.6.1.4.1.45.3.13.5
Bay	58000	1.3.6.1.4.1.45.3.17.3
Bay	310-24T Ethernet Switch	1.3.6.1.4.1.45.3.32.2
Bay	350-24T Ethernet Switch	1.3.6.1.4.1.45.3.30.2
Bay	450T	1.3.6.1.4.1.45.3.35.1
Bay	Accelar	1.3.6.1.4.1.2272.8
Bay	BayStack 303	1.3.6.1.4.1.45.3.32.1
Bay	BayStack 350T	1.3.6.1.4.1.45.3.30.1
Bay	BayStack 380-24T	1.3.6.1.4.1.45.3.45.1
Bay	BayStack 425-48T	1.3.6.1.4.1.45.3.57.1
Bay	BayStack 460-24T	1.3.6.1.4.1.45.3.49.1
Bay	BayStack 470-48T	1.3.6.1.4.1.45.3.46.1
Bay	BayStack 5510-48T	1.3.6.1.4.1.45.3.53.1
Bay	Centillion 100	1.3.6.1.4.1.930.1.1
Bay	Centillion 5000BH	1.3.6.1.4.1.930.1.4
Baystack	BayStack 470-24T	1.3.6.1.4.1.45.3.54.1
Blue Coat	Director	1.3.6.1.4.1.3417.1.2.0
Bluecoat	SG210	1.3.6.1.4.1.3417.1.1.26
Bluecoat	SG510	1.3.6.1.4.1.3417.1.1.27
Bluecoat	SG810	1.3.6.1.4.1.3417.1.1.25
Bluecoat	SG8100a	1.3.6.1.4.1.3417.1.1.28
Blue-Coat	SG 400	1.3.6.1.4.1.3417.1.1.22
Blue-Coat	SG 800	1.3.6.1.4.1.3417.1.1.20
Blue-Coat	SG-8000	1.3.6.1.4.1.3417.1.1.23
Bluesocket	Gateway	1.3.6.1.4.1.9967.100.5000.1
Brocade	FibreChannelSwitch	1.3.6.1.4.1.1588.2.1.1.55
Brocade	2800 Silkworm FC Switch	1.3.6.1.4.1.1588.2.1.1.2
Brocade	Fibre Channel Switch	1.3.6.1.4.1.1588.2.1.1.1
Brocade	FibreChannelSwitch	1.3.6.1.4.1.1588.2.1.1.10
Brocade	Silkworm 3900	1.3.6.1.4.1.1588.2.1.1.37
Bytemobile	BM Optimiser	1.3.6.1.4.1.8521.1.3
Cabletron	EMME	1.3.6.1.4.1.52.3.2.185
Cabletron	NA	1.3.6.1.4.1.52.3.9.3.4.42
Cabletron	NA	1.3.6.1.4.1.52.3.9.5.9.136
Cabletron	NA	1.3.6.1.4.1.52.3.9.5.9.68
Cabletron	ELH100	1.3.6.1.4.1.52.3.9.1.10.5

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cabletron	MicroMMAC	1.3.6.1.4.1.52.3.9.3.4.1
Cabletron	MicroMMAC	1.3.6.1.4.1.52.3.9.3.4.3
Cabletron	MMAC-44T	1.3.6.1.4.1.52.3.9.5.10.68
Cabletron	MRXi	1.3.6.1.4.1.52.3.2.65569
Cabletron	MRXi-MINIMMAC	1.3.6.1.4.1.52
Cabletron	SEHI	1.3.6.1.4.1.52.3.9.3.4.10
Cabletron	SEHI	1.3.6.1.4.1.52.3.9.3.4.11
Cabletron	SEHI	1.3.6.1.4.1.52.3.9.3.4.34
Cabletron	SEHI	1.3.6.1.4.1.52.3.9.3.4.35
Cabletron	TRMM	1.3.6.1.4.1.52.3.2.187
Cabletron	TRMM-2	1.3.6.1.4.1.52.3.2.180
Cabletron	TRMM-4	1.3.6.1.4.1.52.3.2.183
Cabletron	NA	1.3.6.1.4.1.52.3.9.32.9.8
Cabletron	2E253-49R	1.3.6.1.4.1.52.3.9.3.4.82
Cabletron	2E42-27R	1.3.6.1.4.1.52.3.9.3.4.58
Cabletron	2E42-27RDC	1.3.6.1.4.1.52.3.9.3.4.65
Cabletron	2E48-27R	1.3.6.1.4.1.52.3.9.3.4.68
Cabletron	6E122-26	1.3.6.1.4.1.52.3.9.20.2.2
Cabletron	6E123-26	1.3.6.1.4.1.52.3.9.20.2.7
Cabletron	6E128-26	1.3.6.1.4.1.52.3.9.20.2.12
Cabletron	6E132-25	1.3.6.1.4.1.52.3.9.20.2.3
Cabletron	6E133-25	1.3.6.1.4.1.52.3.9.20.2.8
Cabletron	6E138-25	1.3.6.1.4.1.52.3.9.20.2.13
Cabletron	6E233-49	1.3.6.1.4.1.52.3.9.20.2.23
Cabletron	6H122-08	1.3.6.1.4.1.52.3.9.20.2.4
Cabletron	6H122-16	1.3.6.1.4.1.52.3.9.20.2.18
Cabletron	6H128_08	1.3.6.1.4.1.52.3.9.20.2.16
Cabletron	6H133_37	1.3.6.1.4.1.52.3.9.20.2.19
Cabletron	6H202-24	1.3.6.1.4.1.52.3.9.20.2.20
Cabletron	6H252-17	1.3.6.1.4.1.52.3.9.20.2.21
Cabletron	6H262-18	1.3.6.1.4.1.52.3.9.20.2.28
Cabletron	9E106-6	1.3.6.1.4.1.52.3.9.32.5.11
Cabletron	9E128-01	1.3.6.1.4.1.52.3.9.32.5.10
Cabletron	9E132-15	1.3.6.1.4.1.52.3.9.32.5.8
Cabletron	9E138-12	1.3.6.1.4.1.52.3.9.32.5.12
Cabletron	9E423-36	1.3.6.1.4.1.52.3.9.32.9.16
Cabletron	9E428-36	1.3.6.1.4.1.52.3.9.32.9.11
Cabletron	9F120-08	1.3.6.1.4.1.52.3.9.32.6.2
Cabletron	9F241-12	1.3.6.1.4.1.52.3.9.32.6.4
Cabletron	9F426-02	1.3.6.1.4.1.52.3.9.32.9.7

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Cabletron	9F426-03	1.3.6.1.4.1.52.3.9.32.9.14
Cabletron	9G536-04	1.3.6.1.4.1.52.3.9.32.13.7
Cabletron	9H421p12	1.3.6.1.4.1.52.3.9.32.9.15
Cabletron	9H422-12	1.3.6.1.4.1.52.3.9.32.9.9
Cabletron	9H423-26	1.3.6.1.4.1.52.3.9.32.9.23
Cabletron	9H532-18	1.3.6.1.4.1.52.3.9.32.13.1
Cabletron	9H532-24	1.3.6.1.4.1.52.3.9.13.8
Cabletron	9H532-24	1.3.6.1.4.1.52.3.9.32.13.8
Cabletron	ELM	1.3.6.1.4.1.52.3.9.32.5.1
Cabletron	ELM	1.3.6.1.4.1.52.3.9.32.5.3
Cabletron	ELS100	1.3.6.1.4.1.52.3.9.1.10.7
Cabletron	ELS10-26	1.3.6.1.4.1.97.5.7
Cabletron	EMM-E6	1.3.6.1.4.1.52.3.9.3.5.1
Cabletron	ESX-1320	1.3.6.1.4.1.52.3.9.3.4.48
Cabletron	ESXMIM	1.3.6.1.4.1.52.3.2.186
Cabletron	ESXMIM	1.3.6.1.4.1.52.3.2.191
Cabletron	FDDI-Enet	1.3.6.1.4.1.52.3.2.34
Cabletron	mt2H252p25R	1.3.6.1.4.1.52.3.9.3.4.80
Cabletron	Smart Chassis 6000	1.3.6.1.4.1.52.3.9.20.1.1
Cabletron	SSR	1.3.6.1.4.1.52.3.9.20.1.4
Cabletron	SSR 8000	1.3.6.1.4.1.52.3.9.20.1.3
Cabletron	SSR-2000	1.3.6.1.4.1.52.3.9.33.1.1
CacheFlow	500	1.3.6.1.4.1.3417.1.1.8
CacheFlow	600	1.3.6.1.4.1.3417.1.1.13
CacheFlow	700	1.3.6.1.4.1.3417.1.1.16
CacheFlow	CA-6000	1.3.6.1.4.1.3417.1.1.11
CanogaPerkins	8835 Fiber Optic Repeater	1.3.6.1.4.1.919.1.1.2.2
CanogaPerkins	9135	1.3.6.1.4.1.919.1.3.1
CasheFlow	Cashe OS Version:2.2.16	1.3.6.1.4.1.3417.1.1.7
CheckPoint	NET-SNMP HPUX9	1.3.6.1.4.1.8072.3.2.1
CheckPoint	NET SNMP HPUX10	1.3.6.1.4.1.8072.3.2.6
CheckPoint	NET-SNMP BSD	1.3.6.1.4.1.8072.3.2.11
CheckPoint	NET-SNMP FREEBSD	1.3.6.1.4.1.8072.3.2.8
CheckPoint	NET-SNMP HPUX11	1.3.6.1.4.1.8072.3.2.14
CheckPoint	NET-SNMP IRIX	1.3.6.1.4.1.8072.3.2.9
CheckPoint	NET-SNMP NETBSD	1.3.6.1.4.1.8072.3.2.7
CheckPoint	NET-SNMP SUNOS4	1.3.6.1.4.1.8072.3.2.2
CheckPoint	NET-SNMP ULTRIX	1.3.6.1.4.1.8072.3.2.5
CheckPoint	NET-SNMP UNKNOWN	1.3.6.1.4.1.8072.3.2.255
CheckPoint	NET-SNMP WIN32	1.3.6.1.4.1.8072.3.2.13

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

CheckPoint	NET-SNMPOPENBSD	1.3.6.1.4.1.8072.3.2.12
CheckPoint	NET-SNMP-OSF	1.3.6.1.4.1.8072.3.2.4
Ciena	CN 2000	1.3.6.1.4.1.6782.1.1.1.1.7
Ciena	CN2000	1.3.6.1.4.1.6782.1.1.1.1.5
Ciena	CN2000	1.3.6.1.4.1.7737.5.2.2.6
Ciena	CN2600	1.3.6.1.4.1.5672.1.2.1
Cipheroptics	SG100 Gateway	1.3.6.1.4.1.8799.1.1
Citrix	Netscaler	1.3.6.1.4.1.5951.1
Clarent	SDM-8200	1.3.6.1.4.1.727.7.1.82000
CNT	UltraNet Storage Director	1.3.6.1.4.1.333.2
Codex	Motorola 6520	1.3.6.1.4.1.449.2.1.6520
Codex	Motorola 6560	1.3.6.1.4.1.449.2.1.6560
Codex	Motorola VANGUARD 200	1.3.6.1.4.1.449.2.1.200
Codex	Motorola VANGUARD 300	1.3.6.1.4.1.449.2.1.300
Codex	Motorola VANGUARD 320	1.3.6.1.4.1.449.2.1.320
Codex	Motorola VANGUARD 340	1.3.6.1.4.1.449.2.1.0
Codex	Motorola VANGUARD 340	1.3.6.1.4.1.449.2.1.340
Codex	Motorola VANGUARD 7310	1.3.6.1.4.1.449.2.1.7310
Compaq	IP Console Switch	1.3.6.1.4.1.232.160.1.2
Compaq	Integrated-Lights-Out	1.3.6.1.4.1.311.1.1.3.1.3
ComPoint	Dv460	1.3.6.1.4.1.4280
Cosine	IPSX9500	1.3.6.1.4.1.3085.1.1.2
Crossbeam	X40 Firewall/Router	1.3.6.1.4.1.6848.1.2
CrossRoads	4450 Bridge	1.3.6.1.4.1.2512.1.1
Cyclades	AlterPath ACS48	1.3.6.1.4.1.2925.4
Cylink	Frame Encryptor	1.3.6.1.4.1.687
Cylink	SNMP Agent	1.3.6.1.4.1.687.2.10
D.N.A.SNMP	NA	1.3.6.1.4.1.193.20.1
DEC	DECbridge	1.3.6.1.4.1.36.2.15.3.6.10
DEC	AlphaServer 4100 5/30	1.3.6.1.4.1.36.2.15.2.3
DEC	DECconcentrator 500	1.3.6.1.4.1.36.2.15.5.1
DEC	DEChub 900	1.3.6.1.4.1.36.2.15.10.3.1
DEC	DECrepeater 90TS	1.3.6.1.4.1.36.2.15.9.8.1
DEC	DECswitch 900EF	1.3.6.1.4.1.36.2.15.3.11.1
DEC	DECswitch 900EF	1.3.6.1.4.1.36.2.15.3.7.1
DEC	GIGAswitch	1.3.6.1.4.1.36.2.15.3.3
DEC	VNswitch900EF-MM	1.3.6.1.4.1.36.2.15.11.13.1
DEC	DECserver 700-08	1.3.6.1.4.1.36.2.15.5.1.3
DEC	DECserver 700-16	1.3.6.1.4.1.36.2.15.6.6.1
DEC	DECserver 900TM	1.3.6.1.4.1.36.2.15.6.7.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

DEC	DECServer716	1.3.6.1.4.1.6200.1.2.3
DEC	DECserver90M	1.3.6.1.4.1.36.2.15.6.4.1
DEC/Entrasys	RoamAbout Access Point	1.3.6.1.4.1.36.2.15.3.9.1
DefensePro	DefensePro	1.3.6.1.4.1.89.1.1.62.16
Dell	Dell PowerConnect 3348	1.3.6.1.4.1.674.10895.3003
Dell	DELL PowerConnect 3448P	1.3.6.1.4.1.674.10895.3009
Dell	Ethernet Switch PowerConnect3004	1.3.6.1.4.1.674.10895.3004
Dell	powerconnect 3000	1.3.6.1.4.1.674.10895.3000
Dell	Powerconnect 3024	1.3.6.1.4.1.674.10895.1
Dell	PowerConnect 3424P	1.3.6.1.4.1.674.10895.3008
Dell	PowerConnect 3448	1.3.6.1.4.1.674.10895.3007
Dell	PowerConnect3248	1.3.6.1.4.1.674.10895.3
Dell	PowerConnect3424	1.3.6.1.4.1.674.10895.3006
Dell	PowerConnect5224	1.3.6.1.4.1.674.10895.4
Digilink	DL 3100	1.3.6.1.4.1.300.1
D-Link	DES-3526	1.3.6.1.4.1.171.10.64.1
D-Link	DES-5200	1.3.6.1.4.1.171.10.9.5
Eastern-Research	DNX-11	1.3.6.1.4.1.644.2.4
eComServer	NetWatch	1.3.6.1.4.1.1764.1
Edgewater Networks	EM800 POE Switch	1.3.6.1.4.1.19139.10.5
Electronics-For Imaging-Inc.	EFI Fiery Color Printer Server	1.3.6.1.4.1.2136.2.2
Electronics-For Imaging-Inc.	EFI Fiery Server X12	1.3.6.1.4.1.2136.2.11.2
Electronics-For Imaging-Inc.	EFI Fiery Server ZX	1.3.6.1.4.1.2136.2.6.1
EMC	Celerra	1.3.6.1.4.1.1139
EMC	Clarion IP4700 File Server	1.3.6.1.4.1.106.1.4.1
EMC	EDL710R0275	1.3.6.1.4.1.7368.5.10
Emerson	CHLORIDE EDR2400	1.3.6.1.4.1.1364.1?
Enterasys	B2G124-24	1.3.6.1.4.1.5624.2.2.314
Enterasys	B2H124-48	1.3.6.1.4.1.5624.2.2.317
EnterasysNetworks	5H102-48	1.3.6.1.4.1.5624.2.1.18
EnterasysNetworks	6H302-48	1.3.6.1.4.1.5624.2.1.3
EnterasysNetworks	VH-2402S/S2	1.3.6.1.4.1.5624.2.1.11
EnterasysNetworks	XP 2400	1.3.6.1.4.1.5624.2.1.42
Expand	Accelerator 4800	1.3.6.1.4.1.3405.3
Extreme	Alpine3804	1.3.6.1.4.1.1916.2.20
Extreme	Alpine3808	1.3.6.1.4.1.1916.2.17
Extreme	BlackDiamond6804	1.3.6.1.4.1.1916.2.27

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Extreme	BlackDiamond6808	1.3.6.1.4.1.1916.2.11
Extreme	BlackDiamond6816	1.3.6.1.4.1.1916.2.24
Extreme	BlackDiamond8810	1.3.6.1.4.1.1916.2.62
Extreme	Summit 48i	1.3.6.1.4.1.1916.2.16
Extreme	Summit 48i	1.3.6.1.4.1.1916.2.54
Extreme	Summit 5i	1.3.6.1.4.1.1916.2.15
Extreme	Summit 5iTX	1.3.6.1.4.1.1916.2.22
Extreme	Summit Black Diamond 10808	1.3.6.1.4.1.1916.2.56
Extreme	Summit X406	1.3.6.1.4.1.1916.2.71
Extreme	Summit X450	1.3.6.1.4.1.1916.2.66
Extreme	Summit24	1.3.6.1.4.1.1916.2.7
Extreme	Summit24e3	1.3.6.1.4.1.1916.2.25
Extreme	Summit4	1.3.6.1.4.1.1916.2.4
Extreme	Summit48	1.3.6.1.4.1.1916.2.6
Extreme	Summit48i1u	1.3.6.1.4.1.1916.2.28
Extreme	Summit4fx	1.3.6.1.4.1.1916.2.5
Extreme	Summit7iSX	1.3.6.1.4.1.1916.2.12
Extreme	Summit7iTx	1.3.6.1.4.1.1916.2.13
Extreme	SummitX450-48t	1.3.6.1.4.1.1916.2.76
Extreme	SUMMITX450A-24TDC	1.3.6.1.4.1.1916.2.80
Extreme	SW5450	1.3.6.1.4.1.232.111.1.5
F5	3600 LTM ASM	1.3.6.1.4.1.3375.2.1.3.4.21
F5	BIG-IP	1.3.6.1.4.1.3375.2.1.3.4.4
F5	BIG-IP	1.3.6.1.4.1.3375.2.1.3.4.6
F5	BIG-IP 6400	1.3.6.1.4.1.3375.2.1.3.4.10
F5 Networks	BIG-IP	1.3.6.1.4.1.3375.1.1
F5Networks	BIG-IP	1.3.6.1.4.1.3375.2
F5Networks	BIG-IP	1.3.6.1.4.1.3375.2.1.3.4.11
FibroLAN	Metrostar	1.3.6.1.4.1.4467.100.100.1
First Virtual	Multimedia Switch	1.3.6.1.4.1.1296.1.1
Flowpoint	Efficient 5871 IDSL Route	1.3.6.1.4.1.1548.5871.0
Fluke	Networks OptiView Integrated Network Analyzer	1.3.6.1.4.1.1226.1.3.1
Force 10	S25DC	1.3.6.1.4.1.6027.1.3.9
Force10	E600	1.3.6.1.4.1.6027.1.1.4
Force10	Force10	1.3.6.1.4.1.6027.1.1
Force10	S50V	1.3.6.1.4.1.6027.1.3.3
Force10Networks	E600	1.3.6.1.4.1.6027.1.4
Fore	6k7k8k	1.3.6.1.4.1.326.2.6.1.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Fore	ASN9000	1.3.6.1.4.1.326.2.6.1.3
Fore	ASX1000	1.3.6.1.4.1.326.2.2
Fore	ES2810	1.3.6.1.4.1.326.2.10.1
Fore	ES3810	1.3.6.1.4.1.326.2.3
Fore	ForeRunner ASX-200BX	1.3.6.1.4.1.326.2.2.5
Fortigate	FWDB	1.3.6.1.4.1.12356.3001
Foundry	WXR09502d	1.3.6.1.4.1.1991.1.3.47.8.2
Foundry	RF Probe	1.3.6.1.4.1.1991.1.7.1.1
Foundry	AP IP150	1.3.6.1.4.1.1991.1.6.2.1.2
Foundry	IronRouter	1.3.6.1.4.1.1991.1.3.10.1
Foundry	NetIron MLX	1.3.6.1.4.1.1991.1.3.44.1.2
Foundry	NetIron MLX	1.3.6.1.4.1.1991.1.3.44.2.2
Foundry	NetIron XMR	1.3.6.1.4.1.1991.1.3.41.3.2
Foundry	NetIronMLX	1.3.6.1.4.1.1991.1.3.44.3.2
Foundry	Wireless AP	1.3.6.1.4.1.1991.1.6.2.1.1
Foundry	4802	1.3.6.1.4.1.1991.1.3.21.1
Foundry	4802	1.3.6.1.4.1.1991.1.3.21.2
Foundry	4802	1.3.6.1.4.1.1991.1.3.21.3
Foundry	BigIron	1.3.6.1.4.1.1991.1.3.11.1
Foundry	BigIron	1.3.6.1.4.1.1991.1.3.24.2
Foundry	BigIron	1.3.6.1.4.1.1991.1.3.7.1
Foundry	BigIron 15000	1.3.6.1.4.1.1991.1.3.14.2
Foundry	BigIron MG8	1.3.6.1.4.1.1991.1.3.32.2
Foundry	BigIron15000	1.3.6.1.4.1.1991.1.3.14.1
Foundry	BigIron15000	1.3.6.1.4.1.1991.1.3.14.3
Foundry	BigIron4000	1.3.6.1.4.1.1991.1.3.6.1
Foundry	BigIron4000	1.3.6.1.4.1.1991.1.3.6.2
Foundry	BigIron4000	1.3.6.1.4.1.1991.1.3.6.3
Foundry	BigIron8000	1.3.6.1.4.1.1991.1.3.7.3
Foundry	BIR06616	1.3.6.1.4.1.1991.1.2
Foundry	EdgeIron 4802CF	1.3.6.1.4.1.1991.1.5.1.1.4.3.1
Foundry	EdgeIron 4802F	1.3.6.1.4.1.1991.1.4.1.1.5.100.1.1.1.1
Foundry	Fast Iron BackBone	1.3.6.1.4.1.1991.1.3.23.1
Foundry	FastIron	1.3.6.1.4.1.1991.1.3.1.1
Foundry	FastIron	1.3.6.1.4.1.1991.1.3.1.2
Foundry	FastIron 1500	1.3.6.1.4.1.1991.1.3.24.1
Foundry	FastIron 400	1.3.6.1.4.1.1991.1.3.22.1
Foundry	FastIron 800	1.3.6.1.4.1.1991.1.3.23.2
Foundry	FastIron Edge 2402	1.3.6.1.4.1.1991.1.3.25.1
Foundry	FastIron Edge 2402CF	1.3.6.1.4.1.1991.1.5.1.1.4.2.1



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Foundry	FastIron Edge 4801G	1.3.6.1.4.1.1991.1.3.34.2.2.1.1
Foundry	FastIron Edge 4802	1.3.6.1.4.1.1991.1.3.26.1
Foundry	FastIron Edge 4802F	1.3.6.1.4.1.738.1.5.100.1.1.222.1
Foundry	FastIron Edge 9604	1.3.6.1.4.1.1991.1.3.27.1
Foundry	FastIron FES12gcf	1.3.6.1.4.1.1991.1.3.28.1
Foundry	FastIron FESX424+2XG	1.3.6.1.4.1.1991.1.3.34.1.3.1.1
Foundry	FastIron FESX424F	1.3.6.1.4.1.1991.1.3.34.3.1.2.2
Foundry	FastIron FESX424F	1.3.6.1.4.1.1991.1.3.34.3.1.1.1
Foundry	FastIron GS624P-POE	1.3.6.1.4.1.1991.1.3.45.1.3.1.1
Foundry	FastIron GS648P-POE	1.3.6.1.4.1.1991.1.3.45.2.2.1.1
Foundry	FastIron SuperX	1.3.6.1.4.1.1991.1.3.36.1.1
Foundry	FastIron SX1600	1.3.6.1.4.1.1991.1.3.36.5.1
Foundry	FastIron2	1.3.6.1.4.1.1991.1.3.8.1
Foundry	FastIron2	1.3.6.1.4.1.1991.1.3.8.2
Foundry	FastIron2GC	1.3.6.1.4.1.1991.1.3.12.1
Foundry	FastIron2GC	1.3.6.1.4.1.1991.1.3.12.2
Foundry	FastIron2Plus	1.3.6.1.4.1.1991.1.3.9.1
Foundry	FastIron2Plus	1.3.6.1.4.1.1991.1.3.9.2
Foundry	FastIron2PlusGC	1.3.6.1.4.1.1991.1.3.13.1
Foundry	FastIron2PlusGC	1.3.6.1.4.1.1991.1.3.13.2
Foundry	FastIron3	1.3.6.1.4.1.1991.1.3.16.1
Foundry	FastIron3	1.3.6.1.4.1.1991.1.3.16.2
Foundry	FastIron3GC	1.3.6.1.4.1.1991.1.3.17.1
Foundry	FastIron3GC	1.3.6.1.4.1.1991.1.3.17.2
Foundry	FES12GCF-PREM	1.3.6.1.4.1.1991.1.3.28.2
Foundry	FES2402-ILP	1.3.6.1.4.1.1991.1.3.29.1
Foundry	FES4802	1.3.6.1.4.1.1991.1.3.26.2
Foundry	FES4802-ILP	1.3.6.1.4.1.1991.1.3.30.1
Foundry	FES9604-PREM	1.3.6.1.4.1.1991.1.3.27.2
Foundry	FESX-424-PREM	1.3.6.1.4.1.1991.1.3.34.1.1.1.2
Foundry	FESX-424-PREM	1.3.6.1.4.1.1991.1.3.40.3.2
Foundry	FESX448	1.3.6.1.4.1.1991.1.3.34.2.3.1.2
Foundry	FESX448-PREM	1.3.6.1.4.1.1991.1.3.34.2.1.1.2
Foundry	FGS648P	1.3.6.1.4.1.1991.1.3.45.2.1.1.1
Foundry	FLS Switch	1.3.6.1.4.1.1991.1.3.46.2.1.1.1
Foundry	FWSX	1.3.6.1.4.1.1991.1.3.35.1.1.1.1
Foundry	IronRouter	1.3.6.1.4.1.1991.1.3.7.2
Foundry	IronWare	1.3.6.1.4.1.1991.1.3.47.7.2
Foundry	NetIron	1.3.6.1.4.1.1991.1.3.2.1
Foundry	NetIron1500	1.3.6.1.4.1.1991.1.3.15.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Foundry	ServerIron	1.3.6.1.4.1.1991.1.1
Foundry	ServerIron	1.3.6.1.4.1.1991.1.3.3.1
Foundry	ServerIron	1.3.6.1.4.1.1991.1.3.3.2
Foundry	ServerIron	1.3.6.1.4.1.1991.1.3.3.3
Foundry	ServerIron1500	1.3.6.1.4.1.1991.1.3.20.1
Foundry	ServerIron1500	1.3.6.1.4.1.1991.1.3.20.2
Foundry	ServerIron400	1.3.6.1.4.1.1991.1.3.18.1
Foundry	ServerIron400	1.3.6.1.4.1.1991.1.3.18.2
Foundry	ServerIron800	1.3.6.1.4.1.1991.1.3.19.1
Foundry	ServerIron800	1.3.6.1.4.1.1991.1.3.19.2
Foundry	SuperX 800-PREM	1.3.6.1.4.1.1991.1.3.36.4.2
Foundry	SX800	1.3.6.1.4.1.1991.1.3.36.3.1
Foundry	TurboIron	1.3.6.1.4.1.1991.1.3.4.1
Foundry	TurboIron	1.3.6.1.4.1.1991.1.3.4.2
Foundry	TurboIron	1.3.6.1.4.1.1991.1.3.5.4
Foundry	TurboIron8	1.3.6.1.4.1.1991.1.3.5.1
Foundry	TurboIron8	1.3.6.1.4.1.1991.1.3.5.2
Foundry	TurboIron8	1.3.6.1.4.1.1991.1.3.5.3
Foundry Networks	FastIron SX 800	1.3.6.1.4.1.1991.1.3.36.3.3
Frontier-Software Development	CiscoSwitchProbe	1.3.6.1.4.1.141.1.1.8150
Frontier-Software Development	CiscoSwitchProbe	1.3.6.1.4.1.141.1.1.8700
Frontier-Software Development	tr-4m	1.3.6.1.4.1.141.1.1.6020
FW	FW Rev 1.97	1.3.6.1.4.1.321.1.1.0
Gandalf	Ethernet Bridge	1.3.6.1.4.1.64
Ganymede	NA	1.3.6.1.4.1.2297.3.1
General_DataComm	SNMP553SD	1.3.6.1.4.1.498.6.3
General_DataComm	AI 294 Card	1.3.6.1.4.1.498.23.1
General_DataComm	SpectraComm_Manager	1.3.6.1.4.1.498.3.6
Hatteras_Networks	HN400	1.3.6.1.4.1.8550.1.1.1.1
HDS	NA	1.3.6.1.4.1.3.1.1
Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.10.1.1
Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.10.1.2
Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.2.5
Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.7.6.3.2
Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.7.6.5
Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.7.6.5.2
Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.7.6.7.2.1
Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.9.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Hewlett-Packard	NA	1.3.6.1.4.1.11.2.3.9.8.1.2
Hewlett-Packard	NA	1.3.6.1.4.1.11.5.5.1.1
Hewlett-Packard	NA	1.3.6.1.4.1.368.1.2
Hewlett-Packard	HP ETHERNET MULTI-ENVIRONMENT ROM A.05	1.3.6.1.4.1.11.2.3.9.2
Hewlett-Packard	HPJ3188A	1.3.6.1.4.1.11.2.3.7.5.19
Hewlett-Packard	J4093A ProCurve	1.3.6.1.4.1.11.2.3.7.11.11
Hewlett-Packard	J4812A ProCurve Switch	1.3.6.1.4.1.11.2.3.7.11.18
Hewlett-Packard	J4813A ProCurve Switch 2524	1.3.6.1.4.1.11.2.3.7.11.19
Hewlett-Packard	J4887A ProCurve Switch 4104GL	1.3.6.1.4.1.11.2.3.7.11.27
Hewlett-Packard	J9470A ProCurve Switch 3500-24	1.3.6.1.4.1.11.2.3.7.11.111
Hirschmann	RS20-0800M2M2SDAEHH	1.3.6.1.4.1.248.14.10.40
Hitachi	9900 Raid Array	1.3.6.1.4.1.116.3.11.4.1.1
HP	Blade	1.3.6.1.4.1.11.5.7.5.1
HP	HP4GbVCFCModule	1.3.6.1.4.1.3873.1.7
HP	HPDevice	1.3.6.1.4.1.11.5.7.3.2
HP	HPUX-10.20	1.3.6.1.4.1.11.2.3.2.3
HP	KVM 4x1x16	1.3.6.1.4.1.232.160.1.4
HP	5412 96G	1.3.6.1.4.1.11.2.3.7.11.51
HP	BL p-class C-GbE2 Interconnect Switch	1.3.6.1.4.1.11.2.3.7.11.33.1.1.1
HP	HP J4120A ProCurve Switch 1600M	1.3.6.1.4.1.11.2.3.7.11.8
HP	HP J4865A ProCurve Switch 4108GL	1.3.6.1.4.1.11.2.3.7.11.23
HP	J4110A ProCurve Switch 8000M	1.3.6.1.4.1.11.2.3.7.11.7
HP	J4121A ProCurve Switch 4000M	1.3.6.1.4.1.11.2.3.7.11.9
HP	J4819A (ProCurve Switch 5308XL)	1.3.6.1.4.1.11.2.3.7.11.17
HP	J4899B ProCurve Switch 2650	1.3.6.1.4.1.11.2.3.7.11.44
HP	J8164A ProCurve Switch 2626-PWR	1.3.6.1.4.1.11.2.3.7.11.36
HP	J8693A ProCurve Switch 3500yl-48G	1.3.6.1.4.1.11.2.3.7.11.59
HP	Procurve 2650-PWR	1.3.6.1.4.1.11.2.3.7.11.35
HP	Procurve J4093A	1.3.6.1.4.1.11.2.3.7.11.31

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

HP	ProCurve J4900A Switch 2626	1.3.6.1.4.1.11.2.3.7.11.34
HP	ProLiant BL e-Class C-GbE	1.3.6.1.4.1.232.161.1.36
HP	ProLiant BL p-Class GbE2	1.3.6.1.4.1.232.161.1.37
Huawei	AR-18-20S	1.3.6.1.4.1.2011.10.1.53
Huawei	AR26	1.3.6.1.4.1.2011.2.45
Huawei	AR28	1.3.6.1.4.1.2011.1.1.1.12830
Huawei	AR28-09	1.3.6.1.4.1.2011.1.1.1.12809
Huawei	AR28-31	1.3.6.1.4.1.2011.1.1.1.12831
Huawei	Huawei Versatile Routing	1.3.6.1.4.1.2011.2.29
Huawei	MA5600T	1.3.6.1.4.1.2011.2.80
Huawei	MA5600T	1.3.6.1.4.1.2011.2.80.8
Huawei	NE08E	1.3.6.1.4.1.2011.2.26.2
Huawei	NE16E	1.3.6.1.4.1.2011.2.26.1
Huawei	NE20	1.3.6.1.4.1.2011.2.48
Huawei	NE40e	1.3.6.1.4.1.2011.2.62.2.5
Huawei	NE80a	1.3.6.1.4.1.2011.2.17
Huawei	NE80E	1.3.6.1.4.1.2011.2.62.2.2
Huawei	Quidway S3528P	1.3.6.1.4.1.2011.2.23.40
Huawei	S3526EF	1.3.6.1.4.1.2011.2.23.28
Huawei	S3552F	1.3.6.1.4.1.2011.2.23.67
Huawei	S8505	1.3.6.1.4.1.2011.2.23.32
Hubbell-Pulsecom	DSLAM	1.3.6.1.4.1.2218.1.5
Hughes	DNCC	1.3.6.1.4.1.303.3.3.12.1.1.18
Hughes	webACS	1.3.6.1.4.1.303.3.3.12.1.1.7
Hypercom Corporation	IN-tact 1101	1.3.6.1.4.1.626.3.1
IBM	NA	1.3.6.1.4.1.2.6.118.2
IBM	BladeCenter Management Mo	1.3.6.1.4.1.2.6.158.3
IBM	IBM InfoPrint 20	1.3.6.1.4.1.2.3.25
IBM	IBM InfoPrint 40	1.3.6.1.4.1.2.3.48
IBM	IBM OS/400 V4R4M0	1.3.6.1.4.1.2.6.11
IBM	IBM PowerPC Personal Computer	1.3.6.1.4.1.2.3.1.2.1.1.3
IBM	Infoprint 32	1.3.6.1.4.1.2.3.34
IBM	InRange	1.3.6.1.4.1.2.3.1
IBM	Network Printer 24	1.3.6.1.4.1.2.3.6
IBM	Oce digital copier	1.3.6.1.4.1.2.6.46
IBM	RISC/6000	1.3.6.1.4.1.2.3.1.2.1.1.2
IBM	zSeries	1.3.6.1.4.1.2.3.13
IBM	mdl 13 s/n 23t7677	1.3.6.1.4.1.2.6.15

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

IBM	NA	1.3.6.1.4.1.2.6.131
IBM	NA	1.3.6.1.4.1.2.6.72
IBM	Gigabit Ethernet Switch M	1.3.6.1.4.1.2.6.3
Inkra	1518TX/GTX	1.3.6.1.4.1.9527.1.12
INTEL	510T	1.3.6.1.4.1.343.5.1.6
intel	520T	1.3.6.1.4.1.343.5.1.7
Intel	550T	1.3.6.1.4.1.343.5.1.4
INTEL	NetStructure	1.3.6.1.4.1.343.5.1.17
Intermec	ap245	1.3.6.1.4.1.469.1000.1.9
Intermec Technologies	UAP	1.3.6.1.4.1.469.1000.1.6
Intermec_Technologies	WA21	1.3.6.1.4.1.469.1000.1.13
IqinVision	IQeye1	1.3.6.1.4.1.3720.6
Iron-Port	C60	1.3.6.1.4.1.15497.1.1.1
ITWatchDogs	SuperGoose	1.3.6.1.4.1.901.1
Juniper	WXC 250	1.3.6.1.4.1.8239.1.2.7
Juniper	WXC 500	1.3.6.1.4.1.8239.1.2.6
Juniper	Redline-EX3200	1.3.6.1.4.1.6213
Juniper	SA 6000	1.3.6.1.4.1.2021.250.255
Juniper	Juniper WXC-590	1.3.6.1.4.1.8239.1.2.1
Juniper	WX 100	1.3.6.1.4.1.8239.1.2.5
Juniper	WXC 3400	1.3.6.1.4.1.8239.1.2.14
Juniper	WXC-250	1.3.6.1.4.1.8239.1.2.8
Juniper	E320	1.3.6.1.4.1.4874.1.1.1.6.1
Juniper	ERX1440	1.3.6.1.4.1.4874.1.1.1.1.3
Juniper	ERX310	1.3.6.1.4.1.4874.1.1.1.1.5
Juniper	ERX705	1.3.6.1.4.1.4874.1.1.1.1.4
Juniper	J2300	1.3.6.1.4.1.2636.1.1.1.2.23
Juniper	J2300 Backbone Router	1.3.6.1.4.1.2636.1.1.1.2.13
Juniper	J2350	1.3.6.1.4.1.2636.1.1.1.2.24
Juniper	J4300	1.3.6.1.4.1.2636.1.1.1.2.14
Juniper	J4350	1.3.6.1.4.1.2636.1.1.1.2.19
Juniper	J6300	1.3.6.1.4.1.2636.1.1.1.2.15
Juniper	J6350	1.3.6.1.4.1.2636.1.1.1.2.20
Juniper	M-10	1.3.6.1.4.1.2636.1.1.1.2.4
Juniper	M10i Router	1.3.6.1.4.1.2636.1.1.1.2.11
Juniper	M120	1.3.6.1.4.1.2636.1.1.1.2.18
Juniper	M-160	1.3.6.1.4.1.2636.1.1.1.2.3
Juniper	M-20	1.3.6.1.4.1.2636.1.1.1.2.2
Juniper	M320	1.3.6.1.4.1.2636.1.1.1.2.9
Juniper	M-40	1.3.6.1.4.1.2636.1.1.1.2.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Juniper	M40e Backbone Router	1.3.6.1.4.1.2636.1.1.1.2.8
Juniper	M-5	1.3.6.1.4.1.2636.1.1.1.2.5
Juniper	M7i	1.3.6.1.4.1.2636.1.1.1.2.10
Juniper	mx480	1.3.6.1.4.1.2636.1.1.1.2.25
Juniper	T320 Backbone Router	1.3.6.1.4.1.2636.1.1.1.2.7
Juniper	T640 Backbone Router	1.3.6.1.4.1.2636.1.1.1.2.6
Juniper	TX Routing Node (LCC0)	1.3.6.1.4.1.2636.1.1.1.2.17.1
Juniper	TX Routing Node (LCC1)	1.3.6.1.4.1.2636.1.1.1.2.17.2
Juniper	TX Routing Node (LCC2)	1.3.6.1.4.1.2636.1.1.1.2.17.3
Juniper	TX Routing Node (LCC3)	1.3.6.1.4.1.2636.1.1.1.2.17.4
Juniper	WX20	1.3.6.1.4.1.8239.1.2.3
juniper	4200 48T	1.3.6.1.4.1.2636.1.1.1.2.31
juniper	EX	1.3.6.1.4.1.2636.1.1.1.2.30
Juniper	EX8208	1.3.6.1.4.1.2636.1.1.1.2.32
Juniper	Tx Matrix	1.3.6.1.4.1.2636.1.1.1.2.17
Juniper Networks	SRX3400	1.3.6.1.4.1.2636.1.1.1.2.34
Juniper Networks	srx3400	1.3.6.1.4.1.2636.1.1.1.2.35
Kagoor	Session Border Controller 300	1.3.6.1.4.1.7005
Kentrox	DataSMART 558	1.3.6.1.4.1.181.1.25
Kentrox	DataSMART 698	1.3.6.1.4.1.181.1.26
Kentrox	Kentrox-AAC2	1.3.6.1.4.1.181.1.13
Kentrox	MPATH 537	1.3.6.1.4.1.181.1.27
Kentrox	Q2200	1.3.6.1.4.1.181.1.52.1
Kentrox	Q2201	1.3.6.1.4.1.181.1.52.11
Kentrox	Q2300	1.3.6.1.4.1.181.1.52.2
Kentrox	Q2301	1.3.6.1.4.1.181.1.52.12
Kentrox	Q2400	1.3.6.1.4.1.181.1.52.3
Kentrox	Q2401	1.3.6.1.4.1.181.1.52.13
Lantronix	ETS16PR	1.3.6.1.4.1.244.24
Larscom	Mega	1.3.6.1.4.1.555.2.3.5
Larscom	Mega - E	1.3.6.1.4.1.555.2.3.7
Larscom	Mega - T	1.3.6.1.4.1.555.2.3.6
Laurel	ST200	1.3.6.1.4.1.5395.1.1.1.1.1
Lexmark-International	Lexmark Optra	1.3.6.1.4.1.641.1
Liebert	NA	1.3.6.1.4.1.476.1.2.1.1
Liebert	GXT2-2000RT120	1.3.6.1.4.1.476.1.42
Liebert	UPS	1.3.6.1.4.1.476.1.1.1.5
Linksys	SRW 224	1.3.6.1.4.1.3955.6.4.224.1
Linux	NA	1.3.6.1.4.1.1575.1.5
Linux	2610mv1401	1.3.6.1.4.1.9070.1.2.3.1.5

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Linux	Linux host	1.3.6.1.4.1.2312
Linux	linuxEMANATEMasterAgent	1.3.6.1.4.1.99.1.1.3.28
Linux	NetBotz	1.3.6.1.4.1.5528.100.20.10.2000
Linux	Net-SNMP Agent 5.1	1.3.6.1.4.1.8072.3.2.10
Linux	NET-SNMP SOLARIS	1.3.6.1.4.1.8072.3.2.15
Linux	NET-SNMP SOLARIS	1.3.6.1.4.1.8072.3.2.3
Lucent	Model 350 brick	1.3.6.1.4.1.1751.1.56.1.1.3
Lucent	M420	1.3.6.1.4.1.81.17.1.10
Lucent	M440	1.3.6.1.4.1.81.17.1.4
Lucent	STACK	1.3.6.1.4.1.81.17.1.9
Lucent	Access Point 50-LAN	1.3.6.1.4.1.838.5.1.50.0.4
Lucent	AP300	1.3.6.1.4.1.838.5.1.300.0.0
Lucent	APX-1000	1.3.6.1.4.1.529.1.9
Lucent	MAX TNT	1.3.6.1.4.1.529.1.4
Lucent	XEDIA	1.3.6.1.4.1.838.5.1.450.2.0
Lucent	Cajun P120	1.3.6.1.4.1.81.17.2.11
Lucent	Cajun P550	1.3.6.1.4.1.1751.1.45.1
Lucent	Cajun P550	1.3.6.1.4.1.1751.1.45.2
Lucent	Cajun Switch PA80	1.3.6.1.4.1.1751.1.45.8
Lucent	M440-01	1.3.6.1.4.1.81.17.1.11
Lucent	M770	1.3.6.1.4.1.81.17.1.15
Lucent	M770ATM	1.3.6.1.4.1.81.17.1.16
Lucent	P330	1.3.6.1.4.1.81.17.1.17
Lucent	Visage	1.3.6.1.4.1.81.17.1.12
Lucent	Visage	1.3.6.1.4.1.81.17.2.8
Lucent-Xedia	AP3	1.3.6.1.4.1.838.5.1.1.0
Lucent-Xedia	Lucent Access Point 1000	1.3.6.1.4.1.838.5.1.1000.1.6
Lucent-Xedia	Lucent Access Point 1000	1.3.6.1.4.1.838.5.1.1000.4.0
Lucent-Xedia	Lucent Access Point 1000	1.3.6.1.4.1.838.5.1.1000.4.1
Lucent-Xedia	Lucent Access Point 300_ST	1.3.6.1.4.1.838.5.1.300.1.1
Lucent-Xedia	Lucent Access Point 300_ST	1.3.6.1.4.1.838.5.1.300.2.0
Lucent-Xedia	Lucent Access Point 300_ST	1.3.6.1.4.1.838.5.1.300.2.1
Lucent-Xedia	Lucent Access Point 300_ST	1.3.6.1.4.1.838.5.1.300.3.0
Lucent-Xedia	Lucent Access Point 300_U	1.3.6.1.4.1.838.5.1.300.0.1
Lucent-Xedia	Lucent Access Point 300_U	1.3.6.1.4.1.838.5.1.300.1.0
Lucent-Xedia	XEDIA	1.3.6.1.4.1.838.5.1.450.1.7
LuxN	WavSystem	1.3.6.1.4.1.4253.1.1
M410	NA	1.3.6.1.4.1.81.17.1.7
Macintosh	MacOS 9.0	1.3.6.1.4.1.63.1
Marconi	ASX-1200	1.3.6.1.4.1.326.2.2.17

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Marconi	ASX-4000	1.3.6.1.4.1.326.2.2.18
Marconi	ES-1200	1.3.6.1.4.1.326.2.20.1.2.1.2
Marconi	ESR Switch Agent V5.3.2	1.3.6.1.4.1.1012.2.5.2.1
Marconi	ESX minor	1.3.6.1.4.1.2154.1.1.1.2
Marconi	ESX-3000	1.3.6.1.4.1.326.2.2.20
Marconi	TNX	1.3.6.1.4.1.326.2.2.15
Marconi	TNX-1100	1.3.6.1.4.1.326.2.2.16
McDATA	ED-6064	1.3.6.1.4.1.289.2.1.1.2
MG	MG 2K SW	1.3.6.1.4.1.5003.8.1.1.31
MGE	UPS	1.3.6.1.4.1.705.1.2
MicroFrame	SNMP agent for Sentinel 2000	1.3.6.1.4.1.1476
Micomuse	Generic_Agent	1.3.6.1.4.1.1977.1.6.1279.1
Microsoft	GE60/GE60X Gigabit Wireless Link	1.3.6.1.4.1.6080.3.1.9
Microsoft	NA	1.3.6.1.4.1.311.1.1.3.1
Microsoft	NA	1.3.6.1.4.1.311.1.1.3.1.1
Microsoft	NA	1.3.6.1.4.1.311.1.1.3.1.10.14.3.1
Microsoft	Windows CE	1.3.6.1.4.1.311.1.1.3.3
MiLAN	MIL-SM801G	1.3.6.1.4.1.835.25.1.1.1.1
MiraPoint	M300	1.3.6.1.4.1.3246.254.1
MITEL	3300	1.3.6.1.4.1.1027.1.2.3
Motorola	AP5131	1.3.6.1.4.1.388.11.1.2
Motorola	VANGUARD 340	1.3.6.1.4.1.449.2.1.9565
Motorola	Vanguard 6435	1.3.6.1.4.1.449.2.1.6435
Motorola	Vanguard 6455	1.3.6.1.4.1.449.2.1.6455
MRV	OptiSwitch 800	1.3.6.1.4.1.629.16.3.1
MRV	EM316NM	1.3.6.1.4.1.629.200.1.1.1
NBASE	NH1026	1.3.6.1.4.1.629.14.1.1
NBASE	NH2016	1.3.6.1.4.1.629.11.5.1
NCR	MP-RAS	1.3.6.1.4.1.607.1.5.1.0
NEC	IX1035	1.3.6.1.4.1.119.1.84.1.5
NEC	IX2010	1.3.6.1.4.1.119.1.84.2.1
NEC	IX3010	1.3.6.1.4.1.119.1.84.7.1
NEC	BF210/24	1.3.6.1.4.1.119.1.76.5.2
NEC	Bluefire 5003	1.3.6.1.4.1.119.1.3.13.4
NEC	Bluefire 5010 ATM Switch / Router	1.3.6.1.4.1.119.1.3.13.1
NEC	Bluefire 8000 series 10G ATM Switch	1.3.6.1.4.1.119.1.14.12
NEC		1.3.6.1.4.1.119.1.14.8



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

	Bluefire 8000 series 2.5G ATM Switch	
NEC	CX-FH5248-PE	1.3.6.1.4.1.119.1.64.112.2.4
NEC	CX-FH5610E	1.3.6.1.4.1.119.1.64.112.2.105
NEC	CX-uH3024	1.3.6.1.4.1.119.1.64.112.1.201
NEC	NEAX2000IPS IP PBX	1.3.6.1.4.1.119.1.76.3
NEC	NETNEX8775	1.3.6.1.4.1.119.1.14.9
Netapp	FAS 3200	1.3.6.1.4.1.789.2.3
Netapp	R200	1.3.6.1.4.1.789.2.1
NetBotz	RackBotz 303 Appliance	1.3.6.1.4.1.5528.30.1006
NetBotz	WallBotz 310 Appliance	1.3.6.1.4.1.5528.30.1007
Netgear	GSM7212	1.3.6.1.4.1.4526.100.2.1
Netopia	4652	1.3.6.1.4.1.304.2.2.19.4652
Netopia	Netopia R7200-T	1.3.6.1.4.1.304.2.2.18
NetportExpress	NA	1.3.6.1.4.1.343.2.4.11
Netscout	4910	1.3.6.1.4.1.141.1.1.4910
Netscout	9320	1.3.6.1.4.1.141.1.1.9320
Netscout	9903RET	1.3.6.1.4.1.141.1.1.9903
NetScout	9981PET	1.3.6.1.4.1.141.1.1.9981
NetScout	NetScout 6910	1.3.6.1.4.1.141.1.1.6910
Netscout	8110	1.3.6.1.4.1.141.1.1.8110
NetScout	8221	1.3.6.1.4.1.141.1.1.8221
Netscout	9100	1.3.6.1.4.1.141.1.1.9100
NetScout	9112	1.3.6.1.4.1.141.1.1.9241
NetScout	8241ET	1.3.6.1.4.1.141.1.1.8241
Netscout	8243ET	1.3.6.1.4.1.141.1.1.8243
NetScout	CiscoSwitch Probe	1.3.6.1.4.1.141.1.1.7221
NetScout	CiscoSwitch Probe	1.3.6.1.4.1.141.1.1.7500
Netscout	CiscoSwitchProbe	1.3.6.1.4.1.141.1.1.7302
Netscout	CiscoSwitchProbe	1.3.6.1.4.1.141.1.1.8400
Netscout	Netscout/8912ET	1.3.6.1.4.1.141.1.1.8912
Netscreen	5Xt	1.3.6.1.4.1.3224.1.11
Netscreen	ISG-2000	1.3.6.1.4.1.3224.1.16
Netscreen	NetScreen-100	1.3.6.1.4.1.3224.1.4
Netscreen	NetScreen-204	1.3.6.1.4.1.3224.1.9
NetScreen	NetScreen-25	1.3.6.1.4.1.3224.1.8
Netscreen	NetScreen-5	1.3.6.1.4.1.3224.1.2
Netscreen	NetScreen-50	1.3.6.1.4.1.3224.1.7
Netscreen	Netscreen-500	1.3.6.1.4.1.3224.1.6
NetScreen	Netscreen-5200	1.3.6.1.4.1.3224.1.13

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

NetScreen	Netscreen-5GT	1.3.6.1.4.1.3224.1.14
Netscreen	NetScreen-5XT	1.3.6.1.4.1.3224.1.1
NetScreen	NetScreen-ISG-1000	1.3.6.1.4.1.3224.1.28
NetScreen	NetScreen-NS-5XP	1.3.6.1.4.1.3224.1.12
NetScreen	SSG140	1.3.6.1.4.1.3224.1.53
NetScreen	SSG20	1.3.6.1.4.1.3224.1.35
netscreen	SSG20-WLAN	1.3.6.1.4.1.3224.1.36
NetScreen	SSG320	1.3.6.1.4.1.3224.1.54
NetScreen	SSG350	1.3.6.1.4.1.3224.1.55
NetScreen	SSG5	1.3.6.1.4.1.3224.1.29
NetScreen	SSG5 Serial/WLAN	1.3.6.1.4.1.3224.1.32
netscreen	SSG520	1.3.6.1.4.1.3224.1.50
NetScreen	SSG550	1.3.6.1.4.1.3224.1.51
NetScreen	SSG5ISDN	1.3.6.1.4.1.3224.1.30
netscreen	SSG5ISDNWLAN	1.3.6.1.4.1.3224.1.33
NetScreen	SSG5v92	1.3.6.1.4.1.3224.1.31
NetScreen	SSG5V92WLAN	1.3.6.1.4.1.3224.1.34
Netscreen	V5	1.3.6.1.4.1.3224.1.10
NetworkAppliance	NetApp Release 5.3.4R392	1.3.6.1.4.1.789.1.1.1
NetworkAppliance	NetCache C1105	1.3.6.1.4.1.789.2.2
NetworkAssociates	Sniffer Pro 3.0	1.3.6.1.4.1.3401.2
NetworkGeneral	Sniffer	1.3.6.1.4.1.110.3.1.1.2.1
Niksun	NetCVR RMON Device	1.3.6.1.4.1.5713.1.1.2.4
Nokia	Firewall 1220	1.3.6.1.4.1.94.1.21.2.1.139
Nokia	IP110	1.3.6.1.4.1.94.1.21.2.1.10
Nokia	IP1200	1.3.6.1.4.1.94.1.21.2.1.140
Nokia	IP265 Firewall	1.3.6.1.4.1.94.1.21.2.1.142
Nokia	IP350	1.3.6.1.4.1.94.1.21.2.1.138
Nokia	IP380	1.3.6.1.4.1.94.1.21.2.1.137
Nokia	IP440	1.3.6.1.4.1.94.1.21.2.1.5
Nokia	IP530	1.3.6.1.4.1.94.1.21.2.1.11
Nokia	IP710	1.3.6.1.4.1.94.1.21.2.1.1
Nokia	IP710	1.3.6.1.4.1.94.1.21.2.1.15
Nokia	IP740	1.3.6.1.4.1.94.1.21.2.1.12
Nokia	Nokia IP650	1.3.6.1.4.1.94.1.21.2.1.8
Nokia	Nokia2-Firewall-1 3.2-fcs4 releng 783	1.3.6.1.4.1.94.1.21.2.1.9
Nokia	Nokia WAP Server	1.3.6.1.4.1.94.1.33
Nortel	CS 1000 Signalling Server	1.3.6.1.4.1.562.3.21
Nortel	CS 1000E Call Server	1.3.6.1.4.1.562.3

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Nortel	DMS Supernode	1.3.6.1.4.1.562.4.2.2
Nortel	DMSSupernode	1.3.6.1.4.1.562.4.2.1
Nortel	ECM	1.3.6.1.4.1.562.3.13
Nortel	ITG	1.3.6.1.4.1.562.3.11.2
Nortel	NRS	1.3.6.1.4.1.562.3.12
Nortel	Survivable Remote Gateway (SRG)	1.3.6.1.4.1.562.37.1.4
Nortel	Survivable Remote Gateway (SRG)	1.3.6.1.4.1.562.37.1.8
Nortel	VGMC	1.3.6.1.4.1.562.3.11.5
Nortel	Alteon	1.3.6.1.4.1.1872.1.11.2
Nortel	1700	1.3.6.1.4.1.2505.1700
Nortel	Business Communications Manager 2.5	1.3.6.1.4.1.562.37.1.1
Nortel	Business Communications Manager 4.0	1.3.6.1.4.1.562.37.1.7
Nortel	Carrier Passport	1.3.6.1.4.1.562.36.1.3
Nortel	Carrier Passport 7440	1.3.6.1.4.1.562.36.1.1
Nortel	Carrier Passport 7480	1.3.6.1.4.1.562.36.1.2
Nortel	CLAM	1.3.6.1.4.1.541.2.0
Nortel	Contivity	1.3.6.1.4.1.2505.10
Nortel	Contivity	1.3.6.1.4.1.2505.4
Nortel	Contivity	1.3.6.1.4.1.2505.5
Nortel	Contivity	1.3.6.1.4.1.2505.6
Nortel	Contivity	1.3.6.1.4.1.2505.8
Nortel	Contivity 1600	1.3.6.1.4.1.2505.7
Nortel	Contivity 600	1.3.6.1.4.1.2505.600
Nortel	Contivity Extranet Switch V04_06.120	1.3.6.1.4.1.2505.13
Nortel	Contivity Extranet Switch V04_07.021	1.3.6.1.4.1.2505.12
Nortel	Contivity Extranet Switch V04_75.100	1.3.6.1.4.1.2505.2700
Nortel	Contivity VPN 1010	1.3.6.1.4.1.2505.1010
Nortel	Contivity VPN 1100	1.3.6.1.4.1.2505.1100
Nortel	Contivity VPN 1740	1.3.6.1.4.1.2505.1740
Nortel	Contivity VPN 1750	1.3.6.1.4.1.2505.1750
Nortel	Contivity VPN 4600	1.3.6.1.4.1.2505.9
Nortel	MARLIN	1.3.6.1.4.1.541.2
Nortel	Shasta 5000	1.3.6.1.4.1.3199.10.1
Nortel	SR 1001	1.3.6.1.4.1.562.73.2.2.3.1
Nortel	SR 1002	1.3.6.1.4.1.562.73.2.2.3.2

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Nortel	SR 1004	1.3.6.1.4.1.562.73.2.2.3.3
Nortel	SR 1004E	1.3.6.1.4.1.562.73.2.2.3.5
Nortel	2424	1.3.6.1.4.1.1872.1.13.1.1
Nortel	4548GT-PWR	1.3.6.1.4.1.45.3.71.2
Nortel	4550T-PWR	1.3.6.1.4.1.45.3.71.4
Nortel	5530-24TFD	1.3.6.1.4.1.45.3.65
Nortel	Accelar 1150	1.3.6.1.4.1.2272.7
Nortel	ACEdirector 4	1.3.6.1.4.1.1872.1.10
Nortel	ACEswitch 184	1.3.6.1.4.1.1872.1.9
Nortel	Alteon L2/3 GbE	1.3.6.1.4.1.1872.1.18.1
Nortel	Alteon L2-7 GbE	1.3.6.1.4.1.1872.1.15
Nortel	Alteon-2424-SSL	1.3.6.1.4.1.1872.1.13.1.4
Nortel	Alteon-3408	1.3.6.1.4.1.1872.1.13.2.1
Nortel	BayStack 325-24T	1.3.6.1.4.1.45.3.61.1
Nortel	Baystack 3510-24T	1.3.6.1.4.1.45.3.66
Nortel	BayStack 420	1.3.6.1.4.1.45.3.43.1
Nortel	BayStack 425-24T	1.3.6.1.4.1.45.3.57.2
Nortel	Baystack 470-48T	1.3.6.1.4.1.45.3.64.1
Nortel	BayStack 5510-24T	1.3.6.1.4.1.45.3.52.1
Nortel	BayStack 5520-24T	1.3.6.1.4.1.45.3.59.1
Nortel	BayStack_5520-48T	1.3.6.1.4.1.45.3.59.2
Nortel	Business Policy Switch 2000	1.3.6.1.4.1.45.3.40.1
Nortel	CVX-1800	1.3.6.1.4.1.2637.1.2.1.1
Nortel	Nortel 8610	1.3.6.1.4.1.2272.30
Nortel	OPTera Metro 5000	1.3.6.1.4.1.2865.1
Nortel	Passport 8106	1.3.6.1.4.1.2272.33
Nortel	Passport 8110	1.3.6.1.4.1.2272.32
Nortel	PassPort 8603	1.3.6.1.4.1.2272.34
Nortel	Passport 8606	1.3.6.1.4.1.2272.31
Nortel	Passport 8610	1.3.6.1.4.1.2272.37
Nortel	Passport-1424T	1.3.6.1.4.1.2272.42
Nortel	Passport-1612G	1.3.6.1.4.1.2272.44
Nortel	Passport-8310	1.3.6.1.4.1.2272.47
Novell	NA	1.3.6.1.4.1.1727.1.2.1
Novell	NA	1.3.6.1.4.1.23.1.13.2
Novell	Novell NetWare 5.00.10	1.3.6.1.4.1.23.1.6
Novell	Novell NewWare 4.11	1.3.6.1.4.1.23.1.6.4.11
Novell	Novell NewWare 5.00g	1.3.6.1.4.1.23.1.6.5
NSC	NA	1.3.6.1.4.1.10.2.1.3
Nuera	F200	1.3.6.1.4.1.1550.1

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Omnitron	Media Converter	1.3.6.1.4.1.7342.1.1
Omnitronix	SL10	1.3.6.1.4.1.3052.40
Overture	ISG45	1.3.6.1.4.1.7950.1.1.7
Overture	ISG45+	1.3.6.1.4.1.7950.1.1.8
Overture	ISG5000	1.3.6.1.4.1.7950.1.1.2.0
Overture	LPS718	1.3.6.1.4.1.7950.1.1.10
Overture	ISG 6000	1.3.6.1.4.1.7950.1.1.16.0
Overture	ISG2200	1.3.6.1.4.1.7950.1.1.6.0
Overture	ISG5100	1.3.6.1.4.1.7950.1.1.11.0
Packeteer	PacketShaper 5.3.0	1.3.6.1.4.1.2334.1.1.4
Packeteer	App Vantage	1.3.6.1.4.1.2334.1.1.7
Packeteer	Appvantage	1.3.6.1.4.1.2334.1.1.8
Packeteer	PacketShaper	1.3.6.1.4.1.2334.1.1.11
Packeteer	PacketShaper 4.1.2	1.3.6.1.4.1.2334.1.1.5
Packeteer	PacketShaper 6.0.2	1.3.6.1.4.1.2334.1.1.12
Packeteer	10000	1.3.6.1.4.1.2334.1.1.17
Packeteer	PacketShaper 3500	1.3.6.1.4.1.2334.1.1.19
Packeteer	PacketShaper 7500	1.3.6.1.4.1.2334.1.1.20
Paradyne	T1 CSU/DSU	1.3.6.1.4.1.1795
PARADYNE	T1 DSU/CSU	1.3.6.1.4.1.1795.1.14.2.5.2.2
Paradyne	T3 DSU/CSU Model 9580	1.3.6.1.4.1.1795.1.14.2.4.5.1
Paradyne	3160	1.3.6.1.4.1.1795.1.14.2.2.1
Paradyne	9126-IISAPL	1.3.6.1.4.1.1795.1.14.2.4.4.7.3
Paradyne	DDS SLV Model 9624-OS	1.3.6.1.4.1.1795.1.14.2.4.1.8
Paradyne	DDS SLV Model 9626	1.3.6.1.4.1.1795.1.14.2.4.1.6
Paradyne	T1 DSU/CSU Model 7123	1.3.6.1.4.1.1795.1.14.2.4.12.1.1
Paradyne	T1 FLEX Model 9123-C	1.3.6.1.4.1.1795.1.14.2.4.4.11.1
Paradyne	T1 FLEX Model 9123-SLV	1.3.6.1.4.1.1795.1.14.2.4.4.11.2
Paradyne	T1 SLV Model 9124	1.3.6.1.4.1.1795.1.14.2.4.4.5
Paradyne	T1 SLV Model 9124-II	1.3.6.1.4.1.1795.1.14.2.4.4.9
Paradyne	T1 SLV Model 9124-OS	1.3.6.1.4.1.1795.1.14.2.4.4.12
Paradyne	T1 SLV Model 9126-IISLV	1.3.6.1.4.1.1795.1.14.2.4.4.7
Paradyne	T1 SLV Model 9128-II	1.3.6.1.4.1.1795.1.14.2.4.4.8
Paradyne	T3 DSU/CSU Model 9520-II	1.3.6.1.4.1.1795.1.14.2.4.5.3
PARADYNE	DDS/DSU	1.3.6.1.4.1.1795.1.14.2.5.1.2
PARADYNE	GrandSLAM-4200	1.3.6.1.4.1.1795.1.14.17.1.3
Paradyne	iMarc 9123	1.3.6.1.4.1.1795.1.14.2.4.11.5.1
P-Cube	SE1000	1.3.6.1.4.1.5655.1.2
Perle	Iolan+ Terminal Server	1.3.6.1.4.1.441
PowerDsine	PoE PD-6506	1.3.6.1.4.1.7428.1.1.1.2

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

PowerDsine	PoE PD-6512	1.3.6.1.4.1.7428.1.1.1.4
PowerDsine	PoE PD-6524	1.3.6.1.4.1.7428.1.1.1.6
PowerDsine	PD-6006/AC/SNMP-PoE Hub	1.3.6.1.4.1.7428.3.1.7
Powerware	ConnectUPS	1.3.6.1.4.1.534.1
Powerware	ConnectUPS Adapter	1.3.6.1.4.1.534.2.5.1
Precidia	Ether3201-202	1.3.6.1.4.1.6664.10.2.2
Proxim	Tsunami MP11a	1.3.6.1.4.1.11898.2.4.9
Proxim Inc.	NA	1.3.6.1.4.1.841.1
Proxim Inc.	AP-2500	1.3.6.1.4.1.11898.2.4.11
QMS-Inc.	QMS 3225 Print System	1.3.6.1.4.1.480
Quantum	140-NOE-771-00	1.3.6.1.4.1.3833.1.7.255.2
Quick_Eagle	4300/5800	1.3.6.1.4.1.300.200
Quickeagle	DL3800	1.3.6.1.4.1.300.102
Racal Datacomm	CSU/DSU for ISX5311	1.3.6.1.4.1.124.300.1.1
RAD	IP-mux1	1.3.6.1.4.1.164.6.1.3.82
RAD	IP-mux16	1.3.6.1.4.1.164.6.1.3.83
RAD	OPT3	1.3.6.1.4.1.164.6.1.3.79
RAD	unknown	1.3.6.1.4.1.164.6.1.3.49
Radware	CT100	1.3.6.1.4.1.89.1.1.62.11
Radware	Fireproof	1.3.6.1.4.1.89.1.1.62.6
Redback	Networks AOS / SE 800	1.3.6.1.4.1.2352.1.3
Redback	SE 800	1.3.6.1.4.1.2352.1.10
Redback	SE100	1.3.6.1.4.1.2352.1.11
Redback	SE400	1.3.6.1.4.1.2352.1.12
Redback	SMS 10000	1.3.6.1.4.1.2352.1.4
RedCreek	Ravlin 7150	1.3.6.1.4.1.1958.2.9
RedCreek	Ravlin 10	1.3.6.1.4.1.1958.2.4
RedCreek	Ravlin 5300	1.3.6.1.4.1.1958.2.11
Riverbed	Steelhead	1.3.6.1.4.1.17163.1.1
Riverbed	Steelhead	1.3.6.1.4.1.17163.2.1
Riverhead	Linux Riverhead2	1.3.6.1.4.1.9816
Riverstone	15008	1.3.6.1.4.1.5567.1.1.101
Riverstone	8600	1.3.6.1.4.1.5567.1.1.2
Riverstone	RS3100	1.3.6.1.4.1.5567.1.1.11
Riverstone	RS8000	1.3.6.1.4.1.5567.1.1.1
Riverstone Networks	RS8600	1.3.6.1.4.1.285.9.26
Sandvine	PTS8210	1.3.6.1.4.1.11610.1.4.1
Satelcom	MegaBOX-E	1.3.6.1.4.1.397.1.38
Satelcom	MegaPAC-E	1.3.6.1.4.1.397.1.31
SCO	NA	1.3.6.1.4.1.32.1.2.0.0

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Secure_Computing_Corp	SideWinder	1.3.6.1.4.1.1573.2.1
ServerTech	MSSLite	1.3.6.1.4.1.1718.2
ServerTech	Sentry3	1.3.6.1.4.1.1718.3
Shiva	LanRover Access	1.3.6.1.4.1.166.2.8
Shiva	LanRover/E Plus	1.3.6.1.4.1.166.2.3
Siemens	SURPASS hiX 5635	1.3.6.1.4.1.231.7.1.2.2.1.101.1.1
Siemens	Attane i210	1.3.6.1.4.1.231.7.1.5.2.1
Siemens	Efficient 5930 DMT Router v6.1.001	1.3.6.1.4.1.1548.5930.0
Siemens	SpeedStream 5200	1.3.6.1.4.1.763.3
Sitara	QoS Works	1.3.6.1.4.1.2302
SMC	SMC 8648T	1.3.6.1.4.1.202.20.31
SMC	SMC 8648T	1.3.6.1.4.1.202.20.37
SNMPResearch	NA	1.3.6.1.4.1.99.1.1.3.11
Specialix	Jetstream 8500	1.3.6.1.4.1.667.2.1
Stalecom	Megapac	1.3.6.1.4.1.397.1.18
SUN	NA	1.3.6.1.4.1.191.1.32
Sun	NA	1.3.6.1.4.1.42.2.1.1
Sun	Linux nbrnm 1101	1.3.6.1.4.1.2021.250.10
Sun	Linux nbrnm 1101	1.3.6.1.4.1.2021.250.3
SUN	ss73vvnvc02	1.3.6.1.4.1.42.2.15
SUN	ss73vvnvsm01	1.3.6.1.4.1.42.2.2
SUN	SUN Netra 1125	1.3.6.1.4.1.1751.1.30
Sun	SunFire	1.3.6.1.4.1.42.2.70
Sun	T300	1.3.6.1.4.1.42.1.2.1.1
Sun	SUN SPARCstation Solaris2	1.3.6.1.4.1.1919.1.1
Sun	Check Point FireWall	1.3.6.1.4.1.260.1.1
Sun	Check Point FireWall	1.3.6.1.4.1.2620.1.1
Sun	SANbox2-64	1.3.6.1.4.1.42.2.28.3.4.1.1.5
Sun	Sun Blade 1600	1.3.6.1.4.1.42.2.24.1
Symbol	AP1000E V5.21	1.3.6.1.4.1.551.2.1.76
Symbol	AP 3021	1.3.6.1.4.1.388.1.3
Symbol	AP-5131	1.3.6.1.4.1.388.1.8
Symbol	WS5000	1.3.6.1.4.1.388.6.0
Sync-Research-Inc.	3620	1.3.6.1.4.1.485.1.1.1.69
Sync-Research-Inc.	NA	1.3.6.1.4.1.485.1.1.1.63
Sync-Research-Inc.	4203-8T	1.3.6.1.4.1.485.1.1.1.66
Sync-Research-Inc.	Red Kap	1.3.6.1.4.1.485.1.1.1.68
Sync-Research-Inc.	E2003	1.3.6.1.4.1.485.1.1.1.62
Sync-Research-Inc.	Sync	1.3.6.1.4.1.485.1.1.1.64

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

SynOptics	NMM 810M	1.3.6.1.4.1.45.3.16.1
SystemEdge	NA	1.3.6.1.4.1.546
Tandem	NonStop Kernel System Version: G6	1.3.6.1.4.1.169.3.155.1
Tasman	1001	1.3.6.1.4.1.3174.1.30
Tasman	1002	1.3.6.1.4.1.3174.1.22
Tasman	1200	1.3.6.1.4.1.3174.1.7
Tasman	1200	1.3.6.1.4.1.3174.1.8
Tasman	3120	1.3.6.1.4.1.3174.1.32
Tasman	1004T	1.3.6.1.4.1.3174.1.20
Tasman	1400E	1.3.6.1.4.1.3174.1.2
Tasman	Imux1450	1.3.6.1.4.1.3174.1.9
Tektronix	Phaser 740	1.3.6.1.4.1.128.2.1.4.1.3.1
Tektronix	Phaser 750 N	1.3.6.1.4.1.128.2.1.4.1.5.2
Tektronix	Phaser 840DP	1.3.6.1.4.1.128.2.1.4.2.7.2
Tektronix-Phaser	Share Ethernet Card	1.3.6.1.4.1.128.2.2.2.2
Telebit	NA	1.3.6.1.4.1.117.2.1
Telindus	1031	1.3.6.1.4.1.776.64
Telindus	1032	1.3.6.1.4.1.776.65
Telindus	Crocus 10M	1.3.6.1.4.1.776.61
Tellabs	8820	1.3.6.1.4.1.4641.1.1
Tellabs	8840	1.3.6.1.4.1.4641.1.3
Tellabs	8860	1.3.6.1.4.1.4641.1.2
TGV	NA	1.3.6.1.4.1.58.1.1.1.2.1
Tiara	1400	1.3.6.1.4.1.3174.1.1
Timestep	PERMIT/Gate 7520	1.3.6.1.4.1.1022.9
TippingPoint	UnityOne 1200 Fiber	1.3.6.1.4.1.10734.1.3.7
TippingPoint	UnityOne NDS	1.3.6.1.4.1.10734.1.3.9
Top_Layer_Networks	Attack Mitigator	1.3.6.1.4.1.2944.1.1.8
Topspin	SFS3012	1.3.6.1.4.1.6203.20
Topspin	SFS7000D	1.3.6.1.4.1.6203.19
Transition-Networks	E-MCC-1600 Media Converter	1.3.6.1.4.1.868.1.4.2
Trapeze	MXR-2	1.3.6.1.4.1.14525.3.1.4
Tut	MXL-2300	1.3.6.1.4.1.1748.2.5
Tut	T2 DSL	1.3.6.1.4.1.1748.2.20
TutSystems	Espresso GS	1.3.6.1.4.1.1748.2.1
U.S Robotics	17-Slot Chassis with PB clocking	1.3.6.1.4.1.429.2.9
UB	NIU	1.3.6.1.4.1.75.5.3
UB	NIU	1.3.6.1.4.1.75.5.55



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

UB	NIU	1.3.6.1.4.1.75.5.71.8.256.43.256
Unisphere	E320 Virtual Router	1.3.6.1.4.1.4874.1.1.1.6.1.1
Unisphere	ERX1400 Virtual Router	1.3.6.1.4.1.4874.1.1.1.1.1.1
Unisphere	ERX1400 Virtual Router	1.3.6.1.4.1.4874.1.1.1.1.3.1
Unisphere	ERX-1440	1.3.6.1.4.1.4874.1.1.1.1.1
Unisphere	ERX310 Virtual Router	1.3.6.1.4.1.4874.1.1.1.1.5.1
Unisphere	ERX700 Virtual Router	1.3.6.1.4.1.4874.1.1.1.1.2.1
Unisphere	ERX700 Virtual Router	1.3.6.1.4.1.4874.1.1.1.1.4.1
Unisphere	ERX705	1.3.6.1.4.1.4874.1.1.1.1.2
Unisys	ClearPath HMP NX	1.3.6.1.4.1.223.16
UNIX (Berkely)	NA	1.3.6.1.4.1.4.1.2.5
UnixSystem	Unix System V Release 4.2	1.3.6.1.4.1.607.1.4.1
Ushapro	Card v4.3	1.3.6.1.4.1.2468.1.2.1
Vbrick	4200	1.3.6.1.4.1.4289.1.2.1.2
Vbrick	NA	1.3.6.1.4.1.4289.3.1
Vegastream	400	1.3.6.1.4.1.4686.11
Vertical Horizon	VH-4802	1.3.6.1.4.1.5624.2.1.10
Visual Networks	NA	1.3.6.1.4.1.1246.1.1.7
Visual Networks	T1 CSU ASE	1.3.6.1.4.1.1246.1.1.1134
Visual Networks	Enterprise Site ASE	1.3.6.1.4.1.1246.1.200
Visual Networks	T1 CSU DROP & INSERT ASE	1.3.6.1.4.1.1246.1.1.523
Visual Networks	Visual UpTime	1.3.6.1.4.1.1246.1.1.536
Visual Networks	ASE Version 4.3.008	1.3.6.1.4.1.1246.1.1.513
VisualNetworks	M204	1.3.6.1.4.1.1246.1.1.204
VisualNetworks	Visual UpTime Select T1 CSU	1.3.6.1.4.1.1246.1.1.109
VisualNetworks	Visual UpTime Select T1 CSU	1.3.6.1.4.1.1246.1.1.49
VisualNetworks	Visual UpTime Select T1 CSU	1.3.6.1.4.1.1246.1.202
VisualNetworks	Visual UpTime Select IP Transport T1 CSU ASE Ver 2.0.026	1.3.6.1.4.1.1246.1.1.110
VisualNetworks	Visual UpTime Select IP Transport T1/E1 INLINE ASE Ver 2.0.026	1.3.6.1.4.1.1246.1.1.113
VN	Inline ASE	1.3.6.1.4.1.1246.1.1.122
Voltaire	SM Agent	1.3.6.1.4.1.5206.1.17
VSAT	NA	1.3.6.1.4.1.303.3.3.19
Wavecom	MA4400-Manager	1.3.6.1.4.1.2750
WavePOINT-II	SN-00UT01200771 V3.20	1.3.6.1.4.1.762.2

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_10.0

Western Multiplex	TSUNAMI100-06	1.3.6.1.4.1.3727.10.0
Westernmultiplex	Tsunami 100	1.3.6.1.4.1.3727.21
Westernmultiplex	Tsunami 480	1.3.6.1.4.1.3727.10
Widebank	28 DS3	1.3.6.1.4.1.964.3.1
Xerox	NA	1.3.6.1.4.1.253.8.62.1.1.3.1.3
Xylogics	NA	1.3.6.1.4.1.15.1.1
Xylogics	NA	1.3.6.1.4.1.15.1.3.1
Xylogics	NA	1.3.6.1.4.1.15.1.3.3
Xylogics	NA	1.3.6.1.4.1.15.1.3.4
Xylogics	NA	1.3.6.1.4.1.15.1.3.10
Xylogics	NA	1.3.6.1.4.1.15.1.3.11
Xylogics	NA	1.3.6.1.4.1.15.1.3.12
Xylogics	NA	1.3.6.1.4.1.15.1.3.8
Xylogics	NA	1.3.6.1.4.1.15.1.3.9
Xyplex	NA	1.3.6.1.4.1.33.8.5.2.10
Xyplex	SBK Remote Router	1.3.6.1.4.1.33.8.5.3.10
Xyplex	Xyplex software X.25 Gateway V1 3.2	1.3.6.1.4.1.33.8.1.7.2
Xyplex	CSERV-20	1.3.6.1.4.1.33.8.1.4.5
Xyplex	CSERV-20	1.3.6.1.4.1.33.8.1.5.5
Zyxel	Prestige-650R	1.3.6.1.4.1.890.1.2.6.22
Zyxel	AAM-1008	1.3.6.1.4.1.890.1.5.11.6