

The following are the supported devices for Prime Collaboration Assurance 9.5.

## Contents

- [1 Supported Software Versions](#)
- [2 Cisco Endpoints](#)
- [3 Cisco Infrastructure Devices](#)
- [4 Cisco Network Devices](#)
- [5 Third-party Endpoints](#)
- [6 Third-party Network Devices](#)

## Supported Software Versions

| Device   | Software Versions   |
|--|---|
| Analog Gateway   | -   |
| Contact Center Enterprise  | 7.0 - 9.0   |
| Contact Center Express   | 4.6 - 9.0   |
| Cisco TelePresence Multipoint Switch   | 1.7 ? 1.9.3   |
| Cisco TelePresence System  | 1.7 ? 1.10  |
| Cisco TelePresence Manager (CTS-Manager)   | 1.7 ? 1.9   |
| Cisco TelePresence Exchange Server (CTX)   | 1.2 - 1.3<br>CTX 1.3 is supported through <a href="#">Cisco Prime Collaboration 9.5 Assurance Patch 1</a> .                               |
| Cisco Unified Communications Manager   | 7.1 ? 9.1(2)  |
| Cisco Unified Communications Manager Business Edition  | 7.1 ? 9.0   |
| Cisco Unified Communications Manager Express   | 7.1 - 8.6.2   |
| Cisco Unified Customer Voice Portal  | 4.0 - 9.0   |
| Cisco Unified Personal Communicator  | 1.1 - 8.6   |
| Cisco IP Communicator  | 1.2 - 8.6   |
| <ul style="list-style-type: none"> <li>• Cisco Codec EX series</li> <li>• Cisco TelePresence System Integrator C Series</li> </ul> | <ul style="list-style-type: none"> <li>• EX series:<br/>TC 4.2 - 6.0; TE 6.0</li> <li>• C, MX, and SX series:<br/>TC 4.2 - 6.0</li> </ul> |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|   |  |
|---|--|
| <ul style="list-style-type: none"> <li>• Cisco TelePresence MX Series</li> <li>• Cisco TelePresence System Profile Series</li> <li>• Cisco TelePresence SX20 Quick Set</li> <li>• Cisco TX 9000 series</li> </ul> | <ul style="list-style-type: none"> <li>• TX series: TX 6.0</li> </ul>  |
| Cisco IP Video Phone E20  | TE 4.0 - 6.0   |
| Emergency Responder   | 1.0 - 9.0  |
| Expert Advisor  | 7.2 - 7.6  |
| Finesse   | 8.0 - 9.0  |
| Cisco MCU   | 4.1 ? 4.4  |
| Cisco TelePresence MSE Supervisor   | 2.1 ? 2.3  |
| Mediasense  | 8.0 - 9.0  |
| Meeting Place   | 7.0 - 8.5  |
| Meeting Place Express   | 2.0 - 2.1  |
| Personal Assistant  | 1.3 -1.4   |
| Cisco TelePresence System MXP series  | 9.1  |
| Polycom VSX series<br>Polycom HDX series  | 2.5 - 3.0<br>(for HDX series)<br>9.0<br>(for VSX series)   |
| Cisco Unified Presence  | 8.0 - 9.1(1)   |
| Network devices (routers and switches)  |  |
| Cisco TelePresence Management Suite (Cisco TMS)   | 13.0 ? 14.1<br><br>New features supported in 14.1 are not supported.   |
| Cisco Telepresence Server   | 2.1 ? 3.0<br><br>For 3.0, support is available for the Standalone operation mode (locally managed mode); the Flexible operation mode (remotely managed mode) is not supported. |
| Cisco Telepresence Conductor  | 1.1 - 2.0  |
| Cisco Unity   | 7.0 - 8.6  |
| Cisco Unity Connection  | 7.0 - 9.1(2)   |
| Cisco Unity Express   | 7.0 - 9.0  |
| Cisco TelePresence Video Communication Server (Control and Expressway)  | 6.0 ? 7.2.1  |
| Wireless  | -  |

|  |                        |
|--|------------------------|
| Third party devices  | -                      |
| Cisco Jabber Video for Telepresence (Movi)   | all software versions. |
| Cisco Cius   | all software versions. |
| Cisco IP phones (89xx, 99xx)   | all software versions. |
| Border Element, Gatekeeper, H323 Gateway, SIP Gateway MGCP Gateway, SRST Device, Voice Gateway | IOS 12.x or later      |

## Cisco Endpoints

| Device Group         | Device Series             | Device Name             | SystemObjectID         |
|----------------------|---------------------------|-------------------------|------------------------|
| TelePresence         | Cisco TelePresence System | Cisco TelePresence 1000 | 1.3.6.1.4.1.9.1.800    |
| TelePresence         | Cisco TelePresence System | Cisco TelePresence 1000 | 1.3.6.1.4.1.9.1.801    |
| TelePresence         | Cisco TelePresence System | Cisco TelePresence 1000 | 1.3.6.1.4.1.9.1.1003   |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoC20                | 1.3.6.1.4.1.9.1.c20    |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoC40                | 1.3.6.1.4.1.9.1.c40    |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoC60                | 1.3.6.1.4.1.9.1.c60    |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoC90                | 1.3.6.1.4.1.9.1.c90    |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoEX60               | 1.3.6.1.4.1.9.1.ex60   |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoEX90               | 1.3.6.1.4.1.9.1.ex90   |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoMX200              | 1.3.6.1.4.1.9.1.mx200  |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoMX300              | 1.3.6.1.4.1.9.1.mx300  |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoProfile42-C20      | 1.3.6.1.4.1.9.1.p42c20 |
| Cisco Codec C Series | Cisco Codec C Series      | ciscoProfile42-C40      | 1.3.6.1.4.1.9.1.p42c40 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                           |                           |                     |                             |
|---------------------------|---------------------------|---------------------|-----------------------------|
| Cisco Codec C Series      | Cisco Codec C Series      | ciscoProfile42-C60  | 1.3.6.1.4.1.9.1.p42c60      |
| Cisco Codec C Series      | Cisco Codec C Series      | ciscoProfile52      | 1.3.6.1.4.1.9.1.p52         |
| Cisco Codec C Series      | Cisco Codec C Series      | ciscoProfile52-Dual | 1.3.6.1.4.1.9.1.p52dual     |
| Cisco Codec C Series      | Cisco Codec C Series      | ciscoProfile65      | 1.3.6.1.4.1.9.1.p65         |
| Cisco Codec C Series      | Cisco Codec C Series      | ciscoProfile65-Dual | 1.3.6.1.4.1.9.1.p65dual     |
| Cisco TelePresence SX20   | Cisco Codec C Series      | ciscoSX20           | 1.3.6.1.4.1.9.1.sx20        |
| Cisco Cius                | Cisco Cius                | ciscoCius           | 1.3.6.1.4.1.9.1.cius        |
| Cisco Jabber              | Cisco Jabber              | ciscoJabber         | 1.3.6.1.4.1.9.1.ciscojabber |
| Cisco Phone               | Cisco Phone               | ciscoPhone          | 1.3.6.1.4.1.9.1.phone       |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS1000        | 1.3.6.1.4.1.9.1.cts1000     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS1100        | 1.3.6.1.4.1.9.1.cts1100     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS1300        | 1.3.6.1.4.1.9.1.cts1300     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS1310        | 1.3.6.1.4.1.9.1.cts1310     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS1400        | 1.3.6.1.4.1.9.1.cts1400     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS3000        | 1.3.6.1.4.1.9.1.cts3000     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS3010        | 1.3.6.1.4.1.9.1.cts3010     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS3200        | 1.3.6.1.4.1.9.1.cts3200     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS3210        | 1.3.6.1.4.1.9.1.cts3210     |
| Cisco TelePresence System | Cisco TelePresence System | ciscoCTS500         | 1.3.6.1.4.1.9.1.cts500      |
|                           |                           | ciscoTX9000         | 1.3.6.1.4.1.9.1.tx9000      |

Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                           |                           |              |                            |
|---------------------------|---------------------------|--------------|----------------------------|
| Cisco TelePresence System | Cisco TelePresence System |              |                            |
| Cisco TelePresence System | Cisco TelePresence System | ciscoTX9200  | 1.3.6.1.4.1.9.1.tx9200     |
| Cisco TelePresence E20    | Cisco TelePresence System | ciscoE20     | 1.3.6.1.4.1.5596.160.6.4.1 |
| Cisco Unified IP Phones   | -                         | Cisco 30 SP+ |                            |
| Cisco Unified IP Phones   | -                         | Cisco 12 SP+ |                            |
| Cisco Unified IP Phones   | -                         | Cisco 12 SP  |                            |
| Cisco Unified IP Phones   | -                         | Cisco 30 VIP |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7902   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7905   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7910   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7912   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7920   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7921   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7935   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7936   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7940   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7941   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7985   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7961   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7960   |                            |
| Cisco Unified IP Phones   | -                         | Cisco 7970   |                            |
|                           | -                         | Cisco 7971   |                            |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                         |   |                |
|-------------------------|---|----------------|
| Cisco Unified IP Phones |   |                |
| Cisco Unified IP Phones | - | Cisco 7911     |
| Cisco Unified IP Phones | - | Cisco 7931     |
| Cisco Unified IP Phones | - | Cisco 7942     |
| Cisco Unified IP Phones | - | Cisco 7945     |
| Cisco Unified IP Phones | - | Cisco 7962     |
| Cisco Unified IP Phones | - | Cisco 7965     |
| Cisco Unified IP Phones | - | Cisco 7975     |
| Cisco Unified IP Phones | - | Cisco 7906     |
| Cisco Unified IP Phones | - | Cisco 7961G-GE |
| Cisco Unified IP Phones | - | Cisco 7941G-GE |
| Cisco Unified IP Phones | - | Cisco 7971G-GE |
| Cisco Unified IP Phones | - | Cisco 7905     |
| Cisco Unified IP Phones | - | Cisco 7937     |
| Cisco Unified IP Phones | - | Cisco 7921     |
| Cisco Unified IP Phones | - | Cisco 3911     |
| Cisco Unified IP Phones | - | Cisco 6921     |
| Cisco Unified IP Phones | - | Cisco 6941     |
| Cisco Unified IP Phones | - | Cisco 6961     |
| Cisco Unified IP Phones | - | Cisco 9971     |
| Cisco Unified IP Phones | - | Cisco 9951     |
| Cisco Unified IP Phones | - | Cisco 8961     |
| Cisco Unified IP Phones | - | Cisco 6901     |

|                         |   |   |
|-------------------------|---|---|
| Cisco Unified IP Phones | - | Cisco 6911                              |
| Cisco Unified IP Phones | - | Cisco 6945                              |
| Cisco Unified IP Phones | - | Cisco 6951                              |
| Cisco Unified IP Phones | - | Cisco 7925                              |
| Cisco Unified IP Phones | - | Cisco 7926                              |
| Cisco Unified IP Phones | - | Cisco 3905                              |
| Cisco Unified IP Phones | - | Cisco 8941                              |
| Cisco Unified IP Phones | - | Cisco 8945                              |
| Cisco Unified IP Phones | - | Cisco 9945                              |
| Cisco Unified IP Phones | - | Cisco 9965                              |
| -                       | - | Cisco Dual Mode for Android             |
| -                       | - | Cisco Dual Mode for iPhone              |
| -                       | - | Cisco IP Communicator                   |
| -                       | - | Cisco Unified Client Services Framework |
| -                       | - | Cisco Unified Personal Communicator     |

## Cisco Infrastructure Devices

| Product Series     | Product Name                         | System OID                   |
|--------------------|--------------------------------------|------------------------------|
| Cisco Call Manager | Cisco Unified Communications Manager | 1.3.6.1.4.1.9.1.cucm         |
| Cisco MCU          | Cisco MSE 8050 (Supervisor)          | 1.2.826.0.1.4616240.1.7.8050 |
| Cisco MCU          | Cisco MCU MSE 8420                   | 1.2.826.0.1.4616240.1.1.8420 |
| Cisco MCU          | Cisco MCU MSE 8510                   | 1.2.826.0.1.4616240.1.1.8510 |
| Cisco MCU          | Cisco MCU 4200                       | 1.2.826.0.1.4616240.1.1.4200 |
| Cisco MCU          | Cisco MCU 4201                       | 1.2.826.0.1.4616240.1.1.4201 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|   |                                    |                              |
|---|------------------------------------|------------------------------|
| Cisco MCU                                   | Cisco MCU 4203                     | 1.2.826.0.1.4616240.1.1.4203 |
| Cisco MCU                                   | Cisco MCU 4205                     | 1.2.826.0.1.4616240.1.1.4205 |
| Cisco MCU                                   | Cisco MCU 4210                     | 1.2.826.0.1.4616240.1.1.4210 |
| Cisco MCU                                   | Cisco MCU 4215                     | 1.2.826.0.1.4616240.1.1.4215 |
| Cisco MCU                                   | Cisco MCU 4220                     | 1.2.826.0.1.4616240.1.1.4220 |
| Cisco MCU                                   | Cisco MCU 4500                     | 1.2.826.0.1.4616240.1.1.4500 |
| Cisco MCU                                   | Cisco MCU 4501                     | 1.2.826.0.1.4616240.1.1.4501 |
| Cisco MCU                                   | Cisco MCU 4505                     | 1.2.826.0.1.4616240.1.1.4505 |
| Cisco MCU                                   | Cisco MCU 4510                     | 1.2.826.0.1.4616240.1.1.4510 |
| Cisco MCU                                   | Cisco MCU 4515                     | 1.2.826.0.1.4616240.1.1.4515 |
| Cisco MCU                                   | Cisco MCU 4520                     | 1.2.826.0.1.4616240.1.1.4520 |
| Cisco MCU                                   | Cisco MCU 5310                     | 1.3.6.1.4.1.9.1.1540         |
| Cisco Telepresence Conductor                | Cisco Telepresence Conductor       | 1.3.6.1.4.1.5596.180.6.4.1   |
| Cisco TelePresence Manager                  | Cisco CTS Manager                  | 1.3.6.1.4.1.9.1.ctsman       |
| Cisco TMS                                   | Cisco TMS                          | 1.3.6.1.4.1.311.1.1.3.1.2    |
| Cisco TPS                                   | Cisco Telepresence Server MSE 8710 | 1.2.826.0.1.4616240.1.1.8710 |
| Cisco TPS                                   | Cisco Telepresence Server 7010     | 1.2.826.0.1.4616240.1.1.7010 |
| Cisco CTX                                   | Cisco Telepresence Exchange Server | 1.3.6.1.4.1.9.1.587          |
| Cisco VCS                                   | Cisco VCS                          | 1.3.6.1.4.1.9.1.vcs          |
| Cisco 7800 Series Media Convergence Servers | MCS7816H                           | 1.3.6.1.4.1.9.1.900          |
|   | MCS7828H                           | 1.3.6.1.4.1.9.1.901          |
|   | MCS7825H                           | 1.3.6.1.4.1.9.1.583          |
|   | MCS7835H                           | 1.3.6.1.4.1.9.1.584          |
|   | MCS7845H                           | 1.3.6.1.4.1.9.1.586          |
|   | MCS7815 I                          | 1.3.6.1.4.1.9.1.582          |
|   | MCS7835 I                          | 1.3.6.1.4.1.9.1.585          |
|   | MCS7845 I                          | 1.3.6.1.4.1.9.1.587          |
|   | MCS7855 I                          | 1.3.6.1.4.1.9.1.588          |
|   | MCS7865 I                          | 1.3.6.1.4.1.9.1.589          |
|   | MCS7825 I                          | 1.3.6.1.4.1.9.1.746          |
|   | MCS7816 I                          | 1.3.6.1.4.1.9.1.898          |
| MCS7828 I                                   | 1.3.6.1.4.1.9.1.899                |                              |
| Cisco Unified Border Element (CUBE)         | Cisco 2800 Series ISR              | ?                            |
|   | Cisco 2900 Series ISR              | ?                            |
|   | Cisco 3800 Series ISR              | ?                            |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|  |                                  |                     |
|--|----------------------------------|---------------------|
|  | Cisco 3900 Series ISR            | ?                   |
|  | Cisco 7200VXR Routers            | ?                   |
|  | Cisco 7301 Routers               | ?                   |
|  | Cisco AS5350XM Universal Gateway | ?                   |
|  | Cisco AS5400XM Universal Gateway | ?                   |
| Cisco Unified Client Services Framework (CUCSF) Client                     | ?                                | ?                   |
| Cisco Unified Communications 500 Series for Small Business                 | UC520s8U4FXO                     | 1.3.6.1.4.1.9.1.878 |
|  | UC520s8U4FXOW                    | 1.3.6.1.4.1.9.1.879 |
|  | UC520s8U2BRI                     | 1.3.6.1.4.1.9.1.880 |
|  | UC520s8U2BRIW                    | 1.3.6.1.4.1.9.1.881 |
|  | UC520s16U4FXO                    | 1.3.6.1.4.1.9.1.882 |
|  | UC520s16U4FXOW                   | 1.3.6.1.4.1.9.1.883 |
|  | UC520s16U2BRI                    | 1.3.6.1.4.1.9.1.884 |
|  | UC520s16U2BRIW                   | 1.3.6.1.4.1.9.1.885 |
|  | UC520m32U8FXO                    | 1.3.6.1.4.1.9.1.886 |
|  | UC520m32U4BRI                    | 1.3.6.1.4.1.9.1.888 |
|  | UC520m48U12FXO                   | 1.3.6.1.4.1.9.1.890 |
|  | UC520m48U6BRI                    | 1.3.6.1.4.1.9.1.892 |
|  | UC520m48U1T1E1F                  | 1.3.6.1.4.1.9.1.894 |
| UC520m48U1T1E1B  | 1.3.6.1.4.1.9.1.895              |                     |
| Cisco Unified Communications Integration for Microsoft Office Communicator | ?                                | ?                   |
| Cisco Unified Communications Manager                                       | ?                                | ?                   |
| Cisco Unified Communications Manager Business Edition                      | ?                                | ?                   |
| Cisco Unified Communications Manager Express                               | ?                                | ?                   |
| Cisco Unified Contact Center Enterprise Edition                            | ?                                | 1.3.6.1.4.1.9.1.693 |
| Cisco Unified Contact Center Express Edition                               | ?                                | ?                   |

Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|   |     |                      |
|---|-----|----------------------|
| Cisco Unified Customer Voice Portal   | ?   | ?                    |
| Cisco Expert Advisor  | ?   | ?                    |
| Cisco Unified MeetingPlace Enterprise   | ?   | 1.3.6.1.4.1.9.9.733  |
| Cisco Unified MeetingPlace Express  | ?   | ?                    |
| Cisco Unified Personal Communicator   | ?   | ?                    |
| Cisco Unified Presence Server   | ?   | ?                    |
| Cisco Unified SIP Proxy   | NME | 1.3.6.1.4.1.9.1.1406 |
|   | SM  | 1.3.6.1.4.1.9.1.1150 |
| Cisco Emergency Responder   | ?   | ?                    |
| Cisco Personal Assistant  | ?   | ?                    |
| Cisco Unity   | ?   | ?                    |
| Cisco Unity Connection  | ?   | ?                    |
| Cisco Unity Express   | ?   | ?                    |
| Media Sense   | ?   | ?                    |
| Finesse   | ?   | ?                    |
| Cisco NAM software (Versions - 4.x, 5.0, 5.1, and 5.1 (2) )   | ?   | ?                    |
| Cisco NAM hardware:   | ?   | ?                    |
| <p>1. Cisco NAM 2200 Series Appliances</p> <ul style="list-style-type: none"> <li>• NAM2204-RJ45</li> <li>• NAM2204-SFP</li> <li>• NAM2220</li> </ul> <p>2. Cisco Catalyst 6500 and Cisco 7600 Series; Cisco Integrated Services Routers (Branch Routers)</p> <ul style="list-style-type: none"> <li>• NME-NAM-80S</li> <li>• NME-NAM-120S</li> <li>• WS-SVC-NAM-1</li> <li>• WS-SVC-NAM-2</li> <li>• WS-SVC-NAM-1-250S</li> <li>• WS-SVC-NAM-2-250S</li> </ul> |     |                      |

|  |   |   |
|--|---|---|
| <ul style="list-style-type: none"> <li>• NM-NAM (Supported with NAM 4.0 only. NAM 4.1 and 4.2 are not supported on NM-NAM.)</li> </ul> |   |   |
| Cisco 1040 Sensor (Binary Image file name - SvcMonAB2_102.img)   | ? | ? |

## Cisco Network Devices

| Device Group                          | Device Series                                | Device Name                                  | SystemObjectID              |
|---------------------------------------|--|--|-----------------------------|
| Cisco UCS Series                      | Cisco UCS Series Servers                     | Cisco UCS 6120XP 20-Port Fabric Interconnect | 1.3.6.1.4.1.9.12.3.1.3.847  |
| Cisco UCS Series                      | Cisco UCS Series Servers                     | Cisco UCS 6140XP 40-Port Fabric Interconnect | 1.3.6.1.4.1.9.12.3.1.3.899  |
| Cisco UCS Series                      | Cisco UCS Series Servers                     | Cisco UCS 6248UP 48-Port Fabric Interconnect | 1.3.6.1.4.1.9.12.3.1.3.1062 |
| Cisco UCS Series                      | Cisco UCS Series Servers                     | Cisco UCS 6296UP 96-Port Fabric Interconnect | 1.3.6.1.4.1.9.12.3.1.3.1063 |
| Universal Gateways and Access Servers | Cisco 2500 Series Access Servers             | Cisco 2509 Access Server                     | 1.3.6.1.4.1.9.1.153         |
| Universal Gateways and Access Servers | Cisco 2500 Series Access Servers             | Cisco 2510 Access Server                     | 1.3.6.1.4.1.9.1.26          |
| Universal Gateways and Access Servers | Cisco 2500 Series Access Servers             | Cisco 2511 Access Server                     | 1.3.6.1.4.1.9.1.154         |
| Universal Gateways and Access Servers | Cisco 2500 Series Access Servers             | Cisco 2512 Access Server                     | 1.3.6.1.4.1.9.1.28          |
| Universal Gateways and Access Servers | Cisco AS5200 Series Universal Access Servers | Cisco AS5201 Universal Access Server         | 1.3.6.1.4.1.9.1.109         |
|                                       |  |  | 1.3.6.1.4.1.9.1.313         |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                                       |  |   |                     |
|---------------------------------------|--|---|---------------------|
| Universal Gateways and Access Servers | Cisco AS5300 Series Universal Gateways         | Cisco AS5350 Universal Gateway          |                     |
| Universal Gateways and Access Servers | Cisco AS5300 Series Universal Gateways         | Cisco AS5300 Access Server              | 1.3.6.1.4.1.9.1.162 |
| Universal Gateways and Access Servers | Cisco AS5300 Series Universal Gateways         | Cisco AS5350XM Universal Gateway        | 1.3.6.1.4.1.9.1.679 |
| Universal Gateways and Access Servers | Cisco AS5400 Series Universal Gateways         | Cisco AS5400 Universal Gateway          | 1.3.6.1.4.1.9.1.274 |
| Universal Gateways and Access Servers | Cisco AS5400 Series Universal Gateways         | Cisco AS5400XM Universal Gateway        | 1.3.6.1.4.1.9.1.668 |
| Universal Gateways and Access Servers | Cisco AS5800 Series Universal Gateways         | Cisco AS5800 Access Server              | 1.3.6.1.4.1.9.1.188 |
| Universal Gateways and Access Servers | Cisco AS5800 Series Universal Gateways         | Cisco AS5850 Universal Gateway          | 1.3.6.1.4.1.9.1.308 |
| Universal Gateways and Access Servers | Other Access Devices                           | TerminalServer                          | 1.3.6.1.4.1.9.1.2   |
| Content Networking                    | Cisco 500 Series Cache Engines                 | Cisco 500 Cache Engine                  | 1.3.6.1.4.1.9.1.240 |
| Content Networking                    | Cisco 500 Series Cache Engines                 | Cisco 500 Cache Engine                  | 1.3.6.1.4.1.9.1.9   |
| Content Networking                    | Cisco 500 Series Cache Engines                 | Cisco 500 Cache Engine                  | 1.3.6.1.4.1.9.1.244 |
| Content Networking                    | Cisco Micro Webservers                         | Cisco Micro Webserver 200               | 1.3.6.1.4.1.9.1.176 |
| Content Networking                    | Cisco 4600 Series Content Distribution Manager | Cisco 4650 Content Distribution Manager | 1.3.6.1.4.1.9.1.487 |
| Content Networking                    | Cisco 4600 Series Content Distribution Manager | Cisco 4630 Content Distribution Manager | 1.3.6.1.4.1.9.1.486 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                    |   |   |                     |
|--------------------|---|---|---------------------|
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 507 Content Engine                    | 1.3.6.1.4.1.9.1.409 |
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 507 AV Content Engine                 | 1.3.6.1.4.1.9.1.432 |
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 560 Content Engine                    | 1.3.6.1.4.1.9.1.410 |
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 560 Content Engine                    | 1.3.6.1.4.1.9.1.433 |
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 590 Content Engine                    | 1.3.6.1.4.1.9.1.411 |
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 510 Content Engine                    | 1.3.6.1.4.1.9.1.505 |
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 565 Content Engine                    | 1.3.6.1.4.1.9.1.491 |
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 566 Content Engine                    | 1.3.6.1.4.1.9.1.596 |
| Content Networking | Cisco 500 Series Content Engines                    | Cisco 501 Content Engine                    | 1.3.6.1.4.1.9.1.612 |
| Content Networking | Cisco 600 Series Content Engines                    | Cisco 611 Content Engine                    | 1.3.6.1.4.1.9.1.708 |
| Content Networking | Cisco 600 Series Content Engines                    | Cisco 674 Content Engine                    | 1.3.6.1.4.1.9.1.996 |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-274 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.987 |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-474 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.986 |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-511 Wide Area Application Engines | 1.3.6.1.4.1.9.1.595 |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-511 Wide Area Application Engines | 1.3.6.1.4.1.9.1.681 |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-511 Wide Area Application Engines | 1.3.6.1.4.1.9.1.785 |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-512 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.759 |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-512 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.776 |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-574 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.985 |
|                    |   |   | 1.3.6.1.4.1.9.1.786 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                    |   |   |                         |
|--------------------|---|---|-------------------------|
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-611 Wide Area Application Engine  |                         |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-612 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.757     |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-612 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.761     |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-612 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.777     |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-674 Wide Area Application Engine  | 1.3.6.1.4.1.9.1.957     |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-7326 Wide Area Application Engine | 1.3.6.1.4.1.9.1.787     |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-7341 Wide Area Application Engine | 1.3.6.1.4.1.9.1.907     |
| Content Networking | Cisco Wide Area Application Engine (WAE) Appliances | Cisco WAE-7371 Wide Area Application Engine | 1.3.6.1.4.1.9.1.908     |
| Content Networking | Cisco 7300 Series Content Engines                   | Cisco 7320 Content Engine                   | 1.3.6.1.4.1.9.1.412     |
| Content Networking | Cisco 7300 Series Content Engines                   | Cisco 7305 Content Engine                   | 1.3.6.1.4.1.9.1.504     |
| Content Networking | Cisco 7300 Series Content Engines                   | Cisco 7325 Content Engine                   | 1.3.6.1.4.1.9.1.492     |
| Content Networking | Cisco 7300 Series Content Engines                   | Cisco 7306 Content Engine                   | 1.3.6.1.4.1.9.1.600     |
| Content Networking | Cisco 7300 Series Content Engines                   | Cisco 7326 Content Engine                   | 1.3.6.1.4.1.9.1.601     |
| Content Networking | Cisco 7300 Series Content Engines                   | Cisco 7341 Content Engine                   | 1.3.6.1.4.1.9.1.982     |
| Content Networking | Cisco 7300 Series Content Engines                   | Cisco 7371 Content Engine                   | 1.3.6.1.4.1.9.1.983     |
| Content Networking | Cisco DistributedDirector                           | Cisco DistributedDirector 4700M             | 1.3.6.1.4.1.9.1.50      |
| Content Networking | Cisco CSS 11000 Series Content Services Switches    | Cisco CSS 11050 Content Services Switch     | 1.3.6.1.4.1.2467.4.4    |
| Content Networking | Cisco CSS 11000 Series Content Services Switches    | Cisco CSS 11050 Content Services Switch     | 1.3.6.1.4.1.9.9.368.4.4 |
|                    |   |   | 1.3.6.1.4.1.2467.4.1    |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                    |   |   |                         |
|--------------------|---|---|-------------------------|
| Content Networking | Cisco CSS 11000 Series Content Services Switches          | Cisco CSS 11100 Content Services Switch             |                         |
| Content Networking | Cisco CSS 11000 Series Content Services Switches          | Cisco CSS 11150 Content Services Switch             | 1.3.6.1.4.1.2467.4.3    |
| Content Networking | Cisco CSS 11000 Series Content Services Switches          | Cisco CSS 11150 Content Services Switch             | 1.3.6.1.4.1.9.9.368.4.3 |
| Content Networking | Cisco CSS 11000 Series Content Services Switches          | Cisco CSS 11800 Content Services Switch             | 1.3.6.1.4.1.2467.4.2    |
| Content Networking | Cisco CSS 11000 Series Content Services Switches          | Cisco CSS 11800 Content Services Switch             | 1.3.6.1.4.1.9.9.368.4.2 |
| Content Networking | Cisco 4400 Series Content Routers                         | Cisco 4450 Content Router                           | 1.3.6.1.4.1.9.1.532     |
| Content Networking | Cisco 4400 Series Content Routers                         | Cisco 4430 Content Router                           | 1.3.6.1.4.1.9.1.531     |
| Content Networking | Cisco CSS 11500 Series Content Services Switches          | Cisco CSS 11506 Content Services Switch             | 1.3.6.1.4.1.2467.4.6    |
| Content Networking | Cisco CSS 11500 Series Content Services Switches          | Cisco CSS 11506 Content Services Switch             | 1.3.6.1.4.1.9.9.368.4.6 |
| Content Networking | Cisco CSS 11500 Series Content Services Switches          | Cisco CSS 11503 Content Services Switch             | 1.3.6.1.4.1.2467.4.5    |
| Content Networking | Cisco CSS 11500 Series Content Services Switches          | Cisco CSS 11503 Content Services Switch             | 1.3.6.1.4.1.9.9.368.4.5 |
| Content Networking | Cisco CSS 11500 Series Content Services Switches          | Cisco CSS 11501 Content Services Switch             | 1.3.6.1.4.1.2467.4.7    |
| Content Networking | Cisco CSS 11500 Series Content Services Switches          | Cisco CSS 11501 Content Services Switch             | 1.3.6.1.4.1.9.9.368.4.7 |
| Content Networking | Cisco ACE GSS 4400 Series Global Site Selector Appliances | Cisco GSS 4480,4490,4491,4492R Global Site Selector | 1.3.6.1.4.1.9.1.517     |
| Content Networking | Cisco ACE GSS 4400 Series Global Site Selector Appliances | Cisco GSS 4490 Global Site Selector                 | 1.3.6.1.4.1.9.1.518     |
| Content Networking | Cisco ACE GSS 4400 Series Global Site Selector            | Cisco GSS 4491 Global Site Selector                 | 1.3.6.1.4.1.9.1.519     |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                              | Appliances   |   |                              |
|------------------------------|--|---|------------------------------|
| Cisco Interfaces and Modules | Cisco Interface Cards  | Cisco Intrusion Prevention System Advanced Integration Module | 1.3.6.1.4.1.9.12.3.1.9.2.213 |
| Cisco Interfaces and Modules | Cisco Interface Cards  | Cisco Intrusion Prevention System Network Module              | 1.3.6.1.4.1.9.12.3.1.9.2.180 |
| Cisco Interfaces and Modules | Cisco Interface Cards  | Cisco 3205 Wireless Mobile Interface Card (WMIC)              | 1.3.6.1.4.1.9.1.819          |
| Cisco Interfaces and Modules | Cisco Interface Cards  | Cisco 3202 Wireless Mobile Interface Card (WMIC)              | 1.3.6.1.4.1.9.1.667          |
| Cisco Interfaces and Modules | Cisco Services-Ready Engine (SRE) Modules                        | Application Extension Platform for SRE                        | 1.3.6.1.4.1.9.1.1280         |
| Cisco Interfaces and Modules | Cisco Services-Ready Engine (SRE) Modules                        | Application Extension Platform for SRE                        | 1.3.6.1.4.1.9.1.1281         |
| Cisco Interfaces and Modules | Cisco Services-Ready Engine (SRE) Modules                        | Application Extension Platform for SRE                        | 1.3.6.1.4.1.9.1.1282         |
| Cisco Interfaces and Modules | Cisco Services-Ready Engine (SRE) Modules                        | Application Extension Platform for SRE                        | 1.3.6.1.4.1.9.1.1283         |
| Cisco Interfaces and Modules | Cisco Services-Ready Engine (SRE) Modules                        | Application Extension Platform for SRE                        | 1.3.6.1.4.1.9.1.1284         |
| Cisco Interfaces and Modules | Cisco Services-Ready Engine (SRE) Modules                        | Cisco Wide Area Application Services (WAAS) Modules for SRE   | 1.3.6.1.4.1.9.1.1212         |
| Cisco Interfaces and Modules | Cisco Services-Ready Engine (SRE) Modules                        | Cisco Wide Area Application Services (WAAS) Modules for SRE   | 1.3.6.1.4.1.9.1.1213         |
| Cisco Interfaces and Modules | Cisco Application Extension Platform Modules and Interface Cards | Cisco Application Extension Platform Network Module Enhanced  | 1.3.6.1.4.1.9.1.1151         |
| Cisco Interfaces and Modules | Cisco Application Extension Platform Modules and                 | Cisco Application Extension Platform Network Module           | 1.3.6.1.4.1.9.1.1288         |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                              | Interface Cards  | Enhanced   |                      |
|------------------------------|--|--|----------------------|
| Cisco Interfaces and Modules | Cisco Application Extension Platform Modules and Interface Cards | Cisco Application Extension Platform Network Module Enhanced       | 1.3.6.1.4.1.9.1.1289 |
| Cisco Interfaces and Modules | Cisco Application Extension Platform Modules and Interface Cards | Cisco Application Extension Platform Network Module Enhanced       | 1.3.6.1.4.1.9.1.1290 |
| Cisco Interfaces and Modules | Cisco Application Extension Platform Modules and Interface Cards | Cisco Application Extension Platform Advanced Integration Module   | 1.3.6.1.4.1.9.1.1152 |
| Cisco Interfaces and Modules | Cisco Application Extension Platform Modules and Interface Cards | Cisco Application Extension Platform Advanced Integration Module 2 | 1.3.6.1.4.1.9.1.1153 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer 2 EtherSwitch Service Module                  | 1.3.6.1.4.1.9.1.1048 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer 2 EtherSwitch Service Module                  | 1.3.6.1.4.1.9.1.1051 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer 2 EtherSwitch Service Module                  | 1.3.6.1.4.1.9.1.1052 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer 2 EtherSwitch Service Module                  | 1.3.6.1.4.1.9.1.1055 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module            | 1.3.6.1.4.1.9.1.1049 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module            | 1.3.6.1.4.1.9.1.1050 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module            | 1.3.6.1.4.1.9.1.1053 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module            | 1.3.6.1.4.1.9.1.1054 |
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules                         | Cisco Enhanced Layer2,Layer3 EtherSwitch Service                   | 1.3.6.1.4.1.9.1.1056 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                              |  | Module  |                              |
|------------------------------|--|---|------------------------------|
| Cisco Interfaces and Modules | Cisco Ethernet Switching Network Modules | Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module       | 1.3.6.1.4.1.9.1.1057         |
| Cisco Interfaces and Modules | Cisco Service Control Engines            | Cisco SCE 2020 Service Control Engine                         | 1.3.6.1.4.1.9.1.684          |
| Cisco Interfaces and Modules | Cisco Service Control Engines            | Cisco SCE 8000 Service Control Engine                         | 1.3.6.1.4.1.9.1.913          |
| Cisco Interfaces and Modules | Cisco Service Control Engines            | Cisco SCE 1000 Series Service Control Engine                  | 1.3.6.1.4.1.9.1.683          |
| Cisco Interfaces and Modules | Cisco Interface Cards                    | Cisco Intrusion Prevention System Advanced Integration Module | 1.3.6.1.4.1.9.12.3.1.9.2.213 |
| Cisco Interfaces and Modules | Cisco Interface Cards                    | Cisco Intrusion Prevention System Network Module              | 1.3.6.1.4.1.9.12.3.1.9.2.180 |
| Cisco Interfaces and Modules | Cisco Interface Cards                    | Cisco 3205 Wireless Mobile Interface Card (WMIC)              | 1.3.6.1.4.1.9.1.819          |
| Cisco Interfaces and Modules | Cisco Interface Cards                    | Cisco 3202 Wireless Mobile Interface Card (WMIC)              | 1.3.6.1.4.1.9.1.667          |
| Cisco Interfaces and Modules | Cisco Voice Modules and Interface Cards  | Cisco Unity Express Network Module                            | 1.3.6.1.4.1.9.1.622          |
| Cisco Interfaces and Modules | Cisco Voice Modules and Interface Cards  | Cisco Unity Express Network Module                            | 1.3.6.1.4.1.9.1.711          |
| Cisco Interfaces and Modules | Cisco Voice Modules and Interface Cards  | Cisco Unity Express Network Module                            | 1.3.6.1.4.1.9.1.866          |
| Cisco Interfaces and Modules | Cisco Voice Modules and Interface Cards  | Cisco Unity Express Advanced Integration Module               | 1.3.6.1.4.1.9.1.623          |
| Cisco Interfaces and Modules | Cisco Voice Modules and Interface Cards  | Cisco Unity Express Advanced Integration Module               | 1.3.6.1.4.1.9.1.867          |
| Cisco Interfaces and Modules | Cisco Voice Modules and Interface Cards  | Cisco Unity Express Advanced Integration Module               | 1.3.6.1.4.1.9.1.868          |
| Cisco Interfaces and Modules | Cisco Voice Modules and Interface Cards  | Cisco Unified SIP Proxy SM-SRE                                | 1.3.6.1.4.1.9.1.1150         |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                              |   |   |                      |
|------------------------------|---|---|----------------------|
| Cisco Interfaces and Modules | Cisco Voice Modules and Interface Cards | Cisco Unified SIP Proxy NME   | 1.3.6.1.4.1.9.1.1406 |
| Cisco Interfaces and Modules | Cisco IGX Universal Router Modules      | Cisco IGX Universal Router Module 2FE                               | 1.3.6.1.4.1.9.1.374  |
| Cisco Interfaces and Modules | Cisco IGX Universal Router Modules      | Cisco IGX Universal Router Module 2FE-2V                            | 1.3.6.1.4.1.9.1.375  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco 2600,2800,3700,3800 Series 16-Port EtherSwitch Service Module | 1.3.6.1.4.1.9.1.663  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco 2600,2800,3700,3800 Series 16-Port EtherSwitch Service Module | 1.3.6.1.4.1.9.1.702  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco 2600,3600,3700 Series Content Engine Modules                  | 1.3.6.1.4.1.9.1.454  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco Catalyst 6000 Multilayer Switch Feature Card MSFC2            | 1.3.6.1.4.1.9.1.301  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco Catalyst 6000 Series Supervisor Module with MSFC              | 1.3.6.1.4.1.9.1.258  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco Catalyst 6000 Multilayer Switch Feature Card MSFC3            | 1.3.6.1.4.1.9.1.557  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco Catalyst 5000 RSM   | 1.3.6.1.4.1.9.1.168  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco Catalyst 5500 RSM   | 1.3.6.1.4.1.9.1.257  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco Catalyst 6000 Series Switches MSM                             | 1.3.6.1.4.1.9.1.256  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco Catalyst 6000 Access Gateway line card                        | 1.3.6.1.4.1.9.1.573  |
| Cisco Interfaces and Modules | Cisco Network Modules                   | Cisco IDS Access Router Network Module                              | 1.3.6.1.4.1.9.1.654  |
| Cisco Interfaces             | Cisco Network Modules                   | Cisco 2800,3800 Series 23-Port EtherSwitch                          | 1.3.6.1.4.1.9.1.664  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

| and Modules                  |                        | Service Module  |                      |
|------------------------------|------------------------|---|----------------------|
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco 2800,3800 Series 23-Port EtherSwitch Service Module                             | 1.3.6.1.4.1.9.1.703  |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco 2851,3800 Series 24-Port EtherSwitch (with Stackwise Connectors) Service Module | 1.3.6.1.4.1.9.1.665  |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco 2851,3800 Series 48-Port EtherSwitch Service Module                             | 1.3.6.1.4.1.9.1.666  |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco Wide Area Application Services Network Module(NME-WAE-502)                      | 1.3.6.1.4.1.9.1.823  |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco Wide Area Application Services Network Module(NME-WAE-502)                      | 1.3.6.1.4.1.9.1.1161 |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco Wide Area Application Services Network Module(NME-WAE-502)                      | 1.3.6.1.4.1.9.1.1162 |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco Wide Area Application Services Network Module(NME-WAE-502)                      | 1.3.6.1.4.1.9.1.1209 |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco Wide Area Application Services Network Module(NME-WAE-502)                      | 1.3.6.1.4.1.9.1.1210 |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco Wide Area Application Services Network Module(NME-WAE-502)                      | 1.3.6.1.4.1.9.1.1211 |
| Cisco Interfaces and Modules | Cisco Network Modules  | Cisco Wide Area Application Services Network Module(NME-WAE-522)                      | 1.3.6.1.4.1.9.1.1211 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA 5585 IPS Security Services Processor Virtual Sensor                         | 1.3.6.1.4.1.9.1.1437 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA 5585 IPS Security Services Processor Virtual Sensor                         | 1.3.6.1.4.1.9.1.1438 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA 5585 IPS Security Services Processor Virtual Sensor                         | 1.3.6.1.4.1.9.1.1439 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                              |                        |   |                      |
|------------------------------|------------------------|---|----------------------|
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA 5585 IPS Security Services Processor Virtual Sensor | 1.3.6.1.4.1.9.1.1440 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA 5585 IPS Security Services Processor                | 1.3.6.1.4.1.9.1.1232 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA 5585 IPS Security Services Processor                | 1.3.6.1.4.1.9.1.1233 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA 5585 IPS Security Services Processor                | 1.3.6.1.4.1.9.1.1234 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA 5585 IPS Security Services Processor                | 1.3.6.1.4.1.9.1.1235 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Content Switching Module with SSL                       | 1.3.6.1.4.1.9.1.524  |
| Cisco Interfaces and Modules | Cisco Services Modules | SAMI  | 1.3.6.1.4.1.9.1.744  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Catalyst 6500 Series SSL Services Module                | 1.3.6.1.4.1.9.1.554  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ACE Application Control Engine Module                   | 1.3.6.1.4.1.9.1.730  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ACE Application Control Engine Module                   | 1.3.6.1.4.1.9.1.1291 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ACE Application Control Engine Module                   | 1.3.6.1.4.1.9.1.1231 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ACE 4710 Application Control Engine                     | 1.3.6.1.4.1.9.1.824  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Branch Routers Series Network Analysis Module (NME-NAM) | 1.3.6.1.4.1.9.1.826  |
| Cisco Interfaces and Modules | Cisco Services Modules | Router RPM  | 1.3.6.1.4.1.9.1.457  |
| Cisco Interfaces and Modules | Cisco Services Modules | Router RPM  | 1.3.6.1.4.1.9.1.199  |
| Cisco Interfaces and Modules | Cisco Services Modules | Router RPM  | 1.3.6.1.4.1.9.1.440  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                              |                        |   |                      |
|------------------------------|------------------------|---|----------------------|
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module                   | 1.3.6.1.4.1.9.1.662  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module                   | 1.3.6.1.4.1.9.1.655  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module                   | 1.3.6.1.4.1.9.1.944  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA Advanced Inspection and Prevention Security Services Card                           | 1.3.6.1.4.1.9.1.1039 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA Advanced Inspection and Prevention Security Services Card                           | 1.3.6.1.4.1.9.1.1010 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA Advanced Inspection and Prevention Security Services Card                           | 1.3.6.1.4.1.9.1.1085 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA Advanced Inspection and Prevention Security Services Card                           | 1.3.6.1.4.1.9.1.1086 |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Catalyst 6500 Series Firewall Services Module   | 1.3.6.1.4.1.9.1.522  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Catalyst 6500 Series Firewall Services Module Security Context                          | 1.3.6.1.4.1.9.1.674  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Catalyst 6500 Series Firewall Services Module System Context                            | 1.3.6.1.4.1.9.1.767  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Catalyst 6500 Series Wireless LAN Services Module                                       | 1.3.6.1.4.1.9.1.599  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Catalyst 6500 Series Intrusion Detection System (IDSM-2) Services Module                | 1.3.6.1.4.1.9.1.653  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco Catalyst 6500 Series Intrusion Detection System (IDSM-2) Services Module Virtual Sensor | 1.3.6.1.4.1.9.1.815  |
| Cisco Interfaces and Modules | Cisco Services Modules | Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module Virtual Sensor    | 1.3.6.1.4.1.9.1.817  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                              |                               |  |                               |
|------------------------------|-------------------------------|--|-------------------------------|
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module Virtual Sensor | 1.3.6.1.4.1.9.1.816           |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco ASA Advanced Inspection and Prevention (AIP) Security Services Module Virtual Sensor | 1.3.6.1.4.1.9.1.943           |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco ONS Radio Access Network (RAN) Service Module  | 1.3.6.1.4.1.9.1.772           |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco ASA 5585 IPS Security Services Processor   | 1.3.6.1.4.1.9.1.1232          |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco ASA 5585 IPS Security Services Processor   | 1.3.6.1.4.1.9.1.1233          |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco ASA 5585 IPS Security Services Processor   | 1.3.6.1.4.1.9.1.1234          |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco ASA 5585 IPS Security Services Processor   | 1.3.6.1.4.1.9.1.1235          |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco Catalyst 6500 Series ASA Services Module   | 1.3.6.1.4.1.9.1.1277          |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco Catalyst 6500 Series ASA Services Module Security Context                            | 1.3.6.1.4.1.9.1.1275          |
| Cisco Interfaces and Modules | Cisco Services Modules        | Cisco Catalyst 6500 Series ASA Services Module System Context                              | 1.3.6.1.4.1.9.1.1276          |
| Cisco Interfaces and Modules | Cisco Service Control Engines | Cisco SCE 2020 Service Control Engine  | 1.3.6.1.4.1.9.1.684           |
| Cisco Interfaces and Modules | Cisco Service Control Engines | Cisco SCE 8000 Service Control Engine  | 1.3.6.1.4.1.9.1.913           |
| Cisco Interfaces and Modules | Cisco Service Control Engines | Cisco SCE 1000 Series Service Control Engine   | 1.3.6.1.4.1.9.1.683           |
| Cisco Interfaces and Modules | Network Analysis Modules      | 6380-NAM   | 1.3.6.1.4.1.9.5.1.3.1.1.2.223 |
| Cisco Interfaces and Modules | Network Analysis Modules      | WS-SVC-NAM-1   | 1.3.6.1.4.1.9.5.1.3.1.1.2.914 |
|                              |                               | WS-SVC-NAM-2   | 1.3.6.1.4.1.9.5.1.3.1.1.2.291 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                              |                          |  |                               |
|------------------------------|--------------------------|--|-------------------------------|
| Cisco Interfaces and Modules | Network Analysis Modules |  |                               |
| Cisco Interfaces and Modules | Network Analysis Modules | WS-SVC-NAM-3   | 1.3.6.1.4.1.9.1.1029          |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco Catalyst 6500 Series Network Analysis Module (NAM-3) | 1.3.6.1.4.1.9.12.3.1.9.29.175 |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco Catalyst 6500 Series Network Analysis Module (NAM-3) | 1.3.6.1.4.1.9.1.1529          |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco Nexus 1000V NAM VSB                                  | 1.3.6.1.4.1.9.1.1214          |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco WAAS NAM Virtual Blade                               | 1.3.6.1.4.1.9.1.1169          |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco 2600,3660,3700 Series NAM                            | 1.3.6.1.4.1.9.1.562           |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco Catalyst 4000 Series NAM                             | 1.3.6.1.4.1.9.1.575           |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco NAM 2204 Appliance                                   | 1.3.6.1.4.1.9.1.1032          |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco NAM 2220 Appliance                                   | 1.3.6.1.4.1.9.1.1033          |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco Prime NAM 2304 Appliance                             | 1.3.6.1.4.1.9.1.1527          |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco Prime NAM 2320 Appliance                             | 1.3.6.1.4.1.9.1.1528          |
| Cisco Interfaces and Modules | Network Analysis Modules | Cisco SM-SRE Network Analysis Module                       | 1.3.6.1.4.1.9.1.1314          |
| Cisco Interfaces and Modules | Netflow Generation Agent | Cisco Netflow Generation Agent (NGA) 3140                  | 1.3.6.1.4.1.9.1.1539          |
| Cisco Interfaces and Modules | NetScout Probes          | NetScout Model 8221  | 1.3.6.1.4.1.141.1.1.8221      |
| Cisco Interfaces and Modules | NetScout Probes          | NetScout Model 8241ET                                      | 1.3.6.1.4.1.141.1.1.8241      |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                                   |  |                                     |                          |
|-----------------------------------|--|-------------------------------------|--------------------------|
| Cisco Interfaces and Modules      | NetScout Probes                            | NetScout Model 8243ET               | 1.3.6.1.4.1.141.1.1.8243 |
| Cisco Interfaces and Modules      | NetScout Probes                            | Netscout Model 8912ET               | 1.3.6.1.4.1.141.1.1.8912 |
| DSL and Long Reach Ethernet (LRE) | DSL  | Cisco 6200 Series IP DSL Switches   | 1.3.6.1.4.1.9.1.192      |
| DSL and Long Reach Ethernet (LRE) | Cisco 600 Series Modems                    | Cisco 626 ADSL Modem                | 1.3.6.1.4.1.9.1.329      |
| DSL and Long Reach Ethernet (LRE) | Cisco 600 Series Modems                    | Cisco 627 ADSL Modem                | 1.3.6.1.4.1.9.1.330      |
| DSL and Long Reach Ethernet (LRE) | Cisco 600 Series Modems                    | Cisco 633 SDSL Digital Service Unit | 1.3.6.1.4.1.9.1.331      |
| DSL and Long Reach Ethernet (LRE) | Cisco Catalyst 2900 Series LRE XL Switches | Cisco Catalyst 2912 LRE XL Switch   | 1.3.6.1.4.1.9.1.370      |
| DSL and Long Reach Ethernet (LRE) | Cisco Catalyst 2900 Series LRE XL Switches | Cisco Catalyst 2924 LRE XL Switch   | 1.3.6.1.4.1.9.1.369      |
| DSL and Long Reach Ethernet (LRE) | Cisco Catalyst 2900 Series LRE XL Switches | Cisco Catalyst 2908 XL Switch       | 1.3.6.1.4.1.9.1.170      |
| DSL and Long Reach Ethernet (LRE) | Cisco 6000 Series IP DSL Switches          | Cisco 6015 IP DSL Switch            | 1.3.6.1.4.1.9.1.299      |
| DSL and Long Reach Ethernet (LRE) | Cisco 6000 Series IP DSL Switches          | Cisco 6130 IP DSL Switch            | 1.3.6.1.4.1.9.1.252      |
| DSL and Long Reach Ethernet (LRE) | Cisco 6000 Series IP DSL Switches          | Cisco 6160 IP DSL Switch            | 1.3.6.1.4.1.9.1.297      |
| DSL and Long Reach Ethernet       | Cisco 6000 Series IP DSL Switches          | Cisco 6260 IP DSL Switch            | 1.3.6.1.4.1.9.1.253      |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                                   |   |   |                             |
|-----------------------------------|---|---|-----------------------------|
| (LRE)                             |   |   |                             |
| DSL and Long Reach Ethernet (LRE) | Cisco Catalyst 2950 LRE Series Switches | Cisco Catalyst 2950 8 LRE Switch                          | 1.3.6.1.4.1.9.1.483         |
| DSL and Long Reach Ethernet (LRE) | Cisco Catalyst 2950 LRE Series Switches | Cisco Catalyst 2950 24 LRE Switch                         | 1.3.6.1.4.1.9.1.482         |
| Optical Networking                | Metro Core                              | Cisco Metro 1500 Series (MAN DWDM)                        | 1.3.6.1.4.1.2544.1.3        |
| Optical Networking                | Metro Core                              | Cisco ONS 15454   | 1.3.6.1.4.1.3607.1.20.10.10 |
| Optical Networking                | Cisco ONS 15400 Series                  | Cisco ONS 15454 M6 Multiservice Transport Platform (MSTP) | 1.3.6.1.4.1.3607.1.20.10.70 |
| Optical Networking                | Cisco ONS 15500 Series                  | Cisco ONS 15540 ESP Extended Services Platform            | 1.3.6.1.4.1.9.1.406         |
| Optical Networking                | Cisco ONS 15500 Series                  | Cisco ONS 15540 ESP Extended Services Platform            | 1.3.6.1.4.1.9.1.481         |
| Optical Networking                | Cisco ONS 15500 Series                  | Cisco ONS 15530 DWDM Multiservice Aggregation Platform    | 1.3.6.1.4.1.9.1.460         |
| Optical Networking                | Cisco ONS 15500 Series                  | Cisco ONS 15530 DWDM Multiservice Aggregation Platform    | 1.3.6.1.4.1.9.1.461         |
| Optical Networking                | Cisco ONS 15500 Series                  | Cisco ONS 15530 DWDM Multiservice Aggregation Platform    | 1.3.6.1.4.1.9.1.462         |
| Optical Networking                | Cisco ONS 15500 Series                  | Cisco ONS 15501-DC  | 1.3.6.1.4.1.1869.11.11.5.1  |
| Optical Networking                | Cisco ONS 15500 Series                  | Cisco ONS 15501-AC  | 1.3.6.1.4.1.1869.11.11.5.3  |
| Optical Networking                | Cisco ONS 15300 Series                  | Cisco ONS 15305 Multiservice Customer Access Platform     | 1.3.6.1.4.1.7546.1.4.1.1.3  |
| Routers                           | Cisco 1800 Series Routers               | Cisco 1841,1841VE Integrated Services Router              | 1.3.6.1.4.1.9.1.620         |
| Routers                           | Cisco 1800 Series Routers               | Cisco 1841,1841VE Integrated Services Router              | 1.3.6.1.4.1.9.1.1369        |
| Routers                           | Cisco 1800 Series Routers               | Cisco 1861,1861W Integrated Services Router               | 1.3.6.1.4.1.9.1.902         |
| Routers                           | Cisco 1800 Series Routers               | Cisco 1861,1861W Integrated Services Router               | 1.3.6.1.4.1.9.1.903         |
| Routers                           |   |   | 1.3.6.1.4.1.9.1.904         |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |                           |  |                      |
|---------|---------------------------|--|----------------------|
|         | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        |                      |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.905  |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.939  |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.940  |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.990  |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.991  |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.992  |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.993  |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.994  |
| Routers | Cisco 1800 Series Routers | Cisco 1861,1861W Integrated Services Router        | 1.3.6.1.4.1.9.1.995  |
| Routers | Cisco 1800 Series Routers | Cisco 1805,1805EJ Integrated Services Router       | 1.3.6.1.4.1.9.1.981  |
| Routers | Cisco 1800 Series Routers | Cisco 1801,1801W,1801WM Integrated Services Router | 1.3.6.1.4.1.9.1.638  |
| Routers | Cisco 1800 Series Routers | Cisco 1801,1801W,1801WM Integrated Services Router | 1.3.6.1.4.1.9.1.783  |
| Routers | Cisco 1800 Series Routers | Cisco 1802 Integrated Services Router              | 1.3.6.1.4.1.9.1.639  |
| Routers | Cisco 1800 Series Routers | Cisco 1803,1803W Integrated Services Router        | 1.3.6.1.4.1.9.1.640  |
| Routers | Cisco 1800 Series Routers | Cisco 1811,1811W Integrated Services Router        | 1.3.6.1.4.1.9.1.641  |
| Routers | Cisco 1800 Series Routers | Cisco 1812,1812W Integrated Services Router        | 1.3.6.1.4.1.9.1.642  |
| Routers | Cisco 1800 Series Routers | Cisco 1861E Integrated Services Router             | 1.3.6.1.4.1.9.1.1339 |
| Routers | Cisco 1800 Series Routers | Cisco 1861E Integrated Services Router             | 1.3.6.1.4.1.9.1.1340 |
| Routers | Cisco 1800 Series Routers | Cisco 1861E Integrated Services Router             | 1.3.6.1.4.1.9.1.1341 |
| Routers | Cisco 1800 Series Routers | Cisco 1861E Integrated Services Router             | 1.3.6.1.4.1.9.1.1342 |
| Routers | Cisco 1800 Series Routers | Cisco 1861E Integrated Services Router             | 1.3.6.1.4.1.9.1.1343 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |   |   |                      |
|---------|---|---|----------------------|
| Routers | Cisco 1800 Series Routers                     | Cisco 1861E Integrated Services Router      | 1.3.6.1.4.1.9.1.1344 |
| Routers | CSM Generic Router                            | Cisco Generic Integrated Services Router    | 1.0.0.0.0.0.0.1      |
| Routers | CSM Generic Router                            | Cisco Generic Aggregation Services Router   | 1.0.0.0.0.0.0.2      |
| Routers | Cisco 5900 Series Embedded Services Routers   | Cisco 5915 Embedded Service Router          | 1.3.6.1.4.1.9.1.1355 |
| Routers | Cisco 5900 Series Embedded Services Routers   | Cisco 5915 Embedded Service Router          | 1.3.6.1.4.1.9.1.1356 |
| Routers | Cisco 5900 Series Embedded Services Routers   | Cisco 5940 Embedded Services Router         | 1.3.6.1.4.1.9.1.1163 |
| Routers | Cisco 5900 Series Embedded Services Routers   | Cisco 5940 Embedded Services Router         | 1.3.6.1.4.1.9.1.1164 |
| Routers | Cisco 2800 Series Integrated Services Routers | Cisco 2801 Integrated Services Router       | 1.3.6.1.4.1.9.1.619  |
| Routers | Cisco 2800 Series Integrated Services Routers | Cisco 2811VE Integrated Services Router     | 1.3.6.1.4.1.9.1.576  |
| Routers | Cisco 2800 Series Integrated Services Routers | Cisco 2811VE Integrated Services Router     | 1.3.6.1.4.1.9.1.1370 |
| Routers | Cisco 2800 Series Integrated Services Routers | Cisco 2821 Integrated Services Router       | 1.3.6.1.4.1.9.1.577  |
| Routers | Cisco 2800 Series Integrated Services Routers | Cisco 2851 Integrated Services Router       | 1.3.6.1.4.1.9.1.578  |
| Routers | Cisco 3800 Series Integrated Services Routers | Cisco 3825 Integrated Services Router       | 1.3.6.1.4.1.9.1.543  |
| Routers | Cisco 3800 Series Integrated Services Routers | Cisco 3845 Integrated Services Router       | 1.3.6.1.4.1.9.1.544  |
| Routers | Cisco 3800 Series Integrated Services Routers | Cisco 3825 NOVPN Integrated Services Router | 1.3.6.1.4.1.9.1.1103 |
| Routers | Cisco 3800 Series Integrated Services Routers | Cisco 3845 NOVPN Integrated Services Router | 1.3.6.1.4.1.9.1.1102 |
| Routers | Cisco AGSPlus                                 | Cisco AGSPlus Router                        | 1.3.6.1.4.1.9.1.11   |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |   |                                 |                     |
|---------|---|---------------------------------|---------------------|
|         | Routers                                 |                                 |                     |
| Routers | Cisco 3000 Series Routers               | Cisco 3000 Router               | 1.3.6.1.4.1.9.1.6   |
| Routers | Cisco 3100 Series Routers               | Cisco 3101 Router               | 1.3.6.1.4.1.9.1.32  |
| Routers | Cisco 3100 Series Routers               | Cisco 3102 Router               | 1.3.6.1.4.1.9.1.33  |
| Routers | Cisco 3100 Series Routers               | Cisco 3103 Router               | 1.3.6.1.4.1.9.1.34  |
| Routers | Cisco 3100 Series Routers               | Cisco 3104 Router               | 1.3.6.1.4.1.9.1.35  |
| Routers | Cisco 7000 Series Routers               | Cisco 7000 Router               | 1.3.6.1.4.1.9.1.8   |
| Routers | Cisco 7000 Series Routers               | Cisco 7010 Router               | 1.3.6.1.4.1.9.1.12  |
| Routers | Cisco 6400 Series Broadband Aggregators | Cisco 6400 Broadband Aggregator | 1.3.6.1.4.1.9.1.180 |
| Routers | Cisco 6400 Series Broadband Aggregators | Cisco 6400 Broadband Aggregator | 1.3.6.1.4.1.9.1.211 |
| Routers | Cisco 6400 Series Broadband Aggregators | Cisco 6400 Broadband Aggregator | 1.3.6.1.4.1.9.1.464 |
| Routers | Cisco 1000 Series Routers               | Cisco 1000 Router               | 1.3.6.1.4.1.9.1.40  |
| Routers | Cisco 1000 Series Routers               | Cisco 1003 Router               | 1.3.6.1.4.1.9.1.41  |
| Routers | Cisco 1000 Series Routers               | Cisco 1004 Router               | 1.3.6.1.4.1.9.1.44  |
| Routers | Cisco 1000 Series Routers               | Cisco 1005 Router               | 1.3.6.1.4.1.9.1.49  |
| Routers | Cisco 1000 Series Routers               | Cisco 1020 Router               | 1.3.6.1.4.1.9.1.43  |
| Routers | Cisco 12000 Series Routers              | Cisco 12004 Router              | 1.3.6.1.4.1.9.1.181 |
| Routers | Cisco 12000 Series Routers              | Cisco 12006 Router              | 1.3.6.1.4.1.9.1.590 |
| Routers | Cisco 12000 Series Routers              | Cisco 12008 Router              | 1.3.6.1.4.1.9.1.182 |
| Routers | Cisco 12000 Series Routers              | Cisco 12010 Router              | 1.3.6.1.4.1.9.1.348 |
| Routers | Cisco 12000 Series Routers              | Cisco 12012 Router              | 1.3.6.1.4.1.9.1.173 |
| Routers | Cisco 12000 Series Routers              | Cisco 12016 Router              | 1.3.6.1.4.1.9.1.273 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |  |  |                     |
|---------|--|--|---------------------|
| Routers | Cisco 12000 Series Routers               | Cisco 12410 Router                     | 1.3.6.1.4.1.9.1.394 |
| Routers | Cisco 12000 Series Routers               | Cisco 12416 Router                     | 1.3.6.1.4.1.9.1.385 |
| Routers | Cisco 12000 Series Routers               | Cisco 12406 Router                     | 1.3.6.1.4.1.9.1.388 |
| Routers | Cisco 12000 Series Routers               | Cisco 12404 Router                     | 1.3.6.1.4.1.9.1.423 |
| Routers | Cisco 12000 Series Routers               | Cisco 12816 Router                     | 1.3.6.1.4.1.9.1.477 |
| Routers | Cisco 12000 Series Routers               | Cisco 12810 Router                     | 1.3.6.1.4.1.9.1.478 |
| Routers | Cisco 1400 Series Routers                | Cisco 1401 Router                      | 1.3.6.1.4.1.9.1.206 |
| Routers | Cisco 1400 Series Routers                | Cisco 1417 Router                      | 1.3.6.1.4.1.9.1.250 |
| Routers | Cisco 1600 Series Routers                | Cisco 1601 Router                      | 1.3.6.1.4.1.9.1.113 |
| Routers | Cisco 1600 Series Routers                | Cisco 1602 Router                      | 1.3.6.1.4.1.9.1.114 |
| Routers | Cisco 1600 Series Routers                | Cisco 1603 Router                      | 1.3.6.1.4.1.9.1.115 |
| Routers | Cisco 1600 Series Routers                | Cisco 1604 Router                      | 1.3.6.1.4.1.9.1.116 |
| Routers | Cisco 1600 Series Routers                | Cisco 1605 Router                      | 1.3.6.1.4.1.9.1.172 |
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1701 ADSL Security Access Router | 1.3.6.1.4.1.9.1.550 |
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1711 Security Access Router      | 1.3.6.1.4.1.9.1.538 |
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1712 Security Access Router      | 1.3.6.1.4.1.9.1.539 |
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1720 Modular Access Router       | 1.3.6.1.4.1.9.1.201 |
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1750 Modular Access Router       | 1.3.6.1.4.1.9.1.216 |
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1751 Modular Access Router       | 1.3.6.1.4.1.9.1.326 |
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1710 Security Access Router      | 1.3.6.1.4.1.9.1.200 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |  |                                  |                     |
|---------|--|----------------------------------|---------------------|
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1760 Modular Access Router | 1.3.6.1.4.1.9.1.416 |
| Routers | Cisco 1700 Series Modular Access Routers | Cisco 1721 Modular Access Router | 1.3.6.1.4.1.9.1.444 |
| Routers | Cisco 2500 Series Routers                | Cisco 2500 Router                | 1.3.6.1.4.1.9.1.13  |
| Routers | Cisco 2500 Series Routers                | Cisco 2506 Router                | 1.3.6.1.4.1.9.1.22  |
| Routers | Cisco 2500 Series Routers                | Cisco 2508 Router                | 1.3.6.1.4.1.9.1.24  |
| Routers | Cisco 2500 Series Routers                | Cisco 2501 Router                | 1.3.6.1.4.1.9.1.17  |
| Routers | Cisco 2500 Series Routers                | Cisco 2501 Router                | 1.3.6.1.4.1.9.1.165 |
| Routers | Cisco 2500 Series Routers                | Cisco 2501 Router                | 1.3.6.1.4.1.9.1.166 |
| Routers | Cisco 2500 Series Routers                | Cisco 2502 Router                | 1.3.6.1.4.1.9.1.18  |
| Routers | Cisco 2500 Series Routers                | Cisco 2502 Router                | 1.3.6.1.4.1.9.1.167 |
| Routers | Cisco 2500 Series Routers                | Cisco 2503 Router                | 1.3.6.1.4.1.9.1.19  |
| Routers | Cisco 2500 Series Routers                | Cisco 2504 Router                | 1.3.6.1.4.1.9.1.20  |
| Routers | Cisco 2500 Series Routers                | Cisco 2505 Router                | 1.3.6.1.4.1.9.1.21  |
| Routers | Cisco 2500 Series Routers                | Cisco 2507 Router                | 1.3.6.1.4.1.9.1.23  |
| Routers | Cisco 2500 Series Routers                | Cisco 2513 Router                | 1.3.6.1.4.1.9.1.29  |
| Routers | Cisco 2500 Series Routers                | Cisco 2514 Router                | 1.3.6.1.4.1.9.1.30  |
| Routers | Cisco 2500 Series Routers                | Cisco 2515 Router                | 1.3.6.1.4.1.9.1.31  |
| Routers | Cisco 2500 Series Routers                | Cisco 2516 Router                | 1.3.6.1.4.1.9.1.42  |
| Routers | Cisco 2500 Series Routers                | Cisco 2520 Router                | 1.3.6.1.4.1.9.1.70  |
| Routers | Cisco 2500 Series Routers                | Cisco 2521 Router                | 1.3.6.1.4.1.9.1.71  |
| Routers | Cisco 2500 Series Routers                | Cisco 2522 Router                | 1.3.6.1.4.1.9.1.72  |
| Routers | Cisco 2500 Series Routers                | Cisco 2523 Router                | 1.3.6.1.4.1.9.1.73  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |  |                                  |                     |
|---------|--|----------------------------------|---------------------|
| Routers | Cisco 2500 Series Routers                | Cisco 2524 Router                | 1.3.6.1.4.1.9.1.74  |
| Routers | Cisco 2500 Series Routers                | Cisco 2525 Router                | 1.3.6.1.4.1.9.1.75  |
| Routers | Cisco 2500 Series Routers                | Cisco 2517 Router                | 1.3.6.1.4.1.9.1.67  |
| Routers | Cisco 2500 Series Routers                | Cisco 2518 Router                | 1.3.6.1.4.1.9.1.68  |
| Routers | Cisco 2500 Series Routers                | Cisco 2519 Router                | 1.3.6.1.4.1.9.1.69  |
| Routers | Cisco 2500 Series Routers                | Cisco 2509 Router                | 1.3.6.1.4.1.9.1.25  |
| Routers | Cisco 2500 Series Routers                | Cisco 2511 Router                | 1.3.6.1.4.1.9.1.27  |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2610 Multiservice Platform | 1.3.6.1.4.1.9.1.185 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2610 Multiservice Platform | 1.3.6.1.4.1.9.1.418 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2610 Multiservice Platform | 1.3.6.1.4.1.9.1.466 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2611 Multiservice Platform | 1.3.6.1.4.1.9.1.186 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2611 Multiservice Platform | 1.3.6.1.4.1.9.1.419 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2611 Multiservice Platform | 1.3.6.1.4.1.9.1.467 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2612 Multiservice Platform | 1.3.6.1.4.1.9.1.187 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2613 Multiservice Platform | 1.3.6.1.4.1.9.1.195 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2620 Multiservice Platform | 1.3.6.1.4.1.9.1.208 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2620 Multiservice Platform | 1.3.6.1.4.1.9.1.468 |
| Routers | Cisco 2600 Series Multiservice Platforms | Cisco 2621 Multiservice Platform | 1.3.6.1.4.1.9.1.209 |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |   |   |                      |
|---------|---|---|----------------------|
| Routers | Cisco 2600 Series Multiservice Platforms      | Cisco 2621 Multiservice Platform          | 1.3.6.1.4.1.9.1.469  |
| Routers | Cisco 2600 Series Multiservice Platforms      | Cisco 2650 Multiservice Platform          | 1.3.6.1.4.1.9.1.319  |
| Routers | Cisco 2600 Series Multiservice Platforms      | Cisco 2650 Multiservice Platform          | 1.3.6.1.4.1.9.1.470  |
| Routers | Cisco 2600 Series Multiservice Platforms      | Cisco 2651 Multiservice Platform          | 1.3.6.1.4.1.9.1.320  |
| Routers | Cisco 2600 Series Multiservice Platforms      | Cisco 2651 Multiservice Platform          | 1.3.6.1.4.1.9.1.471  |
| Routers | Cisco 2600 Series Multiservice Platforms      | Cisco 2691 Multiservice Platform          | 1.3.6.1.4.1.9.1.413  |
| Routers | Cisco MWR 2900 Series Mobile Wireless Routers | Cisco MWR 2941-DC Mobile Wireless Router  | 1.3.6.1.4.1.9.1.1014 |
| Routers | Cisco MWR 2900 Series Mobile Wireless Routers | Cisco MWR 2941-DC Mobile Wireless Router  | 1.3.6.1.4.1.9.1.1215 |
| Routers | Cisco 3200 Series Mobile Access Routers       | Cisco 3251 Mobile Access Router Card      | 1.3.6.1.4.1.9.1.479  |
| Routers | Cisco 3200 Series Mobile Access Routers       | Cisco 3220 Mobile Access Router           | 1.3.6.1.4.1.9.1.553  |
| Routers | Cisco 3200 Series Mobile Access Routers       | Cisco 3201 Wireless Mobile Interface card | 1.3.6.1.4.1.9.1.581  |
| Routers | Cisco 3200 Series Mobile Access Routers       | Cisco 3270 Rugged Router                  | 1.3.6.1.4.1.9.1.689  |
| Routers | Cisco 3200 Series Mobile Access Routers       | Cisco 3270 Rugged Router                  | 1.3.6.1.4.1.9.1.690  |
| Routers | Cisco 3600 Series Multiservice Platforms      | Cisco 3620 Multiservice Platform          | 1.3.6.1.4.1.9.1.122  |
| Routers | Cisco 3600 Series Multiservice Platforms      | Cisco 3620 Multiservice Platform          | 1.3.6.1.4.1.9.1.123  |
| Routers | Cisco 3600 Series Multiservice Platforms      | Cisco 3640 Multiservice Platform          | 1.3.6.1.4.1.9.1.110  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |  |  |                     |
|---------|--|--|---------------------|
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3640 Multiservice Platform               | 1.3.6.1.4.1.9.1.189 |
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3660 Multiservice Platform               | 1.3.6.1.4.1.9.1.205 |
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3661 Multiservice Platform               | 1.3.6.1.4.1.9.1.338 |
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3661 Multiservice Platform               | 1.3.6.1.4.1.9.1.339 |
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3662 Telco Versatile DCN Access Platform | 1.3.6.1.4.1.9.1.340 |
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3662 Telco Versatile DCN Access Platform | 1.3.6.1.4.1.9.1.341 |
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3662 Telco Versatile DCN Access Platform | 1.3.6.1.4.1.9.1.342 |
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3662 Telco Versatile DCN Access Platform | 1.3.6.1.4.1.9.1.343 |
| Routers | Cisco 3600 Series Multiservice Platforms                 | Cisco 3631 Central Office Access Router        | 1.3.6.1.4.1.9.1.425 |
| Routers | Cisco 600 Series DSL Customer Premises Equipment Routers | Cisco 673 SDSL DSL Router                      | 1.3.6.1.4.1.9.1.332 |
| Routers | Cisco 600 Series DSL Customer Premises Equipment Routers | Cisco 675 ADSL Router                          | 1.3.6.1.4.1.9.1.333 |
| Routers | Cisco 600 Series DSL Customer Premises Equipment Routers | Cisco 675 ADSL Router                          | 1.3.6.1.4.1.9.1.334 |
| Routers | Cisco 600 Series DSL Customer Premises Equipment Routers | Cisco 676 ADSL Router                          | 1.3.6.1.4.1.9.1.335 |
| Routers | Cisco 600 Series DSL Customer Premises Equipment Routers | Cisco 677 ADSL Router                          | 1.3.6.1.4.1.9.1.336 |
| Routers |  | Cisco 677 ADSL Router                          | 1.3.6.1.4.1.9.1.363 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |  |                              |                     |
|---------|--|------------------------------|---------------------|
|         | Cisco 600 Series DSL Customer Premises Equipment Routers |                              |                     |
| Routers | Cisco 600 Series DSL Customer Premises Equipment Routers | Cisco 678 ADSL Router        | 1.3.6.1.4.1.9.1.337 |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 761 ISDN Access Router | 1.3.6.1.4.1.9.1.98  |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 762 ISDN Access Router | 1.3.6.1.4.1.9.1.99  |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 772 ISDN Access Router | 1.3.6.1.4.1.9.1.127 |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 775 ISDN Access Router | 1.3.6.1.4.1.9.1.128 |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 776 ISDN Access Router | 1.3.6.1.4.1.9.1.129 |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 751 ISDN Access Router | 1.3.6.1.4.1.9.1.81  |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 752 ISDN Access Router | 1.3.6.1.4.1.9.1.82  |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 753 ISDN Access Router | 1.3.6.1.4.1.9.1.83  |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 765 ISDN Access Router | 1.3.6.1.4.1.9.1.102 |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 766 ISDN Access Router | 1.3.6.1.4.1.9.1.103 |
| Routers | Cisco 700 Series ISDN Access Routers                     | Cisco 771 ISDN Access Router | 1.3.6.1.4.1.9.1.126 |
| Routers | Cisco 7200 Series Routers                                | Cisco 7202 Router            | 1.3.6.1.4.1.9.1.194 |
| Routers | Cisco 7200 Series Routers                                | Cisco 7204 Router            | 1.3.6.1.4.1.9.1.125 |
| Routers | Cisco 7200 Series Routers                                | Cisco 7204VXR Router         | 1.3.6.1.4.1.9.1.223 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |                           |                      |                     |
|---------|---------------------------|----------------------|---------------------|
| Routers | Cisco 7200 Series Routers | Cisco 7206 Router    | 1.3.6.1.4.1.9.1.108 |
| Routers | Cisco 7200 Series Routers | Cisco 7206VXR Router | 1.3.6.1.4.1.9.1.222 |
| Routers | Cisco 7200 Series Routers | Cisco 7201 Router    | 1.3.6.1.4.1.9.1.821 |
| Routers | Cisco 7500 Series Routers | Cisco 7505 Router    | 1.3.6.1.4.1.9.1.48  |
| Routers | Cisco 7500 Series Routers | Cisco 7506 Router    | 1.3.6.1.4.1.9.1.47  |
| Routers | Cisco 7500 Series Routers | Cisco 7507 Router    | 1.3.6.1.4.1.9.1.45  |
| Routers | Cisco 7500 Series Routers | Cisco 7507 Router    | 1.3.6.1.4.1.9.1.288 |
| Routers | Cisco 7500 Series Routers | Cisco 7507 Router    | 1.3.6.1.4.1.9.1.290 |
| Routers | Cisco 7500 Series Routers | Cisco 7513 Router    | 1.3.6.1.4.1.9.1.46  |
| Routers | Cisco 7500 Series Routers | Cisco 7513 Router    | 1.3.6.1.4.1.9.1.289 |
| Routers | Cisco 7500 Series Routers | Cisco 7513 Router    | 1.3.6.1.4.1.9.1.291 |
| Routers | Cisco 7500 Series Routers | Cisco 7576 Router    | 1.3.6.1.4.1.9.1.204 |
| Routers | Cisco 7600 Series Routers | Cisco 7609 Router    | 1.3.6.1.4.1.9.1.509 |
| Routers | Cisco 7600 Series Routers | Cisco 7609 Router    | 1.3.6.1.4.1.9.5.55  |
| Routers | Cisco 7600 Series Routers | Cisco 7603 Router    | 1.3.6.1.4.1.9.1.401 |
| Routers | Cisco 7600 Series Routers | Cisco 7603 Router    | 1.3.6.1.4.1.9.5.53  |
| Routers | Cisco 7600 Series Routers | Cisco 7603 Router    | 1.3.6.1.4.1.9.1.862 |
| Routers | Cisco 7600 Series Routers | Cisco 7604 Router    | 1.3.6.1.4.1.9.1.658 |
| Routers | Cisco 7600 Series Routers | Cisco 7606 Router    | 1.3.6.1.4.1.9.1.402 |
| Routers | Cisco 7600 Series Routers | Cisco 7606 Router    | 1.3.6.1.4.1.9.5.54  |
| Routers | Cisco 7600 Series Routers | Cisco 7613 Router    | 1.3.6.1.4.1.9.5.60  |
| Routers | Cisco 7600 Series Routers | Cisco 7613 Router    | 1.3.6.1.4.1.9.1.528 |
| Routers | Cisco 7600 Series Routers | Cisco 7609S Router   | 1.3.6.1.4.1.9.1.864 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |                           |   |                      |
|---------|---------------------------|---|----------------------|
| Routers | Cisco 7600 Series Routers | Cisco 7606-S Router                               | 1.3.6.1.4.1.9.1.863  |
| Routers | Cisco 800 Series Routers  | Cisco 819 Hardened Integrated Services Router     | 1.3.6.1.4.1.9.1.1384 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Hardened Integrated Services Router     | 1.3.6.1.4.1.9.1.1385 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Hardened Integrated Services Router     | 1.3.6.1.4.1.9.1.1386 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Hardened Integrated Services Router     | 1.3.6.1.4.1.9.1.1387 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Hardened Integrated Services Router     | 1.3.6.1.4.1.9.1.1388 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Hardened Integrated Services Router     | 1.3.6.1.4.1.9.1.1389 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Non-Hardened Integrated Services Router | 1.3.6.1.4.1.9.1.1378 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Non-Hardened Integrated Services Router | 1.3.6.1.4.1.9.1.1379 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Non-Hardened Integrated Services Router | 1.3.6.1.4.1.9.1.1380 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Non-Hardened Integrated Services Router | 1.3.6.1.4.1.9.1.1381 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Non-Hardened Integrated Services Router | 1.3.6.1.4.1.9.1.1382 |
| Routers | Cisco 800 Series Routers  | Cisco 819 Non-Hardened Integrated Services Router | 1.3.6.1.4.1.9.1.1383 |
| Routers | Cisco 800 Series Routers  | Cisco 887VA-W Integrated Services Router          | 1.3.6.1.4.1.9.1.1375 |
| Routers | Cisco 800 Series Routers  | Cisco 887VA-W Integrated Services Router          | 1.3.6.1.4.1.9.1.1376 |
| Routers | Cisco 800 Series Routers  | Cisco 887VA-W Integrated Services Router          | 1.3.6.1.4.1.9.1.1377 |
| Routers | Cisco 800 Series Routers  | Cisco 886VA-W Integrated Services Router          | 1.3.6.1.4.1.9.1.1374 |
| Routers | Cisco 800 Series Routers  | Cisco 866VAE Integrated Services Router           | 1.3.6.1.4.1.9.1.1359 |
| Routers | Cisco 800 Series Routers  | Cisco 866VAE Integrated Services Router           | 1.3.6.1.4.1.9.1.1360 |
| Routers | Cisco 800 Series Routers  | Cisco 866VAE Integrated Services Router           | 1.3.6.1.4.1.9.1.1361 |
| Routers | Cisco 800 Series Routers  | Cisco 867VAE Integrated Services Router           | 1.3.6.1.4.1.9.1.1358 |
| Routers | Cisco 800 Series Routers  | Cisco 802 ISDN Router                             | 1.3.6.1.4.1.9.1.213  |
| Routers | Cisco 800 Series Routers  | Cisco 802 ISDN Router                             | 1.3.6.1.4.1.9.1.295  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |                          |   |                     |
|---------|--------------------------|---|---------------------|
| Routers | Cisco 800 Series Routers | Cisco 851,851W Integrated Services Router | 1.3.6.1.4.1.9.1.566 |
| Routers | Cisco 800 Series Routers | Cisco 857,857W Integrated Services Router | 1.3.6.1.4.1.9.1.567 |
| Routers | Cisco 800 Series Routers | Cisco 871,871W Integrated Services Router | 1.3.6.1.4.1.9.1.571 |
| Routers | Cisco 800 Series Routers | Cisco 878,878W Integrated Services Router | 1.3.6.1.4.1.9.1.570 |
| Routers | Cisco 800 Series Routers | Cisco 876,876W Integrated Services Router | 1.3.6.1.4.1.9.1.568 |
| Routers | Cisco 800 Series Routers | Cisco 877,877W Integrated Services Router | 1.3.6.1.4.1.9.1.569 |
| Routers | Cisco 800 Series Routers | Cisco 877,877W Integrated Services Router | 1.3.6.1.4.1.9.1.782 |
| Routers | Cisco 800 Series Routers | Cisco 803 ISDN Router                     | 1.3.6.1.4.1.9.1.214 |
| Routers | Cisco 800 Series Routers | Cisco 804 ISDN Router                     | 1.3.6.1.4.1.9.1.215 |
| Routers | Cisco 800 Series Routers | Cisco 804 ISDN Router                     | 1.3.6.1.4.1.9.1.296 |
| Routers | Cisco 800 Series Routers | Cisco 805 Serial Router                   | 1.3.6.1.4.1.9.1.245 |
| Routers | Cisco 800 Series Routers | Cisco 826 ADSL Router                     | 1.3.6.1.4.1.9.1.321 |
| Routers | Cisco 800 Series Routers | Cisco 826 ADSL Router                     | 1.3.6.1.4.1.9.1.322 |
| Routers | Cisco 800 Series Routers | Cisco 827 ADSL Router                     | 1.3.6.1.4.1.9.1.284 |
| Routers | Cisco 800 Series Routers | Cisco 827-4V ADSL Router                  | 1.3.6.1.4.1.9.1.270 |
| Routers | Cisco 800 Series Routers | Cisco 806 Broadband Router                | 1.3.6.1.4.1.9.1.384 |
| Routers | Cisco 800 Series Routers | Cisco 828 G.SHDSL Router                  | 1.3.6.1.4.1.9.1.382 |
| Routers | Cisco 800 Series Routers | Cisco 827 H ADSL Router                   | 1.3.6.1.4.1.9.1.446 |
| Routers | Cisco 800 Series Routers | Cisco 801 ISDN Router                     | 1.3.6.1.4.1.9.1.212 |
| Routers | Cisco 800 Series Routers | Cisco 811 ISDN Router                     | 1.3.6.1.4.1.9.1.395 |
| Routers | Cisco 800 Series Routers | Cisco 813 ISDN Router                     | 1.3.6.1.4.1.9.1.396 |
| Routers | Cisco 800 Series Routers | Cisco 831 Ethernet Broadband Router       | 1.3.6.1.4.1.9.1.497 |
| Routers | Cisco 800 Series Routers | Cisco 836 ADSL over ISDN Broadband Router | 1.3.6.1.4.1.9.1.499 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |                          |  |                      |
|---------|--------------------------|--|----------------------|
| Routers | Cisco 800 Series Routers | Cisco 837 ADSL Broadband Router                      | 1.3.6.1.4.1.9.1.495  |
| Routers | Cisco 800 Series Routers | Cisco 861,861W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.834  |
| Routers | Cisco 800 Series Routers | Cisco 877 Integrated Services Router                 | 1.3.6.1.4.1.9.1.782  |
| Routers | Cisco 800 Series Routers | Cisco 815 Integrated Services Router                 | 1.3.6.1.4.1.9.1.733  |
| Routers | Cisco 800 Series Routers | Cisco 881,881W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.837  |
| Routers | Cisco 800 Series Routers | Cisco 881,881W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.838  |
| Routers | Cisco 800 Series Routers | Cisco 881,881W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1371 |
| Routers | Cisco 800 Series Routers | Cisco 881,881W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1372 |
| Routers | Cisco 800 Series Routers | Cisco 881,881W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1373 |
| Routers | Cisco 800 Series Routers | Cisco 881,881W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1600 |
| Routers | Cisco 800 Series Routers | Cisco 881SRST,881SRSTW Integrated Services Router G2 | 1.3.6.1.4.1.9.1.840  |
| Routers | Cisco 800 Series Routers | Cisco 886,886W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.842  |
| Routers | Cisco 800 Series Routers | Cisco 886,886W Integrated Services Router G2         | 1.3.6.1.4.1.9.1.843  |
| Routers | Cisco 800 Series Routers | Cisco 886SRST,886SRSTW Integrated Services Router G2 | 1.3.6.1.4.1.9.1.846  |
| Routers | Cisco 800 Series Routers | Cisco 887,887W Integrated Services Routers G2        | 1.3.6.1.4.1.9.1.847  |
| Routers | Cisco 800 Series Routers | Cisco 887,887W Integrated Services Routers G2        | 1.3.6.1.4.1.9.1.848  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |                          |  |                      |
|---------|--------------------------|--|----------------------|
| Routers | Cisco 800 Series Routers | Cisco 887,887W Integrated Services Routers G2          | 1.3.6.1.4.1.9.1.1105 |
| Routers | Cisco 800 Series Routers | Cisco 887V Integrated Services Router G2               | 1.3.6.1.4.1.9.1.1040 |
| Routers | Cisco 800 Series Routers | Cisco 887V Integrated Services Router G2               | 1.3.6.1.4.1.9.1.1138 |
| Routers | Cisco 800 Series Routers | Cisco 887V Integrated Services Router G2               | 1.3.6.1.4.1.9.1.1139 |
| Routers | Cisco 800 Series Routers | Cisco 888,888W,888GW Integrated Services Router G2     | 1.3.6.1.4.1.9.1.852  |
| Routers | Cisco 800 Series Routers | Cisco 888,888W,888GW Integrated Services Router G2     | 1.3.6.1.4.1.9.1.853  |
| Routers | Cisco 800 Series Routers | Cisco 888ESRST,888ESRSTW Integrated Services Router G2 | 1.3.6.1.4.1.9.1.1100 |
| Routers | Cisco 800 Series Routers | Cisco 888E,888EW Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1096 |
| Routers | Cisco 800 Series Routers | Cisco 888E,888EW Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1097 |
| Routers | Cisco 800 Series Routers | Cisco 888E,888EW Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1098 |
| Routers | Cisco 800 Series Routers | Cisco 888E,888EW Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1394 |
| Routers | Cisco 800 Series Routers | Cisco 888E,888EW Integrated Services Router G2         | 1.3.6.1.4.1.9.1.1099 |
| Routers | Cisco 800 Series Routers | Cisco 888EA Integrated Services Router G2              | 1.3.6.1.4.1.9.1.1542 |
| Routers | Cisco 800 Series Routers | Cisco 888SRST,888SRSTW Integrated Services Router G2   | 1.3.6.1.4.1.9.1.851  |
| Routers | Cisco 800 Series Routers | Cisco 888SRST,888SRSTW Integrated Services Router G2   | 1.3.6.1.4.1.9.1.856  |
| Routers | Cisco 800 Series Routers | Cisco 866 Integrated Services Router                   | 1.3.6.1.4.1.9.1.835  |
| Routers | Cisco 800 Series Routers | Cisco 867,867W   | 1.3.6.1.4.1.9.1.836  |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         | Routers                     | Integrated Services Router<br>G2                       |                      |
|---------|-----------------------------|--|----------------------|
| Routers | Cisco 800 Series<br>Routers | Cisco 891,891W<br>Integrated Services Router<br>G2     | 1.3.6.1.4.1.9.1.857  |
| Routers | Cisco 800 Series<br>Routers | Cisco 892,892W<br>Integrated Services Router<br>G2     | 1.3.6.1.4.1.9.1.858  |
| Routers | Cisco 800 Series<br>Routers | Cisco 892F,892FW<br>Integrated Services Router         | 1.3.6.1.4.1.9.1.1249 |
| Routers | Cisco 800 Series<br>Routers | Cisco 885 Integrated<br>Services Router                | 1.3.6.1.4.1.9.1.859  |
| Routers | Cisco 800 Series<br>Routers | Cisco 885 Integrated<br>Services Router                | 1.3.6.1.4.1.9.1.861  |
| Routers | Cisco 800 Series<br>Routers | Cisco 887VA M<br>Integrated Services Router<br>G2      | 1.3.6.1.4.1.9.1.1271 |
| Routers | Cisco 800 Series<br>Routers | Cisco 886VA,886VAG<br>Integrated Services Router<br>G2 | 1.3.6.1.4.1.9.1.1273 |
| Routers | Cisco 800 Series<br>Routers | Cisco 886VA,886VAG<br>Integrated Services Router<br>G2 | 1.3.6.1.4.1.9.1.1390 |
| Routers | Cisco 800 Series<br>Routers | Cisco 881W,881WD<br>Integrated Services Router         | 1.3.6.1.4.1.9.1.1566 |
| Routers | Cisco 800 Series<br>Routers | Cisco 881W,881WD<br>Integrated Services Router         | 1.3.6.1.4.1.9.1.1567 |
| Routers | Cisco 800 Series<br>Routers | Cisco C896VA Integrated<br>Services Router             | 1.3.6.1.4.1.9.1.1627 |
| Routers | Cisco 800 Series<br>Routers | Cisco C897VA Integrated<br>Services Router             | 1.3.6.1.4.1.9.1.1622 |
| Routers | Cisco 800 Series<br>Routers | Cisco C897VA Integrated<br>Services Router             | 1.3.6.1.4.1.9.1.1623 |
| Routers | Cisco 800 Series<br>Routers | Cisco C897VAW<br>Integrated Services Router            | 1.3.6.1.4.1.9.1.1624 |
| Routers | Cisco 800 Series<br>Routers | Cisco C897VAW<br>Integrated Services Router            | 1.3.6.1.4.1.9.1.1625 |
| Routers | Cisco 800 Series<br>Routers | Cisco C897VAW<br>Integrated Services Router            | 1.3.6.1.4.1.9.1.1626 |
| Routers | Cisco 800 Series<br>Routers | Cisco C898EA Integrated<br>Services Router             | 1.3.6.1.4.1.9.1.1621 |
| Routers | Cisco 800 Series<br>Routers | Cisco 887VA Integrated<br>Services Router G2           | 1.3.6.1.4.1.9.1.1274 |
| Routers | Cisco 800 Series<br>Routers | Cisco 887VA Integrated<br>Services Router G2           | 1.3.6.1.4.1.9.1.1391 |
| Routers |                             |  | 1.3.6.1.4.1.9.1.1392 |

Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |                          |   |                      |
|---------|--------------------------|---|----------------------|
|         | Cisco 800 Series Routers | Cisco 887VA Integrated Services Router G2                       |                      |
| Routers | Cisco 800 Series Routers | Cisco 887VA Integrated Services Router G2                       | 1.3.6.1.4.1.9.1.1393 |
| Routers | Cisco 800 Series Routers | Cisco 887VA Integrated Services Router G2                       | 1.3.6.1.4.1.9.1.1601 |
| Routers | Cisco 800 Series Routers | Cisco 887VA Integrated Services Router G2                       | 1.3.6.1.4.1.9.1.1602 |
| Routers | Cisco 800 Series Routers | Cisco Catalyst 6500 Series ASA Services Module Security Context | 1.3.6.1.4.1.9.1.1275 |
| Routers | Cisco 800 Series Routers | Cisco 880 3G Integrated Services Router G2                      | 1.3.6.1.4.1.9.1.1299 |
| Routers | Cisco 800 Series Routers | Cisco 880 3G Integrated Services Router G2                      | 1.3.6.1.4.1.9.1.1395 |
| Routers | Cisco 800 Series Routers | Cisco 880 3G Integrated Services Router G2                      | 1.3.6.1.4.1.9.1.1396 |
| Routers | Cisco 800 Series Routers | Cisco 880 3G Integrated Services Router G2                      | 1.3.6.1.4.1.9.1.1397 |
| Routers | Cisco 800 Series Routers | Cisco 880 3G Integrated Services Router G2                      | 1.3.6.1.4.1.9.1.1398 |
| Routers | Cisco 800 Series Routers | Cisco 880 3G Integrated Services Router G2                      | 1.3.6.1.4.1.9.1.1399 |
| Routers | Cisco 800 Series Routers | Cisco 880 3G Integrated Services Router G2                      | 1.3.6.1.4.1.9.1.1400 |
| Routers | Cisco 800 Series Routers | Cisco 887VA-W Integrated Services Router G2                     | 1.3.6.1.4.1.9.1.1375 |
| Routers | Cisco 800 Series Routers | Cisco 887VA-W Integrated Services Router G2                     | 1.3.6.1.4.1.9.1.1376 |
| Routers | Cisco 800 Series Routers | Cisco 887VA-W Integrated Services Router G2                     | 1.3.6.1.4.1.9.1.1377 |
| Routers | Cisco 800 Series Routers | Cisco 886VA-W Integrated Services Router G2                     | 1.3.6.1.4.1.9.1.1374 |
| Routers | Cisco 800 Series Routers | Cisco 867VAE Integrated Services Router                         | 1.3.6.1.4.1.9.1.1358 |
| Routers | Cisco 800 Series Routers | Cisco 867VAE Integrated Services Router                         | 1.3.6.1.4.1.9.1.1360 |
| Routers | Cisco 800 Series Routers | Cisco 867VAE Integrated Services Router                         | 1.3.6.1.4.1.9.1.1272 |
| Routers | Cisco 800 Series Routers | Cisco 866VAE Integrated Services Router                         | 1.3.6.1.4.1.9.1.1359 |
| Routers |                          |   | 1.3.6.1.4.1.9.1.1361 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |                          |   |                      |
|---------|--------------------------|---|----------------------|
|         | Cisco 800 Series Routers | Cisco 866VAE Integrated Services Router                                       |                      |
| Routers | Cisco 800 Series Routers | Cisco 819 Non-Hardened Integrated Services Router                             | 1.3.6.1.4.1.9.1.1378 |
| Routers | Cisco 800 Series Routers | Cisco 819 Non-Hardened Integrated Services Router                             | 1.3.6.1.4.1.9.1.1379 |
| Routers | Cisco 800 Series Routers | Cisco 819 Non-Hardened Integrated Services Router                             | 1.3.6.1.4.1.9.1.1380 |
| Routers | Cisco 800 Series Routers | Cisco 819 Non-Hardened Integrated Services Router                             | 1.3.6.1.4.1.9.1.1381 |
| Routers | Cisco 800 Series Routers | Cisco 819 Non-Hardened Integrated Services Router                             | 1.3.6.1.4.1.9.1.1382 |
| Routers | Cisco 800 Series Routers | Cisco 819 Non-Hardened Integrated Services Router                             | 1.3.6.1.4.1.9.1.1383 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened Integrated Services Router                                 | 1.3.6.1.4.1.9.1.1384 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened Integrated Services Router                                 | 1.3.6.1.4.1.9.1.1385 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened Integrated Services Router                                 | 1.3.6.1.4.1.9.1.1386 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened Integrated Services Router                                 | 1.3.6.1.4.1.9.1.1387 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened Integrated Services Router                                 | 1.3.6.1.4.1.9.1.1388 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened Integrated Services Router                                 | 1.3.6.1.4.1.9.1.1389 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened Integrated Services Router                                 | 1.3.6.1.4.1.9.1.1575 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services Router | 1.3.6.1.4.1.9.1.1570 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services Router | 1.3.6.1.4.1.9.1.1571 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services Router | 1.3.6.1.4.1.9.1.1572 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services Router | 1.3.6.1.4.1.9.1.1573 |
| Routers | Cisco 800 Series Routers | Cisco 819 Hardened 3G with Dual Radio 802.11n WiFi Integrated Services        | 1.3.6.1.4.1.9.1.1574 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |  | Router                                    |                      |
|---------|--|---|----------------------|
| Routers | Cisco 800 Series Routers                       | Cisco C892FSP Integrated Services Router  | 1.3.6.1.4.1.9.1.1620 |
| Routers | Cisco 800 Series Routers                       | Cisco 812 3G Integrated Services Router   | 1.3.6.1.4.1.9.1.1578 |
| Routers | Cisco 800 Series Routers                       | Cisco 812 CiFi Integrated Services Router | 1.3.6.1.4.1.9.1.1579 |
| Routers | Cisco 800 Series Routers                       | Cisco 812 CiFi Integrated Services Router | 1.3.6.1.4.1.9.1.1580 |
| Routers | Cisco 800 Series Routers                       | Cisco 812 CiFi Integrated Services Router | 1.3.6.1.4.1.9.1.1581 |
| Routers | Cisco 800 Series Routers                       | Cisco 812 CiFi Integrated Services Router | 1.3.6.1.4.1.9.1.1582 |
| Routers | Cisco Small Business 100 Series Routers        | Cisco Small Business 101 Series Routers   | 1.3.6.1.4.1.9.1.627  |
| Routers | Cisco Small Business 100 Series Routers        | Cisco Small Business 106 Series Routers   | 1.3.6.1.4.1.9.1.628  |
| Routers | Cisco Small Business 100 Series Routers        | Cisco Small Business 107 Series Routers   | 1.3.6.1.4.1.9.1.629  |
| Routers | Cisco 10000 Series Routers                     | Cisco 10008 Router                        | 1.3.6.1.4.1.9.1.438  |
| Routers | Cisco 10000 Series Routers                     | Cisco 10005 Router                        | 1.3.6.1.4.1.9.1.437  |
| Routers | Cisco MC3810 Multiservice Access Concentrators | Cisco MC3810-V Access Concentrator        | 1.3.6.1.4.1.9.1.157  |
| Routers | Cisco MC3810 Multiservice Access Concentrators | Cisco MC3810-V3 Access Concentrator       | 1.3.6.1.4.1.9.1.286  |
| Routers | Cisco SOHO 70 Series Routers                   | Cisco SOHO 77 ADSL Router                 | 1.3.6.1.4.1.9.1.353  |
| Routers | Cisco SOHO 70 Series Routers                   | Cisco SOHO 76 ADSL Router                 | 1.3.6.1.4.1.9.1.354  |
| Routers | Cisco SOHO 70 Series Routers                   | Cisco SOHO 71 Broadband Router            | 1.3.6.1.4.1.9.1.463  |
| Routers | Cisco SOHO 70 Series Routers                   | Cisco SOHO 77 H ADSL Router               | 1.3.6.1.4.1.9.1.447  |
| Routers | Cisco SOHO 70 Series Routers                   | Cisco SOHO 78 G.SHDSL Router              | 1.3.6.1.4.1.9.1.383  |
| Routers | Cisco SOHO 90 Series Secure Broadband Routers  | Cisco SOHO 91 Ethernet Broadband Router   | 1.3.6.1.4.1.9.1.498  |
| Routers |  |   | 1.3.6.1.4.1.9.1.500  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |   |   |                     |
|---------|---|---|---------------------|
|         | Cisco SOHO 90 Series Secure Broadband Routers | Cisco SOHO 96 ADSL over ISDN Secure Broadband Routers |                     |
| Routers | Cisco SOHO 90 Series Secure Broadband Routers | Cisco SOHO 97 ADSL Broadband Router                   | 1.3.6.1.4.1.9.1.496 |
| Routers | Cisco 7400 Series Routers                     | Cisco 7401 Application Specific Router                | 1.3.6.1.4.1.9.1.403 |
| Routers | Cisco 7300 Series Routers                     | Cisco 7304 Router                                     | 1.3.6.1.4.1.9.1.439 |
| Routers | Cisco 7300 Series Routers                     | Cisco 7301 Router                                     | 1.3.6.1.4.1.9.1.476 |
| Routers | Cisco 10700 Series Routers                    | Cisco 10720 Router                                    | 1.3.6.1.4.1.9.1.397 |
| Routers | Cisco 3700 Series Multiservice Access Routers | Cisco 3725 Multiservice Access Router                 | 1.3.6.1.4.1.9.1.414 |
| Routers | Cisco 3700 Series Multiservice Access Routers | Cisco 3745 Multiservice Access Router                 | 1.3.6.1.4.1.9.1.436 |
| Routers | Cisco MWR 1900 Mobile Wireless Routers        | Cisco 1900 Mobile Wireless Edge Router                | 1.3.6.1.4.1.9.1.398 |
| Routers | Cisco MWR 1900 Mobile Wireless Routers        | Cisco MWR 1941-DC Mobile Wireless Edge Router         | 1.3.6.1.4.1.9.1.520 |
| Routers | Cisco MWR 1900 Mobile Wireless Routers        | Cisco MWR 1941-DC-A Mobile Wireless Edge Router       | 1.3.6.1.4.1.9.1.732 |
| Routers | Cisco Carrier Routing System                  | Cisco CRS-1 16-Slot Single-Shelf System               | 1.3.6.1.4.1.9.1.613 |
| Routers | Cisco Carrier Routing System                  | Cisco CRS-1 8-Slot Single-Shelf System                | 1.3.6.1.4.1.9.1.643 |
| Routers | Cisco Carrier Routing System                  | Cisco CRS-1 4-Slot Single-Shelf System                | 1.3.6.1.4.1.9.1.822 |
| Routers | Cisco 5700 Series Routers                     | Cisco 5720 Integrated Encryption Router               | 1.3.6.1.4.1.9.1.820 |
| Routers | Cisco 5700 Series Routers                     | Cisco 5740 Integrated Encryption Router               | 1.3.6.1.4.1.9.1.833 |
| Routers | Cisco 5700 Series Routers                     | Cisco 5750 Integrated Encryption Router               | 1.3.6.1.4.1.9.1.731 |
| Routers | Other Routers                                 | Cisco GatewayServer                                   | 1.3.6.1.4.1.9.1.1   |
| Routers | Other Routers                                 | Cisco Trouter   | 1.3.6.1.4.1.9.1.3   |
| Routers | Other Routers                                 | Cisco ProtocolTranslator                              | 1.3.6.1.4.1.9.1.4   |
| Routers | Other Routers                                 | Cisco IGS-L, IGS-R                                    | 1.3.6.1.4.1.9.1.5   |
| Routers | Other Routers                                 | Cisco Router 2000                                     | 1.3.6.1.4.1.9.1.10  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |  |                                      |                              |
|---------|--|--------------------------------------|------------------------------|
| Routers | Other Routers  | Cisco Router 2102                    | 1.3.6.1.4.1.9.1.15           |
| Routers | Other Routers  | Cisco Router 2202                    | 1.3.6.1.4.1.9.1.16           |
| Routers | Other Routers  | Cisco 3200 Series 3202               | 1.3.6.1.4.1.9.1.36           |
| Routers | Other Routers  | Cisco 3200 Series 3204               | 1.3.6.1.4.1.9.1.37           |
| Routers | Other Routers  | Cisco 4500 Series 4500               | 1.3.6.1.4.1.9.1.14           |
| Routers | Other Routers  | Cisco AccessProRC                    | 1.3.6.1.4.1.9.1.38           |
| Routers | Other Routers  | Cisco AccessProEC                    | 1.3.6.1.4.1.9.1.39           |
| Routers | Other Routers  | Cisco ODS FDDI<br>Network Controller | 1.3.6.1.4.1.50.7             |
| Routers | Other Routers  | Cisco 10000 Series<br>C10400         | 1.3.6.1.4.1.9.1.272          |
| Routers | Other Routers  | Cisco Optical Regenerator            | 1.3.6.1.4.1.9.1.254          |
| Routers | Other Routers  | Cisco MWAM                           | 1.3.6.1.4.1.9.12.3.1.9.17.39 |
| Routers | Other Routers  | Cisco MWAM                           | 1.3.6.1.4.1.9.1.621          |
| Routers | Cisco ASR 901<br>Series Aggregation<br>Services Routers  | Cisco ASR 901-12C-F-D<br>Router      | 1.3.6.1.4.1.9.1.1521         |
| Routers | Cisco ASR 901<br>Series Aggregation<br>Services Routers  | Cisco ASR 901-12C-FT-D<br>Router     | 1.3.6.1.4.1.9.1.1522         |
| Routers | Cisco ASR 1000<br>Series Aggregation<br>Services Routers | Cisco ASR 9001 Router                | 1.3.6.1.4.1.9.1.1639         |
| Routers | Cisco ASR 1000<br>Series Aggregation<br>Services Routers | Cisco ASR 9010 Router                | 1.3.6.1.4.1.9.1.1017         |
| Routers | Cisco ASR 1000<br>Series Aggregation<br>Services Routers | Cisco ASR 9006 Router                | 1.3.6.1.4.1.9.1.1018         |
| Routers | Cisco ASR 1000<br>Series Aggregation<br>Services Routers | Cisco ASR 1002 Router                | 1.3.6.1.4.1.9.1.923          |
| Routers | Cisco ASR 1000<br>Series Aggregation<br>Services Routers | Cisco ASR 1001 Router                | 1.3.6.1.4.1.9.1.1165         |
| Routers | Cisco ASR 1000<br>Series Aggregation<br>Services Routers | Cisco ASR 1004 Router                | 1.3.6.1.4.1.9.1.924          |
| Routers | Cisco ASR 1000<br>Series Aggregation<br>Services Routers | Cisco ASR 1006 Router                | 1.3.6.1.4.1.9.1.925          |
| Routers | Cisco ASR 1000<br>Series Aggregation<br>Services Routers | Cisco ASR 1002 Fixed<br>Router       | 1.3.6.1.4.1.9.1.1116         |
| Routers | Cisco ASR 1000<br>Series Aggregation                     | Cisco ASR 1002-X Router              | 1.3.6.1.4.1.9.1.1525         |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|         |  |   |                      |
|---------|--|---|----------------------|
|         | Services Routers                                   |   |                      |
| Routers | Cisco ASR 1000 Series Aggregation Services Routers | Cisco ASR 1013 Router                           | 1.3.6.1.4.1.9.1.1166 |
| Routers | Cisco ASR 9000 Series Aggregation Services Routers | Cisco ASR 9010 Router                           | 1.3.6.1.4.1.9.1.1017 |
| Routers | Cisco ASR 9000 Series Aggregation Services Routers | Cisco ASR 9006 Router                           | 1.3.6.1.4.1.9.1.1018 |
| Routers | Cisco ASR 9000 Series Aggregation Services Routers | Cisco ASR 9001 Router                           | 1.3.6.1.4.1.9.1.1639 |
| Routers | Cisco ASR 903 Series Aggregation Services Routers  | Cisco ASR 903 Router                            | 1.3.6.1.4.1.9.1.1441 |
| Routers | Cisco ASR 901 Series Aggregation Services Routers  | Cisco ASR 901-12C-F-D Router                    | 1.3.6.1.4.1.9.1.1521 |
| Routers | Cisco ASR 901 Series Aggregation Services Routers  | Cisco ASR 901-12C-FT-D Router                   | 1.3.6.1.4.1.9.1.1522 |
| Routers | Cisco 1900 Series Integrated Services Routers      | Cisco 1941 Integrated Services Router G2        | 1.3.6.1.4.1.9.1.1047 |
| Routers | Cisco 1900 Series Integrated Services Routers      | Cisco 1941W Integrated Services Router G2       | 1.3.6.1.4.1.9.1.1095 |
| Routers | Cisco 1900 Series Integrated Services Routers      | Cisco 1941W Integrated Services Router G2       | 1.3.6.1.4.1.9.1.1172 |
| Routers | Cisco 1900 Series Integrated Services Routers      | Cisco 1941W Integrated Services Router G2       | 1.3.6.1.4.1.9.1.1173 |
| Routers | Cisco 1900 Series Integrated Services Routers      | Cisco 1941W Integrated Services Router G2       | 1.3.6.1.4.1.9.1.1174 |
| Routers | Cisco 1900 Series Integrated Services Routers      | Cisco 1941W Integrated Services Router G2       | 1.3.6.1.4.1.9.1.1220 |
| Routers | Cisco 1900 Series Integrated Services Routers      | Cisco 1905 Serial Integrated Services Router G2 | 1.3.6.1.4.1.9.1.1192 |
| Routers | Cisco 1900 Series Integrated Services Routers      | Cisco 1921 Integrated Services Router G2        | 1.3.6.1.4.1.9.1.1191 |
| Routers | Cisco 2900 Series                                  | Cisco 2951 Integrated                           | 1.3.6.1.4.1.9.1.1043 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |  |  |                           |
|-------------------|--|--|---------------------------|
|                   | Integrated Services Routers G2                   | Services Router G2                           |                           |
| Routers           | Cisco 2900 Series Integrated Services Routers G2 | Cisco 2911 Integrated Services Router G2     | 1.3.6.1.4.1.9.1.1045      |
| Routers           | Cisco 2900 Series Integrated Services Routers G2 | Cisco 2921 Integrated Services Router G2     | 1.3.6.1.4.1.9.1.1044      |
| Routers           | Cisco 2900 Series Integrated Services Routers G2 | Cisco 2901 Integrated Services Router G2     | 1.3.6.1.4.1.9.1.1046      |
| Routers           | Cisco 2000 Series Connected Grid Routers         | Cisco 2010 Connected Grid Router             | 1.3.6.1.4.1.9.1.1253      |
| Routers           | Cisco 2000 Series Connected Grid Routers         | Cisco 2010 Connected Grid Router             | 1.3.6.1.4.1.9.1.1526      |
| Routers           | Cisco 3900 Series Integrated Services Routers G2 | Cisco 3945 Integrated Services Router G2     | 1.3.6.1.4.1.9.1.1041      |
| Routers           | Cisco 3900 Series Integrated Services Routers G2 | Cisco 3925 Integrated Services Router G2     | 1.3.6.1.4.1.9.1.1042      |
| Routers           | Cisco 3900 Series Integrated Services Routers G2 | Cisco 3945E Integrated Services Router G2    | 1.3.6.1.4.1.9.1.1145      |
| Routers           | Cisco 3900 Series Integrated Services Routers G2 | Cisco 3925E Integrated Services Router G2    | 1.3.6.1.4.1.9.1.1144      |
| Routers           | Cisco 1000 Voice Series Routers                  | CSR1000V                                     | 1.3.6.1.4.1.9.1.1537      |
| Routers           | Cisco 4400 Series Integrated Services Routers    | Cisco 4451 Series Integrated Services Router | 1.3.6.1.4.1.9.1.1707      |
| Routers           | Cisco 4400 Series Integrated Services Routers    | Cisco 4452 Series Integrated Services Router | 1.3.6.1.4.1.9.1.1708      |
| Switches and Hubs | Cisco Catalyst 2100 Series Switches              | Cisco Catalyst 2100 Switch                   | 1.3.6.1.4.1.437.1.1.3.3.2 |
| Switches and Hubs | Cisco Catalyst 2360 Series Switches              | Cisco Catalyst 2360-48TD-S                   | 1.3.6.1.4.1.9.1.1292      |
| Switches and Hubs | Cisco Catalyst 4500-X Series Switches            | Cisco Catalyst 4500X-16 SFP+ Switch          | 1.3.6.1.4.1.9.1.1605      |
| Switches and Hubs | Cisco Catalyst 4500-X Series Switches            | Cisco Catalyst 4500X-32 SFP+ Switch          | 1.3.6.1.4.1.9.1.1606      |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |  |  |                           |
|-------------------|--|--|---------------------------|
| Switches and Hubs | Cisco Catalyst 2928 Series Switches              | Cisco Catalyst 2928-24TC-C Switch  | 1.3.6.1.4.1.9.1.1328      |
| Switches and Hubs | Cisco Catalyst 2928 Series Switches              | Cisco Catalyst C2928-24LT-C Switch   | 1.3.6.1.4.1.9.1.1330      |
| Switches and Hubs | Cisco Catalyst 2928 Series Switches              | Cisco Catalyst C2928-48TC-C Switch   | 1.3.6.1.4.1.9.1.1329      |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SG300-28P 28-Port Gigabit PoE Managed Switch                         | 1.3.6.1.4.1.9.6.1.83.28.2 |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SF300-08 8-Port 10/100 Managed Switch                                | 1.3.6.1.4.1.9.6.1.82.8.4  |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SF302-08 8-Port 10/100 Managed Switch with Gigabit Uplinks           | 1.3.6.1.4.1.9.6.1.82.8.1  |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SF302-08MP 8-Port 10/100 Max PoE Managed Switch with Gigabit Uplinks | 1.3.6.1.4.1.9.6.1.82.8.3  |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SF302-08P 8-Port 10/100 PoE Managed Switch with Gigabit Uplinks      | 1.3.6.1.4.1.9.6.1.82.8.2  |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SF300-24 24-Port 10/100 Managed Switch with Gigabit Uplinks          | 1.3.6.1.4.1.9.6.1.82.24.1 |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SF300-24P 24-Port 10/100 PoE Managed Switch with Gigabit Uplinks     | 1.3.6.1.4.1.9.6.1.82.24.2 |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SF300-48 48-Port 10/100 Managed Switch with Gigabit Uplinks          | 1.3.6.1.4.1.9.6.1.82.48.1 |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SF300-48P 48-Port 10/100 PoE Managed Switch with Gigabit Uplinks     | 1.3.6.1.4.1.9.6.1.82.48.2 |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SG300-10 10-Port Gigabit Managed Switch                              | 1.3.6.1.4.1.9.6.1.83.10.1 |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SG300-10MP 10-Port Gigabit Max-PoE Managed Switch                    | 1.3.6.1.4.1.9.6.1.83.10.3 |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches | Cisco SG300-10P 10-Port Gigabit PoE Managed Switch                         | 1.3.6.1.4.1.9.6.1.83.10.2 |
| Switches and Hubs | Cisco Small Business 300 Series                  | Cisco SG300-20 20-Port Gigabit Managed Switch                              | 1.3.6.1.4.1.9.6.1.83.20.1 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   | Managed Switches   |  |                           |
|-------------------|--|--|---------------------------|
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches           | Cisco SG300-28 28-Port Gigabit Managed Switch  | 1.3.6.1.4.1.9.6.1.83.28.1 |
| Switches and Hubs | Cisco Small Business 300 Series Managed Switches           | Cisco SG300-52 52-Port Gigabit Managed Switch  | 1.3.6.1.4.1.9.6.1.83.52.1 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SF500-24 24-Port 10/100 Stackable Managed Switch                               | 1.3.6.1.4.1.9.6.1.80.24.1 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SF500-24 24-Port 10/100 POE Stackable Managed Switch                           | 1.3.6.1.4.1.9.6.1.80.24.2 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SF500-48 48-Port 10/100 Stackable Managed Switch                               | 1.3.6.1.4.1.9.6.1.80.48.1 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SF500-48P 48P-Port 10/100 POE Stackable Managed Switch                         | 1.3.6.1.4.1.9.6.1.80.48.2 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SG500-28 28-port Gigabit Stackable Managed Switch                              | 1.3.6.1.4.1.9.6.1.81.28.1 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SG500-28P 28-port Gigabit POE Stackable Managed Switch                         | 1.3.6.1.4.1.9.6.1.81.28.2 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SG500-52 52-port Gigabit Stackable Managed Switch                              | 1.3.6.1.4.1.9.6.1.81.52.1 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SG500-52P 52-port Gigabit POE Stackable Managed Switch                         | 1.3.6.1.4.1.9.6.1.81.52.2 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SG500X-24 24-Port Gigabit with 4-Port 10-Gigabit Stackable Managed Switch      | 1.3.6.1.4.1.9.6.1.85.24.1 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SG500X-24P 24-Port Gigabit POE with 4-Port 10-Gigabit Stackable Managed Switch | 1.3.6.1.4.1.9.6.1.85.24.2 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |  |  |                           |
|-------------------|--|--|---------------------------|
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SG500X-48 48-Port Gigabit with 4-Port 10-Gigabit Stackable Managed Switch      | 1.3.6.1.4.1.9.6.1.85.48.1 |
| Switches and Hubs | Cisco Small Business 500 Series Stackable Managed Switches | Cisco SG500X-48P 48-Port Gigabit POE with 4-Port 10-Gigabit Stackable Managed Switch | 1.3.6.1.4.1.9.6.1.85.48.2 |
| Switches and Hubs | Cisco 2500 Series Connected Grid Switches                  | Cisco CGS-2520-24TC Connected Grid Switch  | 1.3.6.1.4.1.9.1.1245      |
| Switches and Hubs | Cisco 2500 Series Connected Grid Switches                  | Cisco CGS-2520-16S-8PC Connected Grid Switch   | 1.3.6.1.4.1.9.1.1246      |
| Switches and Hubs | Cisco ME 3600X Series Ethernet Access Switches             | Cisco ME 3600X-24FS-M Switch   | 1.3.6.1.4.1.9.1.1250      |
| Switches and Hubs | Cisco ME 3600X Series Ethernet Access Switches             | Cisco ME 3600X-24TS-M Switch   | 1.3.6.1.4.1.9.1.1251      |
| Switches and Hubs | Cisco Catalyst 2100 Series Switches                        | Cisco Catalyst 2100 Switch   | 1.3.6.1.4.1.437.1.1.3.3.2 |
| Switches and Hubs | Cisco 1220 Etherswitch Series                              | Cisco 1220 Etherswitch   | 1.3.6.1.4.1.9.5.19        |
| Switches and Hubs | Cisco Catalyst 1200 Series Switches                        | 1200   | 1.3.6.1.4.1.9.5.5         |
| Switches and Hubs | Cisco Catalyst 1200 Series Switches                        | 1220   | 1.3.6.1.4.1.9.5.27        |
| Switches and Hubs | Cisco Workgroup Concentrators                              | Cisco WS-C1100 CDDI,FDDI Workgroup Concentrator                                      | 1.3.6.1.4.1.9.5.4         |
| Switches and Hubs | Cisco Workgroup Concentrators                              | Cisco WS-C1100 CDDI,FDDI Workgroup Concentrator                                      | 1.3.6.1.4.1.9.5.1         |
| Switches and Hubs | Cisco Workgroup Concentrators                              | Cisco WS-C1400 Workgroup Concentrator  | 1.3.6.1.4.1.9.5.6         |
| Switches and Hubs | Cisco Workgroup Concentrators                              | Cisco 1000 Workgroup Concentrator  | 1.3.6.1.4.1.9.5.3         |
| Switches and Hubs | Cisco Lightstream ATM Switches                             | Cisco LightStream 1010 ATM Switches  | 1.3.6.1.4.1.9.5.11        |
| Switches and Hubs | Cisco Lightstream ATM Switches                             | Cisco LightStream 1010 ATM Switches  | 1.3.6.1.4.1.9.1.107       |
| Switches and Hubs | Cisco Lightstream ATM Switches                             | Cisco LightStream 1015 ATM Switches  | 1.3.6.1.4.1.9.1.164       |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches                        | Cisco Catalyst 3560-24PS Switch  | 1.3.6.1.4.1.9.1.563       |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                       |   |                      |
|-------------------|---------------------------------------|---|----------------------|
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560-48PS Switch             | 1.3.6.1.4.1.9.1.564  |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560G-24PS Switch            | 1.3.6.1.4.1.9.1.614  |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560G-24TS Switch            | 1.3.6.1.4.1.9.1.615  |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560-24TS Switch             | 1.3.6.1.4.1.9.1.633  |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560G-48PS Switch            | 1.3.6.1.4.1.9.1.616  |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560G-48TS Switch            | 1.3.6.1.4.1.9.1.617  |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560-48TS Switch             | 1.3.6.1.4.1.9.1.634  |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst C3560-8PC-S Switch           | 1.3.6.1.4.1.9.1.1466 |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst C3560-12PC-S Switch          | 1.3.6.1.4.1.9.1.1465 |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560-8PC Compact Switch      | 1.3.6.1.4.1.9.1.797  |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560-12PC-S Compact Switch   | 1.3.6.1.4.1.9.1.1015 |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560V2-24DC Switch           | 1.3.6.1.4.1.9.1.1019 |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560V2-24TS Switch           | 1.3.6.1.4.1.9.1.1020 |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560V2-24PS Switch           | 1.3.6.1.4.1.9.1.1021 |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560V2-48TS Switch           | 1.3.6.1.4.1.9.1.1024 |
| Switches and Hubs | Cisco Catalyst 3560 Series Switches   | Cisco Catalyst 3560V2-48PS Switch           | 1.3.6.1.4.1.9.1.1025 |
| Switches and Hubs | Cisco Catalyst 3560-C Series Switches | Cisco Catalyst 3560CG-8PC-S Compact Switch  | 1.3.6.1.4.1.9.1.1317 |
| Switches and Hubs | Cisco Catalyst 3560-C Series Switches | Cisco Catalyst 3560CG-8TC-S Compact Switch  | 1.3.6.1.4.1.9.1.1318 |
| Switches and Hubs | Cisco Catalyst 3560-C Series Switches | Cisco Catalyst 3560CPD-8PT-S Compact Switch | 1.3.6.1.4.1.9.1.1368 |
| Switches and Hubs | Cisco Catalyst 3560-C Series Switches | Cisco Catalyst 3560C-12PC-S Switch          | 1.3.6.1.4.1.9.1.1465 |
|                   |                                       |   | 1.3.6.1.4.1.9.1.952  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                       |   |                      |
|-------------------|---------------------------------------|---|----------------------|
| Switches and Hubs | Cisco Catalyst 2960-C Series Switches | Cisco Catalyst 2960CPD-8TT-L Switch                     |                      |
| Switches and Hubs | Cisco Catalyst 2960-C Series Switches | Cisco Catalyst 2960CPD-8TT-L Switch                     | 1.3.6.1.4.1.9.1.1278 |
| Switches and Hubs | Cisco Catalyst 2960-C Series Switches | Cisco Catalyst 2960CPD-8PT-L Switch                     | 1.3.6.1.4.1.9.1.1315 |
| Switches and Hubs | Cisco Catalyst 2960-C Series Switches | Cisco Catalyst 2960CG-8TC-L Compact Switch              | 1.3.6.1.4.1.9.1.1316 |
| Switches and Hubs | Cisco Catalyst 2960-C Series Switches | Cisco Catalyst 2960C-8PC-L Switch                       | 1.3.6.1.4.1.9.1.1366 |
| Switches and Hubs | Cisco Catalyst 2960-C Series Switches | Cisco Catalyst 2960C-12PC-L Switch                      | 1.3.6.1.4.1.9.1.1367 |
| Switches and Hubs | Cisco Catalyst 2960-C Series Switches | Cisco Catalyst 2960C-8TC-L Switch                       | 1.3.6.1.4.1.9.1.1365 |
| Switches and Hubs | Cisco Catalyst 2960-C Series Switches | Cisco Catalyst 2960C-8TC-S Switch                       | 1.3.6.1.4.1.9.1.1364 |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches | Cisco SM-ES3-16-P                                       | 1.3.6.1.4.1.9.1.1049 |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches | Cisco Enhanced Layer2,Layer3 EtherSwitch Service Module | 1.3.6.1.4.1.9.1.1057 |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches | Cisco SM-ES3-24-P                                       | 1.3.6.1.4.1.9.1.1053 |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches | Cisco SM-ES3G-16-P                                      | 1.3.6.1.4.1.9.1.1050 |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches | Cisco SM-ES3G-24-P                                      | 1.3.6.1.4.1.9.1.1054 |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches | Cisco Catalyst 3560E-24TD-E,S Switch                    | 1.3.6.1.4.1.9.1.793  |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches | Cisco Catalyst 3560E-48TD-E,S Switch                    | 1.3.6.1.4.1.9.1.794  |
| Switches and Hubs | Cisco Catalyst 3560-E Series          | Cisco Catalyst 3560E-24PD-E,S Switch                    | 1.3.6.1.4.1.9.1.795  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   | Switches                                  |  |                      |
|-------------------|---|--|----------------------|
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches     | Cisco Catalyst 3560E-48PD-E,S Switch   | 1.3.6.1.4.1.9.1.796  |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches     | Cisco Catalyst 3560E-12D-S,E Switch    | 1.3.6.1.4.1.9.1.930  |
| Switches and Hubs | Cisco Catalyst 3560-E Series Switches     | Cisco Catalyst 3560E-12SD-E,S Switch   | 1.3.6.1.4.1.9.1.956  |
| Switches and Hubs | Cisco Catalyst 3560-X Series Switches     | Cisco Catalyst 3560X-24T-L,S Switch    | 1.3.6.1.4.1.9.1.1226 |
| Switches and Hubs | Cisco Catalyst 3560-X Series Switches     | Cisco Catalyst 3560X-48T-L,S Switch    | 1.3.6.1.4.1.9.1.1227 |
| Switches and Hubs | Cisco Catalyst 3560-X Series Switches     | Cisco Catalyst 3560X-24P-L,S Switch    | 1.3.6.1.4.1.9.1.1228 |
| Switches and Hubs | Cisco Catalyst 3560-X Series Switches     | Cisco Catalyst 3560X-48PF-L,S Switch   | 1.3.6.1.4.1.9.1.1229 |
| Switches and Hubs | Cisco Catalyst 3750 Metro Series Switches | Cisco Catalyst 3750 Metro 24-DC Switch | 1.3.6.1.4.1.9.1.574  |
| Switches and Hubs | Cisco Catalyst 3750-E Series Switches     | Cisco Catalyst 3750E-24TD-E,S Switch   | 1.3.6.1.4.1.9.1.789  |
| Switches and Hubs | Cisco Catalyst 3750-E Series Switches     | Cisco Catalyst 3750E-48TD-E,S Switch   | 1.3.6.1.4.1.9.1.790  |
| Switches and Hubs | Cisco Catalyst 3750-E Series Switches     | Cisco Catalyst 3750E-48PD-E,S Switch   | 1.3.6.1.4.1.9.1.791  |
| Switches and Hubs | Cisco Catalyst 3750-E Series Switches     | Cisco Catalyst 3750E-24PD-E,S Switch   | 1.3.6.1.4.1.9.1.792  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches       | Cisco 3750 Stackable Switches          | 1.3.6.1.4.1.9.1.516  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches       | Cisco Catalyst 3750G-24PS Switch       | 1.3.6.1.4.1.9.1.602  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches       | Cisco Catalyst 3750G-48PS Switch       | 1.3.6.1.4.1.9.1.603  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches       | Cisco Catalyst 3750G-24TS-1U Switch    | 1.3.6.1.4.1.9.1.624  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches       | Cisco Catalyst 3750-24FS Switch        | 1.3.6.1.4.1.9.1.656  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                       |                                      |                      |
|-------------------|---------------------------------------|--------------------------------------|----------------------|
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750-24PS Switch      | 1.3.6.1.4.1.9.1.536  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750-24TS Switch      | 1.3.6.1.4.1.9.1.513  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750-48PS Switch      | 1.3.6.1.4.1.9.1.535  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-16TD Switch     | 1.3.6.1.4.1.9.1.591  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-48TS Switch     | 1.3.6.1.4.1.9.1.604  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-12S-SD Switch   | 1.3.6.1.4.1.9.1.688  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-12S Switch      | 1.3.6.1.4.1.9.1.530  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-24WS Switch     | 1.3.6.1.4.1.9.1.778  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-24WS Switch     | 1.3.6.1.4.1.9.1.779  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-24 Switch       | 1.3.6.1.4.1.9.1.511  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-48 Switch       | 1.3.6.1.4.1.9.1.512  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750G-24T Switch      | 1.3.6.1.4.1.9.1.514  |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750V2-24TS Switch    | 1.3.6.1.4.1.9.1.1022 |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750V2-24PS Switch    | 1.3.6.1.4.1.9.1.1023 |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750V2-48TS Switch    | 1.3.6.1.4.1.9.1.1026 |
| Switches and Hubs | Cisco Catalyst 3750 Series Switches   | Cisco Catalyst 3750V2-48PS Switch    | 1.3.6.1.4.1.9.1.1027 |
| Switches and Hubs | Cisco Catalyst 3750-X Series Switches | Cisco Catalyst 3750X-24T-L,S Switch  | 1.3.6.1.4.1.9.1.1222 |
| Switches and Hubs | Cisco Catalyst 3750-X Series Switches | Cisco Catalyst 3750X-48T-L,S Switch  | 1.3.6.1.4.1.9.1.1223 |
| Switches and Hubs | Cisco Catalyst 3750-X Series Switches | Cisco Catalyst 3750X-24P-L,S Switch  | 1.3.6.1.4.1.9.1.1224 |
| Switches and Hubs | Cisco Catalyst 3750-X Series Switches | Cisco Catalyst 3750X-48PF-L,S Switch | 1.3.6.1.4.1.9.1.1225 |
| Switches and Hubs | Cisco Catalyst 3750-X Series          | Cisco Catalyst 3750X-24S-S Switch    | 1.3.6.1.4.1.9.1.1404 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   | Switches                                  |  |                      |
|-------------------|---|--|----------------------|
| Switches and Hubs | Cisco Catalyst 3750-X Series Switches     | Cisco Catalyst 3750X-12S-S Switch                      | 1.3.6.1.4.1.9.1.1405 |
| Switches and Hubs | Cisco 2500 Series Connected Grid Switches | Cisco CGS-2520-24TC Connected Grid Switch              | 1.3.6.1.4.1.9.1.1245 |
| Switches and Hubs | Cisco 2500 Series Connected Grid Switches | Cisco CGS-2520-16S-8PC Connected Grid Switch           | 1.3.6.1.4.1.9.1.1246 |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Switch Module 3012 for IBM BladeCenter  | 1.3.6.1.4.1.9.1.999  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Switch Module 3012 for IBM BladeCenter  | 1.3.6.1.4.1.9.1.1000 |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Blade Switch 3020 for HP                | 1.3.6.1.4.1.9.1.748  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Blade Switch 3030 for Dell              | 1.3.6.1.4.1.9.1.749  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Blade Switch 3032 for Dell M1000E       | 1.3.6.1.4.1.9.1.920  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Blade Switch 3040 for FSC               | 1.3.6.1.4.1.9.1.784  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Stack of CBS3100 switch modules                        | 1.3.6.1.4.1.9.1.946  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Switch Module 3110G for IBM BladeCenter | 1.3.6.1.4.1.9.1.909  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Switch Module 3110G for IBM BladeCenter | 1.3.6.1.4.1.9.1.910  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Switch Module 3110X for IBM BladeCenter | 1.3.6.1.4.1.9.1.947  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Switch Module 3110X for IBM BladeCenter | 1.3.6.1.4.1.9.1.911  |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series   | Cisco Catalyst Switch Module 3110X for IBM BladeCenter | 1.3.6.1.4.1.9.1.912  |
| Switches and      | Cisco Catalyst                            | Cisco Catalyst Blade                                   | 1.3.6.1.4.1.9.1.948  |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |   |   |                           |
|-------------------|---|---|---------------------------|
| Hubs              | Blade Switch 3000 Series                | Switch 3120X for HP                               |                           |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series | Cisco Catalyst Blade Switch 3120X for HP          | 1.3.6.1.4.1.9.1.919       |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series | Cisco Catalyst Blade Switch 3120G for HP          | 1.3.6.1.4.1.9.1.918       |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series | Cisco Catalyst Blade Switch 3125G for HP          | 1.3.6.1.4.1.9.1.1001      |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series | Cisco Catalyst Blade Switch 3125X for HP          | 1.3.6.1.4.1.9.1.1002      |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series | Cisco Catalyst Blade Switch 3130X for Dell M1000E | 1.3.6.1.4.1.9.1.949       |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series | Cisco Catalyst Blade Switch 3130X for Dell M1000E | 1.3.6.1.4.1.9.1.922       |
| Switches and Hubs | Cisco Catalyst Blade Switch 3000 Series | Cisco Catalyst Blade Switch 3130G for Dell M1000E | 1.3.6.1.4.1.9.1.921       |
| Switches and Hubs | Cisco 1500 Series Micro Hubs            | MicroHub 1503                                     | 1.3.6.1.4.1.9.1.160       |
| Switches and Hubs | Cisco 1500 Series Micro Hubs            | MicroHub 1502                                     | 1.3.6.1.4.1.9.1.161       |
| Switches and Hubs | Cisco 1538 Series Micro Hubs            | Cisco 1538M Micro Hub                             | 1.3.6.1.4.1.9.1.224       |
| Switches and Hubs | Cisco Catalyst 1600 Series Switches     | Cisco Catalyst 1600 Switch                        | 1.3.6.1.4.1.9.5.8         |
| Switches and Hubs | Cisco Catalyst 1600 Series Switches     | Cisco Catalyst 1600 Switch                        | 1.3.6.1.4.1.9.5.9         |
| Switches and Hubs | Cisco Catalyst 1900 Series Switches     | Cisco Catalyst 1912 C A Switch                    | 1.3.6.1.4.1.9.1.175       |
| Switches and Hubs | Cisco Catalyst 1900 Series Switches     | Cisco Catalyst 1924 A Switch                      | 1.3.6.1.4.1.9.5.18        |
| Switches and Hubs | Cisco Catalyst 1900 Series Switches     | Cisco Catalyst 1924 A Switch                      | 1.3.6.1.4.1.9.5.16        |
| Switches and Hubs | Cisco Catalyst 1900 Series Switches     | Cisco Catalyst 1900 C                             | 1.3.6.1.4.1.9.5.28        |
| Switches and Hubs | Cisco Catalyst 1900 Series Switches     | Cisco Catalyst 1900 L                             | 1.3.6.1.4.1.9.5.31        |
| Switches and Hubs | Cisco Catalyst 2800 Series Switches     | Cisco Catalyst 2800 Switch                        | 1.3.6.1.4.1.437.1.1.3.3.3 |
| Switches and Hubs | Cisco Catalyst 2800 Series Switches     | Cisco Catalyst 2820 Modular Ethernet Switch       | 1.3.6.1.4.1.9.5.20        |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |  |                                     |                      |
|-------------------|--|-------------------------------------|----------------------|
| Switches and Hubs | Cisco Catalyst 2900 Series Switches    | Cisco Catalyst 2948G-GE-TX Switch   | 1.3.6.1.4.1.9.5.62   |
| Switches and Hubs | Cisco Catalyst 2900 Series Switches    | Cisco Catalyst 2926 Switch          | 1.3.6.1.4.1.9.5.35   |
| Switches and Hubs | Cisco Catalyst 2900 Series Switches    | Cisco Catalyst 2948G-L2 Switch      | 1.3.6.1.4.1.9.5.42   |
| Switches and Hubs | Cisco Catalyst 2900 Series Switches    | Cisco Catalyst 2980G-A Switch       | 1.3.6.1.4.1.9.5.51   |
| Switches and Hubs | Cisco Catalyst 2900 Series Switches    | Cisco Catalyst 2980G-A Switch       | 1.3.6.1.4.1.9.5.49   |
| Switches and Hubs | Cisco Catalyst 2900 Series XL Switches | Cisco Catalyst 2912 XL Switch       | 1.3.6.1.4.1.9.1.219  |
| Switches and Hubs | Cisco Catalyst 2900 Series XL Switches | Cisco Catalyst 2924C XL Switch      | 1.3.6.1.4.1.9.1.184  |
| Switches and Hubs | Cisco Catalyst 2900 Series XL Switches | Cisco Catalyst 2924C XL Switch      | 1.3.6.1.4.1.9.1.218  |
| Switches and Hubs | Cisco Catalyst 2900 Series XL Switches | Cisco Catalyst 2924 XL Switch       | 1.3.6.1.4.1.9.1.183  |
| Switches and Hubs | Cisco Catalyst 2900 Series XL Switches | Cisco Catalyst 2924 XL Switch       | 1.3.6.1.4.1.9.1.217  |
| Switches and Hubs | Cisco Catalyst 2900 Series XL Switches | Cisco Catalyst 2924M XL Switch      | 1.3.6.1.4.1.9.1.220  |
| Switches and Hubs | Cisco Catalyst 2900 Series XL Switches | Cisco Catalyst 2912MF XL Switch     | 1.3.6.1.4.1.9.1.221  |
| Switches and Hubs | Cisco Catalyst 2900 Series XL Switches | Cisco Catalyst 2916M XL Switch      | 1.3.6.1.4.1.9.1.171  |
| Switches and Hubs | Cisco Catalyst 2918 Series Switches    | Cisco Catalyst 2918-24TT-C Switch   | 1.3.6.1.4.1.9.1.965  |
| Switches and Hubs | Cisco Catalyst 2918 Series Switches    | Cisco Catalyst 2918-24TC-C Switch   | 1.3.6.1.4.1.9.1.966  |
| Switches and Hubs | Cisco Catalyst 2918 Series Switches    | Cisco Catalyst 2918-48TT-C Switch   | 1.3.6.1.4.1.9.1.967  |
| Switches and Hubs | Cisco Catalyst 2918 Series Switches    | Cisco Catalyst 2918-48TC-C Switch   | 1.3.6.1.4.1.9.1.968  |
| Switches and Hubs | Cisco Catalyst 2928 Series Switches    | Cisco Catalyst 2928-24TC-C Switch   | 1.3.6.1.4.1.9.1.1328 |
| Switches and Hubs | Cisco Catalyst 2928 Series Switches    | Cisco Catalyst C2928-24LT-C Switch  | 1.3.6.1.4.1.9.1.1330 |
| Switches and Hubs | Cisco Catalyst 2928 Series Switches    | Cisco Catalyst C2928-48TC-C Switch  | 1.3.6.1.4.1.9.1.1329 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches    | Cisco Catalyst 2960S-48FPD-L Switch | 1.3.6.1.4.1.9.1.1258 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches    | Cisco Catalyst 2960S-48LPD-L Switch | 1.3.6.1.4.1.9.1.1259 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches    | Cisco Catalyst 2960S-48TD-L Switch  | 1.3.6.1.4.1.9.1.1260 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                     |  |                      |
|-------------------|-------------------------------------|--|----------------------|
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-24PS-L Switch         | 1.3.6.1.4.1.9.1.1265 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-K9-M Switch           | 1.3.6.1.4.1.9.1.1208 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-24TS-L Switch         | 1.3.6.1.4.1.9.1.1267 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-48TS-S Switch         | 1.3.6.1.4.1.9.1.1256 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-24TC Switch            | 1.3.6.1.4.1.9.1.694  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-24TT Switch            | 1.3.6.1.4.1.9.1.716  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-48TC Switch            | 1.3.6.1.4.1.9.1.695  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-48TT Switch            | 1.3.6.1.4.1.9.1.717  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960G-24TC Switch           | 1.3.6.1.4.1.9.1.696  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960G-48TC Switch           | 1.3.6.1.4.1.9.1.697  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-8TC Compact Switch     | 1.3.6.1.4.1.9.1.798  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960G-8TC Compact Switch    | 1.3.6.1.4.1.9.1.799  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-24-S Switch            | 1.3.6.1.4.1.9.1.929  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-24TC-S Switch          | 1.3.6.1.4.1.9.1.928  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-48TC-S Switch          | 1.3.6.1.4.1.9.1.927  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-24PC-L Switch          | 1.3.6.1.4.1.9.1.950  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-24LT-L Switch          | 1.3.6.1.4.1.9.1.951  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960PD-8TT-L Compact Switch | 1.3.6.1.4.1.9.1.952  |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-8TC-S Compact Switch   | 1.3.6.1.4.1.9.1.1006 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-48TT-S Switch          | 1.3.6.1.4.1.9.1.1005 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-48PST-L Switch         | 1.3.6.1.4.1.9.1.1016 |
|                   |                                     |  | 1.3.6.1.4.1.9.1.1146 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                     |                                      |                      |
|-------------------|-------------------------------------|--------------------------------------|----------------------|
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-24LC-S Switch    |                      |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-24PC-S Switch    | 1.3.6.1.4.1.9.1.1147 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960-48PST-S Switch   | 1.3.6.1.4.1.9.1.1148 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-48TD-L Switch   | 1.3.6.1.4.1.9.1.1260 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S                 | 1.3.6.1.4.1.9.1.1208 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-24TD-L Switch   | 1.3.6.1.4.1.9.1.1262 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-48FPD-L Switch  | 1.3.6.1.4.1.9.1.1258 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-48LPD-L Switch  | 1.3.6.1.4.1.9.1.1259 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-24PD-L Switch   | 1.3.6.1.4.1.9.1.1261 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-48TS-L Switch   | 1.3.6.1.4.1.9.1.1266 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-24TS-L Switch   | 1.3.6.1.4.1.9.1.1267 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-48TS-S Switch   | 1.3.6.1.4.1.9.1.1256 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-24TS-S Switch   | 1.3.6.1.4.1.9.1.1257 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-48FPS-L Switch  | 1.3.6.1.4.1.9.1.1263 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-48LPS-L Switch  | 1.3.6.1.4.1.9.1.1264 |
| Switches and Hubs | Cisco Catalyst 2960 Series Switches | Cisco Catalyst 2960S-24PS-L Switch   | 1.3.6.1.4.1.9.1.1265 |
| Switches and Hubs | Cisco Catalyst 3000 Series Switches | Cisco Catalyst 3000 Switch           | 1.3.6.1.4.1.9.5.10   |
| Switches and Hubs | Cisco Catalyst 3000 Series Switches | Cisco Catalyst 3100 Switch           | 1.3.6.1.4.1.9.5.23   |
| Switches and Hubs | Cisco Catalyst 3000 Series Switches | Cisco Catalyst 3200 Switch           | 1.3.6.1.4.1.9.5.15   |
| Switches and Hubs | Cisco Catalyst 3550 Series Switches | Cisco Catalyst 3550 12T Switch       | 1.3.6.1.4.1.9.1.368  |
| Switches and Hubs | Cisco Catalyst 3550 Series Switches | Cisco Catalyst 3550 12G Switch       | 1.3.6.1.4.1.9.1.431  |
| Switches and Hubs | Cisco Catalyst 3550 Series Switches | Cisco Catalyst 3550 24 Switch        | 1.3.6.1.4.1.9.1.366  |
| Switches and Hubs | Cisco Catalyst 3550 Series Switches | Cisco Catalyst 3550 24 DC SMI Switch | 1.3.6.1.4.1.9.1.452  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |  |  |                     |
|-------------------|--|--|---------------------|
| Switches and Hubs | Cisco Catalyst 3550 Series Switches    | Cisco Catalyst 3550 48 Switch            | 1.3.6.1.4.1.9.1.367 |
| Switches and Hubs | Cisco Catalyst 3550 Series Switches    | Cisco Catalyst 3550 24 FX SMI Switch     | 1.3.6.1.4.1.9.1.453 |
| Switches and Hubs | Cisco Catalyst 3550 Series Switches    | Cisco Catalyst 3550 24 PWR Switch        | 1.3.6.1.4.1.9.1.485 |
| Switches and Hubs | Cisco Catalyst 3500 Series XL Switches | Cisco Catalyst 3508G XL Switch           | 1.3.6.1.4.1.9.1.246 |
| Switches and Hubs | Cisco Catalyst 3500 Series XL Switches | Cisco Catalyst 3512 XL Switch            | 1.3.6.1.4.1.9.1.247 |
| Switches and Hubs | Cisco Catalyst 3500 Series XL Switches | Cisco Catalyst 3524 XL Switch            | 1.3.6.1.4.1.9.1.248 |
| Switches and Hubs | Cisco Catalyst 3500 Series XL Switches | Cisco Catalyst 3524 PWR XL Switch        | 1.3.6.1.4.1.9.1.287 |
| Switches and Hubs | Cisco Catalyst 3500 Series XL Switches | Cisco Catalyst 3548 XL Switch            | 1.3.6.1.4.1.9.1.278 |
| Switches and Hubs | Cisco Catalyst 3900 Series Switches    | Cisco Catalyst 3900 Switch               | 1.3.6.1.4.1.9.5.33  |
| Switches and Hubs | Cisco Catalyst 3900 Series Switches    | Cisco Catalyst 3920 Switch               | 1.3.6.1.4.1.9.5.37  |
| Switches and Hubs | Cisco Catalyst 4000 Series Switches    | Cisco Catalyst 4604 Access Gateway       | 1.3.6.1.4.1.9.1.318 |
| Switches and Hubs | Cisco Catalyst 4000 Series Switches    | Cisco Catalyst 4003 Switch               | 1.3.6.1.4.1.9.5.40  |
| Switches and Hubs | Cisco Catalyst 4000 Series Switches    | Cisco Catalyst 4006 Switch               | 1.3.6.1.4.1.9.5.46  |
| Switches and Hubs | Cisco Catalyst 4000 Series Switches    | Cisco Catalyst 4006 Switch               | 1.3.6.1.4.1.9.1.448 |
| Switches and Hubs | Cisco Catalyst 4000 Series Switches    | Cisco Catalyst 4006 Switch               | 1.3.6.1.4.1.9.1.300 |
| Switches and Hubs | Cisco Catalyst 4000 Series Switches    | Cisco Catalyst 4912G Switch              | 1.3.6.1.4.1.9.5.41  |
| Switches and Hubs | Cisco Catalyst 4000 Series Switches    | Cisco Catalyst 4000 Switch               | 1.3.6.1.4.1.9.1.7   |
| Switches and Hubs | Cisco Catalyst G-L3 Series Switches    | Cisco Catalyst C2948G-L3 Ethernet Switch | 1.3.6.1.4.1.9.1.275 |
| Switches and Hubs | Cisco Catalyst G-L3 Series Switches    | Cisco Catalyst C2948G-L3 Ethernet Switch | 1.3.6.1.4.1.9.1.386 |
| Switches and Hubs | Cisco Catalyst G-L3 Series Switches    | Cisco Catalyst 4908G-L3 Switch           | 1.3.6.1.4.1.9.1.298 |
| Switches and Hubs | Cisco Catalyst G-L3 Series Switches    | Cisco Catalyst 4908G-L3 Switch           | 1.3.6.1.4.1.9.1.387 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                       |   |                      |
|-------------------|---------------------------------------|---|----------------------|
| Switches and Hubs | Cisco Catalyst G-L3 Series Switches   | Cisco Catalyst 4840G Switch                   | 1.3.6.1.4.1.9.1.312  |
| Switches and Hubs | Cisco Catalyst G-L3 Series Switches   | Cisco IE-3010-24TC Industrial Ethernet Switch | 1.3.6.1.4.1.9.1.1320 |
| Switches and Hubs | Cisco IE 3000 Series Switches         | Cisco IE 3000-4TC Industrial Ethernet Switch  | 1.3.6.1.4.1.9.1.958  |
| Switches and Hubs | Cisco IE 3000 Series Switches         | Cisco IE 3000-8TC Industrial Ethernet Switch  | 1.3.6.1.4.1.9.1.959  |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS06SG                      | 1.3.6.1.4.1.9.1.1479 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS06SG                      | 1.3.6.1.4.1.9.1.1480 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS06T                       | 1.3.6.1.4.1.9.1.1477 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS06T                       | 1.3.6.1.4.1.9.1.1478 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS06TG                      | 1.3.6.1.4.1.9.1.1481 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS06TG                      | 1.3.6.1.4.1.9.1.1482 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS10C                       | 1.3.6.1.4.1.9.1.1483 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS10C                       | 1.3.6.1.4.1.9.1.1484 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS10CG                      | 1.3.6.1.4.1.9.1.1485 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS10CG                      | 1.3.6.1.4.1.9.1.1486 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS10CGN                     | 1.3.6.1.4.1.9.1.1488 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS10CGP                     | 1.3.6.1.4.1.9.1.1487 |
| Switches and Hubs | Rockwell Stratix                      | Rockwell Stratix BMS20C                       | 1.3.6.1.4.1.9.1.1489 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                       |   |                      |
|-------------------|---------------------------------------|---|----------------------|
| Hubs              | 5700 Series Switches                  |   |                      |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS20C                           | 1.3.6.1.4.1.9.1.1490 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS20CGL                         | 1.3.6.1.4.1.9.1.1491 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS20CGP                         | 1.3.6.1.4.1.9.1.1492 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix BMS20CGPK                        | 1.3.6.1.4.1.9.1.1493 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix MS06SA                           | 1.3.6.1.4.1.9.1.1519 |
| Switches and Hubs | Rockwell Stratix 5700 Series Switches | Rockwell Stratix MS06S                            | 1.3.6.1.4.1.9.1.1476 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-4TS Industrial Ethernet Switch      | 1.3.6.1.4.1.9.1.1468 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-4T Industrial Ethernet Switch       | 1.3.6.1.4.1.9.1.1469 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-4TS-G Industrial Ethernet Switch    | 1.3.6.1.4.1.9.1.1470 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-4T-G Industrial Ethernet Switch     | 1.3.6.1.4.1.9.1.1471 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-8TC Industrial Ethernet Switch      | 1.3.6.1.4.1.9.1.1472 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-8TC-G Industrial Ethernet Switch    | 1.3.6.1.4.1.9.1.1473 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-16TC Industrial Ethernet Switch     | 1.3.6.1.4.1.9.1.1474 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-16TC-G Industrial Ethernet Switch   | 1.3.6.1.4.1.9.1.1475 |
| Switches and Hubs | Cisco IE 2000 Series Switches         | Cisco IE 2000-16TC-G-X Industrial Ethernet Switch | 1.3.6.1.4.1.9.1.1520 |
| Switches and Hubs | Rockwell Stratix 8000 Series Switches | Rockwell Stratix MS06T                            | 1.3.6.1.4.1.9.1.960  |
| Switches and Hubs | Rockwell Stratix 8000 Series Switches | Rockwell Stratix MS06T                            | 1.3.6.1.4.1.9.1.1170 |
| Switches and Hubs | Rockwell Stratix 8000 Series Switches | Rockwell Stratix MS10T                            | 1.3.6.1.4.1.9.1.961  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |  |   |                      |
|-------------------|--|---|----------------------|
| Switches and Hubs | Rockwell Stratix 8000 Series Switches                  | Rockwell Stratix MS10T                    | 1.3.6.1.4.1.9.1.1171 |
| Switches and Hubs | Cisco Catalyst 5000 Series Switches                    | Cisco Catalyst 5000 Switch                | 1.3.6.1.4.1.9.5.7    |
| Switches and Hubs | Cisco Catalyst 5000 Series Switches                    | Cisco Catalyst 5002 Switch                | 1.3.6.1.4.1.9.5.29   |
| Switches and Hubs | Cisco Catalyst 5500 Series Switches                    | Cisco Catalyst 5500 Switch                | 1.3.6.1.4.1.9.5.17   |
| Switches and Hubs | Cisco Catalyst 5500 Series Switches                    | Cisco Catalyst 5505 Switch                | 1.3.6.1.4.1.9.5.34   |
| Switches and Hubs | Cisco Catalyst 5500 Series Switches                    | Cisco Catalyst 5509 Switch                | 1.3.6.1.4.1.9.5.36   |
| Switches and Hubs | Cisco Catalyst 6000 Series Switches                    | Cisco Catalyst 6006 Switch                | 1.3.6.1.4.1.9.1.280  |
| Switches and Hubs | Cisco Catalyst 6000 Series Switches                    | Cisco Catalyst 6006 Switch                | 1.3.6.1.4.1.9.5.38   |
| Switches and Hubs | Cisco Catalyst 6000 Series Switches                    | Cisco Catalyst 6009 Switch                | 1.3.6.1.4.1.9.1.281  |
| Switches and Hubs | Cisco Catalyst 6000 Series Switches                    | Cisco Catalyst 6009 Switch                | 1.3.6.1.4.1.9.5.39   |
| Switches and Hubs | Cisco Catalyst 6000 Series Switches                    | Cisco Catalyst 6000 Switch                | 1.3.6.1.4.1.9.1.241  |
| Switches and Hubs | Cisco Catalyst 8500 Series Multiservice Switch Routers | Cisco Catalyst 8510 MSR Switch            | 1.3.6.1.4.1.9.1.230  |
| Switches and Hubs | Cisco Catalyst 8500 Series Multiservice Switch Routers | Cisco Catalyst 8540 MSR Switch            | 1.3.6.1.4.1.9.1.202  |
| Switches and Hubs | Cisco Catalyst 8500 Series Multiservice Switch Routers | Cisco Catalyst 8515 MSR Switch            | 1.3.6.1.4.1.9.1.231  |
| Switches and Hubs | Cisco Catalyst 8500 Series Multiservice Switch Routers | Cisco Catalyst 8515 CSR Switch            | 1.3.6.1.4.1.9.1.196  |
| Switches and Hubs | Cisco 1548 Series Micro Switch                         | Cisco 1548M Micro Switch                  | 1.3.6.1.4.1.9.1.225  |
| Switches and Hubs | Cisco BPX 8600 Series Switches                         | Cisco BPX 8650 IP,ATM Multiservice Switch | 1.3.6.1.4.1.9.1.238  |
| Switches and Hubs | Cisco BPX 8600 Series Switches                         | Cisco BPX 8680 IP,ATM Multiservice Switch | 1.3.6.1.4.1.9.1.239  |
| Switches and Hubs | Cisco BPX 8600 Series Switches                         | Cisco BPX 8620 Switch                     | 1.3.6.1.4.1.9.1.237  |
| Switches and Hubs | Cisco BPX 8600 Series Switches                         | Cisco BPX Switch                          | 1.3.6.1.4.1.351.100  |
|                   |  |   | 1.3.6.1.4.1.9.1.232  |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |   |   |                     |
|-------------------|---|---|---------------------|
| Switches and Hubs | Cisco IGX 8400 Series Switches                        | Cisco IGX 8410 Multiservice Switch            |                     |
| Switches and Hubs | Cisco IGX 8400 Series Switches                        | Cisco IGX 8420 Multiservice Switch            | 1.3.6.1.4.1.9.1.233 |
| Switches and Hubs | Cisco IGX 8400 Series Switches                        | Cisco IGX 8430 Multiservice Switch            | 1.3.6.1.4.1.9.1.234 |
| Switches and Hubs | Cisco IGX 8400 Series Switches                        | Cisco IGX 8450 SES Multiservice Switch        | 1.3.6.1.4.1.9.1.235 |
| Switches and Hubs | Cisco MGX 8200 Series Edge Concentrators              | Cisco MGX 8220 Edge Concentrator              | 1.3.6.1.4.1.351.110 |
| Switches and Hubs | Cisco MGX 8200 Series Edge Concentrators              | Cisco MGX 8230 Edge Concentrator              | 1.3.6.1.4.1.9.1.304 |
| Switches and Hubs | Cisco MGX 8200 Series Edge Concentrators              | Cisco MGX 8240 Private Line Gateway           | 1.3.6.1.4.1.9.1.311 |
| Switches and Hubs | Cisco MGX 8200 Series Edge Concentrators              | Cisco MGX 8250 Edge Concentrator              | 1.3.6.1.4.1.9.1.305 |
| Switches and Hubs | Cisco 8110 Series Broadband Network Termination Units | Cisco 8110 Broadband Network Termination Unit | 1.3.6.1.4.1.9.1.349 |
| Switches and Hubs | Cisco MGX 8800 Series Switches                        | Cisco MGX 8850 Multiservice Switch            | 1.3.6.1.4.1.9.1.228 |
| Switches and Hubs | Cisco MGX 8800 Series Switches                        | Cisco MGX 8850 Voice Gateway                  | 1.3.6.1.4.1.351.130 |
| Switches and Hubs | Cisco MGX 8800 Series Switches                        | Cisco MGX 8830 ATM Multiservice Switch        | 1.3.6.1.4.1.9.1.229 |
| Switches and Hubs | Cisco MGX 8800 Series Switches                        | Cisco MGX 8830 ATM Multiservice Switch        | 1.3.6.1.4.1.9.1.458 |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches                   | Cisco Catalyst 6506 Switch                    | 1.3.6.1.4.1.9.1.282 |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches                   | Cisco Catalyst 6506 Switch                    | 1.3.6.1.4.1.9.5.45  |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches                   | Cisco Catalyst 6509 Switch                    | 1.3.6.1.4.1.9.5.44  |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches                   | Cisco Catalyst 6509 Switch                    | 1.3.6.1.4.1.9.1.283 |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches                   | Cisco Catalyst 6509-NEB Switch                | 1.3.6.1.4.1.9.5.47  |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches                   | Cisco Catalyst 6509-NEB Switch                | 1.3.6.1.4.1.9.1.310 |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches                   | Cisco Catalyst 6509-NEB-A Switch              | 1.3.6.1.4.1.9.1.534 |
|                   |   |   | 1.3.6.1.4.1.9.5.61  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                     |   |                      |
|-------------------|-------------------------------------|---|----------------------|
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Catalyst 6509-NEB-A Switch          |                      |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Catalyst 6513 Switch                | 1.3.6.1.4.1.9.5.50   |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Catalyst 6513 Switch                | 1.3.6.1.4.1.9.1.400  |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Catalyst 6503 Switch                | 1.3.6.1.4.1.9.5.56   |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Catalyst 6503 Switch                | 1.3.6.1.4.1.9.1.449  |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Catalyst 6504-E Switch              | 1.3.6.1.4.1.9.5.64   |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Catalyst 6504-E Switch              | 1.3.6.1.4.1.9.1.657  |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Virtual Switching System            | 1.3.6.1.4.1.9.1.896  |
| Switches and Hubs | Cisco Catalyst 6500 Series Switches | Cisco Catalyst 6509-V-E Switch            | 1.3.6.1.4.1.9.1.832  |
| Switches and Hubs | Cisco Catalyst 4200 Series Switches | Cisco Catalyst 4224 Access Gateway Switch | 1.3.6.1.4.1.9.1.399  |
| Switches and Hubs | Cisco Catalyst 2350 Series Switches | Cisco Catalyst 2350-48TD-S Switch         | 1.3.6.1.4.1.9.1.1104 |
| Switches and Hubs | Cisco Catalyst 2940 Series Switches | Cisco Catalyst 2940-8TF Switch            | 1.3.6.1.4.1.9.1.542  |
| Switches and Hubs | Cisco Catalyst 2940 Series Switches | Cisco Catalyst 2940-8TT Switch            | 1.3.6.1.4.1.9.1.540  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950T 24 Switch            | 1.3.6.1.4.1.9.1.359  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950T 24 Switch            | 1.3.6.1.4.1.9.1.360  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950 12 Switch             | 1.3.6.1.4.1.9.1.323  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950 24 Switch             | 1.3.6.1.4.1.9.1.324  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950C 24 Switch            | 1.3.6.1.4.1.9.1.325  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950G 24 EI DC Switch      | 1.3.6.1.4.1.9.1.472  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950SX 24 Switch           | 1.3.6.1.4.1.9.1.480  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950SX 48 SI Switch        | 1.3.6.1.4.1.9.1.560  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2955S 12 Switch            | 1.3.6.1.4.1.9.1.508  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950T 48 SI Switch         | 1.3.6.1.4.1.9.1.559  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                                     |                                    |                      |
|-------------------|-------------------------------------|------------------------------------|----------------------|
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950G 12 EI Switch  | 1.3.6.1.4.1.9.1.427  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950G 24 EI Switch  | 1.3.6.1.4.1.9.1.428  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2950G 48 EI Switch  | 1.3.6.1.4.1.9.1.429  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2955C 12 Switch     | 1.3.6.1.4.1.9.1.489  |
| Switches and Hubs | Cisco Catalyst 2950 Series Switches | Cisco Catalyst 2955T 12 Switch     | 1.3.6.1.4.1.9.1.488  |
| Switches and Hubs | Cisco Catalyst 2970 Series Switches | Cisco Catalyst 2970G-24T Switch    | 1.3.6.1.4.1.9.1.527  |
| Switches and Hubs | Cisco Catalyst 2970 Series Switches | Cisco Catalyst 2970G-24TS Switch   | 1.3.6.1.4.1.9.1.561  |
| Switches and Hubs | Cisco Catalyst 2975 Series Switches | Cisco Catalyst 2975 Switch         | 1.3.6.1.4.1.9.1.1067 |
| Switches and Hubs | Cisco Catalyst 2975 Series Switches | Cisco Catalyst 2975 Switch         | 1.3.6.1.4.1.9.1.1068 |
| Switches and Hubs | Cisco MGX 8900 Series Switches      | Cisco MGX 8950 Multiservice Switch | 1.3.6.1.4.1.9.1.315  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4507RE Switch       | 1.3.6.1.4.1.9.1.1286 |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4510RE Switch       | 1.3.6.1.4.1.9.1.1287 |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4503 Switch         | 1.3.6.1.4.1.9.5.58   |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4503 Switch         | 1.3.6.1.4.1.9.1.503  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4506 Switch         | 1.3.6.1.4.1.9.5.59   |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4506 Switch         | 1.3.6.1.4.1.9.1.502  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4507R Switch        | 1.3.6.1.4.1.9.1.501  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4510R Switch        | 1.3.6.1.4.1.9.1.537  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4506-E Switch       | 1.3.6.1.4.1.9.1.875  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4510R-E Switch      | 1.3.6.1.4.1.9.1.877  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4503-E Switch       | 1.3.6.1.4.1.9.1.874  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4507R-E Switch      | 1.3.6.1.4.1.9.1.876  |
| Switches and Hubs | Cisco Catalyst 4500 Series Switches | Cisco Catalyst 4507R plus E Switch | 1.3.6.1.4.1.9.1.1286 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |   |  |                      |
|-------------------|---|--|----------------------|
| Switches and Hubs | Cisco Catalyst 4500 Series Switches                   | Cisco Catalyst 4510R plus E Switch               | 1.3.6.1.4.1.9.1.1287 |
| Switches and Hubs | Cisco Catalyst 4900 Series Switches                   | Cisco Catalyst 4948 Switch                       | 1.3.6.1.4.1.9.1.626  |
| Switches and Hubs | Cisco Catalyst 4900 Series Switches                   | Cisco Catalyst 4948 10 Gigabit Ethernet Switch   | 1.3.6.1.4.1.9.1.659  |
| Switches and Hubs | Cisco Catalyst 4900 Series Switches                   | Cisco Catalyst 4900M Switch                      | 1.3.6.1.4.1.9.1.917  |
| Switches and Hubs | Cisco Catalyst 4900 Series Switches                   | Cisco Catalyst 4928 10 Gigabit Ethernet Switch   | 1.3.6.1.4.1.9.1.1004 |
| Switches and Hubs | Cisco Catalyst 4900 Series Switches                   | Cisco Catalyst 4948E Ethernet Switch             | 1.3.6.1.4.1.9.1.1178 |
| Switches and Hubs | Cisco Catalyst 4900 Series Switches                   | Cisco Catalyst 4948E-F Switch                    | 1.3.6.1.4.1.9.1.1327 |
| Switches and Hubs | Cisco ME 3600X Series Ethernet Access Switches        | Cisco ME 3600X-24FS-M Switch                     | 1.3.6.1.4.1.9.1.1250 |
| Switches and Hubs | Cisco ME 3600X Series Ethernet Access Switches        | Cisco ME 3600X-24TS-M Switch                     | 1.3.6.1.4.1.9.1.1251 |
| Switches and Hubs | Cisco IE 3010 Series Switches                         | Cisco IE-3010-16S-8PC Industrial Ethernet Switch | 1.3.6.1.4.1.9.1.1319 |
| Switches and Hubs | Cisco IE 3010 Series Switches                         | Cisco IE-3010-24TC Industrial Ethernet Switch    | 1.3.6.1.4.1.9.1.1320 |
| Switches and Hubs | Cisco ME 3800X Series Carrier Ethernet Switch Routers | Cisco ME 3800X-24FS-M Switch Router              | 1.3.6.1.4.1.9.1.1252 |
| Switches and Hubs | Cisco Catalyst 8500 Series Campus Switch Routers      | Cisco Catalyst 8510 CSR Switch                   | 1.3.6.1.4.1.9.1.190  |
| Switches and Hubs | Cisco Catalyst 8500 Series Campus Switch Routers      | Cisco Catalyst 8540 CSR Switch                   | 1.3.6.1.4.1.9.1.203  |
| Switches and Hubs | Cisco ME 2400 Series Ethernet Access Switches         | Cisco ME 2400-24TS-A Switch                      | 1.3.6.1.4.1.9.1.734  |
| Switches and Hubs | Cisco ME 2400 Series Ethernet Access Switches         | Cisco ME 2400-24TS-D Switch                      | 1.3.6.1.4.1.9.1.735  |
| Switches and Hubs | Cisco ME 3400 Series Ethernet Access Switches         | Cisco ME 3400-24TS-A Switch                      | 1.3.6.1.4.1.9.1.736  |
| Switches and Hubs | Cisco ME 3400 Series Ethernet Access Switches         | Cisco ME 3400-24TS-D Switch                      | 1.3.6.1.4.1.9.1.737  |
|                   |   |  | 1.3.6.1.4.1.9.1.780  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |  |                                    |                      |
|-------------------|--|------------------------------------|----------------------|
| Switches and Hubs | Cisco ME 3400 Series Ethernet Access Switches  | Cisco ME 3400G-12CS-A Switch       |                      |
| Switches and Hubs | Cisco ME 3400 Series Ethernet Access Switches  | Cisco ME 3400G-12CS-D Switch       | 1.3.6.1.4.1.9.1.781  |
| Switches and Hubs | Cisco ME 3400 Series Ethernet Access Switches  | Cisco ME 3400G-2CS-A Switch        | 1.3.6.1.4.1.9.1.825  |
| Switches and Hubs | Cisco ME 3400 Series Ethernet Access Switches  | Cisco ME 3400-24FS-A Switch        | 1.3.6.1.4.1.9.1.873  |
| Switches and Hubs | Cisco ME 4900 Series Ethernet Switches         | Cisco ME 4924-10GE Switch          | 1.3.6.1.4.1.9.1.788  |
| Switches and Hubs | Cisco ME 3400E Series Ethernet Access Switches | Cisco ME 3400EG-2CS-A Switch       | 1.3.6.1.4.1.9.1.1007 |
| Switches and Hubs | Cisco ME 3400E Series Ethernet Access Switches | Cisco ME 3400EG-12CS-M Switch      | 1.3.6.1.4.1.9.1.1008 |
| Switches and Hubs | Cisco ME 3400E Series Ethernet Access Switches | Cisco ME 3400E-24TS-M Switch       | 1.3.6.1.4.1.9.1.1009 |
| Switches and Hubs | Cisco ME 6500 Series Ethernet Switches         | Cisco ME 6524GS-8S Ethernet Switch | 1.3.6.1.4.1.9.1.719  |
| Switches and Hubs | Cisco ME 6500 Series Ethernet Switches         | Cisco ME 6524TS-8S Ethernet Switch | 1.3.6.1.4.1.9.1.720  |
| Switches and Hubs | Cisco Pro Series                               | Cisco Pro 761                      | 1.3.6.1.4.1.9.1.88   |
| Switches and Hubs | Cisco Pro Series                               | Cisco Pro 762                      | 1.3.6.1.4.1.9.1.89   |
| Switches and Hubs | Cisco Pro Series                               | Cisco Pro 771                      | 1.3.6.1.4.1.9.1.143  |
| Switches and Hubs | Cisco Pro Series                               | Cisco Pro 772                      | 1.3.6.1.4.1.9.1.144  |
| Switches and Hubs | Cisco Pro Series                               | Cisco Pro 775                      | 1.3.6.1.4.1.9.1.145  |
| Switches and Hubs | Cisco Pro Series                               | Cisco Pro 765                      | 1.3.6.1.4.1.9.1.92   |
| Switches and Hubs | Cisco Pro Series                               | Cisco Pro 766                      | 1.3.6.1.4.1.9.1.93   |
| Switches and Hubs | Cisco Pro Series                               | Cisco Pro 1003                     | 1.3.6.1.4.1.9.1.51   |
|                   | Cisco Pro Series                               | Cisco Pro 1004                     | 1.3.6.1.4.1.9.1.52   |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                  |                   |                     |
|-------------------|------------------|-------------------|---------------------|
| Switches and Hubs |                  |                   |                     |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 1005    | 1.3.6.1.4.1.9.1.53  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 1601    | 1.3.6.1.4.1.9.1.117 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 1602    | 1.3.6.1.4.1.9.1.118 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 1603    | 1.3.6.1.4.1.9.1.119 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 1604    | 1.3.6.1.4.1.9.1.120 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2500PCE | 1.3.6.1.4.1.9.1.55  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2501    | 1.3.6.1.4.1.9.1.56  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2502    | 1.3.6.1.4.1.9.1.130 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2503    | 1.3.6.1.4.1.9.1.57  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2504    | 1.3.6.1.4.1.9.1.131 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2505    | 1.3.6.1.4.1.9.1.58  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2506    | 1.3.6.1.4.1.9.1.132 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2507    | 1.3.6.1.4.1.9.1.59  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2508    | 1.3.6.1.4.1.9.1.133 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2509    | 1.3.6.1.4.1.9.1.60  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2510    | 1.3.6.1.4.1.9.1.134 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2511    | 1.3.6.1.4.1.9.1.61  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2512    | 1.3.6.1.4.1.9.1.135 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2513    | 1.3.6.1.4.1.9.1.136 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2514    | 1.3.6.1.4.1.9.1.62  |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2515    | 1.3.6.1.4.1.9.1.137 |
| Switches and Hubs | Cisco Pro Series | Cisco Pro 2516    | 1.3.6.1.4.1.9.1.63  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                      |  |                            |
|-------------------|----------------------|--|----------------------------|
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2517                               | 1.3.6.1.4.1.9.1.138        |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2518                               | 1.3.6.1.4.1.9.1.139        |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2519                               | 1.3.6.1.4.1.9.1.64         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2521                               | 1.3.6.1.4.1.9.1.65         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2520                               | 1.3.6.1.4.1.9.1.104        |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2522                               | 1.3.6.1.4.1.9.1.105        |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2523                               | 1.3.6.1.4.1.9.1.140        |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2524                               | 1.3.6.1.4.1.9.1.106        |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 2525                               | 1.3.6.1.4.1.9.1.141        |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 4500                               | 1.3.6.1.4.1.9.1.66         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 4700                               | 1.3.6.1.4.1.9.1.142        |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 751                                | 1.3.6.1.4.1.9.1.76         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 752                                | 1.3.6.1.4.1.9.1.77         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 753                                | 1.3.6.1.4.1.9.1.78         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro Workgroup Switch 1420              | 1.3.6.1.4.1.9.5.21         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro Workgroup Switch 1601              | 1.3.6.1.4.1.9.5.25         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro Workgroup Switch 1800              | 1.3.6.1.4.1.9.5.24         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro Workgroup Switch 2200              | 1.3.6.1.4.1.9.5.13         |
| Switches and Hubs | Cisco Pro Series     | Cisco Pro 3116                               | 1.3.6.1.4.1.9.1.149        |
| Switches and Hubs | Unified Computing    | Cisco UCS 6140XP 40-Port Fabric Interconnect | 1.3.6.1.4.1.9.12.3.1.3.899 |
| Switches and Hubs | Unified Computing    | Cisco UCS 6120XP 20-Port Fabric Interconnect | 1.3.6.1.4.1.9.12.3.1.3.847 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 7000 9-Slot Switch               | 1.3.6.1.4.1.9.12.3.1.3.932 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                      |   |                             |
|-------------------|----------------------|---|-----------------------------|
| Switches and Hubs | Data Center Switches | Cisco Nexus 3048 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.1106 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 3064 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.1060 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 3064 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.1105 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 5010 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.798  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 5020 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.719  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 5020 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.720  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 5020T Switch                            | 1.3.6.1.4.1.9.12.3.1.3.936  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 5548 O2 32X10GE                         | 1.3.6.1.4.1.9.12.3.1.3.1084 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 7000 10-Slot Switch                     | 1.3.6.1.4.1.9.12.3.1.3.612  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 7000 18-Slot Switch                     | 1.3.6.1.4.1.9.12.3.1.3.777  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 1000V Series Switches                   | 1.3.6.1.4.1.9.12.3.1.3.840  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 1010 Virtual Services Appliance         | 1.3.6.1.4.1.9.12.3.1.3.907  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 4001I Switch Module for IBM BladeCenter | 1.3.6.1.4.1.9.12.3.1.3.903  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 4005I Switch Module for IBM BladeCenter | 1.3.6.1.4.1.9.12.3.1.3.930  |
| Switches and Hubs | Data Center Switches | Cisco Nexus 5548P Switch                            | 1.3.6.1.4.1.9.12.3.1.3.1008 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 5548UP Switch                           | 1.3.6.1.4.1.9.12.3.1.3.1084 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 5596UP Switch                           | 1.3.6.1.4.1.9.12.3.1.3.1038 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 3064 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.1060 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 3064 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.1105 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 3048 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.1106 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 3016 Switch                             | 1.3.6.1.4.1.9.12.3.1.3.1107 |
| Switches and Hubs | Data Center Switches | Cisco Nexus 7000 9-Slot Switch                      | 1.3.6.1.4.1.9.12.3.1.3.932  |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                   |                               |  |                                  |
|-------------------|-------------------------------|--|----------------------------------|
| Switches and Hubs | Cisco FastHub 100 Series Hubs | FastHub 116T   | 1.3.6.1.4.1.9.1.150              |
| Switches and Hubs | Cisco FastHub 100 Series Hubs | FastHub 116C   | 1.3.6.1.4.1.9.1.151              |
| Switches and Hubs | Cisco FastHub 100 Series Hubs | FastHub 100  | 1.3.6.1.4.1.9.1.226              |
| Switches and Hubs | Cisco FastHub 200 Series Hubs | FastHub 216T   | 1.3.6.1.4.1.9.1.169              |
| Switches and Hubs | Cisco FastHub 300 Series Hubs | FastHub 316C   | 1.3.6.1.4.1.9.1.148              |
| Switches and Hubs | Cisco FastHub 300 Series Hubs | FastHub 316T   | 1.3.6.1.4.1.9.1.147              |
| Switches and Hubs | Cisco FastHub Series Hubs     | FastHubBMMTX   | 1.3.6.1.4.1.9.1.177              |
| Switches and Hubs | Cisco FastHub Series Hubs     | FastHubBMMFX   | 1.3.6.1.4.1.9.1.178              |
| Switches and Hubs | Other Switches and Hubs       | Adapter Card   | 1.3.6.1.4.1.9.5.2                |
| Switches and Hubs | Other Switches and Hubs       | Catalyst WSC2900   | 1.3.6.1.4.1.9.5.12               |
| Switches and Hubs | Other Switches and Hubs       | Catalyst WSC3001   | 1.3.6.1.4.1.9.5.26               |
| Switches and Hubs | Other Switches and Hubs       | Cisco IGXSes   | 1.3.6.1.4.1.9.1.243              |
| Switches and Hubs | Other Switches and Hubs       | CPW1220i   | 1.3.6.1.4.1.9.5.30               |
| Switches and Hubs | Other Switches and Hubs       | DCD  | 1.3.6.1.4.1.9.5.22               |
| Switches and Hubs | Other Switches and Hubs       | ESStack  | 1.3.6.1.4.1.9.5.14               |
| Switches and Hubs | Other Switches and Hubs       | TSSStack   | 1.3.6.1.4.1.9.5.32               |
| Switches and Hubs | Other Switches and Hubs       | WSC1900 Lite Fx  | 1.3.6.1.4.1.9.5.175              |
| Switches and Hubs | Other Switches and Hubs       | Cisco FastHub 1116   | 1.3.6.1.4.1.9.1.152              |
| Switches and Hubs | Other Switches and Hubs       | Cisco Intelligent Gigabit Ethernet Switch Module for IBM eServer BladeCenter | 1.3.6.1.4.1.9.1.592              |
| Switches and Hubs | Other Switches and Hubs       | Cisco Intelligent Gigabit Ethernet Switch Module for IBM eServer BladeCenter | 1.3.6.1.4.1.9.1.660              |
| Switches and Hubs | Other Switches and Hubs       | Cisco Gigabit Ethernet Switch Module   | 1.3.6.1.4.1.11.2.3.7.11.33.3.1.1 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                            |  |  |                      |
|----------------------------|--|--|----------------------|
| Switches and Hubs          | Cisco Catalyst 3850 Series Ethernet Stackable Switch | Cisco Catalyst 3850 48P 10/100/1000 PoE+ Ports Layer 2/Layer 3 Ethernet Stackable Switch | 1.3.6.1.4.1.9.1.1641 |
| Switches and Hubs          | Cisco Catalyst 3850 Series Ethernet Stackable Switch | Cisco Catalyst 3850 24P 10/100/1000 PoE+ Ports Layer 2/Layer 3 Ethernet Stackable Switch | 1.3.6.1.4.1.9.1.1642 |
| Switches and Hubs          | Cisco Catalyst 3850 Series Ethernet Stackable Switch | Cisco Catalyst 3850 48 10/100/1000 PoE+ Ports Layer 2/Layer 3 Ethernet Stackable Switch  | 1.3.6.1.4.1.9.1.1643 |
| Switches and Hubs          | Cisco Catalyst 3850 Series Ethernet Stackable Switch | Cisco Catalyst 3850 24 10/100/1000 PoE+ Ports Layer 2/Layer 3 Ethernet Stackable Switch  | 1.3.6.1.4.1.9.1.1644 |
| Video and Content Delivery | Cisco RF Gateway Series                              | Cisco RF Gateway 10  | 1.3.6.1.4.1.9.1.931  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7120 Router  | 1.3.6.1.4.1.9.1.259  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7120 Router  | 1.3.6.1.4.1.9.1.260  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7120 Router  | 1.3.6.1.4.1.9.1.261  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7120 Router  | 1.3.6.1.4.1.9.1.262  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7120 Router  | 1.3.6.1.4.1.9.1.263  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7120 Router  | 1.3.6.1.4.1.9.1.264  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7140 Router  | 1.3.6.1.4.1.9.1.265  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7140 Router  | 1.3.6.1.4.1.9.1.266  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7140 Router  | 1.3.6.1.4.1.9.1.267  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7140 Router  | 1.3.6.1.4.1.9.1.268  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7140 Router  | 1.3.6.1.4.1.9.1.269  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7140 Router  | 1.3.6.1.4.1.9.1.276  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7140 Router  | 1.3.6.1.4.1.9.1.277  |
| Security and VPN           | Cisco 7100 Series VPN Routers                        | Cisco 7160 VPN Router  | 1.3.6.1.4.1.9.1.358  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                  |                                     |  |                              |
|------------------|-------------------------------------|--|------------------------------|
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 506 Firewall                   | 1.3.6.1.4.1.9.1.389          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 515 Firewall                   | 1.3.6.1.4.1.9.1.390          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 515 Firewall Security Context  | 1.3.6.1.4.1.9.1.678          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 520 Firewall                   | 1.3.6.1.4.1.9.1.391          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 525 Firewall                   | 1.3.6.1.4.1.9.1.392          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 525 Firewall Security Context  | 1.3.6.1.4.1.9.1.676          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 535 Firewall                   | 1.3.6.1.4.1.9.1.393          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 535 Firewall Security Context  | 1.3.6.1.4.1.9.1.675          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 501 Firewall                   | 1.3.6.1.4.1.9.1.417          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 515E Firewall                  | 1.3.6.1.4.1.9.1.451          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 515E Firewall Security Context | 1.3.6.1.4.1.9.1.677          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | Cisco PIX 506E Firewall                  | 1.3.6.1.4.1.9.1.450          |
| Security and VPN | Cisco PIX 500 Series Firewalls      | PIX Firewall                             | 1.3.6.1.4.1.9.1.227          |
| Security and VPN | Cisco VPN 5000 Series Concentrators | VPN 500x Concentrator                    | 1.3.6.1.4.1.255.1.1          |
| Security and VPN | Cisco VPN 3000 Series Concentrators | Cisco VPN 30xx Concentrator              | 1.3.6.1.4.1.3076.1.2.1.1.1.1 |
| Security and VPN | Cisco VPN 3000 Series Concentrators | Cisco VPN 30xx Concentrator              | 1.3.6.1.4.1.3076.1.2.1.1.1.2 |
| Security and VPN | Cisco VPN 3000 Series Concentrators | Cisco VPN 30xx Concentrator              | 1.3.6.1.4.1.3076.1.2.1.1.2.1 |
| Security and VPN | Cisco VPN 3000 Series Concentrators | Cisco VPN 30xx Concentrator              | 1.3.6.1.4.1.3076.1.2.1.1.3.1 |
| Security and VPN | Cisco IPS 4200 Series Sensors       | Cisco IDS 4210 Sensor                    | 1.3.6.1.4.1.9.1.645          |
| Security and VPN | Cisco IPS 4200 Series Sensors       | Cisco IDS 4215 Sensor                    | 1.3.6.1.4.1.9.1.646          |
|                  |                                     | Cisco IDS 4220 Sensor                    | 1.3.6.1.4.1.9.1.741          |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                  |  |   |                      |
|------------------|--|---|----------------------|
| Security and VPN | Cisco IPS 4200 Series Sensors                      |   |                      |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IDS 4230 Sensor                                     | 1.3.6.1.4.1.9.1.742  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IDS 4235 Sensor                                     | 1.3.6.1.4.1.9.1.647  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4240 Sensor                                     | 1.3.6.1.4.1.9.1.648  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IDS 4250 Sensor                                     | 1.3.6.1.4.1.9.1.649  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IDS 4250 XL Sensor                                  | 1.3.6.1.4.1.9.1.651  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4255 Sensor                                     | 1.3.6.1.4.1.9.1.652  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4260 Sensor                                     | 1.3.6.1.4.1.9.1.743  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IDS 4215 Virtual Sensor                             | 1.3.6.1.4.1.9.1.807  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IDS 4235 Virtual Sensor                             | 1.3.6.1.4.1.9.1.808  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4240 Virtual Sensor                             | 1.3.6.1.4.1.9.1.812  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IDS 4250 Virtual Sensor                             | 1.3.6.1.4.1.9.1.809  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4250 SX Virtual Sensor                          | 1.3.6.1.4.1.9.1.810  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IDS 4250 XL Virtual Sensor                          | 1.3.6.1.4.1.9.1.811  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4255 Virtual Sensor                             | 1.3.6.1.4.1.9.1.813  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4260 Virtual Sensor                             | 1.3.6.1.4.1.9.1.814  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4270 Sensor                                     | 1.3.6.1.4.1.9.1.830  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4270 Virtual Sensor                             | 1.3.6.1.4.1.9.1.831  |
| Security and VPN | Cisco IPS 4200 Series Sensors                      | Cisco IPS 4250 SX Sensor                                  | 1.3.6.1.4.1.9.1.650  |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance System Context | 1.3.6.1.4.1.9.1.1202 |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance System Context | 1.3.6.1.4.1.9.1.1203 |
| Security and VPN | Cisco ASA-5500 Series Adaptive                     | Cisco ASA-5585 Adaptive Security Appliance                | 1.3.6.1.4.1.9.1.1204 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                  | Security Appliances                                | System Context  |                            |
|------------------|--|---|----------------------------|
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance System Context   | 1.3.6.1.4.1.9.1.1205       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.1198       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.1199       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.1200       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.1201       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.1194       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.1195       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.1196       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.1197       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5510 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.669        |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5510 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.12.3.1.3.447 |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5510 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.773        |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5520 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.670        |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5520 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.12.3.1.3.448 |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5520 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.671        |
| Security and     | Cisco ASA-5500                                     | Cisco ASA-5540 Adaptive                                     | 1.3.6.1.4.1.9.1.672        |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

| VPN              | Series Adaptive Security Appliances                | Security Appliance  |                            |
|------------------|--|---|----------------------------|
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5540 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.12.3.1.3.449 |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5540 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.673        |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5560 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.12.3.1.3.454 |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5550 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.753        |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5550 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.763        |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5505 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.745        |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5505 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.12.3.1.3.560 |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5580 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.914        |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.1194       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.1195       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.1196       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance                  | 1.3.6.1.4.1.9.1.1197       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.1198       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.1199       |
| Security and VPN | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.1200       |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                    |  |   |                      |
|--------------------|--|---|----------------------|
| Security and VPN   | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.1201 |
| Security and VPN   | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance System Context   | 1.3.6.1.4.1.9.1.1202 |
| Security and VPN   | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance System Context   | 1.3.6.1.4.1.9.1.1203 |
| Security and VPN   | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance System Context   | 1.3.6.1.4.1.9.1.1204 |
| Security and VPN   | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5585 Adaptive Security Appliance System Context   | 1.3.6.1.4.1.9.1.1205 |
| Security and VPN   | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5580 Adaptive Security Appliance Security Context | 1.3.6.1.4.1.9.1.915  |
| Security and VPN   | Cisco ASA-5500 Series Adaptive Security Appliances | Cisco ASA-5580 Adaptive Security Appliance System Context   | 1.3.6.1.4.1.9.1.916  |
| Security and VPN   | IDS Management                                     | Cisco Threat Response                                       |                      |
| Network Management | Other Network Management Products                  | Cisco Cluster Management Suite                              |                      |
| Network Management | Other Network Management Products                  | Cisco CNS Configuration Engine                              |                      |
| Network Management | Other Network Management Products                  | CiscoWorks Auto Update Server                               |                      |
| Network Management | CiscoWorks Wireless LAN Solution Engine            | CiscoWorks 1105 for Wireless LAN Solution Engine            | 1.3.6.1.4.1.9.1.459  |
| Network Management | CiscoWorks Wireless LAN Solution Engine            | CiscoWorks 1130 for Wireless LAN Solution Engine            | 1.3.6.1.4.1.9.1.630  |
| Network Management | CiscoWorks Wireless LAN Solution Engine            | CiscoWorks 1030 for Wireless LAN Solution Engine            | 1.3.6.1.4.1.9.1.631  |
| Network Management | CiscoWorks Wireless LAN Solution Engine            | CiscoWorks 1132 for Wireless LAN Solution Engine            | 1.3.6.1.4.1.9.1.712  |
| Network Management | CiscoWorks Wireless LAN Solution Engine            | CiscoWorks 1133 for Wireless LAN Solution Engine            | 1.3.6.1.4.1.9.1.752  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                    |  |  |                          |
|--------------------|--|--|--------------------------|
| Network Management | CiscoWorks Wireless LAN Solution Engine          | Cisco Wireless LAN Solution Engine S20                     | 1.3.6.1.4.1.9.1.709      |
| Network Management | Cisco SwitchProbes                               | Cisco SwitchProbe  | 1.3.6.1.4.1.141.1.1.7500 |
| Network Management | Cisco SwitchProbes                               | Cisco SwitchProbe  | 1.3.6.1.4.1.141.1.1.7211 |
| Network Management | Cisco SwitchProbes                               | Cisco SwitchProbe  | 1.3.6.1.4.1.141.1.1.7221 |
| Network Management | Cisco SwitchProbes                               | Cisco SwitchProbe  | 1.3.6.1.4.1.141.1.1.8400 |
| Network Management | Cisco SwitchProbes                               | Cisco SwitchProbe  | 1.3.6.1.4.1.141.1.1.7302 |
| Network Management | CiscoWorks Hosting Solution Engine               | Cisco 1105 for Hosting Solution Engine                     | 1.3.6.1.4.1.9.1.405      |
| Network Management | CiscoWorks                                       | CiscoWorks Monitoring Center for Security                  |                          |
| Network Management | CiscoWorks                                       | CiscoWorks Management Center for Cisco Security Agents     |                          |
| Network Management | CiscoWorks                                       | CiscoWorks Management Center for Cisco Security Agents 4.0 |                          |
| Broadband Cable    | Cisco CVA120 Series Cable Voice Adapters         | Cisco CVA122E Cable Voice Adapter                          | 1.3.6.1.4.1.9.1.371      |
| Broadband Cable    | Cisco uBR7200 Series Universal Broadband Routers | Cisco uBR7223 Universal Broadband Router                   | 1.3.6.1.4.1.9.1.210      |
| Broadband Cable    | Cisco uBR7200 Series Universal Broadband Routers | Cisco uBR7246 Universal Broadband Router                   | 1.3.6.1.4.1.9.1.179      |
| Broadband Cable    | Cisco uBR7200 Series Universal Broadband Routers | Cisco uBR7246VXR Universal Broadband Router                | 1.3.6.1.4.1.9.1.271      |
| Broadband Cable    | Cisco uBR7225VXR Universal Broadband Routers     | Cisco uBR7225VXR Universal Broadband Router                | 1.3.6.1.4.1.9.1.827      |
| Broadband Cable    | Cisco uBR900 Series Cable Access Routers         | Cisco uBR904 Cable Access Router                           | 1.3.6.1.4.1.9.1.191      |
| Broadband Cable    | Cisco uBR900 Series Cable Access Routers         | Cisco uBR905 Cable Access Router                           | 1.3.6.1.4.1.9.1.351      |
|                    |  |  | 1.3.6.1.4.1.9.1.294      |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                    |  |   |                            |
|--------------------|--|---|----------------------------|
| Broadband Cable    | Cisco uBR900 Series Cable Access Routers         | Cisco uBR914 Cable Data Service Unit      |                            |
| Broadband Cable    | Cisco uBR900 Series Cable Access Routers         | Cisco uBR924 Cable Access Router          | 1.3.6.1.4.1.9.1.255        |
| Broadband Cable    | Cisco uBR900 Series Cable Access Routers         | Cisco uBR925 Cable Access Router          | 1.3.6.1.4.1.9.1.316        |
| Broadband Cable    | Cisco uBR7100 Series Universal Broadband Routers | Cisco uBR7100 Universal Broadband Router  | 1.3.6.1.4.1.9.1.309        |
| Broadband Cable    | Cisco uBR7100 Series Universal Broadband Routers | Cisco uBR7114 Universal Broadband Router  | 1.3.6.1.4.1.9.1.346        |
| Broadband Cable    | Cisco uBR7100 Series Universal Broadband Routers | Cisco uBR7114E Universal Broadband Router | 1.3.6.1.4.1.9.1.347        |
| Broadband Cable    | Cisco uBR7100 Series Universal Broadband Routers | Cisco uBR7111 Universal Broadband Router  | 1.3.6.1.4.1.9.1.344        |
| Broadband Cable    | Cisco uBR7100 Series Universal Broadband Routers | Cisco uBR7111E Universal Broadband Router | 1.3.6.1.4.1.9.1.345        |
| Broadband Cable    | Cable Modem Termination Systems (CMTS)           | Cisco uBR10012 Universal Broadband Router | 1.3.6.1.4.1.9.1.317        |
| Storage Networking | Cisco SN 5400 Series Storage Routers             | Cisco SN 5428 Storage Router              | 1.3.6.1.4.1.9.1.475        |
| Storage Networking | Cisco SN 5400 Series Storage Routers             | Cisco SN 5420 Storage Router              | 1.3.6.1.4.1.9.1.407        |
| Storage Networking | Cisco MDS 9000 Series Multilayer Switches        | Cisco MDS 9506 Multilayer Director Switch | 1.3.6.1.4.1.9.12.3.1.3.375 |
| Storage Networking | Cisco MDS 9000 Series Multilayer Switches        | Cisco MDS 9509 Multilayer Director Switch | 1.3.6.1.4.1.9.12.3.1.3.376 |
| Storage Networking | Cisco MDS 9000 Series Multilayer Switches        | Cisco MDS 9513 Multilayer Director Switch | 1.3.6.1.4.1.9.12.3.1.3.377 |
| Storage Networking | Cisco MDS 9000 Series Multilayer Switches        | Cisco MDS 9216 Multilayer Fabric Switch   | 1.3.6.1.4.1.9.1.521        |
| Storage Networking | Cisco MDS 9000 Series Multilayer Switches        | Cisco MDS 9216 Multilayer Fabric Switch   | 1.3.6.1.4.1.9.12.3.1.3.380 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                     |   |  |                            |
|---------------------|---|--|----------------------------|
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9216A Multilayer Fabric Switch                             | 1.3.6.1.4.1.9.12.3.1.3.442 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9132 Multilayer Fabric Switch                              | 1.3.6.1.4.1.9.12.3.1.3.462 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9116 Multilayer Fabric Switch                              | 1.3.6.1.4.1.9.12.3.1.3.463 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9216i Multilayer Fabric Switch                             | 1.3.6.1.4.1.9.12.3.1.3.472 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9120 Multilayer Fabric Switch                              | 1.3.6.1.4.1.9.12.3.1.3.414 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9140 Multilayer Fabric Switch                              | 1.3.6.1.4.1.9.12.3.1.3.411 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9124 Multilayer Fabric Switch                              | 1.3.6.1.4.1.9.12.3.1.3.587 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9124e Multilayer Fabric Switch                             | 1.3.6.1.4.1.9.12.3.1.3.606 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9222i Multiservice Modular Switch                          | 1.3.6.1.4.1.9.12.3.1.3.651 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9134 Multilayer Fabric Switch                              | 1.3.6.1.4.1.9.12.3.1.3.616 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS IBM Blade Switch   | 1.3.6.1.4.1.9.12.3.1.3.601 |
| Storage Networking  | Cisco MDS 9000 Series Multilayer Switches   | Cisco MDS 9148 Multilayer Fabric Switch                              | 1.3.6.1.4.1.9.12.3.1.3.841 |
| Voice and Telephony | Virtual Machine                             | VMware Virtual Machine for Cisco Unified Communications Applications | 1.3.6.1.4.1.9.1.1348       |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers | Cisco 7815I Media Convergence Server                                 | 1.3.6.1.4.1.9.1.582        |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers | Cisco 7825H Media Convergence Server                                 | 1.3.6.1.4.1.9.1.583        |
| Voice and Telephony | Cisco 7800 Series Media Convergence         | Cisco 7825I Media Convergence Server                                 | 1.3.6.1.4.1.9.1.746        |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                     | Servers  |   |                     |
|---------------------|--|---|---------------------|
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco 7835H Media Convergence Server  | 1.3.6.1.4.1.9.1.584 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco 7835I Media Convergence Server  | 1.3.6.1.4.1.9.1.585 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco 7845H Media Convergence Server  | 1.3.6.1.4.1.9.1.586 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco 7845I Media Convergence Server  | 1.3.6.1.4.1.9.1.587 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco 7855I Media Convergence Server  | 1.3.6.1.4.1.9.1.588 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco 7865I Media Convergence Server  | 1.3.6.1.4.1.9.1.589 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco MCS 7828-I3 Unified Communications Manager Business Edition Appliance | 1.3.6.1.4.1.9.1.899 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco MCS 7816-I3   | 1.3.6.1.4.1.9.1.898 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco MCS 7816-H3   | 1.3.6.1.4.1.9.1.900 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco MCS 7828-H3 Unified Communications Manager Business Edition Appliance | 1.3.6.1.4.1.9.1.901 |
| Voice and Telephony | Cisco 7800 Series Media Convergence Servers    | Cisco 78xx Media Convergence Server   |                     |
| Voice and Telephony | Conferencing                                   | Cisco Unified MeetingPlace  | 1.3.6.1.4.1.9.9.733 |
| Voice and Telephony | Cisco IAD2400 Series Integrated Access Devices | Cisco IAD2420 Integrated Access Device                                      | 1.3.6.1.4.1.9.1.362 |
| Voice and Telephony | Cisco IAD2400 Series Integrated Access Devices | Cisco IAD2431 Series Integrated Access Device                               | 1.3.6.1.4.1.9.1.546 |
| Voice and Telephony | Cisco IAD2400 Series Integrated Access Devices | Cisco IAD2431 Series Integrated Access Device                               | 1.3.6.1.4.1.9.1.547 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                     |  |   |                     |
|---------------------|--|---|---------------------|
| Voice and Telephony | Cisco IAD2400 Series Integrated Access Devices | Cisco IAD2431 Series Integrated Access Device | 1.3.6.1.4.1.9.1.548 |
| Voice and Telephony | Cisco IAD2400 Series Integrated Access Devices | Cisco IAD2431 Series Integrated Access Device | 1.3.6.1.4.1.9.1.549 |
| Voice and Telephony | Cisco IAD2400 Series Integrated Access Devices | Cisco IAD2430 Integrated Access Device        | 1.3.6.1.4.1.9.1.54  |
| Voice and Telephony | Cisco IAD2400 Series Integrated Access Devices | Cisco IAD2430 Integrated Access Device        | 1.3.6.1.4.1.9.1.545 |
| Voice and Telephony | Cisco IAD2400 Series Integrated Access Devices | Cisco IAD2435 Integrated Access Device        | 1.3.6.1.4.1.9.1.962 |
| Voice and Telephony | Cisco IAD880 Series Integrated Access Devices  | Cisco IAD881,IAD881W Integrated Access Device | 1.3.6.1.4.1.9.1.839 |
| Voice and Telephony | Cisco IAD880 Series Integrated Access Devices  | Cisco IAD881,IAD881W Integrated Access Device | 1.3.6.1.4.1.9.1.841 |
| Voice and Telephony | Cisco IAD880 Series Integrated Access Devices  | Cisco IAD886,IAD886W Integrated Access Device | 1.3.6.1.4.1.9.1.844 |
| Voice and Telephony | Cisco IAD880 Series Integrated Access Devices  | Cisco IAD886,IAD886W Integrated Access Device | 1.3.6.1.4.1.9.1.845 |
| Voice and Telephony | Cisco IAD880 Series Integrated Access Devices  | Cisco IAD887,IAD887W Integrated Access Device | 1.3.6.1.4.1.9.1.849 |
| Voice and Telephony | Cisco IAD880 Series Integrated Access Devices  | Cisco IAD887,IAD887W Integrated Access Device | 1.3.6.1.4.1.9.1.850 |
| Voice and Telephony | Cisco IAD880 Series Integrated Access Devices  | Cisco IAD888,IAD888W Integrated Access Device | 1.3.6.1.4.1.9.1.854 |
| Voice and Telephony | Cisco IAD880 Series Integrated Access Devices  | Cisco IAD888,IAD888W Integrated Access Device | 1.3.6.1.4.1.9.1.855 |
| Voice and Telephony | Cisco DPA 7600 Series Gateways                 | Cisco DPA 7630 Voice Mail Gateway             | 1.3.6.1.4.1.9.1.365 |
| Voice and Telephony | Cisco DPA 7600 Series Gateways                 | Cisco DPA 7610 Voice Mail Gateway             | 1.3.6.1.4.1.9.1.381 |
| Voice and Telephony | Cisco VG200 Series Gateways                    | Cisco VG248 48-Port Analog Phone Gateway      | 1.3.6.1.4.1.9.1.404 |
| Voice and Telephony | Cisco VG200 Series Gateways                    | Cisco VG224 Voice Gateway                     | 1.3.6.1.4.1.9.1.558 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                     |  |  |                           |
|---------------------|--|--|---------------------------|
| Voice and Telephony | Cisco VG200 Series Gateways                            | Cisco VG200 Voice Gateway                                  | 1.3.6.1.4.1.9.1.279       |
| Voice and Telephony | Cisco VG200 Series Gateways                            | Cisco VG202 Analog Voice Gateway                           | 1.3.6.1.4.1.9.1.964       |
| Voice and Telephony | Cisco VG200 Series Gateways                            | Cisco VG204 Analog Voice Gateway                           | 1.3.6.1.4.1.9.1.963       |
| Voice and Telephony | Cisco VG300 Series Gateways                            | Cisco VG350 Analog Voice Gateway                           | 1.3.6.1.4.1.9.1.1557      |
| Voice and Telephony | Cisco ICS 7700 Series Integrated Communication Systems | Cisco ICS 7750 Integrated Communication System             | 1.3.6.1.4.1.9.1.302       |
| Voice and Telephony | Cisco ICS 7700 Series Integrated Communication Systems | Cisco ICS 7750 Integrated Communication System             | 1.3.6.1.4.1.9.1.303       |
| Voice and Telephony | Cisco ICS 7700 Series Integrated Communication Systems | Cisco ICS 7750 Integrated Communication System             | 1.3.6.1.4.1.9.1.314       |
| Voice and Telephony | Cisco ICS 7700 Series Integrated Communication Systems | Cisco ICS 7750 Integrated Communication System             | 1.3.6.1.4.1.9.1.456       |
| Voice and Telephony | Call Control   | Cisco CallManager  | 1.3.6.1.4.1.311.1.1.3.1.1 |
| Voice and Telephony | Call Control   | Cisco CallManager  | 1.3.6.1.4.1.311.1.1.3.1.2 |
| Voice and Telephony | Call Control   | Cisco CallManager  | 1.3.6.1.4.1.311.1.1.3.1.3 |
| Voice and Telephony | Call Control   | Cisco CallManager  | 1.3.6.1.4.1.99.1.1.3.28   |
| Voice and Telephony | Call Control   | Cisco CallManager  | 1.3.6.1.4.1.9.1.1348      |
| Voice and Telephony | Call Control   | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.878       |
| Voice and Telephony | Call Control   | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.879       |
| Voice and Telephony | Call Control   | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.880       |
| Voice and Telephony | Call Control   | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.881       |
|                     | Call Control   |  | 1.3.6.1.4.1.9.1.882       |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                        |   |  |                     |
|------------------------|---|--|---------------------|
| Voice and Telephony    |   | Cisco Unified Communications 500 Series for Small Business |                     |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.883 |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.884 |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.885 |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.886 |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.888 |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.890 |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.892 |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.894 |
| Voice and Telephony    | Call Control                                      | Cisco Unified Communications 500 Series for Small Business | 1.3.6.1.4.1.9.1.895 |
| Voice and Telephony    | Customer Contact                                  |  |                     |
| Voice and Telephony    | Voice Applications                                | MeetingPlace Express                                       | 1.3.6.1.4.1.9.1.710 |
| Server Fabric Switches | Cisco SFS 3000 Series Multifabric Server Switches | Cisco SFS 3012 Multifabric Server Switch                   | 1.3.6.1.4.1.6203.3  |
| Server Fabric Switches | Cisco SFS 3000 Series Multifabric Server Switches | Cisco SFS 3012 Multifabric Server Switch                   | 1.3.6.1.4.1.6203.20 |
| Server Fabric Switches | Cisco SFS 3000 Series Multifabric Server Switches | Cisco SFS 3504 Multifabric Server Switch                   | 1.3.6.1.4.1.6203.16 |
| Server Fabric Switches | Cisco SFS 7000 Series InfiniBand Server Switches  | Cisco SFS 7008 InfiniBand Server Switch                    | 1.3.6.1.4.1.6203.18 |
| Server Fabric          | Cisco SFS 7000                                    | Cisco SFS 7000   | 1.3.6.1.4.1.6203.17 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

| Switches               | Series InfiniBand Server Switches                | InfiniBand Server Switch                 |                      |
|------------------------|--|--|----------------------|
| Server Fabric Switches | Cisco SFS 7000 Series InfiniBand Server Switches | Cisco SFS 7000D InfiniBand Server Switch | 1.3.6.1.4.1.6203.19  |
| Server Fabric Switches | IBM BladeCenter InfiniBand Switch                | Cisco BladeCenterH                       | 1.3.6.1.4.1.6203.15  |
| Autonomous AP          | Cisco Aironet 3500 Series                        | Cisco Aironet 3500 Access Point          | 1.3.6.1.4.1.9.1.1124 |
| Autonomous AP          | Cisco Aironet 3500 Series                        | Cisco Aironet 3500 Access Point          | 1.3.6.1.4.1.9.1.1125 |
| Autonomous AP          | Cisco Aironet 340 Series                         | Cisco Aironet 340 Access Points          | 1.3.6.1.4.1.9.1.379  |
| Autonomous AP          | Cisco Aironet 350 Series                         | Cisco Aironet 350 Access Points          | 1.3.6.1.4.1.9.1.380  |
| Autonomous AP          | Cisco Aironet 350 Series                         | Cisco Aironet 350 Access Points          | 1.3.6.1.4.1.9.1.552  |
| Autonomous AP          | Cisco 800 Series Access Points                   | Cisco AP801agn Access Point              | 1.3.6.1.4.1.9.1.988  |
| Autonomous AP          | Cisco 800 Series Access Points                   | Cisco AP801gn Access Point               | 1.3.6.1.4.1.9.1.989  |
| Autonomous AP          | Cisco Aironet 1100 Series                        | Cisco Aironet 1100 Series Access Point   | 1.3.6.1.4.1.9.1.507  |
| Autonomous AP          | Cisco Aironet 1100 Series                        | Cisco Aironet 1130 Series Access Point   | 1.3.6.1.4.1.9.1.618  |
| Autonomous AP          | Cisco Aironet 1140 Series                        | Cisco Aironet 1140 Access Point          | 1.3.6.1.4.1.9.1.1034 |
| Autonomous AP          | Cisco Aironet 1140 Series                        | Cisco Aironet 1140 Access Point          | 1.3.6.1.4.1.9.1.1035 |
| Autonomous AP          | Cisco Aironet 1200 Series                        | Cisco Aironet 1200 Access Point          | 1.3.6.1.4.1.9.1.474  |
| Autonomous AP          | Cisco Aironet 1200 Series                        | Cisco Aironet 1210 Access Point          | 1.3.6.1.4.1.9.1.525  |
| Autonomous AP          | Cisco Aironet 1240 AG Series                     | Cisco Aironet 1240 AG Access Point       | 1.3.6.1.4.1.9.1.685  |
| Autonomous AP          | Cisco Aironet 1250 Series                        | Cisco Aironet 1250 Series Access Point   | 1.3.6.1.4.1.9.1.758  |
| Autonomous AP          | Cisco Aironet 1400 Series                        | BR1410                                   | 1.3.6.1.4.1.9.1.533  |
| Autonomous AP          | Cisco Aironet 1400 Series                        | Aironet BR 1430                          | 1.3.6.1.4.1.9.1.1031 |
| Autonomous AP          | Cisco Aironet 1300 Series                        | Aironet BR1300                           | 1.3.6.1.4.1.9.1.565  |
| Autonomous AP          | Cisco Aironet 1040 Series                        | Cisco Aironet 1040                       | 1.3.6.1.4.1.9.1.1270 |
|                        |  | Cisco Aironet 1040                       | 1.3.6.1.4.1.9.1.1269 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|               |  |                                    |                                |
|---------------|--|------------------------------------|--------------------------------|
| Autonomous AP | Cisco Aironet 1040 Series                  |                                    |                                |
| Autonomous AP | Cisco Aironet 1260 Series                  | Cisco Aironet 1260                 | 1.3.6.1.4.1.9.1.1248           |
| Autonomous AP | Cisco Aironet 1260 Series                  | Cisco Aironet 1260                 | 1.3.6.1.4.1.9.1.1247           |
| Autonomous AP | Cisco Aironet 2600I Series                 | Cisco Aironet 2600I Access Point   | 1.3.6.1.4.1.9.1.1647           |
| Autonomous AP | Cisco Aironet 2600E Series                 | Cisco Aironet 2600E                | 1.3.6.1.4.1.9.1.1659           |
| Autonomous AP | Cisco Aironet 3500I Series                 | Cisco Aironet 3500I Access Point   | 1.3.6.1.4.1.9.1.1124           |
| Autonomous AP | Cisco Aironet 3500E Series                 | Cisco Aironet 3500E                | 1.3.6.1.4.1.9.1.1125           |
| Autonomous AP | Cisco Aironet 3600I Series                 | Cisco Aironet 3600I Access Point   | 1.3.6.1.4.1.9.1.1662           |
| Autonomous AP | Cisco Aironet 3600I Series                 | Cisco Aironet 3600I Access Point   | 1.3.6.1.4.1.9.1.1661           |
| Autonomous AP | Cisco Aironet 1550 Series                  | Cisco Aironet 1550 Access Point    | 1.3.6.1.4.1.9.1.1664           |
| Autonomous AP | Cisco Aironet 1550 Series                  | Cisco Aironet 1550 Access Point    | 1.3.6.1.4.1.9.1.1665           |
| Unified AP    | Cisco 5212 Series Unified Access Points    | Cisco 5212 Unified Access Point    | 1.3.6.1.4.1.14179.2.2.1.1.22.1 |
| Unified AP    | Cisco 5312 Series Unified Access Points    | Cisco 5312 Unified Access Point    | 1.3.6.1.4.1.14179.2.2.1.1.22.2 |
| Unified AP    | Cisco MIMO Series Unified Access Points    | Cisco MIMO Unified Access Point    | 1.3.6.1.4.1.14179.2.2.1.1.22.3 |
| Unified AP    | Cisco UNKNOWN Series Unified Access Points | Cisco UNKNOWN Unified Access Point | 1.3.6.1.4.1.14179.2.2.1.1.22.4 |
| Unified AP    | Cisco 1100 Series Unified Access Points    | Cisco 1100 Unified Access Point    | 1.3.6.1.4.1.14179.2.2.1.1.22.5 |
| Unified AP    | Cisco 1130 Series Unified Access Points    | Cisco 1130 Unified Access Point    | 1.3.6.1.4.1.14179.2.2.1.1.22.6 |
| Unified AP    | Cisco 1240 Series Unified Access Points    | Cisco 1240 Unified Access Point    | 1.3.6.1.4.1.14179.2.2.1.1.22.7 |
| Unified AP    | Cisco 1200 Series Unified Access Points    | Cisco 1200 Unified Access Point    | 1.3.6.1.4.1.14179.2.2.1.1.22.8 |
| Unified AP    |  |                                    | 1.3.6.1.4.1.14179.2.2.1.1.22.9 |



## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|            |   |                                   |                                 |
|------------|---|-----------------------------------|---------------------------------|
|            | Cisco 1310 Series Unified Access Points   | Cisco 1310 Unified Access Point   |                                 |
| Unified AP | Cisco 1500 Series Unified Access Points   | Cisco 1500 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.10 |
| Unified AP | Cisco 1250 Series Unified Access Points   | Cisco 1250 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.11 |
| Unified AP | Cisco 1505 Series Unified Access Points   | Cisco 1505 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.12 |
| Unified AP | Cisco 3201 Series Unified Access Points   | Cisco 3201 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.13 |
| Unified AP | Cisco 1520 Series Unified Access Points   | Cisco 1520 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.14 |
| Unified AP | Cisco 801GN Series Unified Access Points  | Cisco 801GN Unified Access Point  | 1.3.6.1.4.1.14179.2.2.1.1.22.15 |
| Unified AP | Cisco 1140 Series Unified Access Points   | Cisco 1140 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.16 |
| Unified AP | Cisco 801AGN Series Unified Access Points | Cisco 801AGN Unified Access Point | 1.3.6.1.4.1.14179.2.2.1.1.22.17 |
| Unified AP | Cisco 3500I Series Unified Access Points  | Cisco 3500I Unified Access Point  | 1.3.6.1.4.1.14179.2.2.1.1.22.18 |
| Unified AP | Cisco 3500E Series Unified Access Points  | Cisco 3500E Unified Access Point  | 1.3.6.1.4.1.14179.2.2.1.1.22.19 |
| Unified AP | Cisco 1260 Series Unified Access Points   | Cisco 1260 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.20 |
| Unified AP | Cisco 1040 Series Unified Access Points   | Cisco 1040 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.21 |
| Unified AP | Cisco 1550 Series Unified Access Points   | Cisco 1550 Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.22 |
| Unified AP | Cisco 602I Series Unified Access Points   | Cisco 602I Unified Access Point   | 1.3.6.1.4.1.14179.2.2.1.1.22.23 |
| Unified AP | Cisco 3500P Series Unified Access Points  | Cisco 3500P Unified Access Point  | 1.3.6.1.4.1.14179.2.2.1.1.22.24 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                     |  |                                      |                                  |
|---------------------|--|--------------------------------------|----------------------------------|
| Unified AP          | Cisco 802GN Series Unified Access Points     | Cisco 802GN Unified Access Point     | 1.3.6.1.4.1.14179.2.2.1.1.22.25  |
| Unified AP          | Cisco 802AGN Series Unified Access Points    | Cisco 802AGN Unified Access Point    | 1.3.6.1.4.1.14179.2.2.1.1.22.26  |
| Unified AP          | Cisco 3600I Series Unified Access Points     | Cisco 3600I Unified Access Point     | 1.3.6.1.4.1.14179.2.2.1.1.22.27  |
| Unified AP          | Cisco 3600E Series Unified Access Points     | Cisco 3600E Unified Access Point     | 1.3.6.1.4.1.14179.2.2.1.1.22.28  |
| Unified AP          | Cisco 2600I Series Unified Access Points     | Cisco 2600I Unified Access Point     | 1.3.6.1.4.1.14179.2.2.1.1.22.29  |
| Unified AP          | Cisco 2600E Series Unified Access Points     | Cisco 2600E Unified Access Point     | 1.3.6.1.4.1.14179.2.2.1.1.22.30  |
| Unified AP          | Cisco 1600I Series Unified Access Points     | Cisco 1600I Unified Access Point     | 1.3.6.1.4.1.14179.2.2.1.1.22.32  |
| Unified AP          | Cisco 1600E Series Unified Access Points     | Cisco 1600E Unified Access Point     | 1.3.6.1.4.1.14179.2.2.1.1.22.33  |
| Unmanaged AP        | Cisco Unmanaged Series Unified Access Points | Cisco Unmanaged Unified Access Point | 1.3.6.1.4.1.14179.2.2.1.1.22.999 |
| Wireless Controller | Cisco 2000 Series Wireless LAN Controllers   | Cisco 2006 Wireless LAN Controller   | 1.3.6.1.4.1.14179.1.1.4.2        |
| Wireless Controller | Cisco 2100 Series Wireless LAN Controllers   | Cisco 2106 Wireless LAN Controller   | 1.3.6.1.4.1.9.1.828              |
| Wireless Controller | Cisco 2100 Series Wireless LAN Controllers   | Cisco 2106 Wireless LAN Controller   | 1.3.6.1.4.1.9.1.818              |
| Wireless Controller | Cisco 4400 Series Wireless LAN Controllers   | Cisco 4404 Wireless LAN Controller   | 1.3.6.1.4.1.14179.1.1.4.4        |
| Wireless Controller | Cisco 4400 Series Wireless LAN Controllers   | Cisco 4404 Wireless LAN Controller   | 1.3.6.1.4.1.14179.1.1.4.3        |
| Wireless Controller | Cisco 4400 Series Wireless LAN Controllers   | Cisco 4404 Wireless LAN Controller   | 1.3.6.1.4.1.14179.1.1.4.5        |
| Wireless Controller | Cisco 4400 Series Wireless LAN Controllers   | Cisco 4402 Wireless LAN Controller   | 1.3.6.1.4.1.9.1.747              |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                     |  |   |                             |
|---------------------|--|---|-----------------------------|
| Wireless Controller | Cisco WiSM Series Controller                   | Cisco WiSM Controller                   | 1.3.6.1.4.1.14179.1.1.4.4   |
| Wireless Controller | Cisco 5500 Series Wireless LAN Controllers     | Cisco 5508 Wireless LAN Controller      | 1.3.6.1.4.1.9.1.1069        |
| Wireless Controller | Cisco 2500 Series Wireless LAN Controller      | Cisco 2504 Wireless LAN Controller      | 1.3.6.1.4.1.9.1.1279        |
| Wireless Controller | Cisco Catalyst 6500 Series WLSM                | Cisco WiSM2 Controller                  | 1.3.6.1.4.1.9.1.1293        |
| Wireless Controller | Cisco SRE 700 Series Wireless Controllers      | Cisco SRE 700 Wireless Controller       | 1.3.6.1.4.1.9.1.1230        |
| Wireless Controller | Cisco Flex 7500 Series Wireless LAN Controller | Cisco Flex 7510 Wireless LAN Controller | 1.3.6.1.4.1.9.1.1295        |
| Wireless Controller | Cisco 8500 Series Wireless LAN Controller      | Cisco Flex 8500 Wireless LAN Controller | 1.3.6.1.4.1.9.1.1615        |
| Wireless Controller | Cisco VIRTUAL Series Wireless LAN Controller   | Cisco Virtual Wireless LAN Controller   | 1.3.6.1.4.1.9.1.1631        |
| Wireless Controller | Cisco 5760 Series Wireless LAN Controller      | Cisco 5760 Wireless LAN Controller      | 1.3.6.1.4.1.9.1.1645        |
| Cisco MXP Series    | Cisco MXP Series                               | Cisco MXP 1000                          | 1.3.6.1.4.1.9.1.mxp1000     |
| Cisco MXP Series    | Cisco MXP Series                               | Cisco MXP 150                           | 1.3.6.1.4.1.9.1.mxp1000     |
| Cisco MXP Series    | Cisco MXP Series                               | Cisco MXP 1500                          | 1.3.6.1.4.1.9.1.mxp1000     |
| Cisco MXP Series    | Cisco MXP Series                               | Cisco MXP 1700                          | 1.3.6.1.4.1.9.1.mxp1000     |
| Cisco MXP Series    | Cisco MXP Series                               | Cisco MXP 3000                          | 1.3.6.1.4.1.9.1.mxp1000     |
| Cisco MXP Series    | Cisco MXP Series                               | Cisco MXP 6000                          | 1.3.6.1.4.1.9.1.mxp1000     |
| Cisco MXP Series    | Cisco MXP Series                               | Cisco MXP95Edge                         | 1.3.6.1.4.1.5596.10.6.4.1   |
| Cisco MXP Series    | Cisco MXP Series                               | Cisco Profile 52 6000MXP                | 1.3.6.1.4.1.9.1.p52.6000mxp |

## Third-party Endpoints

| Device Series               | Device Name | SystemObjectID       |
|-----------------------------|-------------|----------------------|
| Polycom TelePresence System | Polycom     | 1.3.6.1.4.1.2684.1.1 |

## Third-party Network Devices

| Device Series                    | Device Group              | SystemObjectID           |
|----------------------------------|---------------------------|--------------------------|
| Aruba 5000 Series controller     | Aruba 5000 Controller     | 1.3.6.1.4.1.14823.1.1.1  |
| Aruba 2400 Series controller     | Aruba 2400 Controller     | 1.3.6.1.4.1.14823.1.1.2  |
| Aruba 800 Series controller      | Aruba 800 Controller      | 1.3.6.1.4.1.14823.1.1.3  |
| Aruba 6000 Series controller     | Aruba 6000 Controller     | 1.3.6.1.4.1.14823.1.1.4  |
| Aruba 2400E Series controller    | Aruba 2400E Controller    | 1.3.6.1.4.1.14823.1.1.7  |
| Aruba 800E Series controller     | Aruba 800E Controller     | 1.3.6.1.4.1.14823.1.1.8  |
| Aruba 804 Series controller      | Aruba 804 Controller      | 1.3.6.1.4.1.14823.1.1.9  |
| Aruba 200 Series controller      | Aruba 200 Controller      | 1.3.6.1.4.1.14823.1.1.10 |
| Aruba 2424 Series controller     | Aruba 2424 Controller     | 1.3.6.1.4.1.14823.1.1.11 |
| Aruba 6000-SC3 Series controller | Aruba 6000-SC3 Controller | 1.3.6.1.4.1.14823.1.1.12 |
| Aruba 3200 Series controller     | Aruba 3200 Controller     | 1.3.6.1.4.1.14823.1.1.13 |
| Aruba 3200-8 Series controller   | Aruba 3200-8 Controller   | 1.3.6.1.4.1.14823.1.1.14 |
| Aruba 3400 Series controller     | Aruba 3400 Controller     | 1.3.6.1.4.1.14823.1.1.15 |
| Aruba 3400-32 Series controller  | Aruba 3400-32 Controller  | 1.3.6.1.4.1.14823.1.1.16 |
| Aruba 3600 Series controller     | Aruba 3600 Controller     | 1.3.6.1.4.1.14823.1.1.17 |
| Aruba 3600-64 Series controller  | Aruba 3600-64 Controller  | 1.3.6.1.4.1.14823.1.1.18 |
| Aruba 650 Series controller      | Aruba 650Controller       | 1.3.6.1.4.1.14823.1.1.19 |
| Aruba 651 Series controller      | Aruba 651 Controller      | 1.3.6.1.4.1.14823.1.1.20 |
| Aruba 620 Series controller      | Aruba 620 Controller      | 1.3.6.1.4.1.14823.1.1.23 |
| Aruba 50 Series Access Points    | Aruba 50 Access Point     | 1.3.6.1.4.1.14823.1.2.1  |
| Aruba 52 Series Access Points    | Aruba 52 Access Point     | 1.3.6.1.4.1.14823.1.2.2  |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|   |                                 |                          |
|---|---------------------------------|--------------------------|
| Aruba 60 Series Access Points           | Aruba 60 Access Point           | 1.3.6.1.4.1.14823.1.2.3  |
| Aruba 61 Series Access Points           | Aruba 61 Access Point           | 1.3.6.1.4.1.14823.1.2.4  |
| Aruba 70 Series Access Points           | Aruba 70 Access Point           | 1.3.6.1.4.1.14823.1.2.5  |
| Aruba Wall jack 61 Series Access Points | Aruba Wall jack 61 Access Point | 1.3.6.1.4.1.14823.1.2.6  |
| Aruba 2E Series Access Points           | Aruba 2E Access Point           | 1.3.6.1.4.1.14823.1.2.7  |
| Aruba 1200 Series Access Points         | Aruba 1200 Access Point         | 1.3.6.1.4.1.14823.1.2.8  |
| Aruba 80S Series Access Points          | Aruba 80S Access Point          | 1.3.6.1.4.1.14823.1.2.9  |
| Aruba 80M Series Access Points          | Aruba 80M Access Point          | 1.3.6.1.4.1.14823.1.2.10 |
| Aruba WG 102 Series Access Points       | Aruba WG 102 Access Point       | 1.3.6.1.4.1.14823.1.2.11 |
| Aruba 40 Series Access Points           | Aruba 40 Access Point           | 1.3.6.1.4.1.14823.1.2.12 |
| Aruba 41 Series Access Points           | Aruba 41 Access Point           | 1.3.6.1.4.1.14823.1.2.13 |
| Aruba 65 Series Access Points           | Aruba 65 Access Point           | 1.3.6.1.4.1.14823.1.2.14 |
| Aruba MW 1700 Series Access Points      | Aruba MW 1700 Access Point      | 1.3.6.1.4.1.14823.1.2.15 |
| Aruba Duowj Series Access Points        | Aruba DuoWj Access Point        | 1.3.6.1.4.1.14823.1.2.16 |
| Aruba Duo Series Access Points          | Aruba Duo Access Point          | 1.3.6.1.4.1.14823.1.2.17 |
| Aruba 80MB Series Access Points         | Aruba 80MB Access Point         | 1.3.6.1.4.1.14823.1.2.18 |
| Aruba 80SB Series Access Points         | Aruba 80SB Access Point         | 1.3.6.1.4.1.14823.1.2.19 |
| Aruba 85 Series Access Points           | Aruba 85 Access Point           | 1.3.6.1.4.1.14823.1.2.20 |
| Aruba 124 Series Access Points          | Aruba 124 Access Point          | 1.3.6.1.4.1.14823.1.2.21 |
| Aruba 125 Series Access Points          | Aruba 125 Access Point          | 1.3.6.1.4.1.14823.1.2.22 |
|   |                                 | 1.3.6.1.4.1.14823.1.2.23 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                                      |                                   |                          |
|--------------------------------------|-----------------------------------|--------------------------|
| Aruba 120 Series Access Points       | Aruba 120 Access Point            |                          |
| Aruba 121 Series Access Points       | Aruba 121 Access Point            | 1.3.6.1.4.1.14823.1.2.24 |
| Aruba 1250 Series Access Points      | Aruba 1250 Access Point           | 1.3.6.1.4.1.14823.1.2.25 |
| Aruba 120 ABG Series Access Points   | Aruba 120 ABG Access Point        | 1.3.6.1.4.1.14823.1.2.26 |
| Aruba 121 ABG Series Access Points   | Aruba 121 ABG Series Access Point | 1.3.6.1.4.1.14823.1.2.27 |
| Aruba 124 ABG Series Access Points   | Aruba 124 ABG Access Point        | 1.3.6.1.4.1.14823.1.2.28 |
| Aruba 125 APG Series Access Points   | Aruba 125 APG Access Point        | 1.3.6.1.4.1.14823.1.2.29 |
| Aruba RAP 5WN Series Access Points   | Aruba RAP 5WN Access Point        | 1.3.6.1.4.1.14823.1.2.30 |
| Aruba RAP 5 Series Access Points     | Aruba RAP 5 Access Point          | 1.3.6.1.4.1.14823.1.2.31 |
| Aruba RAP 2WG Series Access Points   | Aruba RAP 2WG Access Point        | 1.3.6.1.4.1.14823.1.2.32 |
| Aruba reserved4 Series Access Points | Aruba reserved4 Access Point      | 1.3.6.1.4.1.14823.1.2.33 |
| Aruba 105 Series Access Points       | Aruba 105 Access Point            | 1.3.6.1.4.1.14823.1.2.34 |
| Aruba 65 WB Series Access Points     | Aruba 65 WB Access Point          | 1.3.6.1.4.1.14823.1.2.35 |
| Aruba 651 Series Access Points       | Aruba 651 Access Point            | 1.3.6.1.4.1.14823.1.2.36 |
| Aruba reserved6 Series Access Points | Aruba reserved6 Access Point      | 1.3.6.1.4.1.14823.1.2.37 |
| Aruba 60P Series Access Points       | Aruba 60P Access Point            | 1.3.6.1.4.1.14823.1.2.38 |
| Aruba reserved7 Series Access Points | Aruba reserved7 Access Point      | 1.3.6.1.4.1.14823.1.2.39 |
| Aruba 92 Series Access Points        | Aruba 92 Access Point             | 1.3.6.1.4.1.14823.1.2.40 |

## Supported\_Devices\_for\_Cisco\_Prime\_Collaboration\_Assurance\_9.5

|                                      |                              |                            |
|--------------------------------------|------------------------------|----------------------------|
| Aruba 93 Series Access Points        | Aruba 93 Access Point        | 1.3.6.1.4.1.14823.1.2.41   |
| Aruba 68 Series Access Points        | Aruba 68 Access Point        | 1.3.6.1.4.1.14823.1.2.42   |
| Aruba 68P Series Access Points       | Aruba 68P Access Point       | 1.3.6.1.4.1.14823.1.2.43   |
| Aruba 175P Series Access Points      | Aruba 175P Access Point      | 1.3.6.1.4.1.14823.1.2.44   |
| Aruba 175AC Series Access Points     | Aruba 175AC Access Point     | 1.3.6.1.4.1.14823.1.2.45   |
| Aruba 175DC Series Access Points     | Aruba 175DC Access Point     | 1.3.6.1.4.1.14823.1.2.46   |
| Aruba 134 Series Access Points       | Aruba 134 Access Point       | 1.3.6.1.4.1.14823.1.2.47   |
| Aruba 135 Series Access Points       | Aruba 135 Access Point       | 1.3.6.1.4.1.14823.1.2.48   |
| Aruba reserved8 Series Access Points | Aruba reserved8 Access Point | 1.3.6.1.4.1.14823.1.2.49   |
| Aruba Undefined Series Access Points | Aruba Undefined Access Point | 1.3.6.1.4.1.14823.1.2.9999 |
| Third Party Device                   | Third Party Device           | 1.3.6.1.4.1                |