

When\_agent\_drops\_from\_conference,\_all\_parties\_on\_conference\_are\_dropped

## **When agent drops from conference, all parties on conference are dropped**

<b>Problem Summary</b>	When an agent drops from a conference, all parties on the conference are dropped as well.
<b>Error Message</b>	None.
<b>Possible Cause</b>	The agent device is not configured with "keep-conference."
<b>Recommended Action</b>	Make sure the agent's device is configured with "keep-conference" on Cisco Unified CME.
<b>Release</b>	Release 7.0(1)
<b>Associated CDETS #</b>	None.