Main page: Cisco Unified MeetingPlace, Release 7.0

Up one level: Reference Information

To find this page, click **System Configuration > Remote Server Configuration > Add New**.

Note: In this document, a "system" refers to a complete Cisco Unified MeetingPlace site installation, which includes one active Application Server and one active Media Server. The system may also include one or more Web Servers.

Table: Field Reference: Add Server Configuration Page and Edit Server Configuration Page

Field	Description
Name	Name of the remote system. This name will appear on the end-user web interface when scheduling meetings.
Home Server number	Enter a unique number that identifies the remote server on all RSNA systems. This same value must be used in the Schedule home server user profile field for users that are local to the server. If you check Reserved Meeting Server: • The Home Server number field is cleared and cannot be modified. • In the database, this remote server record is assigned the Home Server number of 777777.
Reserved Meeting Server	Whether the remote server is the RSNA Reserved Meeting Server. If you check this: • The Home Server number field is cleared and cannot be modified. • In the database, this remote server record is assigned the Home Server number of 777777.
SIP Agent Address 1 SIP Agent Address 2	IP address of the remote Application Server(s). The second remote server entry is optional.
Routing Unit Number	*Reserved for a future release*.
Routing Codec	*Reserved for a future release*.
Web conferencing enabled	Whether Cisco Unified MeetingPlace Web Conferencing is installed and operational on the remote system.

	Default: No
Web URL	URL of the primary Web Server for the remote system.

Related Topics

- Configuring Reservationless Single Number Access (RSNA) for Cisco Unified MeetingPlace module
- Configuring Endpoints for Cisco Unified MeetingPlace
- Remote Server Configuration Page