## **Back to: CUPI for End Users Overview**

## **Contents**

- 1 About Unified Messaging Service Accounts
- 2 Listing and Viewing

## **About Unified Messaging Service Accounts**

A user may have zero or more unified messaging service accounts (also known as external service accounts). Examples of these services include Cisco Unified MeetingPlace 8.0, Exchange 2003, Exchange 2007, Exchange 2010. Using CUPI for End Users, a user can:

- Retrieve a list of its unified messaging service accounts,
- Retrieve one of its unified messaging service accounts, and
- Change the password for one of its unified messaging service accounts

## **Listing and Viewing**

To retrieve a list of unified messaging service accounts, use the GET method with URI \_/vmrest/user/externalserviceaccounts\_. In the following example, the user has two unified messaging service accounts, Exchange2K3 and Exchange2K7:

```
GET http://<connection-server>/vmrest/user/externalserviceaccounts
<?xml version="1.0" encoding="UTF-8"?>
<UserExternalServiceAccounts>
  <UserExternalServiceAccount>
    <URI>/vmrest/user/externalserviceaccounts/510eeaa6-6e85-40f3-88b3-863c2a4eec84</URI>
    <IsEnabled>true</IsEnabled>
    <UseServiceCredentials>true</UseServiceCredentials>
    <LoginType>0</LoginType>
    <ObjectId>510eeaa6-6e85-40f3-88b3-863c2a4eec84</objectId>
    <DisplayName>Exchange2K3</DisplayName>
  </UserExternalServiceAccount>
  <UserExternalServiceAccount>
    <URI>/vmrest/user/externalserviceaccounts/75436abf-8784-450f-ac61-23a08be2c364</URI>
    <IsEnabled>true</IsEnabled>
    <UseServiceCredentials>false/UseServiceCredentials>
    <LoginType>2</LoginType>
    <UserId>fung</UserId>
    <ObjectId>75436abf-8784-450f-ac61-23a08be2c364</ObjectId>
    <DisplayName>Exchange2K7</DisplayName>
  </UserExternalServiceAccount>
</UserExternalServiceAccounts>
```

For each unified messaging service account, CUPI returns the following information:

- URI The URI for retrieving the unified messaging service account
- IsEnabled A flag to indicate whether the unified messaging service account is enabled
- UseServiceCredentials A flag to indicate whether service credentials or user credentials are used to sign in the unified messaging service account

Contents 1

Cisco\_Unity\_Connection\_Provisioning\_Interface\_(CUPI)\_API\_--\_For\_End\_Users\_--\_Unified\_Messaging\_Accounts

- LoginType A flag to indicate whether the user alias (0), a guest account (1), or a specified user ID (2) is used to sign in the account
- UserId The user ID to sign in to the unified messaging service account, if one is used
- ObjectId The unique ID of the unified messaging service account
- Display Name The display name of the unified messaging service account

To retrieve a specific unified messaging service account, use the GET method with the URI field from above as follows:

Some unified messaging service accounts use service credentials to sign in; others employ user-supplied credentials. This is indicated by the \_UseServiceCredentials\_ field. For unified messaging service accounts that require user credentials for signing in (for example, those with \_UseServiceCredentials\_ set to false), the user may specify the password via a PUT method by using the unified messaging service account URI and a query parameter, \_password\_, as follows:

```
PUT https://<connection-server>/vmrest/user/externalserviceaccounts/75436abf-8784-450f-ac61-23a08b
204
No Content
null
```

Note that if you attempt to specify the password of a unified messaging service account that does not require a user password (for example, one where \_UseServiceCredentials\_ is set to true), an error will be returned.

Listing and Viewing 2