This chapter gives a description, entity, SNMP number, and trap for each commonly encountered Cisco ONS 15454 transient condition.

Contents

- 1 Transients Indexed By Alphabetical Entry
  - 1.1 Table 3-1: ONS 15454 Transient Condition Alphabetical Index
- 2 Trouble Notifications
  - 2.1 Condition Characteristics
  - 2.2 Condition States
- 3 Transient Conditions
  - 3.1 ADMIN-DISABLE
  - 3.2 ADMIN-DISABLE-CLR
  - 3.3 ADMIN-LOCKOUT
  - 3.4 ADMIN-LOCKOUT-CLR
  - 3.5 ADMIN-LOGOUT
  - 3.6 ADMIN-SUSPEND
  - 3.7 ADMIN-SUSPEND-CLR
  - 3.8 AUD-ARCHIVE-FAIL
  - 3.9 AUTOWDMANS
  - 3.10 BLSR-RESYNC
  - 3.11 DBBACKUP-FAIL
  - 3.12 DBRESTORE-FAIL
  - 3.13 EFM-ERR-FRM
  - 3.14 EFM-FRM-PER
  - 3.15 EFM-FRM-SEC
  - 3.16 EFM-RLBK-FAIL
  - 3.17 EFM-SYM-PER
  - 3.18 FIREWALL-DIS
  - 3.19 FRCDWKSWBK-NO-TRFSW
  - 3.20 FRCDWKSWPR-NO-TRFSW
  - 3.21 INTRUSION
  - 3.22 IOSCFG-COPY-FAIL
  - 3.23 LOGIN-FAIL-LOCKOUT
  - 3.24 LOGIN-FAIL-ONALRDY
  - 3.25 LOGIN-FAILURE-PSWD
  - 3.26 LOGOUT-IDLE-USER
  - 3.27 MANWKSWBK-NO-TRFSW
  - 3.28 MANWKSWPR-NO-TRFSW
  - 3.29 PM-TCA
  - 3.30 PS
  - 3.31 RMON-ALARM
  - 3.32 RMON-RESET
  - 3.33 SFTWDOWN-FAIL
  - 3.34 USER-LOCKOUT
  - 3.35 USER-LOGIN
  - 3.36 USER-LOGOUT
  - 3.37 WORK-QUEUE-FULL
  - 3.38 WKSWBK
  - 3.39 WKSWPR
  - 3.40 WTR-SPAN

Transients Indexed By Alphabetical Entry

Table 3-1 alphabetically lists all ONS 15454 transient conditions and their entity, SNMP number, and SNMP trap.

Note: The CTC default alarm profile might contain conditions that are not currently implemented but are reserved for future use.

Table 3-1: ONS 15454 Transient Condition Alphabetical Index

Transient Condition	Entity	SNMP Number	SNMP Trap
ADMIN-DISABLE	NE	5270	disableInactiveUser
ADMIN-DISABLE-CLR	NE	5280	disableInactiveClear
ADMIN-LOCKOUT	NE	5040	adminLockoutOfUser
ADMIN-LOCKOUT-CLR	NE	5050	adminLockoutClear
ADMIN-LOGOUT	NE	5020	adminLogoutOfUser
ADMIN-SUSPEND	NE	5340	suspendUser
ADMIN-SUSPEND-CLR	NE	5350	suspendUserClear
AUD-ARCHIVE-FAIL	EQPT	6350	archiveOfAuditLogFailed
AUTOWDMANS	NE	5690	automaticWdmAnsFinished
BLSR-RESYNC	OCN	2100	blsrMultiNodeTableUpdateCompleted
DBBACKUP-FAIL	EQPT	3724	databaseBackupFailed
DBRESTORE-FAIL	EQPT	3726	databaseRestoreFailed
EFM-ERR-FRM	ML100T, ML1000, MLFX, ML2	6800	efmLinkMonitoringErroredFrameEvent
EFM-FRM-PER	ML100T, ML1000, MLFX, ML2	6810	efmLinkMonitoringErroredFramePeriodEvent
EFM-FRM-SEC	ML100T, ML1000, MLFX, ML2	6820	efmLinkMonitoringErroredFrameSecondsSummary
EFM-RLBK-FAIL	ML100T, ML1000, MLFX, ML2	6830	efmRemoteLoopbackRequestFailed
EFM-SYM-PER	ML100T, ML1000, MLFX, ML2	6790	efmLinkMonitoringErroredSymbolPeriodEvent
FIREWALL-DIS	NE	5230	firewallHasBeenDisabled
FRCDWKSWBK-NO-TRFSW	OCN	5560	forcedSwitchBackToWorkingResultedInNoTrafficSwitch
FRCDWKSWPR-NO-TRFSW	OCn	5550	forcedSwitchToProtectResultedInNoTrafficSwitch
INTRUSION	NE	5250	securityIntrusionDetUser

IOSCFG-COPY-FAIL	-	3660	iosConfigCopyFailed
LOGIN-FAIL-LOCKOUT	NE	5080	securityInvalidLoginLockedOutSeeAuditLog
LOGIN-FAIL-ONALRDY	NE	5090	securityInvalidLoginAlreadyLoggedOnSeeAuditLog
LOGIN-FAILURE-PSWD	NE	5070	securityInvalidLoginPasswordSeeAuditLog
LOGOUT-IDLE-USER	-	5110	automaticLogoutOfIdleUser
MANWKSWBK-NO-TRFSW	OCN	5540	manualSwitchBackToWorkingResultedInNoTrafficSwitch
MANWKSWPR-NO-TRFSW	OCN	5530	manualSwitchToProtectResultedInNoTrafficSwitch
PM-TCA	-	2120	performanceMonitorThresholdCrossingAlert
PS	EQPT	2130	protectionSwitch
RMON-ALARM	-	2720	rmonThresholdCrossingAlarm
RMON-RESET	-	2710	rmonHistoriesAndAlarmsResetReboot
SFTWDOWN-FAIL	EQPT	3480	softwareDownloadFailed
USER-LOCKOUT	NE	5030	userLockedOut
USER-LOGIN	NE	5100	loginOfUser
USER-LOGOUT	NE	5120	logoutOfUser
WORK-QUEUE-FULL	EQPT		
WKSWBK	EQPT, OCN	2640	switchedBackToWorking
WKSWPR	2R, TRUNK, EQPT, ESCON, FC, GE, ISC, OCN, STSMON, VT-MON	2650	switchedToProtection
WTR-SPAN	-	3420	spanIsInWaitToRestoreState

Trouble Notifications

The ONS 15454 system reports trouble by using standard condition characteristics that follow the rules in Telcordia GR-253 and graphical user interface (GUI) state indicators.

The ONS 15454 uses standard Telcordia categories to characterize levels of trouble. The system reports trouble notifications as alarms and reports status or descriptive notifications (if configured to do so) as conditions in the CTC Alarms window. Alarms typically signify a problem that you need to remedy, such as a loss of signal. Conditions do not necessarily require troubleshooting.

Condition Characteristics

Conditions include any problem detected on an ONS 15454 shelf. They can include standing or transient notifications. You can retrieve a snapshot of all currently raised conditions on the network, node, or card in the CTC Conditions window or by using the RTRV-COND commands in TL1.

Note: Some cleared conditions are found on the History tab.

For a comprehensive list of conditions, refer to the Cisco ONS SONET TL1 Command Guide.

Condition States

The History tab state (ST) column indicates the disposition of the condition, as follows:

- A raised (R) event is active.
- A cleared (C) event is no longer active.
- A transient (T) event is automatically raised and cleared in CTC during system changes such as user login, log out, and loss of connection to node view. Transient events do not require user action.

Transient Conditions

This section lists in alphabetical order all the transient conditions encountered in Software Release 7.2. The description, entity, SNMP number, and SNMP trap accompany each condition.

ADMIN-DISABLE

The Disable Inactive User (ADMIN-DISABLE) condition occurs when the administrator disables the user or the account is inactive for a specified period.

This transient condition does not result in a standing condition.

ADMIN-DISABLE-CLR

The Disable Inactive Clear (ADMIN-DISABLE-CLR) condition occurs when the administrator clears the disable flag on the user account.

This transient condition does not result in a standing condition.

ADMIN-LOCKOUT

The Admin Lockout of User (ADMIN-LOCKOUT) condition occurs when the administrator locks a user account.

This transient condition does not result in a standing condition.

ADMIN-LOCKOUT-CLR

The Admin Lockout Clear (ADMIN-LOCKOUT-CLR) condition occurs when the administrator unlocks a user account or the lockout time expires.

This transient condition does not result in a standing condition.

ADMIN-LOGOUT

The Admin Logout of User (ADMIN-LOGOUT) condition occurs when the administrator logs off a user session.

This transient condition does not result in a standing condition.

ADMIN-SUSPEND

The Suspend User (ADMIN-SUSPEND) condition occurs when the password for a user account expires.

This transient condition does not result in a standing condition.

ADMIN-SUSPEND-CLR

The Suspend User Clear (ADMIN-SUSPEND-CLR) condition occurs when the user or administrator changes the password.

This transient condition does not result in a standing condition.

AUD-ARCHIVE-FAIL

The Archive of Audit Log Failed (AUD-ARCHIVE-FAIL) condition occurs when the software cannot archive the audit log. The condition normally occurs when the user refers to an FTP server that does not exist, or uses an invalid login when trying to archive. The user must log in again with correct user name, password, and FTP server details.

This transient condition does not result in a standing condition.

AUTOWDMANS

The Automatic WDM ANS Finish (AUTOWDMANS) condition indicates that an automatic node setup command has been initiated. It normally occurs when you replace DWDM cards; the condition is an indication that the system has regulated the card.

This transient condition does not result in a standing condition.

BLSR-RESYNC

The BLSR Multinode Table Update Completed (BLSR-RESYNC) condition might occur when you create or delete circuits on a bidirectional line switched ring (BLSR), change a ring topology (for example, add or delete a BLSR node), or change the BLSR circuit state and ring ID.

This transient condition does not result in a standing condition.

DBBACKUP-FAIL

The Database Backup Failed (DBBACKUP-FAIL) condition occurs when the system fails to back up the database when the backup command is initiated.

This condition can occur when the server is not able to handle the backup operation due to network or server issues. Repeat the same operation again and check to see if it is successful. If the backup fails, it could be due to a network issue or software program failure. Contact TAC for assistance; see the Obtaining Documentation and Submitting a Service Request as needed.

DBRESTORE-FAIL

The Database Restore Failed (DBRESTORE-FAIL) condition occurs when the system fails to restore the backed up database when the restore command is initiated.

This condition can be due to server issues, network issues, or human error (pointing to a file that does not exist, wrong file name, etc.). Retrying the database restore with the correct file will usually succeed. If the network issue persists, you must contact network lab support. If the condition is caused by a network element (NE) failure, contact TAC for assistance. See the Obtaining Documentation and Submitting a Service Request as needed.

EFM-ERR-FRM

The EFM Link Monitoring - Errored Frame Event condition occurs when the number of error frames detected on the remote NE is equal to or greater than the specified threshold for a specified period, and the remote NE notifies local NE of the same. A period is specified by time interval.

This transient condition does not result in a standing condition.

EFM-FRM-PER

The EFM Link Monitoring - Errored Frame Period Event condition occurs when the number of errored frames detected on the remote NE is equal to or greater than the specified threshold for a specified period, and the remote NE notifies local NE of the same. A period is specified by the number of received frames.

This transient condition does not result in a standing condition.

EFM-FRM-SEC

The EFM Link Monitoring - Errored Frame Seconds Summary condition occurs when the number of errored frame seconds (a 1-second interval wherein at least one frame error was detected) on the remote NE crosses the configured threshold. The remote NE notifies local NE of the condition.

EFM-RLBK-FAIL

The EFM - Remote Loopback Request Failed condition occurs when a request fails. When the user triggers a remote loopback request on the local NE, the request is forwarded to the remote NE. If the remote NE does not respond to the request and the local NE times out, this condition notifies the user on local NE about the failure.

This transient condition does not result in a standing condition.

EFM-SYM-PER

The EFM Link Monitoring - Errored Symbol Period Event condition occurs when the symbol errors detected at the remote NE cross a configured threshold. This condition notifies the user onthe local NE of this threshold crossing.

This transient condition does not result in a standing condition.

FIREWALL-DIS

The Firewall Has Been Disabled (FIREWALL-DIS) condition occurs when you provision the firewall to Disabled.

This transient condition does not result in a standing condition.

FRCDWKSWBK-NO-TRFSW

The Forced Switch Back to Working Resulted in No Traffic Switch (FRCDWKSWBK-NO-TRFSW) condition occurs when you perform a Force Switch to the working port/card and the working port/card is already active.

This transient condition might result in a Force Switch (Ring or Span) standing condition for a BLSR.

FRCDWKSWPR-NO-TRFSW

The Forced Switch to Protection Resulted in No Traffic Switch (FRCDWKSWPR-NO-TRFSW) condition occurs when you perform a Force Switch to the protect port/card, and the protect port/card is already active.

This transient condition does not result in a standing condition.

INTRUSION

The Invalid Login Username (INTRUSION) condition occurs when you attempt to login with an invalid user ID.

This transient condition does not result in a standing condition.

IOSCFG-COPY-FAIL

The IOS Config Copy Failed (IOSCFG-COPY-FAIL) condition occurs on ML-Series Ethernet cards when the software fails to upload or download the Cisco IOS startup configuration file to or from an ML-Series card. This condition is similar to the "SFTWDOWN-FAIL" condition, but the IOSCFG-COPY-FAIL condition applies to ML-Series Ethernet cards rather than the TCC2/TCC2P card.

LOGIN-FAIL-LOCKOUT

The Invalid Login-Locked Out (LOGIN-FAIL-LOCKOUT) condition occurs when you attempt to log into a locked account.

This transient condition does not result in a standing condition.

LOGIN-FAIL-ONALRDY

The Security: Invalid Login-Already Logged On (LOGIN-FAIL-ONALRDY) condition occurs when you attempt to login to a node where the user already has an existing session and a Single-User-Per-Node (SUPN) policy exists.

This transient condition does not result in a standing condition.

LOGIN-FAILURE-PSWD

The Invalid Login-Password (LOGIN-FAILURE-PSWD) condition occurs when you attempt to login with an invalid password.

This transient condition does not result in a standing condition.

LOGOUT-IDLE-USER

The Automatic Logout of Idle User (LOGOUT-IDLE-USER) condition occurs when a user session is idle for too long (the idle timeout expires) and the session terminates as a result. You must log in again to restart your session.

MANWKSWBK-NO-TRFSW

The Manual Switch Back To Working Resulted in No Traffic Switch (MANWKSWBK-NO-TRFSW) condition occurs when you perform a Manual switch to the working port/card and the working port/ card is already active.

This transient condition does not result in a standing condition.

MANWKSWPR-NO-TRFSW

The Manual Switch to Protect Resulted in No Traffic Switch (MANWKSWPR-NO-TRFSW) condition occurs when you perform a Manual switch to the protect port/card and the protect port/card is already active.

This transient condition results in a BLSR Manual Switch (Span or Ring) standing condition.

PM-TCA

The Performance Monitor Threshold Crossing Alert (PM-TCA) condition occurs when network collisions cross the rising threshold for the first time.

PS

The Protection Switch (PS) condition occurs when the traffic switches from a working/active card to a protect/standby card.

RMON-ALARM

The RMON Threshold Crossing Alarm (RMON-ALARM) condition occurs when the remote monitoring variable crosses the threshold.

RMON-RESET

The RMON Histories and Alarms Reset Reboot (RMON-RESET) condition occurs when the time-of-day settings on the TCC2/TCC2P card are increased or decreased by more than five seconds. This invalidates all the history data and remote monitoring (RMON) must restart. It can also occur when you reset a card.

SFTWDOWN-FAIL

The Software Download Failed (SFTDOWN-FAIL) condition occurs when the system fails to download the required software.

An incorrect input that points to the wrong place or file, network issues, or a bad (corrupt) package can cause this failure. Retrying the operation with the correct name/location will usually succeed. If network issues persist, you must contact the network lab support. If the package is corrupt, contact Cisco TAC. See the Obtaining Documentation and Submitting a Service Request for details.

USER-LOCKOUT

The User Locked Out (USER-LOCKOUT) condition occurs when the system locks an account because of a failed login attempt. To proceed, the administrator must unlock the account or the lockout time must expire.

USER-LOGIN

The Login of User (USER-LOGIN) occurs when you begin a new session by verifying your User ID and password.

This transient condition does not result in a standing condition.

USER-LOGOUT

The Logout of User (USER-LOGOUT) condition occurs when you stop a login session by logging out of your account.

This transient condition does not result in a standing condition.

WORK-QUEUE-FULL

The Work Queue Full(WORK-QUEUE-FULL) condition occurs when the netTask Queue in VxWorks has filled up and task operations for the card are postponed.

This transient condition does not result in a standing condition.

WKSWBK

The Switched Back to Working (WKSWBK) condition occurs when traffic switches back to the working port/card in a non-revertive protection group.

This transient condition does not result in a standing condition.

WKSWPR

The Switched to Protection (WKSWPR) condition occurs when traffic switches to the protect port/card in a non-revertive protection group. This transient condition does not result in a standing condition. The (WKSWPR) is raised as a standing condition in a revertive protection group.

The Switched to Protection (WKSWPR) condition also occurs after the protection switch in a 1+1 non-revertive protection group as a transient condition. When the protection group is changed to revertive, the (WKSWPR) is not raised as a standing condition or as a new transient condition. However, after a protection switch in a 1:1 protection group, the user will not be allowed to configure the protection group from non-revertive to revertive.

WTR-SPAN

The Span is in Wait To Restore State (WTR-SPAN) condition occurs when a BLSR switches to another span due to a Signal Failure-Span command or a fiber is pulled from a four-fiber BLSR configuration. The condition is raised until the WaitToRestore (WTR) period expires.

This transient condition clears when the BLSR returns to a normal condition or the IDLE state.