

This section describes events received and status codes returned by Tcl IVR scripts. This chapter includes the following topics:

- [Events](#)
- [Status Codes](#)

Guide Contents
<a href="#">Troubleshooting Cisco IOS Voice Overview</a>
<a href="#">Debug Command Output on Cisco IOS Voice Gateways</a>
<a href="#">Filtering Troubleshooting Output</a>
<a href="#">Cisco VoIP Internal Error Codes</a>
<a href="#">Troubleshooting Cisco IOS Voice Telephony</a>
<a href="#">Troubleshooting Cisco IOS Voice Protocols</a>
<a href="#">Troubleshooting Cisco IOS Telephony Applications</a>
<a href="#">Monitoring the Cisco IOS Voice Network</a>
<a href="#">Cause Codes and Debug Values</a>

## Contents

- [1 Events](#)
- [2 Status Codes](#)
  - ◆ [2.1 Authentication Status](#)
  - ◆ [2.2 Authorization Status](#)
  - ◆ [2.3 Digit Collection Status](#)
  - ◆ [2.4 Consult Response](#)
  - ◆ [2.5 Consult Status](#)
  - ◆ [2.6 Disconnect Cause](#)
  - ◆ [2.7 Facility](#)
  - ◆ [2.8 Feature Type](#)
  - ◆ [2.9 Leg Setup Status](#)
  - ◆ [2.10 Media Status](#)
  - ◆ [2.11 Transfer Status](#)
  - ◆ [2.12 VoiceXML Dialog Completion Status](#)

## Events

The following events can be received by the Tcl IVR script. Any events received that are not included below are ignored.

Event	Description
ev_address_resolved	List of endpoint addresses.
ev_alert	An intermediate event generated by the <b>leg setup</b> or <b>leg setup_continue</b> commands to set up a call. If specified in the <b>callinfo parameter</b> , 'notifyEvents, the script receives an <b>ev_alert message</b> once the destination endpoint is successfully alerted. The script running in the transferee gateway could then disconnect the leg towards the transferring endpoint.  If this event is an intercepted event, the application needs to use the <b>leg setup_continue</b> command to allow the system to continue with the setup.
ev_any_event	A special wildcard event that can be used in the state machine to represent any event that might be received by the script.

ev_authorize_done	Confirms the completion of the <b>aaa authorize command</b> . You can use the <b>evt_status</b> info-tag to determine the authorization status (whether it succeeded or failed).
ev_authenticate_done	Confirms the completion of the authentication command. You can use the <b>evt_status</b> info-tag to determine the authentication status (whether it succeeded or failed).
ev_call_timer0	Indicates that the call-level timer expired.
ev_collectdigits_done	Confirms the completion of the <b>leg collectdigits</b> command on the call leg. You can then use the <b>evt_status</b> info-tag to determine the status of the command completion. You can use the <b>evt_dcdigits</b> info-tag to retrieve the collected digits.
ev_connected	An intermediate event generated by the <b>leg setup</b> or <b>leg setup_continue</b> commands to set up a call.  If the <b>callinfo</b> parameter, <b>notifyEvents</b> , is specified, the script receives an <b>ev_connected</b> message when the system receives a connect event from the destination switch.  If this event is an intercepted event, the application needs to use the <b>leg setup_continue</b> command to allow the system to continue with the setup.
ev_consult_request	Indicates a call-transfer consultation-id request from an endpoint.
ev_consult_response	Indicates a response to the <b>leg consult request</b> command. For return codes, see <a href="#">Consult Status</a> under <a href="#">Status Codes</a> .
ev_consultation_done	Indicates the completion of a <b>leg consult response</b> command. For return codes, see <a href="#">Consult Response</a> under <a href="#">Status Codes</a> .
ev_create_done	Confirms the completion of the <b>connection create</b> command. You can use the <b>evt_connection</b> info-tag to determine the ID of the completed connection.
ev_destroy_done	Confirms the completion of the <b>connection destroy</b> command. You can use the <b>evt_connection</b> info-tag to determine the ID of the connection that was destroyed.
ev_digit_end	Indicates that a digit key is pressed and released. You can use the <b>evt_digit</b> info-tag to determine which digit was pressed. You can use the <b>evt_digit_duration</b> info-tag to determine how long (in seconds) the digit was pressed and to detect long pounds or long digits.
ev_disconnect_done	Indicates that the call leg has been cleared.
ev_disconnected	Indicates that one of the call legs needs to disconnect. On receiving this event, the script must issue a <b>leg disconnect</b> on that call leg. You can use the <b>evt_legs</b> info-tag to determine which call leg disconnected.
ev_disc_prog_ind	Indicates that a DISC/PI message is received at a call leg.
ev_facility	Indicates a response to a <b>leg facility</b> command.
ev_grab	Indicates that an application that called this script is requesting that the script return the call leg. The script receiving this event can clean up and return the leg with a <b>handoff return</b> command. Whether this is done is at the discretion of the script receiving the <b>ev_grab</b> event.
ev_hookflash	Indicates a hook flash (such as a quick onhook-offhook in the middle of a call), assuming that the underlying platform or interface supports hook flash detection.
ev_handoff	Indicates that the script received one or more call legs from another application. When the script receives this event, you can use the <b>evt_legs</b> and the <b>evt_connections</b> info-tags to obtain a list of the call legs and connection IDs that accompanied the <b>ev_handoff</b> event.
ev_leg_timer	

	Indicates that the leg timer expired. You can use the <code>evt_legs</code> info-tag to determine which leg timer expired.
<code>ev_media_done</code>	Indicates that the prompt playout either completed or failed. You can use the <code>evt_status</code> info-tag to determine the completion status.
<code>ev_proceeding</code>	<p>An intermediate event generated by the <b>leg setup</b> or <b>leg setup_continue</b> commands to set up a call.</p> <p>If the <code>callinfo</code> parameter, <code>notifyEvents</code>, is specified, the script receives an <code>ev_proceeding</code> message when the system receives a proceeding event from the remote end.</p> <p>If this event is an intercepted event, the application needs to use the <b>leg setup_continue</b> command to allow the system to continue with the setup.</p>
<code>ev_progress</code>	<p>An intermediate event generated by the <b>leg setup</b> or <b>leg setup_continue</b> commands to set up a call.</p> <p>If the <code>callinfo</code> parameter, <code>notifyEvents</code>, is specified, the script receives an <code>ev_progress</code> message when the system receives a progress event from the destination switch.</p> <p>If this event is an intercepted event, the application needs to use the <b>leg setup_continue</b> command to allow the system to continue with the setup.</p>
<code>ev_returned</code>	Indicates that a call leg that was sent to another application (using <b>handoff callappl</b> ) has been returned. This event can be accompanied by one or more call legs that were created by the called application. When the script receives this event, you can use the <code>evt_legs</code> and the <code>evt_connections</code> info-tags to obtain a list of the call legs and connection IDs that accompanied the <code>ev_returned</code> event. You can use the <code>evt_iscommand_done</code> info-tag to verify that all of the call legs sent have been accounted for, meaning that the <b>handoff callappl</b> command is complete.
<code>ev_setup_done</code>	Indicates that the <b>leg setup</b> command has finished. You can then use the <code>evt_status</code> info-tag to determine the status of the command completion (whether the call was successfully set up or failed for some reason).
<code>ev_setup_indication</code>	Indicates that the system received a call. This event and the <code>ev_handoff</code> event are the events that initiate an execution instance of a script.
<code>ev_transfer_request</code>	Indicates a call transfer from an endpoint to the application.
<code>ev_transfer_status</code>	An intermediate event generated by the <b>leg setup</b> command. If specified in the <code>callinfo</code> parameter, <code>notifyEvents</code> , the script receives an <b>ev_transfer_status message</b> . The <code>evt_status</code> information tag would then contain the status value of the call transfer.
<code>ev_vxmldialog_done</code>	Received when the VXML dialog completes. This could be because of a VXML dialog executing an <code>&lt;exit/&gt;</code> tag or interpretation completing the current document without a transition to another document. The dialog could also complete due to an interpretation failure or a document error. This completion status is also available through the <code>evt_status</code> info-tag.
<code>ev_vxmldialog_event</code>	Received by the Tcl IVR application when the VXML dialog initiated on a leg executes a <code>sendevent</code> object tag. The VXML subevent name is available through the <code>evt_vxmlevent</code> info-tag. All events thrown from the dialog markup are of the form <code>vxml.dialog.*</code> . All events generated by the system—perhaps as an indirect reaction to the VXML document executing a certain tag or throwing a certain event like the

dialog completion event- are of the form vxml.session.*.
--

## Status Codes

The evt\_status info-tag returns a status code for the event received. This sections lists the possible status codes and their meaning.

Status codes are grouped according to function. The first two characters of the status code indicate the grouping.

- au-Authentication status
- ao-Authorization status
- cd-Digit collection status
- cr-Consult response
- cs-Consult status
- di- Disconnect cause
- fa-Facility
- ft-Feature type
- ls-Leg setup status
- ms-Media status
- ts-Transfer status
- vd-Voice dialog completion status

### Authentication Status

Authentication status is reported in au\_>xxx format:

Value for xxx	Description
000	Authorization was successful.
001	Authorization error.
002	Authorization failed.

### Authorization Status

Authorization status is reported in ao\_>xxx format:

Value for xxx	Description
000	Authorization was successful.
001	Authorization error.
002	Authorization failed.

### Digit Collection Status

Digit collection status is reported in **cd\_**xxx format:

Value for xxx	Description
001	The digit collection timed out, because no digits were pressed and not enough digits were collected for a match.
002	The digit collection was aborted, because the user pressed an abort key.
003	The digit collection failed, because the buffer overflowed and not enough digits were collected for a match.
004	The digit collection succeeded with a match to the dial plan.
005	The digit collection succeeded with a match to one of the patterns.
006	The digit collection failed because the number collected was invalid.
007	The digit collection was terminated because an ev_disconnected event was received on the call leg.
008	The digit collection was terminated because an ev_grab event was received on the call leg.
009	The digit collection successfully turned on digit reporting to the script.
010	The digit collection was terminated because of an unsupported or unknown feature or event.

## Consult Response

Feature type is reported in **cr\_xxx** format:

Value for xxx	Description
000	Success
001	Failed, invalid state
002	Failed, timeout
003	Failed, abandon
004	Failed, protocol error

## Consult Status

Feature type is reported in **cs\_xxx** format:

Value for xxx	Description
000	Consultation success, consult-id available
001	Consultation failed, request timeout
002	Consultation failed
003	Consultation failed, request rejected
004	Consultation failed, leg disconnected
005	Consultation failed, operation unsupported

## Disconnect Cause

Disconnect causes use the format **di\_xxx** where xxx is the Q931 cause code. Possible values are:

Value for xxx	Description
---------------	-------------

000	Uninitialized
001	Unassigned number
002	No route to the transit network
003	No route to the destination
004	Send information tone
005	Misdialed trunk prefix
006	Unacceptable channel
007	Call awarded
008	Preemption
009	Preemption reserved
016	Normal
017	Busy
018	No response from the user
019	No answer from the user
020	Subscriber is absent
021	Call rejected
022	Number has changed
026	Selected user is clearing
027	Destination is out of order
028	Invalid number
029	Facility rejected
030	Response to status inquiry
034	No circuit available
035	Requested VPCI VCI is not available
036	VPCI VCI assignment failure
037	Cell rate is not available
038	Network is out of order
039	Permanent frame mode is out of service
040	Permanent frame mode is operational
041	Temporary failure
042	Switch is congested
043	Access information has been discarded
044	No required circuit
045	No VPCI VCI is available
046	Precedence call blocked
047	No resource available
048	DSP error
049	QoS is not available
050	Facility is not subscribed
053	Outgoing calls barred
055	Incoming calls barred
057	Bearer capability is not authorized
058	Bearer capability is not available
062	Inconsistency in the information and class

063	Service or option not available
065	Bearer capability is not implemented
066	Change type is not implemented
069	Facility is not implemented
070	Restricted digital information only
079	Service is not implemented
081	Invalid call reference value
082	Channel does not exist
083	Call exists and call ID in use
084	Call ID in use
085	No call suspended
086	Call cleared
087	User is not in CUG
088	Incompatible destination
090	CUG does not exist
091	Invalid transit network
093	AAL parameters not supported
095	Invalid message
096	Mandatory information element (IE) is missing
097	Message type is not implemented
098	Message type is not compatible
099	IE is not implemented
100	Invalid IE contents
101	Message in incomplete call state
102	Recovery on timer expiration
103	Nonimplemented parameter was passed on
110	Unrecognized parameter message discarded
111	Protocol error
127	Internetworking error
128	Next node is unreachable
129	Holst Telephony Service Provider Module (HTSPM) is out of service
160	DTL transit is not my node ID

## Facility

Leg setup requesting address resolution status is reported in **fa\_xxx** format:

Value for xxx	Description
000	supplementary service request succeeded
003	supplementary service request unavailable
007	supplementary service was invoked in an invalid call state
009	supplementary service was invokes in a non-incoming call leg
010	supplementary service interaction is not allowed

050	MCID service is not subscribed
051	MCID request timed out
052	MCID is not configured for this interface

## Feature Type

Feature type is reported in **ft\_**xxx format:

Value for xxx	Description
001	Fax
002	Modem
003	Modem_phase
004	Hookflash
005	OnHook
006	OffHook

## Leg Setup Status

Leg setup status is reported in **ls\_**xxx format:

Value for xxx	Description
000	The call is active or was successful.
001	The outgoing call leg was looped.
002	The call setup timed out (meaning that the destination phone was alerting, but no one answered). The limit of this timeout can be specified in the <b>leg setup</b> command.
003	The call setup failed because of a lack of resources in the network.
004	The call setup failed because of an invalid number.
005	The call setup failed for reasons other than a lack of resources or an invalid number.
006	Unused; setup failure.
007	The destination was busy.
008	The incoming side of the call disconnected.
009	The outgoing side of the call disconnected.
010	The conferencing or connecting of the two call legs failed.
011	Supplementary services internal failure
012	Supplementary services failure
013	Supplementary services failure. Inbound call leg was disconnected.
014	The call was handed off to another application.
015	The call setup was terminated by an application request.
016	The outgoing called number was blocked.
026	Leg redirected
031	Transfer request acknowledge
032	Transfer target alerting (future SIP use)
033	Transfer target trying (future SIP use)



040	Transfer success
041	Transfer success with transfer-to party connected (SIP only)
042	Transfer success unacknowledged (SIP only)
050	Transfer fail
051	Transfer failed, bad request (SIP only)
052	Transfer failed, destination busy
053	Transfer failed, request cancelled
054	Transfer failed, internal error
055	Transfer failed, not implemented (SIP only)
056	Transfer failed, service unavailable or unsupported
057	Transfer failed, leg disconnected
058	Transfer failed, multiple choices (SIP only)
059	Transfer failed, timeout; no response to transfer request

## Media Status

Media status is reported in **ms\_xyy** format:

<b>x indicates the command</b>		<b>yy indicates the status of the command</b>	
<b>Value for x</b>	<b>Description</b>	<b>Value for yy</b>	<b>Description</b>
0	Status for a <b>media play</b> command.	00	The command was successful and the prompt finished.
1	Status for a media record command.	01	Failure
2	Status for a <b>media stop</b> command.	02	Unsupported feature or request
3	Status for a <b>media pause</b> command.	03	Invalid host or URL specified
4	Status for a <b>media resume</b> command.	04	Received disconnected
5	Status for a <b>media seek</b> command to forward.	05	The prompt was interrupted by a key press.
6	Status for a <b>media seek</b> command to rewind.		

## Transfer Status

Transfer status is reported in **ts\_xxx** format:

<b>Value for xxx</b>	<b>Description</b>
000	Generic transfer success
001	Transfer success, transfer-to party is alerting
002	Transfer success, transfer-to party is answered
003	Transfer finished; however, the result of the transfer is not guaranteed
004	Transfer request is accepted

005	Transferee is trying to reach transfer-to party
006	Transfer request is rejected by transferee
007	Invalid transfer number
008	Transfer-to party unreachable
009	Transfer-to party is busy

## VoiceXML Dialog Completion Status

VoiceXML dialog completion status is reported in vd\_xxx format:

<b>Value for xxx</b>	<b>Description</b>
000	Normal completion because of the <exit> tag or execution reaching the end of the document.
001	Termination because of the default VXML event handling requiring VXML termination.
002	Terminated by the Tcl IVR application.
003	Internal failure.