

Welcome to **Cisco DocWiki**. We encourage [registered Cisco.com users](#) to contribute to this wiki to improve Cisco product documentation. Note that you cannot log in to DocWiki with Cisco.com "guest" account credentials.

See [Terms of Use](#) and [About DocWiki](#) for more information about Cisco DocWiki.

Select the "edit" tab to edit an article or select the "discussion" tab to submit questions or comments about the article.

Click [here](#) to return to the Cisco ONS 15400 Series documentation on www.cisco.com.

Contents

- [1](#)
[Audience](#)
- [2](#)
[Organization](#)

Audience

To use this publication, you should be familiar with Cisco or equivalent optical transmission hardware and cabling, telecommunications hardware and cabling, electronic circuitry and wiring practices, and preferably have experience as a telecommunications technician.

Organization

This book is organized into the following sections:

[Preface](#)

[ML-Series Card Overview](#)

[CTC Operations](#)

[Initial Configuration](#)

[Configuring Interfaces](#)

[Configuring POS](#)

[Configuring Bridges](#)

[Configuring STP and RSTP](#)

[Configuring VLANs](#)

Contents

[Configuring IEEE 802.1Q Tunneling and Layer 2 Protocol Tunneling](#)

[Configuring Link Aggregation](#)

[Configuring Networking Protocols](#)

[Configuring IRB](#)

[Configuring VRF Lite](#)

[Configuring Quality of Service](#)

[Configuring the Switching Database Manager](#)

[Configuring Access Control Lists](#)

[Configuring Cisco Proprietary Resilient Packet Ring](#)

[Configuring IEEE 802.17b Resilient Packet Ring](#)

[Configuring Ethernet over MPLS](#)

[Configuring Security for the ML-Series Card](#)

[CE-Series Ethernet Cards](#)

[POS on ONS Ethernet Cards](#)

[Configuring RMON](#)

[Configuring SNMP](#)

[E-Series and G-Series Ethernet Operation](#)

[Configuring CDP](#)

[Configuring CPP](#)

[Configuring Ethernet Virtual Circuits](#)

[Command Reference](#)

[Unsupported CLI Commands](#)

[Using Technical Support](#)