

Cisco Unified MeetingPlace Release 6.1 > Web Conferencing > Configuring > Configuring the Web Conferencing Server

- Using the NTP Configuration Feature
- Configuring the Time Zone

## Contents

- 1 Using the NTP Configuration Feature
  - ◆ 1.1 Before You Begin
  - ◆ 1.2 Restrictions
  - ◆ 1.3 Procedure
- 2 Configuring the Time Zone
  - ◆ 2.1 Procedure

## Using the NTP Configuration Feature

Cisco Unified MeetingPlace Web Conferencing automatically sets up the Windows operating system to use the Windows Time Service to synchronize its clock with the NTP server. This keeps the web server synchronized with the Cisco Unified MeetingPlace Audio Server.

**Note:** By default, NTP uses UDP port 123. If your web server is in the DMZ and your Audio Server is not, you will have to open UDP port 123 in your firewall for the default NTP configuration to work. The default configuration is the web server synchronizing with the Audio Server as the NTP server.

You can also use an alternate NTP server instead of the Cisco Unified MeetingPlace Audio Server. Complete this procedure to configure your system with an alternate NTP server.

**Note:** If you decide to use an alternate NTP server for your web server time synchronization, make sure that your NTP setup keeps the Cisco Unified MeetingPlace Audio Server and web server perfectly in sync. If the two servers are not time-synchronized, certain features will not work.

### Before You Begin

Stop the Cisco Unified MeetingPlace Web Conferencing master service before you adjust the system clock time or perform a manual NTP synchronization.

### Restrictions

Do not adjust the clock on the Windows computer while the web conferencing application is running on the system.

### Procedure

1. Shut down the Cisco Unified MeetingPlace Web Conferencing master service.
2. Double-click the Window Time icon on the Windows system tray.
3. Choose the **Internet Time** tab.
4. Choose to automatically synchronize with an Internet time server.
5. Specify your server name inside the **Server:** field.

We highly recommend that you manually verify that the clocks on the Cisco Unified MeetingPlace Audio Server and your web server are synchronized. Use the **date** command on the Audio Server to obtain the current date and time. For more information, see [Details of Technician Commands](#).

## Configuring the Time Zone

If the Windows time zone does not match the Cisco Unified MeetingPlace Web Conferencing server time zone, you must correct this discrepancy. The time zones may not match because you forgot to set the correct Windows time zone before installing Cisco Unified MeetingPlace Web Conferencing or because you have to relocate your Cisco Unified MeetingPlace Web Conferencing server from one time zone to another and you need to change the Windows time zone as part of this relocation.

To determine whether the time zones match, open the Cisco Unified MeetingPlace Web Conferencing log, called GWSIM\_eventlog\_XXX.txt, and search for the string "time zone".

If the time zones are the same, you will see a message similar to this:

```
Information: CompareTimeZone: Time Zones are the same between Cisco
Unified MeetingPlace Web Conferencing and Breeze. Cisco Unified
MeetingPlace Web Conferencing: (GMT-08) Pacific Standard Time and Breeze:
(GMT-08:00) Pacific Time (US)
```

If the time zones are not the same, the system logs an error and you see a message similar to this:

```
MasterSvc Error: **** Time Zones are NOT matching between Cisco Unified
MeetingPlace Web Conferencing and Breeze. Time Zone Offset-- Cisco
Unified MeetingPlace Web Conferencing: GMT:+01 Breeze: GMT:-08
```

To change the time zone, follow these instructions:

### Restrictions

## Procedure

1. Stop the Cisco Unified MeetingPlace Web Conferencing master service on all Cisco Unified MeetingPlace Web Conferencing servers that use the same database.
2. Open the SQL Server Query Analyzer on the machine where the Cisco Unified MeetingPlace Web Conferencing SQL database is located by following these steps:
  1. Click **start > Programs > Microsoft SQL Server > Query Analyzer**.
  2. In the SQL Server field, choose **(local)**.
  3. Select **SQL Server authentication**.
  4. Enter the login name of "sa" and the password.
  5. Click **OK**.
3. Click **Query > Change Database**.
4. Highlight the name of the slave database (such as MPWEB\_XXXX\_XXXX), and click **OK**.
5. Enter the following SQL string:

```
select * from PPS_ENUM_TIME_ZONES
```
6. Click **Execute Query**.
7. Look through the time zone records and find your time zone ID from the TIME\_ZONE\_ID field.
8. Clear the command window by entering:

```
UPDATE PPS_ACL_PREFERENCES SET TIME_ZONE_ID = <
local_machine_timezone_id >
where <local_machine>timezone_id> is the time zone ID of the local machine.
```
9. Click **Execute Query**.
10. Start the Cisco Unified MeetingPlace Web Conferencing service on all Cisco Unified MeetingPlace Web Conferencing servers.