

**Main page:** [Cisco Unified MeetingPlace, Release 8.0](#)

**Back to:** [Configuration](#)

**Back to:** [Maintenance](#)

**Note:** This topic does *not* apply to deployments in which users schedule meetings from the Cisco WebEx site. For information about Cisco WebEx integration deployments, see the *Planning Guide for Cisco Unified MeetingPlace* at [http://docwiki.cisco.com/wiki/Cisco\\_Unified\\_MeetingPlace%2C\\_Release\\_8.0\\_--\\_Planning\\_Your\\_Deployment](http://docwiki.cisco.com/wiki/Cisco_Unified_MeetingPlace%2C_Release_8.0_--_Planning_Your_Deployment).

We recommend that you monitor heavily used systems at short intervals, such as biweekly or weekly. Monitor systems with lighter use less frequently, such as once a month.

- [IIS File Deletion](#)
- [Checking the Versions of Local Cisco Unified MeetingPlace Web Server Modules](#)
- [How to Schedule a Maintenance Window](#)
- [Optimizing the Performance of a Web Server](#)
- [Rebooting the Server](#)
- [How to Monitor Cisco Unified MeetingPlace Web Server Activities](#)
- [How to Configure the Lumberjack Logging Utility](#)
- [How to Switch the Order of IP Addresses on the Web Server](#)
- [Changing Server IP Addresses and Hostnames](#)

## Contents

- [1 IIS File Deletion](#)
- [2 Checking the Versions of Local Cisco Unified MeetingPlace Web Server Modules](#)
  - ◆ [2.1 Procedure](#)
- [3 How to Schedule a Maintenance Window](#)
  - ◆ [3.1 Reserve All Ports Meetings](#)
    - ◇ [3.1.1 Related Topics](#)
  - ◆ [3.2 Scheduling a Maintenance Window](#)
    - ◇ [3.2.1 Before You Begin](#)
    - ◇ [3.2.2 Procedure](#)
- [4 Optimizing the Performance of a Web Server](#)
  - ◆ [4.1 Procedure](#)
  - ◆ [4.2 Related Topics](#)
- [5 Rebooting the Server](#)
  - ◆ [5.1 Procedure](#)
- [6 How to Monitor Cisco Unified MeetingPlace Web Server Activities](#)
  - ◆ [6.1 Related Topics](#)
  - ◆ [6.2 Using the Cisco Unified MeetingPlace Eventlog](#)
    - ◇ [6.2.1 Procedure](#)
  - ◆ [6.3 Running the Windows Performance Monitoring Tool](#)

- ◇ [6.3.1 Procedure](#)
  - ◇ [6.3.2 Related Topics](#)
- ◆ [6.4 Viewing an Event with the Windows Event Viewer](#)
  - ◇ [6.4.1 Procedure](#)
- [7 How to Configure the Lumberjack Logging Utility](#)
  - ◆ [7.1 Lumberjack Logging Utility](#)
  - ◆ [7.2 Configuring Lumberjack on the Cisco Unified MeetingPlace Web Server](#)
    - ◇ [7.2.1 Before You Begin](#)
    - ◇ [7.2.2 Procedure](#)
    - ◇ [7.2.3 Related Topics](#)
  - ◆ [7.3 Manually Generating a Lumberjack Snapshot](#)
    - ◇ [7.3.1 Procedure](#)
- [8 How to Switch the Order of IP Addresses on the Web Server](#)
  - ◆ [8.1 Changing the Binding Order for a System with One IP Address on Each NIC](#)
    - ◇ [8.1.1 Procedure](#)
    - ◇ [8.1.2 What to Do Next](#)
  - ◆ [8.2 Changing the Binding Order for a System with Two IP Addresses on One NIC](#)
    - ◇ [8.2.1 Procedure](#)
    - ◇ [8.2.2 What to Do Next](#)
  - ◆ [8.3 Making the Change in the Application](#)
    - ◇ [8.3.1 Before You Begin](#)
    - ◇ [8.3.2 Procedure](#)
    - ◇ [8.3.3 Related Topics](#)
- [9 Changing Server IP Addresses and Hostnames](#)
  - ◆ [9.1 Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
    - ◇ [9.1.1 Related Topics](#)
    - ◇ [9.1.2 Removing the Connection to the Application Server](#)
      - [9.1.2.1 Procedure](#)
      - [9.1.2.2 Related Topics](#)
    - ◇ [9.1.3 Changing the IP Address or Hostname of the Application Server](#)
      - [9.1.3.1 Procedure](#)
      - [9.1.3.2 Related Topics](#)
    - ◇ [9.1.4 Changing the Domain Name of the Application Server](#)
      - [9.1.4.1 Procedure](#)
      - [9.1.4.2 Related Topics](#)
    - ◇ [9.1.5 Changing the IP Address for a Domain Name Server or a Network Time Protocol Server](#)
      - [9.1.5.1 Procedure](#)
      - [9.1.5.2 Related Topics](#)
    - ◇ [9.1.6 Updating DNS Entries](#)
      - [9.1.6.1 Procedure](#)
      - [9.1.6.2 Related Topics](#)
    - ◇ [9.1.7 Re-establishing a Connection to an Application Server](#)
      - [9.1.7.1 Procedure](#)
      - [9.1.7.2 What to Do Next](#)
      - [9.1.7.3 Related Topics](#)
  - ◆ [9.2 Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
    - ◇ [9.2.1 Related Topics](#)
    - ◇ [9.2.2 Changing IP Addresses and Hostnames for the Replicated Application Servers](#)
      - [9.2.2.1 Procedure](#)
      - [9.2.2.2 Related Topics](#)

- ◇ [9.2.3 Turning on Replication](#)
  - [9.2.3.1 Procedure](#)
  - [9.2.3.2 Related Topics](#)
- ◆ [9.3 Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
  - ◇ [9.3.1 Related Topics](#)
  - ◇ [9.3.2 Entering Updated Hostnames and IP Addresses on Cisco WebEx Nodes for MCS](#)
    - [9.3.2.1 Procedure](#)
    - [9.3.2.2 Related Topics](#)
  - ◇ [9.3.3 Updating the Cisco WebEx Site](#)
    - [9.3.3.1 Procedure](#)
    - [9.3.3.2 Related Topics](#)
- ◆ [9.4 Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)
  - ◇ [9.4.1 Related Topics](#)
  - ◇ [9.4.2 Turning Off SSL on Internal and External Cisco Unified MeetingPlace Web Servers](#)
    - [9.4.2.1 Procedure](#)
    - [9.4.2.2 Related Topics](#)
  - ◇ [9.4.3 Turning Off SMA for Cisco Unified MeetingPlace Web Server](#)
    - [9.4.3.1 Procedure](#)
    - [9.4.3.2 Related Topics](#)
  - ◇ [9.4.4 Turning On SMA for Cisco Unified MeetingPlace Web Server](#)
    - [9.4.4.1 Procedure](#)
    - [9.4.4.2 Related Topics](#)

## IIS File Deletion

IIS file deletion is optional. If you want to clean up the IIS web server, then understand the following:

- Deleting the default SMTP virtual server or the Administration website in IIS does not have any effect on the Cisco Unified MeetingPlace web user portal.
- Subfolders under wwwroot, such as images, \_private, \_vti\_cnf, \_vti\_log, \_vti\_pvt, \_vti\_script and \_vti\_txt folders all come from Microsoft FrontPage. Deleting these subfolders can cause difficulty with Microsoft FrontPage when publishing to that server.
- Parent Paths are enabled in the Default website, the MPWeb virtual directory and the cgi-bin virtual directory. Enabling Parent Paths allows anonymous users to use `..` to move from the current directory to the parent. Disable this function to prevent such users from traversing the directory tree.

## Checking the Versions of Local Cisco Unified MeetingPlace Web Server Modules

Complete this procedure to check the release number of most local Cisco Unified MeetingPlace Web Server software modules. Releases of all listed modules, with the exception of Gateway SIM, must match, that is, 8.0.x.x, where x.x is the same across all modules.

**Procedure**

1. Sign in to the Cisco Unified MeetingPlace web user portal.
2. Click **Admin**.
3. Click **Versions**.
4. Review your module versions.
5. Click **Back** to return to the main Administration screen.

**How to Schedule a Maintenance Window**

- [Reserve All Ports Meetings](#)
- [Scheduling a Maintenance Window](#)

**Reserve All Ports Meetings**

When you need to schedule time to perform upgrades or other maintenance activities to the Cisco Unified MeetingPlace system, schedule a Reserve All Ports meeting. When you schedule a Reserve All Ports meeting, the Cisco Unified MeetingPlace system performs the following actions:

- Reserves all available ports, or the maximum number of user licenses available in the system
- Blocks out all new callers for the duration of the scheduled meeting
- Prohibits the extension of in-session meetings that began before the Reserve All Ports meeting begins

Reserve All Ports meetings are scheduled, private meetings. The meeting attributes are the same as for scheduled meetings, with the exceptions described in the following table.

<b>Attribute</b>	<b>Value</b>
Frequency	Once
# of calling sites	SysMaintenance
Record meeting?	No
Meeting name	SysMaintenance
Meeting type	All Speaker

**Related Topics**

- [Scheduling a Maintenance Window](#)

## Scheduling a Maintenance Window

**Caution!** As a system administrator, it is your responsibility to ensure that no regular meetings are scheduled before scheduling a Reserve All Ports meeting.

**Caution!** Reserve All Ports meetings prevent the system from scheduling any meetings. Also, during a Reserve All Ports meeting, no prompts are played to alert users to the situation. For these reasons, we strongly recommend that you schedule Reserve All Ports meetings during the lowest usage times. In addition, be sure to cancel any Reserve All Ports meetings that you later determine you do not need.

### Before You Begin

Remember the following information:

- You cannot extend a scheduled Reserve All Ports meeting, but you can reschedule the meeting.
- Only one Reserve All Ports meeting can be scheduled at a time (one Reserve All Ports meeting must be finished or deleted before another can be scheduled).
- If a Reserve All Ports meeting overlaps another scheduled meeting that is then canceled, the Reserve All Ports meeting reserves the ports released by the other meeting.
- Scheduled Reserve All Ports meetings appear in the server exception log, and any changes to a meeting (such as deleting or rescheduling) are shown in the log.
- If callers dial in to the server while a Reserve All Ports meeting is in session (and all ports are reserved), they hear nothing (silence).
- The meeting ID for a Reserve All Ports meeting cannot be changed.

### Procedure

1. Sign in to the Cisco Unified MeetingPlace web user portal with an administrator profile.
2. Click **Schedule Meeting**.
3. Enter your date, time, and duration of your maintenance window.
4. Click **More Options**.
5. Check **Reserve all ports meeting**.
6. Click **Submit**.
7. Click **Schedule**.

## Optimizing the Performance of a Web Server

### Procedure

1. Sign in to the Cisco Unified MeetingPlace web user portal.
2. Click **Admin**.
3. Click **Web Server**.  
Scroll down to the "View" section of the page.
4. Click the name of the Web Server that you want to configure.  
Information about this Web Server populates the "Edit" section of the page.
5. Select the setting that best describes your conferencing environment for **Performance Tuning**.

**Note:** Setting this parameter to the highest level on a computer with inadequate hardware results in poor user performance.

6. Click **Submit**.

#### Related Topics

- [Field Reference: Web Server Specific Fields](#) in the [Web Administration References for Cisco Unified MeetingPlace](#) module

## Rebooting the Server

Complete the following procedure to shut down and restart the Web Server computer from the Web Administration.

#### Procedure

1. Sign in to the Cisco Unified MeetingPlace web user portal.
2. Click **Admin**.
3. Click **Reboot Server**.
4. Click **OK** to confirm the reboot.  
The system shuts down and restarts.

## How to Monitor Cisco Unified MeetingPlace Web Server Activities

The Windows Event Viewer application and the Cisco Unified MeetingPlace Eventlog application both log all Web Server activities. You can use these logs to monitor or troubleshoot the Cisco Unified MeetingPlace Web Server.

- [Using the Cisco Unified MeetingPlace Eventlog](#)
- [Running the Windows Performance Monitoring Tool](#)
- [Viewing an Event with the Windows Event Viewer](#)

#### Related Topics

- [Using Alarms and Logs on Cisco Unified MeetingPlace](#) module
- [How to Configure the Lumberjack Logging Utility](#)

## Using the Cisco Unified MeetingPlace Eventlog

The Eventlog application logs all activities specific to Cisco Unified MeetingPlace Web Master Service.

#### Procedure

### Procedure

1. Right-click the Cisco Unified MeetingPlace icon in the system tray.
2. Select **Eventlog**.  
A DOS command window will open that will contain a view of the latest log messages, which will update as new log messages are generated.

## Running the Windows Performance Monitoring Tool

Complete this procedure to monitor the Cisco Unified MeetingPlace Web Server software performance object in the Windows performance monitoring tool.

### Procedure

1. Click **Start > Run**.  
The Run window displays.
2. Enter **Perfmon**.  
The Performance window displays.
3. Click the Add (+) button.  
The Add Counters window displays.
4. Locate the Performance object field.
5. Select **MeetingPlace Web Server**.  
If your system was upgraded from Release 7.0 to Release 8.0, then select **MeetingPlace Web Conferencing** instead.
6. Select to add or explain specific counters.
  - ◆ Click a counter from the list and click **Explain** to get more information about it.
  - ◆ Click a counter from the list and click **Add** to enable it.

### Related Topics

- [Counters Available in the Cisco Unified MeetingPlace Performance Object in the Web Administration References for Cisco Unified MeetingPlace module](#)

## Viewing an Event with the Windows Event Viewer

The application log provides detailed information about the Cisco Unified MeetingPlace Web Master Service. For more information about the Windows Event Viewer, see your Windows documentation.

**Procedure**

1. Click **Start > Control Panel > Administrative Tools > Event Viewer**.
2. Select **Application** from the left pane.  
A list of events appear in the right pane.
3. Double-click the event to view it.

## How to Configure the Lumberjack Logging Utility

Lumberjack is a logging utility that runs as a background thread. Lumberjack periodically dumps several logs at 24-hour intervals and stores those logs, as well as a specified number of older logs, in a configurable location. All the configuration settings are stored in the registry and worked in to the current registry setting structure of Cisco Unified MeetingPlace. Performance monitor logging configuration settings are stored in definition INI file, so counter list and logging interval can be easily changed.

- [Lumberjack Logging Utility](#)
- [Configuring Lumberjack on the Cisco Unified MeetingPlace Web Server](#)
- [Manually Generating a Lumberjack Snapshot](#)

### Lumberjack Logging Utility

Upon startup of the master service, a new thread for Lumberjack begins. Lumberjack reads the configuration values from the registry and INI file to determine behavior. If a performance monitor definition INI file does not exist, Lumberjack automatically creates a file with a predefined counter list and logging interval by using the Lumberjack default values.

Every 24 hours, Lumberjack creates a new Gateway SIM event log for a 24-hour window. If the eventlog terminates before midnight, Lumberjack restarts it. If the event log runs past midnight of the day that the first call was made, Lumberjack terminates that process. During routing log gathering, Lumberjack also acquires the following information:

- Performance monitor (24-hour window)
- NT Application and System eventlog
- Registry snapshots
- IIS Log

When the master service is running and Lumberjack is enabled, it detects stopped (crashed) services. and collects the following information in a temp folder in the windows temp directory:

- GWSIM eventlog (24 hour window)
- NT Application and System eventlog
- Registry snapshots
- IIS log
- DrWtsn.log and User.dmp
- .exe, .map, and .pdb of downed services
- binaries for authfilt.dll (if downed IIS)



After the information is collected, Lumberjack bundles the files by using pkzipc.exe. This executable file is distributed with MPWEB and located in the DataSvc folder.

The naming convention for the file is `lumberjack_timestamp.zip` for routine logs and `lumberjackCrash_timestamp.zip` for crash logs, where *timestamp* is the time the log gathering started for routine logs and the time of the detected crash for crash logs.

If the master service is simply stopped, the temp directory that is created for routine logs is not deleted so that the logs for one day are bundled together if there is a restart of the master service. This functionality enables the logs that are captured to be reviewed without having to open a zip file and allows for a quicker shutdown and restart of master service because the service does not have to wait to zip files and remove the directory.

## Configuring Lumberjack on the Cisco Unified MeetingPlace Web Server

### Before You Begin

Read the [Lumberjack Logging Utility](#).

### Procedure

1. Select **Start > Run**.  
The Run window displays.
2. Enter **regedit**.
3. Change your registry settings for key `HKLM\Software\Latitude\MeetingPlace WebPublisher\General\` and for key `HKLM\Software\Latitude\MeetingPlace Gateway SIM\General\` as shown in the following table:

Name (Type)	Description	Data and Default
<b>Key: HKLM\Software\Latitude\MeetingPlace WebPublisher\General\</b>		
Server Logging (DWORD)	Enables and disables Lumberjack.	0 - Disabled 1 - Enabled Default is 1.
Log Crash History (DWORD)	Specifies the number of old crash logs to store.	Default is 10.
Log History (DWORD)	Specifies the number of old routine logs to store.	Default is 15.
Log Location (String)	Specifies where to store the .zip files containing logs.	Default is <code>install-location\Cisco Systems\LogFiles</code> .

InstallLocation (String)	Used for gathering .dll, .exe, .map, and .pdb files.	Default is set by the Cisco Unified MeetingPlace Web Server software.
Key: <b>HKLM\Software\Latitude\MeetingPlace Gateway SIM\General\</b>		
InstallLocation (String)	Used for running Gateway SIM eventlog.	Default is set by Gateway SIM.

#### Related Topics

- [Stopping, Starting, or Restarting the Cisco Unified MeetingPlace Web Master Service module](#)

## Manually Generating a Lumberjack Snapshot

Logs gathered because of a manual snapshot request have the format lumberjackSnapshot\_\_*timestamp*.zip.

You can locate these logs either in the default LogFiles folder or in the folder that you specified when you completed the [Configuring Lumberjack on the Cisco Unified MeetingPlace Web Server](#).

#### Procedure

1. Right-click the Cisco Unified MeetingPlace red door icon on the Web Server.
2. Select **Capture Logs**.  
The snapshot log gathering process begins.

## How to Switch the Order of IP Addresses on the Web Server

This topic applies only if you upgraded from Release 7.0 to Release 8.0.

Based on the NIC binding order, the system assigns the first IP address to the [[Cisco Unified MeetingPlace Release 8.0 -- Web Administration References for Cisco Unified MeetingPlace#Hostname [Web Conferencing]]Hostname [Web Conferencing]] and the second IP address to the [[Cisco Unified MeetingPlace Release 8.0 -- Web Administration References for Cisco Unified MeetingPlace#Hostname [Home Page]]Hostname [Home Page]].

**Note:** If you ever change an IP address to a hostname or FQDN, be sure that you replace it with the hostname or FQDN corresponding to that IP address. Do not switch the order of the IP addresses or hostnames as this will cause problems.

If you want to switch the order of the IP addresses, complete the following in the order presented. Select the first or second topic based on your system configuration:

- [Changing the Binding Order for a System with One IP Address on Each NIC](#)

- [Changing the Binding Order for a System with Two IP Addresses on One NIC](#)
- [Making the Change in the Application](#)

## Changing the Binding Order for a System with One IP Address on Each NIC

Complete this procedure if you have one IP address on each NIC. If you do not, complete the [Changing the Binding Order for a System with Two IP Addresses on One NIC](#) instead.

### Procedure

1. On the Start menu, click **Settings > Control Panel > Network Connections**.
2. Click **Advanced > Advanced Settings**.
3. Change the order of the IP addresses/NICs by using the up and down arrows.

### What to Do Next

Proceed to the [Making the Change in the Application](#).

## Changing the Binding Order for a System with Two IP Addresses on One NIC

Complete this procedure if you have two IP addresses on a single NIC. If you do not, complete the [Changing the Binding Order for a System with One IP Address on Each NIC](#) instead.

### Procedure

1. Change the primary IP address to the virtual IP address.
2. Change the virtual IP address to the primary IP address.

### What to Do Next

Proceed to the [Making the Change in the Application](#).

## Making the Change in the Application

### Before You Begin

Depending on your system, complete one of the following:

- [Changing the Binding Order for a System with One IP Address on Each NIC](#)

- [Changing the Binding Order for a System with Two IP Addresses on One NIC](#)

#### Procedure

1. Sign in to the Cisco Unified MeetingPlace web user portal.
2. Click **Admin > Web Server**.
3. From the "View" section of the page, click the name of the web server that you want to configure.  
This populates the "Edit" section of the page with predefined settings.
4. Change the order of the IP addresses for the **Hostname [Home Page]** and the **Hostname [Web Conferencing]**.  
**Note:** The **Hostname [Web Conferencing]** field appears only if you upgraded from Release 7.0 to Release 8.0.
5. Restart the Cisco Unified MeetingPlace Web Master Service.

#### Related Topics

- [Stopping, Starting, or Restarting the Cisco Unified MeetingPlace Web Master Service module](#)

## Changing Server IP Addresses and Hostnames

This section describes how to change the IP address or a hostname for Cisco Unified MeetingPlace Application server, a Cisco Unified MeetingPlace Web Server, or a Hardware Media Server

### Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server

Use this table to go to the procedure you need to perform to change an IP address or hostname for a Web Server and a Cisco Unified MeetingPlace Application server in an audio-only deployment. After you complete each task, return to this table to complete the next task.

Task	Description	For details, see
1	Remove all connections from the Web Server to the Application Server	<a href="#">Removing the Connection to the Application Server</a>
2	On the Application Server you can change the hostname and IP address using the <b>net</b> command.	<a href="#">Changing the IP Address or Hostname of the Application Server</a>
3	You can change the domain name of the Application Server using the <b>net</b> command.	<a href="#">Changing the Domain Name of the Application Server</a>
4	On the Cisco Unified MeetingPlace Web Server, you can change the IP address for the Domain Name Server or a Network Time Protocol Server.	<a href="#">Changing the IP Address for a Domain Name Server or a Network Time Protocol Server</a>
5	You can update your Domain Name Server and Cisco Unified Call Manager with the new hostname and IP address of Application Server and Cisco Unified MeetingPlace Web	<a href="#">Updating DNS Entries</a>

	Server.	
6	Reconnect the Cisco Unified MeetingPlace Web Server to the Application Server.	<a href="#">Re-establishing a Connection to an Application Server</a>

## Related Topics

- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

## Removing the Connection to the Application Server

This procedure is completed on the Cisco Unified MeetingPlace Web Server.

### Procedure

1. Sign in to the Web Server.
2. Stop the web services and the Gateway SIM service, including the Replication Service and Agent Service.
3. Choose **Start > Programs > Cisco Unified MeetingPlace Configuration > Cisco Unified MeetingPlace Gateway Configuration** to open the Cisco Unified MeetingPlace Gateways Configuration utility.
4. Select the Gateway SIM tab.
5. Delete this unit from the active Application Server.
  - ◆ Go to the lower-left pane of the **Gateway SIM** tab.
  - ◆ Select the name of the Application Server that you want to disconnect from.
  - ◆ Select **Delete**.
6. Close the Cisco Unified MeetingPlace Gateways Configuration utility.
7. Change the IP address or host name of the Cisco Unified MeetingPlace Web Server.
8. Disable the usage of unused Web Server hostnames.
  - ◆ Sign in to the Administration Center.
  - ◆ Select **System Configuration > Web Servers**.
  - ◆ Select the **Edit** link of the hostname that is no longer used.
  - ◆ On the Edit Web Server dialog, set the Enabled field to no.
  - ◆ Select **Save**.

## Related Topics

- [Changing Server IP Addresses or Hostnames](#)

Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server

- [Changing the IP Address or Hostname of the Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)

## Changing the IP Address or Hostname of the Application Server

This procedure is completed on the Cisco Unified MeetingPlace Application Server.

### Procedure

1. Sign in to the **CLI** of the Application Server as the **mpxadmin** user.
2. Enter **su -** to switch to the root user.
3. Enter **net** at the prompt to start the Network Configuration Utility.
4. Enter **y** at the prompt to continue.
5. Select **2** to ?Configure Ethernet?.
6. Select **4** to ?Set basic IP parameters?.
7. Enter new values for the **IP address** or skip to Step 9 to change the hostname.
  - ◆ (Optional) Enter a new value for the **network mask**.
  - ◆ (Optional) Enter a new value for the **default gateway**, or enter **None** if there is no default gateway.
8. Select **8** to return to the main menu.
9. Select **3** to ?Set host name?.
10. Enter a new **host name** at the prompt.

**Note:** Make sure you have a DNS table entry for the new host name.
11. Select **7** ?Done?.
12. Enter **y** at the prompt to save your changes.
13. Enter **reboot** to reboot the Application Server.

### Related Topics

- [Changing Server IP Addresses or Hostnames](#)
- [Changing the Domain Name of the Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

## Changing the Domain Name of the Application Server

This procedure is completed on the Cisco Unified MeetingPlace Application Server.

### Procedure

1. Sign in to the **CLI** of the Application Server as the **mpxadmin** user.
2. Enter **su** - to switch to the root user.
3. Enter **net** at the prompt to start the Network Configuration Utility.
4. Enter **y** at the prompt to continue.
5. Select **4** to ?Set domain name?.
6. Enter new **domain name** at the prompt.
7. Select **7** ?Done?.
8. Enter **y** at the prompt to save your changes.
9. Enter **reboot** to reboot the Application Server.

### Related Topics

- [Changing Server IP Addresses or Hostnames](#)
- [Changing the IP Address for a Domain Name Server or a Network Time Protocol Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

## Changing the IP Address for a Domain Name Server or a Network Time Protocol Server

This procedure is completed on the Cisco Unified MeetingPlace Web Server.

### Procedure

1. Sign in to the **CLI** of the Application Server as the **mpxadmin** user.
2. Enter **su** - to switch to the root user.
3. Enter **net** at the prompt to start the Network Configuration Utility.
4. Enter **y** at the prompt to continue.
5. Select **5** to ?Configure DNS service'.  
**Note:** You can change the IP address for up to three domain name servers.
6. Enter a new **domain name server IP address** at the prompt.
7. Select **6** to ?Configure NTP service?'.  
**Note:** You can change the IP address for up to three network time protocol servers.

8. Enter a new **network time protocol server IP address** at the prompt.
9. Select **7 ?Done?**.
10. Enter **y** at the prompt to save your changes.
11. Enter **reboot** to reboot the Application Server.

#### Related Topics

- [Changing Server IP Addresses or Hostnames](#)
- [Updating DNS Entries](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

#### Updating DNS Entries

When you change an IP address or host name for an Application Server or a Web Server, you should update the appropriate DNS entries on your Domain Name Server and Cisco Unified CallManager Express.

#### Procedure

1. Access you domain Name Server.
2. Change the DNS entry for the Application Server to match the address you entered in [Changing the IP Address or Hostname of the Application Server](#).
3. Change the DNS entry for the Web Server to match the address you entered in [Changing the Domain Name of the Application Server](#).
4. Access your Cisco Unified Communications Manager and change the SIP trunk configuration for the Application Server. See [http://www.cisco.com/en/US/docs/voice\\_ip\\_comm/connection/9x/integration/guide/cucm\\_sip/cucintcucmsip060.h](http://www.cisco.com/en/US/docs/voice_ip_comm/connection/9x/integration/guide/cucm_sip/cucintcucmsip060.h)

#### Related Topics

- [Changing Server IP Addresses or Hostnames](#)
- [Re-establishing a Connection to an Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application](#)



Server

- Web Server with Segmented Meeting Access - Changing the IP Address or Hostname

**Re-establishing a Connection to an Application Server**

After changing IP parameters, you should re-establish the connection between the Web Server and the Application Server.

**Procedure**

1. Sign in to the Web Server.
2. Choose **Start > Programs > Cisco Unified MeetingPlace Configuration > Cisco Unified MeetingPlace Gateway Configuration** to open the Cisco Unified MeetingPlace Gateways Configuration utility.
3. Select the **Gateway SIM** tab.
4. Select **Add**.  
The MeetingPlace Server Entry window displays.
5. Enter the new configuration information as follows:

Parameter	Action
Server Name	Enter the hostname of the Cisco Unified MeetingPlace Application Server. <b>Note:</b> If you use an IP address instead of a hostname for the Application Server, you will have to update the IP address on the Web Server whenever you change the IP address on the Application Server.
Shadow Server	Leave this field as is.
Client IP Address	Enter the IP address of the computer on which the Gateway SIM is installed.
Transfer Destination	Leave this field as is.
Link Encryption Disabled	Leave this box unchecked to maintain encrypted communications between the Gateway SIM and the Application Server. Encryption uses a 56-bit DES algorithm with a secret key.

1. Select **OK**.
2. Select **OK** again.
3. Restart the Gateway SIM service and the Cisco Unified MeetingPlace Web Master Service.  
If other Web Servers share the database with the server, restart the services on those servers as well.
4. Update the Web Server's hostname and IP addresses.
  - ◆ Sign in to the web user portal.
  - ◆ Select **Admin > Web Server**.
  - ◆ From the View section, select the name of the Web Server you want to update.  
This populates the Edit section of the page with the pre-defined settings.
  - ◆ Update the IP address or hostname for the **Hostname [Home Page]** and the **Hostname [Web Conferencing]**.
  - ◆ Select **Submit**.

- ◆ Restart the Cisco Unified MeetingPlace Web Master Service.
5. Update the **Click-to-Attend** link.
- ◆ Sign in to the Administration Center.
  - ◆ Select **System Configuration > Usage Configuration**.
  - ◆ In the Click-to-Attend Link Configuration section, update the Web Server hostname entries.
  - ◆ Select **Save**.

### What to Do Next

Sign in as root user and restart the Application Server by entering the `mpx_sys restart` command.

### Related Topics

- [Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

## Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server

Use this table to go to the procedure you need to perform to change an IP address or hostname for a Web Server and a Cisco Unified MeetingPlace Application server in an failover deployment. After you complete each task, return to this table to complete the next task.

Task	Description	For details, see
1	Remove all connections from the Web Server to the Application Server	<a href="#">Removing the Connection to the Application Server</a>
2	Tear down replication between the primary and secondary Application Server. Then you can change the hostname and IP address using the <b>net</b> command.	<a href="#">Changing IP Addresses and Hostnames for the Replicated Application Servers</a>
3	You can update your Domain Name Server and Cisco Unified Call Manager with the new hostname and IP address of Application Server and Cisco Unified MeetingPlace Web Server.	<a href="#">Updating DNS Entries</a>
4	Turn on replication between the primary and secondary Application Servers. Then return the Application Server to <b>activemode</b> .	<a href="#">Turning on Replication</a>
5		

Reconnect the Cisco Unified MeetingPlace Web Server to the Application Server.	<a href="#">Re-establishing a Connection to an Application Server</a>
--	---

### Related Topics

- [Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

### Changing IP Addresses and Hostnames for the Replicated Application Servers

When you change an IP address or host name for an Application Server or a Web Server, you should update the appropriate DNS entries on your Domain Name Server and Cisco Unified CallManager Express.

### Procedure

1. Switch both the primary and secondary Application Servers from **active** to **failover standby** mode. See [http://www.cisco.com/en/US/docs/voice\\_ip\\_comm/meetingplace/8\\_5/english/administration/failover\\_application](http://www.cisco.com/en/US/docs/voice_ip_comm/meetingplace/8_5/english/administration/failover_application) for more information.
2. Change the IP address or hostname of eth0 (referred to as Ethernet Port 1(device eth0)) of the primary Application Server using the **net** command. See [Changing the IP Address or Hostname of the Application Server](#).
3. For the primary Application Server, complete [Changing the Domain Name of the Application Server](#) and [Changing the IP Address for a Domain Name Server or a Network Time Protocol Server](#).
4. Switch the secondary Application Server to **single server** mode.
5. Repeat steps 2 and three for the secondary Application Server.
6. Switch the secondary Application Server to **failover standby** mode. See [http://www.cisco.com/en/US/docs/voice\\_ip\\_comm/meetingplace/8\\_5/english/administration/failover\\_application](http://www.cisco.com/en/US/docs/voice_ip_comm/meetingplace/8_5/english/administration/failover_application) for more information.

### Related Topics

- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Updating DNS Entries](#)

Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server

## Turning on Replication

After you change IP addresses and hostnames for the primary and secondary Application Servers, and return the secondary server to the failover standby mode, turn on replication.

### Procedure

1. Initialize replication between the primary and standby Application Servers
2. Turn on replication between the primary and standby Application Servers
3. Return the primary Application Server to active mode

See

[http://www.cisco.com/en/US/docs/voice\\_ip\\_comm/meetingplace/8\\_5/english/administration/failover\\_app](http://www.cisco.com/en/US/docs/voice_ip_comm/meetingplace/8_5/english/administration/failover_app)  
for more information.

### Related Topics

- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Re-establishing a Connection to an Application Server](#)

## Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server

Use this table to go to the procedure you need to perform to change an IP address or hostname for a Web Server and a Cisco Unified MeetingPlace Application server in a multinode deployment. After you complete each task, return to this table to complete the next task.

Task	Description	For details, see
1	Before you change the hostname or an IP address of a Application Server in a multinode deployment, you must remove the server from the multinode deployment and place it in <b>standby</b> mode.	
2	On the Application Server you can change the hostname and IP address using the <b>net</b> command.	<a href="#">Changing the IP Address or Hostname of the Application Server</a>
3	You can change the domain name of the Application Server using the <b>net</b> command.	<a href="#">Changing the Domain Name of the Application Server</a>
4	On the Cisco Unified MeetingPlace Web Server, you can change the IP address for the Domain Name Server or a Network Time Protocol Server.	<a href="#">Changing the IP Address for a Domain Name Server or a Network Time Protocol Server</a>
5	You can update your Domain Name Server and Cisco Unified Call Manager with the new hostname and IP address of Application	<a href="#">Updating DNS Entries</a>

	Server and Cisco Unified MeetingPlace Web Server.	
6	After your system is up and running, add the Application Server back as part of the multinode deployment.	
7	If you have multiple Cisco WebEx Node for MCS in your deployment, and you have changed the Hostname or the IP address of your Primary or Secondary MBD, you'll need to reflect these changes at your Cisco WebEx Nodes.	<a href="#">Entering Updated Hostnames and IP Addresses on Cisco WebEx Nodes for MCS</a>
8	If you do not have a Cisco WebEx Node for MCS as part of your deployment, you need to update the Cisco WebEx site with the changed hostname or IP address.	<a href="#">Updating the Cisco WebEx Site</a>

## Related Topics

- [Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

## Entering Updated Hostnames and IP Addresses on Cisco WebEx Nodes for MCS

Complete this procedure on each Cisco WebEx Node for MCS in your deployment.

**Note:** Contact the administrator of the Cisco WebEx Node Management System if you want to change the hostname or IP address of a Cisco WebEx Node for MCS. This type of change must be updated on the Cisco WebEx Node Management System, and the Cisco WebEx Node must be reconfigured with new parameters.

### Procedure

1. Sign in to the CLI of each Cisco WebEx Node for MCS as the **mpxadmin** user.
2. Enter **service webex stop** and wait until all services have stopped.
3. Enter **set webex mbd** \_Primary Meeting Director hostname,Secondary Meeting Director hostname\_.  
**Note:** When you enter the Primary and Secondary Meeting Director node hostnames or IP addresses, make sure you enter a comma with no space between the two node names.
4. Enter **service webex start** and to start the services.

## Related Topics

- [Multinode Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)

## Updating the Cisco WebEx Site

Complete this procedure on the active Meeting Director Broker (MBD) node.

**Note:** Cisco Unified MeetingPlace does not automatically update hostname and IP address information on the Cisco WebEx site.

### Procedure

1. To update hostnames and IP addresses on the Cisco WebEx site, go to **Cisco WebEx Configuration > Cisco WebEx Site Configuration** page.
2. Select **Configure WebEx**.

### Related Topics

- [Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

## Web Server with Segmented Meeting Access - Changing the IP Address or Hostname

Use this table to go to the procedure you need to perform to change an IP address or hostname for a Web Server with Segmented Meeting Access. After you complete each task, return to this table to complete the next task.

Task	Description	For details, see
1	If SSL is installed and turned on, disable SSL on the internal and external Web Servers.	<a href="#">Turning Off SSL on Internal and External Cisco Unified MeetingPlace Web Servers</a>
2	Disable SMA on the Web Server before you change an IP address or hostname for an Application Server.	<a href="#">Turning Off SMA for Cisco Unified MeetingPlace Web Servers</a>
3	On the Application Server you can change the hostname and IP address using the <b>net</b> command.	<a href="#">Changing the IP Address or Hostname of the</a>

		<a href="#">Application Server</a>
4	You can change the domain name of the Application Server using the net command.	<a href="#">Changing the Domain Name of the Application Server</a>
5	On the Cisco Unified MeetingPlace Web Server, you can change the IP address for the Domain Name Server or a Network Time Protocol Server.	<a href="#">Changing the IP Address for a Domain Name Server or a Network Time Protocol Server</a>
6	You can update your Domain Name Server and Cisco Unified Call Manager with the new hostname and IP address of Application Server and Cisco Unified MeetingPlace Web Server.	<a href="#">Updating DNS Entries</a>
7	Enable SMA for the Cisco Unified MeetingPlace Web Servers to the Application Server.	<a href="#">Turning On SMA for Cisco Unified MeetingPlace Web Server</a>

### Related Topics

- [Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

### Turning Off SSL on Internal and External Cisco Unified MeetingPlace Web Servers

If the internal and external (DMZ) Cisco Unified MeetingPlace Web Servers have SSL configured, you must turn off SSL before you turn off SMA or change an IP address or hostname for an Application Server.

**Note:** A certificate authority issues a certificate for a particular hostname. Therefore, when you change the hostname, the SSL certificate becomes invalid.

### Procedure

1. Toggle SSL to OFF on all internal Cisco Unified MeetingPlace Web Servers.
2. Reboot all internal Web Servers.
3. Toggle SSL to OFF on all external Web Servers.
4. Reboot all external Web Servers.

### Related Topics

- [Turning Off SMA for Cisco Unified MeetingPlace Web Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

## Turning Off SMA for Cisco Unified MeetingPlace Web Server

You need to disable SMA on the Cisco Unified MeetingPlace Web Server before you change the IP address or hostname for the Application Server.

**Prerequisite** If the internal or external (DMZ) Web Servers have SSL configured, you must turn off SSL before you turn off SMA on the Web Server.

### Procedure

1. Sign in to the web user portal.
2. Select **Admin**.
3. Select **Site**.
4. Select the underlined site name.
5. For the field named "DMZ Web Server," make sure the value is set to **-none-**.
6. Select **Submit**.

### Related Topics

- [Changing the IP Address or Hostname of the Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)

## Turning On SMA for Cisco Unified MeetingPlace Web Server

You need to enable SMA on the Cisco Unified MeetingPlace Web Server after you change the IP address or hostname for the Application Server.

### Procedure

1. Sign in to the web user portal on the internal Web Server.
2. Select **Admin**.
3. Select **Web Server**.
4. From a blank "Web Server Name" field, enter the name of a new Web Server to represent your designated external Web Server.
5. Enter the fully qualified domain name (FQDN) of your external Web Server in the Hostname field as `_hostname.domain_`. If your Web Server is not in a Domain Name Server (DNS), enter the IP address instead.



**Notes:**

- You must be able to resolve this hostname from the internal Web Server.
- If you are using SSL, make sure the hostname of the SSL certificate resolves to the external Web Server IP address.
- If you are using SSL and a segmented DNS, make sure the DNS name and the SSL certificate name are different.

6. Select **Submit** to add this Web Server to the database.

**Related Topics**

- [Audio-only Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Failover Deployment ? Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Multinode Deployment - Changing the IP Address or Hostname for a Web Server and an Application Server](#)
- [Web Server with Segmented Meeting Access - Changing the IP Address or Hostname](#)