

Main page: [Cisco Unified Presence, Release 7.x](#)

Contents

- [1 Previous Topic](#)
- [2 Before You Begin](#)
- [3 Procedure](#)
- [4 Related Topics](#)
- [5 What To Do Next](#)

Previous Topic

- [Configuring User Assignment in System Topology](#)

Notes:

- This procedure is only applicable if you are configuring a multi-node deployment.
- You only need to configure the cluster-wide Cisco Unified Presence address on the publisher node. The information is replicated to all nodes in the cluster.
- When you configure a cluster-wide Cisco Unified Presence address, set the port of SRV to 5060.

Before You Begin

Read the cluster-wide DNS SRV topic.

Procedure

1. Select **Cisco Unified Presence Administration > System > Service Parameters**.
2. Select the Cisco Unified Presence server from the Server menu.
3. Select **Cisco UP Sip Proxy** from the Service menu.
4. Edit the **SRV Cluster Name** field in the General Proxy Parameters (Clusterwide) section.

By default this parameter is empty.

5. Select **SRV** from the Address Resolution Type menu in the General Proxy Parameters (Clusterwide) section.

When you set the Address Resolution to SRV, this value overrides the default value of the Proxy Domain field.

6. Select **Save**.

Related Topics

- [Cluster-wide DNS SRV](#)
- [Getting More Information](#)

What To Do Next

[Uploading the Server Licence File on Cisco Unified Presence](#)