

Main page: [Cisco Unified Presence, Release 7.x](#)

Contents

- [1 Previous Topic](#)
- [2 Restoring a Backup File](#)
 - ◆ [2.1 Before You Begin](#)
 - ◆ [2.2 Procedure](#)
 - ◆ [2.3 Troubleshooting Tips](#)
 - ◆ [2.4 Related Topics](#)
- [3 Restoring a Cluster](#)
 - ◆ [3.1 Restoring the Publisher Node](#)
 - ◇ [3.1.1 Before You Begin](#)
 - ◇ [3.1.2 Procedure](#)
 - ◇ [3.1.3 Troubleshooting Tips](#)
 - ◇ [3.1.4 What To Do Next](#)
 - ◆ [3.2 Restoring Subsequent Cluster Nodes](#)
 - ◇ [3.2.1 Before You Begin](#)
 - ◇ [3.2.2 Procedure](#)
 - ◇ [3.2.3 Troubleshooting Tips](#)
 - ◇ [3.2.4 Related Topics](#)

Previous Topic

[Accessing the Disaster Recovery System](#)

- [Restoring a Backup File](#)
- [Restoring a Cluster](#)

Caution! Always run the Post Install Setup wizard immediately after a fresh installation of Cisco Unified Presence, and *before* you back up or restore your data in the Disaster Recovery System. The operation fails if you install Cisco Unified Presence and attempt to back up or restore data in the Disaster Recovery System before you run the Post Install wizard. For more information, see the *Installation and Upgrade Guide for Cisco Unified Presence*.

Restoring a Backup File

The Restore Wizard walks you through the steps that are required to restore a backup file:

- Select Storage Location-You must first select the storage location from which you want to restore a backup file.
- Select the Backup File-From a list of available files, you must select the backup file that you want to restore.
- Select Features-From the list of available features, you must select the features that you want to restore.
- Select Nodes-If the feature was backed up from multiple nodes, you must select the nodes that you want to restore.

Before You Begin

- Before you restore Cisco Unified Presence, ensure that the Cisco Unified Presence version that is installed on the server matches the version of the backup file that you want to restore.
- Configure your backup devices.

Procedure

1. Select **Navigation > Disaster Recovery System** from the menu in the upper, right corner of Cisco Unified Presence main window.
2. Click **Go**.
3. Enter the same Administrator username and password that you use for the Cisco Unified Operating System.
4. Select **Restore > Restore Wizard**.
5. Complete the Restore Wizard as follows:

Window	Configuration Steps
Restore Wizard Page 1 of 4	<ol style="list-style-type: none"> 1. Select the backup device from which to restore. 2. Click Next.
Restore Wizard Page 2 of 4	<ol style="list-style-type: none"> 1. Select the backup file that you want to restore. The backup filename indicates the date and time that the system created the backup file. 2. Click Next.
Restore Wizard Page 3 of 4	<ol style="list-style-type: none"> 1. Select the features that you want to restore. Only the features that were backed up to the file that you select display. 2. Click Next.
Restore Wizard Page 4 of 4	<ol style="list-style-type: none"> 1. Click Restore to start restoring the data. 2. Select the appropriate node to restore. Caution! After you select the node to which you want the data restored, the system overwrites any existing data on that server.

6. Restart the server.

Troubleshooting Tips

Depending on the size of your database and the components that you select to restore, the system can require one hour or more to restore.

Related Topics

- [How to Back Up Data in the Disaster Recovery System](#)
- [How to View the Status and History of BackUp and Restore Jobs](#)
- [About BackUp and Restore Troubleshooting Operations](#)
- [Getting More Information](#)

Restoring a Cluster

When performing a system data restoration, you can select the nodes in the cluster that you want to restore. If a major failure or a hardware upgrade occurs, you may need to restore all nodes in the cluster. To restore an entire cluster, you must first restore the publisher server and then restore the subsequent nodes.

- [Restoring the Publisher Node](#)
- [Restoring Subsequent Cluster Nodes](#)

Restoring the Publisher Node

Before You Begin

- Before you restore Cisco Unified Presence, ensure that the Cisco Unified Presence version that is installed on the server matches the version of the backup file that you want to restore.
- Perform a fresh installation of Cisco Unified Presence on the first node or publisher server. For more information on installing Cisco Unified Presence, see the *Installation and Upgrade Guide for Cisco Unified Presence*.

Procedure

1. Select **Navigation > Disaster Recovery System** from the menu in the upper, right corner of Cisco Unified Presence main window.
2. Click **Go**.
3. Enter the same Administrator username and password that you use for the Cisco Unified Operating System.
4. Select **Restore > Restore Wizard**.
5. Complete the Restore Wizard as follows:

Window	Configuration Steps
Restore Wizard Page 1 of 4	<ol style="list-style-type: none"> 1. Select the backup device from which to restore. 2. Click Next.
Restore Wizard Page 2 of 4	<ol style="list-style-type: none"> 1. Select the backup file that you want to restore. The backup filename indicates the date and time that the system created the backup file. 2. Click Next.
Restore Wizard Page 3 of 4	<ol style="list-style-type: none"> 1. Select the features that you want to restore. Only the features that were backed up to the file that you select display. 2. Click Next.
Restore Wizard Page 4 of 4	<ol style="list-style-type: none"> 1. Click Restore to start restoring the data. 2. Select to restore your data to the first node (the publisher). Caution! After you select the node to which you want the data restored, the system overwrites any existing data on that server.

6. Restart the server.

Troubleshooting Tips

- During the restore process, do not perform any tasks with Cisco Unified Presence Administration or Cisco Unified Presence User Pages.
- Depending on the size of your database and the components that you select to restore, the system can require one hour or more to restore.

What To Do Next

Restoring Subsequent Cluster Nodes

Restoring Subsequent Cluster Nodes

Before You Begin

- Before you restore Cisco Unified Presence, ensure that the Cisco Unified Presence version that is installed on the server matches the version of the backup file that you want to restore.
- Restore the publisher node, or first node, in the cluster.

Procedure

1. Select **Navigation > Disaster Recovery System** from the menu in the upper, right corner of Cisco Unified Presence main window.
2. Click **Go**.
3. Enter the same Administrator username and password that you use for the Cisco Unified Operating System.
4. Select **Restore > Restore Wizard**.
5. Complete the Restore Wizard as follows:

Window	Configuration Steps
Restore Wizard Page 1 of 4	<ol style="list-style-type: none"> 1. Select the backup device from which to restore. 2. Click Next.
Restore Wizard Page 2 of 4	<ol style="list-style-type: none"> 1. Select the backup file that you want to restore. 2. Click Next. Caution! To restore subsequent nodes in the cluster, you must select the same backup file that you used to restore the first node.
Restore Wizard Page 3 of 4	<ol style="list-style-type: none"> 1. Select the features that you want to restore. Only the features that were backed up to the file that you select display. 2. Click Next.
Restore Wizard Page 4 of 4	<ol style="list-style-type: none"> 1. Click Restore to start restoring the data. 2. Select to restore only the subsequent nodes. Caution! After you select the node to which you want the data restored, the system overwrites any existing data on that server.

6. Restart the server.

Troubleshooting Tips

- During the restore process, do not perform any tasks with Cisco Unified Presence Administration or Cisco Unified Presence User Pages
- Depending on the size of your database and the components that you select to restore, the system can require one hour or more to restore.

Related Topics

- [How to Back Up Data in the Disaster Recovery System](#)
- [How to View the Status and History of BackUp and Restore Jobs](#)
- [About BackUp and Restore Troubleshooting Operations](#)
- [Getting More Information](#)