

This article provides tips for resolving the following Cisco SIP gateway problems:

Guide Contents
<a href="#">Troubleshooting Cisco IOS Voice Overview</a>
<a href="#">Debug Command Output on Cisco IOS Voice Gateways</a>
<a href="#">Filtering Troubleshooting Output</a>
<a href="#">Cisco VoIP Internal Error Codes</a>
<a href="#">Troubleshooting Cisco IOS Voice Telephony</a>
<a href="#">Troubleshooting Cisco IOS Voice Protocols</a>
<a href="#">Troubleshooting Cisco IOS Telephony Applications</a>
<a href="#">Monitoring the Cisco IOS Voice Network</a>
<a href="#">Cause Codes and Debug Values</a>

## Contents

- [1 Unable to Make Outbound Calls from the Cisco SIP Gateway to a SIP Endpoint](#)
- [2 Unable to Make Inbound Calls to a PSTN Through a Cisco SIP Gateway](#)
- [3 Calls to a PSTN via the Cisco SIP Gateway Fail with a "400 Bad Request" Response](#)
  - ◆ [3.1 Table: SIP Header Fields](#)
- [4 Voice Quality Is Compromised on Calls Through or From the Cisco SIP Gateway](#)
- [5 Some SIP Messages Are Retransmitted Too Often](#)
- [6 Call Transfer Does Not Work Correctly](#)
- [7 Troubleshooting Commands](#)

## Unable to Make Outbound Calls from the Cisco SIP Gateway to a SIP Endpoint

If a call cannot be placed from the Cisco SIP gateway, perform the following tasks as necessary:

- Verify that the voice ports are properly configured and enabled for the PSTN-side signaling protocol.
- Verify that there is a valid VoIP dial peer configured that meets the following requirements:
  - ◆ Matches the required destination pattern
  - ◆ Is SIP-enabled (through the **session protocol sipv2** command)
  - ◆ Has the correct dial peer session target defined (through the *'session target 'sip-server* command
  - ◆ Has the codec correctly defined
- Using the **ping** command, verify that the SIP gateway can communicate through IP with the SIP proxy or remote SIP device.
- If the SIP proxy server is defined through the use of a FQDN, verify that the DNS server is correctly configured to resolve that address using a DNS SRV record.
- Ensure that the time zone format configured on the SIP gateway is GMT.
- Check the **debug ccsip all | calls | error | events | messages | states** command output for protocol errors.

## Unable to Make Inbound Calls to a PSTN Through a Cisco SIP Gateway

If inbound calls to a PSTN cannot be made through the Cisco SIP gateway, perform the following tasks as necessary to determine the cause:

- Verify that the voice ports are correctly configured and enabled for the PSTN-side signaling protocol.
- Verify that a valid POTS dial peer is configured and that it matches the required destination pattern.
- Using the **ping** command, verify that the Cisco SIP gateway can communicate with the SIP proxy server or remote SIP device through IP.
- If the inbound call has any hostnames defined as a FQDN, ensure that the proper DNS configuration is enabled on the Cisco SIP gateway (to resolve the hosts).
- View the **debug ccsip all | calls | error | events | messages | states** command output for protocol errors.

## Calls to a PSTN via the Cisco SIP Gateway Fail with a "400 Bad Request" Response

If the Cisco SIP gateway does not like part of a SIP message (header or SDP), the call attempt fails with a "400 Bad Request" response.

To determine whether the call failed because of a SIP header error, issue the **debug ccsip** command that displays information on the error message, or verify that the required SIP header elements exist as defined in [RFC 2543](#). SIP header fields are shown in [Table: SIP Header Fields](#).

**Table: SIP Header Fields**

Header Field	Definition
Call-ID	The Call-ID general-header field uniquely identifies a specific invitation or all registrations of a specific client. Note that a single multimedia conference can give rise to several calls with different Call-IDs. For example, if a user invites a single individual several times to the same (long-running) conference.
Contact	The Contact general-header field <b>MUST</b> appear in INVITE and REGISTER requests and in 200 responses. It can appear in ACK, and in other 1xx, 2xx, 3xx, 485 responses. In general, it provides a URL where the user can be reached for further communications.
Content-Length	The Content-Length entity-header field indicates the size of the message-body, in decimal number of octets, sent to the recipient.
Content-Type	The Content-Type entity-header field indicates the media type of the message-body sent to the recipient.
Cseq	Users <b>MUST</b> add the CSeq (command sequence) general-header field to every request. A CSeq header field in a request contains the request method and a single decimal sequence number chosen by the requesting client, unique within a single value of Call-ID. The sequence number <b>MUST</b> be expressed as a 32-bit unsigned integer. The initial value of the sequence number is arbitrary, but <b>MUST</b> be less than $2^{31}$ . Consecutive requests that differ in request method, headers, or body, but have the same Call-ID <b>MUST</b> contain strictly monotonically increasing and contiguous sequence numbers; sequence numbers do not wrap around. Retransmissions of the same request carry the same sequence number, but an INVITE with a different message body or different header fields (a "re-invitation") acquires a new, higher sequence number. A server <b>MUST</b> echo the CSeq value from the request in its response. If the Method value is missing in the received CSeq header field, the server fills it in appropriately.
Date	Date is a general-header field. Its syntax is:  SIP-date = rfc1123-date


	Note that unlike HTTP/1.1, SIP only supports the most recent <a href="#">RFC 1123</a> [29] formatting for dates.
Diversion	 <b>Note:</b> Currently gateway uses Diversion header in initial outgoing messages.
Expires	<p>The Expires entity-header field gives the date and time after which the message content expires.</p> <p>This header field is currently defined only for the REGISTER and INVITE methods. For REGISTER, it is a request and response-header field. In a REGISTER request, the client indicates how long it wants the registration to be valid. In the response, the server indicates the earliest expiration time of all registrations. The server MAY choose a shorter time interval than that requested by the client, but SHOULD NOT choose a longer one.</p>
From	<p>Requests and responses MUST contain a From general-header field, indicating the initiator of the request. The From field MUST contain a tag. The server copies the From header field from the request to the response. The optional "display-name" is meant to be rendered by a human-user interface. A system SHOULD use the display name "Anonymous" if the identity of the client is to remain hidden.</p> <p>The SIP-URL MUST NOT contain the "transport-param", "maddr-param", "ttl-param", or "headers" elements. A server that receives a SIP-URL with these elements removes them before further processing.</p>
Max-Forwards	<p>The Max-Forwards request-header field may be used with any SIP method to limit the number of proxies or gateways that can forward the request to the next downstream server. This can also be useful when the client is attempting to trace a request chain which appears to be failing or looping in mid chain.</p> <p>The Max-Forwards value is a decimal integer indicating the remaining number of times this request message is allowed to be forwarded.</p> <p>Each proxy or gateway recipient of a request containing a Max-Forwards header field MUST check and update its value before forwarding the request. If the received value is zero (0), the recipient MUST NOT forward the request. Instead, for the OPTIONS and REGISTER methods, it MUST respond as the final recipient. For all other methods, the server returns 483 (too many hops).</p> <p>If the received Max-Forwards value is greater than zero, then the forwarded message MUST contain an updated Max-Forwards field with a value decremented by one (1).</p>
Require	The Require request-header field is used by clients to tell useragent servers about options that the client expects the server to support in order to properly process the request. If a server does not understand the option, it MUST respond by returning status code 420 (bad extension) and list those options it does not understand in the Unsupported header.
Server	The Server response-header field contains information about the software used by the user agent server to handle the request.
Timestamp	The timestamp general-header field describes when the client sent the request to the server. The value of the timestamp is of significance only to the client and it MAY use any time scale. The server MUST echo the exact same value and MAY, if it has accurate information about this, add a floating point number indicating the number of seconds that have elapsed since receiving the request. The timestamp is used by the client to compute the round-trip time to the server so that it can adjust the time out value for retransmissions.
To	The To general-header field specifies recipient of the request, with the same SIP URL syntax as the From field.

Table: SIP Header Fields

	Requests and responses MUST contain a To general-header field, indicating the desired recipient of the request. The optional "display-name" is meant to be rendered by a human-user interface. The UAS or redirect server service processing a request MUST always add a tag to To-header.
User-Agent	The User-Agent general-header field contains information about the client user agent originating the request.
Via	The Via field indicates the path taken by the request so far. This prevents request looping and ensures replies take the same path as the requests, which assists in firewall traversal and other unusual routing situations. When the UAC creates a request, it MUST insert a Via into that request.

Possible SDP-related errors are as follows:

- SDP\_ERR\_INFO\_UNAVAIL
- SDP\_ERR\_VERSINFO\_INVALID
- SDP\_ERR\_CONNINFO\_IN
- SDP\_ERR\_CONNINFO\_IP
- SDP\_ERR\_CONNINFO\_NULL
- SDP\_ERR\_CONNINFO\_INVALID
- SDP\_ERR\_MEDIAINFO\_TYPE
- SDP\_ERR\_MEDIAINFO\_INVALID
- SDP\_ERR\_MEDIAINFO\_NULL
- SDP\_ERR\_OWNERINFO\_NULL
- SDP\_ERR\_OWNERINFO\_SESSID\_NULL
- SDP\_ERR\_OWNERINFO\_SESSID\_INVALID
- SDP\_ERR\_OWNERINFO\_VERSID\_NULL
- SDP\_ERR\_OWNERINFO\_VERSID\_INVALID
- SDP\_ERR\_OWNERINFO\_IN
- SDP\_ERR\_OWNERINFO\_IP
- SDP\_ERR\_TIMEINFO\_ST\_NULL
- SDP\_ERR\_TIMEINFO\_ET\_NULL
- SDP\_ERR\_TIMEINFO\_ST\_INVALID
- SDP\_ERR\_TIMEINFO\_ET\_INVALID
- SDP\_ERR\_ATTRINFO\_INVALID
- SDP\_ERR\_ATTRINFO\_NULL
- SDP\_ERR\_AUDIO\_MEDIA\_UNAVAIL
- SDP\_ERR\_MEDIAINFO\_PORT\_INVALID
- SDP\_ERR\_MEDIAINFO\_MALLOC\_FAIL
- SDP\_ERR\_ATTRINFO\_MALLOC\_FAIL

Possible CheckRequest errors are as follows:

- CHK\_REQ\_FAIL\_MISMATCH\_CSEQ
- CHK\_REQ\_FAIL\_INVALID\_CSEQ
- CHK\_REQ\_FAIL\_FROM\_TO
- CHK\_REQ\_FAIL\_VERSION
- CHK\_REQ\_FAIL\_METHOD\_UNKNOWN
- CHK\_REQ\_FAIL\_REQUIRE\_UNSUPPORTED
- CHK\_REQ\_FAIL\_CONTACT\_MISSING
- CHK\_REQ\_FAIL\_MISMATCH\_CALLID
- CHK\_REQ\_FAIL\_MALFORMED\_CONTACT
- CHK\_REQ\_FAIL\_MALFORMED\_RECORD\_ROUTE

## Voice Quality Is Compromised on Calls Through or From the Cisco SIP Gateway

If the voice quality on calls through or from the Cisco SIP gateway is compromised, perform the following tasks as necessary to determine the cause:

- Check the network path for errors, packet drops, loss, loops, and so forth.
- Verify that the TOS bits have been correctly set in the VoIP dial peer through the use of the **ip precedence** command.
- To minimize excessive collisions and packet loss, connect the Cisco SIP gateway to a switch rather than a hub.
- Verify that enough bandwidth exists on the network for the configured codec (especially for calls over a WAN).
- View the output of the show interface command for packet drops. View the output of the **show voice dsp** command for DSP-related issues.
- Determine whether errors exist on the voice ports that could be causing the problems.

## Some SIP Messages Are Retransmitted Too Often

The Cisco SIP gateway has SIP timers (INVITE request retries, BYE request retries) configured under the SIP UA through the use of the **timers trying number**, **timers expires time**, and **retry invite number** commands. In most networks, the default values work well, but conditions such as network delay, slower-processing proxy servers, and packet loss might require that the timers be adjusted. If some SIP messages appear to be retransmitted too often, adjust these parameters.

## Call Transfer Does Not Work Correctly

If call transfer does not work correctly, perform the following tasks to determine the cause:

- Verify that the application session is defined on the VoIP and POTS dial peers.
- Verify that the remote SIP device that is sending the call through the use of the SIP BYE/Also: method (as defined in Internet draft sip-cc-01.txt).
- Use the **debug voip ccapi inout** command to verify that a dial peer that has application session defined is matched. The application used after the BYE request is sent should be "session" instead of "SESSION."

## Troubleshooting Commands

There are several debug commands that are useful for troubleshooting problems with SIP, as follows:

- **debug ccsip all**
- **debug ccsip calls**
- **debug ccsip error**
- **debug ccsip events**
- **debug ccsip info**
- **debug ccsip media**
- **debug ccsip messages**
- **debug ccsip preauth**
- **debug ccsip states**

Details about these commands can be found in the *Cisco IOS Debug Command Reference*.

 **Note:** The output from these commands can be filtered. For more information, see the [SIP Debug Output Filtering Support](#).

The following show and debug commands shown can be used to troubleshoot the Cisco SIP gateway:

- **show sip status**-Displays the SIP user agent listener status.

```
sip-2600a# show sip status
SIP User Agent Status
SIP User Agent for UDP : ENABLED
SIP User Agent for TCP : ENABLED
SIP max-forwards : 6
```

- **show sip statistics**-Displays SIP user agent statistics.

```
router# show sip statistics
SIP Response Statistics (Inbound/Outbound)
Informational:
Trying 3/0, Ringing 3/0,
Forwarded 0/0, Queued 0/0,
SessionProgress 0/0
Success:
OkInvite 3/0, OkBye 2/0,
OkCancel 0/0, OkOptions 0/0
Redirection (Inbound only):
MultipleChoice 0, MovedPermanently 0,
MovedTemporarily 0, SeeOther 0,
UseProxy 0, AlternateService 0
Client Error:
BadRequest 0/3, Unauthorized 0/0,
PaymentRequired 0/0, Forbidden 0/0,
NotFound 0/0, MethodNotAllowed 0/0,
NotAcceptable 0/0, ProxyAuthReqd 0/0,
ReqTimeout 0/0, Conflict 0/0, Gone 0/0,
LengthRequired 0/0, ReqEntityTooLarge 0/0,
ReqURITooLarge 0/0, UnsupportedMediaType 0/0,
BadExtension 0/0, TempNotAvailable 0/0,
CallLegNonExistent 0/0, LoopDetected 0/0,
TooManyHops 0/0, AddrIncomplete 0/0,
Ambiguous 0/0, BusyHere 0/0
Server Error:
InternalError 0/0, NotImplemented 0/0,
BadGateway 0/0, ServiceUnavail 0/0,
GatewayTimeout 0/0, BadSipVer 0/0
Global Failure:
BusyEverywhere 0/0, Decline 0/0,
NotExistAnywhere 0/0, NotAcceptable 0/0
SIP Total Traffic Statistics (Inbound/Outbound)
Invite 3/7, Ack 2/1, Bye 0/2,
Cancel 0/0, Options 0/0
Retry Statistics
Invite 2, Bye 0, Cancel 0, Response 1
```

- **debug ccsip**-Displays the different **debug ccsip** commands.

```
router# debug ccsip ?
all      Enable all SIP debugging traces
calls    Enable CCSIP SPI calls debugging trace
error    Enable SIP error debugging trace
events   Enable SIP events debugging trace
messages Enable CCSIP SPI messages debugging trace
states   Enable CCSIP SPI states debugging trace
```

## Cisco\_IOS\_Voice\_Troubleshooting\_and\_Monitoring\_--\_Cisco\_SIP\_Gateway\_Troubleshooting

The following is a sample of debug output from one side of a call:

```
Router1# debug ccsip all
All SIP call tracing enabled
Router1#
*Mar 6 14:10:42: 0x624CFEF8 : State change from (STATE_NONE, SUBSTATE_NONE)
  to (STATE_IDLE, SUBSTATE_NONE)
*Mar 6 14:10:42: Queued event from SIP SPI : SIPSPI_EV_CC_CALL_SETUP
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: act_idle_call_setup
*Mar 6 14:10:42: act_idle_call_setup:Not using Voice Class Codec
*Mar 6 14:10:42: act_idle_call_setup: preferred_codec set[0] type :g711ulaw bytes: 160
*Mar 6 14:10:42: Queued event from SIP SPI : SIPSPI_EV_CREATE_CONNECTION
*Mar 6 14:10:42: 0x624CFEF8 : State change from (STATE_IDLE, SUBSTATE_NONE)
  to (STATE_IDLE, SUBSTATE_CONNECTING)
*Mar 6 14:10:42: REQUEST CONNECTION TO IP:166.34.245.231 PORT:5060
*Mar 6 14:10:42: 0x624CFEF8 : State change from (STATE_IDLE, SUBSTATE_CONNECTING)
  to (STATE_IDLE, SUBSTATE_CONNECTING)
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: act_idle_connection_created
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: act_idle_connection_created: Connid(1)
  created to 166.34.245.231:5060, local_port 54113
*Mar 6 14:10:42: sipSPIAddLocalContact
*Mar 6 14:10:42: Queued event from SIP SPI : SIPSPI_EV_SEND_MESSAGE
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: sip_stats_method
*Mar 6 14:10:42: 0x624CFEF8 : State change from (STATE_IDLE, SUBSTATE_CONNECTING)
  to (STATE_SENT_INVITE, SUBSTATE_NONE)
*Mar 6 14:10:42: Sent:
INVITE sip:3660210@166.34.245.231;user=phone;phone-context=unknown SIP/2.0
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>
Date: Sat, 06 Mar 1993 19:10:42 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Cisco-Guid: 2881152943-2184249548-0-483039712
User-Agent: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
CSeq: 101 INVITE
Max-Forwards: 6
Timestamp: 731427042
Contact: <sip:3660110@166.34.245.230:5060;user=phone>
Expires: 180
Content-Type: application/sdp
Content-Length: 137
v=0
o=CiscoSystemsSIP-GW-UserAgent 1212 283 IN IP4 166.34.245.230
s=SIP Call
t=0 0
c=IN IP4 166.34.245.230
m=audio 20208 RTP/AVP 0
*Mar 6 14:10:42: Received:
SIP/2.0 100 Trying
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>
Date: Mon, 08 Mar 1993 22:36:40 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Timestamp: 731427042
Server: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
CSeq: 101 INVITE
Content-Length: 0
*Mar 6 14:10:42: HandleUdpSocketReads :Msg enqueued for SPI with IPAddr: 166.34.245.231:5060
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: act_sentininvite_new_message
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: sipSPICheckResponse
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: sip_stats_status_code
*Mar 6 14:10:42: Roundtrip delay 4 milliseconds for method INVITE
```

## Cisco\_IOS\_Voice\_Troubleshooting\_and\_Monitoring\_--\_Cisco\_SIP\_Gateway\_Troubleshooting

```
*Mar 6 14:10:42: 0x624CFEF8 : State change from (STATE_SENT_INVITE, SUBSTATE_NONE)
  to (STATE_REC'D_PROCEEDING, SUBSTATE_PROCEEDING_PROCEEDING)
*Mar 6 14:10:42: Received:
SIP/2.0 180 Ringing
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>
Date: Mon, 08 Mar 1993 22:36:40 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Timestamp: 731427042
Server: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
CSeq: 101 INVITE
Content-Type: application/sdp
Content-Length: 137
v=0
o=CiscoSystemsSIP-GW-UserAgent 969 7889 IN IP4 166.34.245.231
s=SIP Call
t=0 0
c=IN IP4 166.34.245.231
m=audio 20038 RTP/AVP 0
*Mar 6 14:10:42: HandleUdpSocketReads :Msg enqueued for SPI with IPaddr: 166.34.245.231:5060
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: act_recdproc_new_message
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: sipSPICheckResponse
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: sipSPICheckResponse : Updating session description
*Mar 6 14:10:42: CCSIP-SPI-CONTROL: sip_stats_status_code
*Mar 6 14:10:42: Roundtrip delay 8 milliseconds for method INVITE
*Mar 6 14:10:42: HandleSIP1xxRinging: SDP MediaTypes negotiation successful!
Negotiated Codec      : g711ulaw , bytes :160
Inband Alerting      : 0
*Mar 6 14:10:42: 0x624CFEF8 : State change from (STATE_REC'D_PROCEEDING,
  SUBSTATE_PROCEEDING_PROCEEDING) to (STATE_REC'D_PROCEEDING, SUBSTATE_PROCEEDING_ALERTING)
*Mar 6 14:10:46: Received:
SIP/2.0 200 OK
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>;tag=27D3FCA8-C7F
Date: Mon, 08 Mar 1993 22:36:40 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Timestamp: 731427042
Server: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
Contact: <sip:3660210@166.34.245.231:5060;user=phone>
CSeq: 101 INVITE
Content-Type: application/sdp
Content-Length: 137
v=0
o=CiscoSystemsSIP-GW-UserAgent 969 7889 IN IP4 166.34.245.231
s=SIP Call
t=0 0
c=IN IP4 166.34.245.231
m=audio 20038 RTP/AVP 0
*Mar 6 14:10:46: HandleUdpSocketReads :Msg enqueued for SPI with IPaddr: 166.34.245.231:5060
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: act_recdproc_new_message
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: sipSPICheckResponse
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: sipSPICheckResponse : Updating session description
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: sip_stats_status_code
*Mar 6 14:10:46: Roundtrip delay 3536 milliseconds for method INVITE
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: act_recdproc_new_message:
  SDP MediaTypes negotiation successful!
Negotiated Codec      : g711ulaw , bytes :160
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: sipSPIReconnectConnection
*Mar 6 14:10:46: Queued event from SIP SPI : SIPSPI_EV_RECONNECT_CONNECTION
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: recv_200_OK_for_invite
*Mar 6 14:10:46: Queued event from SIP SPI : SIPSPI_EV_SEND_MESSAGE
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: sip_stats_method
```



## Cisco\_IOS\_Voice\_Troubleshooting\_and\_Monitoring\_--\_Cisco\_SIP\_Gateway\_Troubleshooting

```
*Mar 6 14:10:46: 0x624CFEF8 : State change from (STATE_REC'D_PROCEEDING,
SUBSTATE_PROCEEDING_ALERTING) to (STATE_ACTIVE, SUBSTATE_NONE)
*Mar 6 14:10:46: The Call Setup Information is :
    Call Control Block (CCB) : 0x624CFEF8
    State of The Call       : STATE_ACTIVE
    TCP Sockets Used       : NO
    Calling Number         : 3660110
    Called Number          : 3660210
    Negotiated Codec       : g711ulaw
    Source IP Address (Media): 166.34.245.230
    Source IP Port (Media): 20208
    Destn IP Address (Media): 166.34.245.231
    Destn IP Port (Media): 20038
    Destn SIP Addr (Control) : 166.34.245.231
    Destn SIP Port (Control) : 5060
    Destination Name       : 166.34.245.231
*Mar 6 14:10:46: HandleUdpReconnection: Udp socket connected for fd: 1 with
166.34.245.231:5060
*Mar 6 14:10:46: Sent:
ACK sip:3660210@166.34.245.231:5060;user=phone SIP/2.0
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>;tag=27D3FCA8-C7F
Date: Sat, 06 Mar 1993 19:10:42 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Max-Forwards: 6
Content-Type: application/sdp
Content-Length: 137
CSeq: 101 ACK
v=0
o=CiscoSystemsSIP-GW-UserAgent 1212 283 IN IP4 166.34.245.230
s=SIP Call
t=0 0
c=IN IP4 166.34.245.230
m=audio 20208 RTP/AVP 0
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: ccsip_caps_ind
*Mar 6 14:10:46: ccsip_caps_ind: Load DSP with codec (5) g711ulaw, Bytes=160
*Mar 6 14:10:46: ccsip_caps_ind: set DSP for dtmf-relay = CC_CAP_DTMF_RELAY_INBAND_VOICE
*Mar 6 14:10:46: CCSIP-SPI-CONTROL: ccsip_caps_ack
*Mar 6 14:10:50: Received:
BYE sip:3660110@166.34.245.230:5060;user=phone SIP/2.0
Via: SIP/2.0/UDP 166.34.245.231:54835
From: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>;tag=27D3FCA8-C7F
To: "3660110" <sip:3660110@166.34.245.230>
Date: Mon, 08 Mar 1993 22:36:44 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
User-Agent: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
Max-Forwards: 6
Timestamp: 731612207
CSeq: 101 BYE
Content-Length: 0
*Mar 6 14:10:50: HandleUdpSocketReads :Msg enqueued for SPI with IPAddr: 166.34.245.231:54835
*Mar 6 14:10:50: CCSIP-SPI-CONTROL: act_active_new_message
*Mar 6 14:10:50: CCSIP-SPI-CONTROL: sact_active_new_message_request
*Mar 6 14:10:50: CCSIP-SPI-CONTROL: sip_stats_method
*Mar 6 14:10:50: Queued event from SIP SPI : SIPSPI_EV_SEND_MESSAGE
*Mar 6 14:10:50: CCSIP-SPI-CONTROL: sip_stats_status_code
*Mar 6 14:10:50: CCSIP-SPI-CONTROL: sipSPIInitiateCallDisconnect :
    Initiate call disconnect(16) for outgoing call
*Mar 6 14:10:50: 0x624CFEF8 : State change from (STATE_ACTIVE, SUBSTATE_NONE)
to (STATE_DISCONNECTING, SUBSTATE_NONE)
*Mar 6 14:10:50: Sent:
SIP/2.0 200 OK
Via: SIP/2.0/UDP 166.34.245.231:54835
```

## Cisco\_IOS\_Voice\_Troubleshooting\_and\_Monitoring\_--\_Cisco\_SIP\_Gateway\_Troubleshooting

```
From: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>;tag=27D3FCA8-C7F
To: "3660110" <sip:3660110@166.34.245.230>
Date: Sat, 06 Mar 1993 19:10:50 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Server: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
Timestamp: 731612207
Content-Length: 0
CSeq: 101 BYE
*Mar 6 14:10:50: Queued event From SIP SPI to CCAPI/DNS : SIPSPI_EV_CC_CALL_DISCONNECT
*Mar 6 14:10:50: CCSIP-SPI-CONTROL: act_disconnecting_disconnect
*Mar 6 14:10:50: CCSIP-SPI-CONTROL: sipSPICallCleanup
*Mar 6 14:10:50: Queued event from SIP SPI : SIPSPI_EV_CLOSE_CONNECTION
*Mar 6 14:10:50: CLOSE CONNECTION TO CONNID:1
*Mar 6 14:10:50: sipSPIIcpifUpdate :CallState: 4 Playout: 1755 DiscTime:48305031
  ConnTime 48304651
*Mar 6 14:10:50: 0x624CFEF8 : State change from (STATE_DISCONNECTING, SUBSTATE_NONE)
to (STATE_DEAD, SUBSTATE_NONE)
*Mar 6 14:10:50: The Call Setup Information is :
  Call Control Block (CCB) : 0x624CFEF8
  State of The Call       : STATE_DEAD
  TCP Sockets Used       : NO
  Calling Number         : 3660110
  Called Number          : 3660210
  Negotiated Codec       : g711ulaw
  Source IP Address (Media): 166.34.245.230
  Source IP Port (Media): 20208
  Destn IP Address (Media): 166.34.245.231
  Destn IP Port (Media): 20038
  Destn SIP Addr (Control) : 166.34.245.231
  Destn SIP Port (Control) : 5060
  Destination Name       : 166.34.245.231
*Mar 6 14:10:50:
  Disconnect Cause (CC)   : 16
  Disconnect Cause (SIP)  : 200
*Mar 6 14:10:50: udpsock_close_connect: Socket fd: 1 closed for connid 1 with remote port: 5060
Router1#
```

The debug output is as follows from the other side of the call:

```
3660-2# debug ccsip all
All SIP call tracing enabled
3660-2#
*Mar 8 17:36:40: Received:
INVITE sip:3660210@166.34.245.231;user=phone;phone-context=unknown SIP/2.0
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>
Date: Sat, 06 Mar 1993 19:10:42 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Cisco-Guid: 2881152943-2184249548-0-483039712
User-Agent: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
CSeq: 101 INVITE
Max-Forwards: 6
Timestamp: 731427042
Contact: <sip:3660110@166.34.245.230:5060;user=phone>
Expires: 180
Content-Type: application/sdp
Content-Length: 137
v=0
o=CiscoSystemsSIP-GW-UserAgent 1212 283 IN IP4 166.34.245.230
s=SIP Call
t=0 0
c=IN IP4 166.34.245.230
```

## Cisco\_IOS\_Voice\_Troubleshooting\_and\_Monitoring\_--\_Cisco\_SIP\_Gateway\_Troubleshooting

```
m=audio 20208 RTP/AVP 0
*Mar 8 17:36:40: HandleUdpSocketReads :Msg enqueued for SPI with IPAddr: 166.34.245.230:54113
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: sipSPISipIncomingCall
*Mar 8 17:36:40: 0x624D8CCC : State change from (STATE_NONE, SUBSTATE_NONE)
to (STATE_IDLE, SUBSTATE_NONE)
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: act_idle_new_message
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: sact_idle_new_message_invite
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: sip_stats_method
*Mar 8 17:36:40: sact_idle_new_message_invite:Not Using Voice Class Codec
*Mar 8 17:36:40: sact_idle_new_message_invite: Preferred codec[0] type: g711ulaw Bytes :160
*Mar 8 17:36:40: sact_idle_new_message_invite: Media Negotiation successful for an
incoming call
*Mar 8 17:36:40: sact_idle_new_message_invite: Negotiated Codec
: g711ulaw, bytes :160
Preferred Codec : g711ulaw, bytes :160
*Mar 8 17:36:40: Queued event from SIP SPI : SIPSPI_EV_SEND_MESSAGE
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: sip_stats_status_code
*Mar 8 17:36:40: Num of Contact Locations 1 3660110 166.34.245.230 5060
*Mar 8 17:36:40: 0x624D8CCC : State change from (STATE_IDLE, SUBSTATE_NONE)
to (STATE_REC'D_INVITE, SUBSTATE_REC'D_INVITE_CALL_SETUP)
*Mar 8 17:36:40: Sent:
SIP/2.0 100 Trying
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>
Date: Mon, 08 Mar 1993 22:36:40 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Timestamp: 731427042
Server: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
CSeq: 101 INVITE
Content-Length: 0
*Mar 8 17:36:40: Queued event From SIP SPI to CCAPI/DNS : SIPSPI_EV_CC_CALL_PROCEEDING
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: act_rec'dinvite_proceeding
*Mar 8 17:36:40: Queued event From SIP SPI to CCAPI/DNS : SIPSPI_EV_CC_CALL_ALERTING
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: ccsip_caps_ind
*Mar 8 17:36:40: ccsip_caps_ind: codec(negotiated) = 5(Bytes 160)
*Mar 8 17:36:40: ccsip_caps_ind: Load DSP with codec (5) g711ulaw, Bytes=160
*Mar 8 17:36:40: ccsip_caps_ind: set DSP for dtmf-relay = CC_CAP_DTMF_RELAY_INBAND_VOICE
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: ccsip_caps_ack
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: act_rec'dinvite_alerting
*Mar 8 17:36:40: 180 Ringing with SDP - not likely
*Mar 8 17:36:40: Queued event from SIP SPI : SIPSPI_EV_SEND_MESSAGE
*Mar 8 17:36:40: CCSIP-SPI-CONTROL: sip_stats_status_code
*Mar 8 17:36:40: 0x624D8CCC : State change from (STATE_REC'D_INVITE,
SUBSTATE_REC'D_INVITE_CALL_SETUP) to (STATE_SENT_ALERTING, SUBSTATE_NONE)
*Mar 8 17:36:40: Sent:
SIP/2.0 180 Ringing
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>
Date: Mon, 08 Mar 1993 22:36:40 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Timestamp: 731427042
Server: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
CSeq: 101 INVITE
Content-Type: application/sdp
Content-Length: 137
v=0
o=CiscoSystemsSIP-GW-UserAgent 969 7889 IN IP4 166.34.245.231
s=SIP Call
t=0 0
c=IN IP4 166.34.245.231
m=audio 20038 RTP/AVP 0
*Mar 8 17:36:44: Queued event From SIP SPI to CCAPI/DNS : SIPSPI_EV_CC_CALL_CONNECT
```

## Cisco\_IOS\_Voice\_Troubleshooting\_and\_Monitoring\_--\_Cisco\_SIP\_Gateway\_Troubleshooting

```
*Mar 8 17:36:44: CCSIP-SPI-CONTROL: act_sentalert_connect
*Mar 8 17:36:44: sipSPIAddLocalContact
*Mar 8 17:36:44: Queued event from SIP SPI : SIPSPI_EV_SEND_MESSAGE
*Mar 8 17:36:44: CCSIP-SPI-CONTROL: sip_stats_status_code
*Mar 8 17:36:44: 0x624D8CCC : State change from (STATE_SENT_ALERTING, SUBSTATE_NONE)
to (STATE_SENT_SUCCESS, SUBSTATE_NONE)
*Mar 8 17:36:44: Sent:
SIP/2.0 200 OK
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>;tag=27D3FCA8-C7F
Date: Mon, 08 Mar 1993 22:36:40 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Timestamp: 731427042
Server: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
Contact: <sip:3660210@166.34.245.231:5060;user=phone>
CSeq: 101 INVITE
Content-Type: application/sdp
Content-Length: 137
v=0
o=CiscoSystemsSIP-GW-UserAgent 969 7889 IN IP4 166.34.245.231
s=SIP Call
t=0 0
c=IN IP4 166.34.245.231
m=audio 20038 RTP/AVP 0
*Mar 8 17:36:44: Received:
ACK sip:3660210@166.34.245.231:5060;user=phone SIP/2.0
Via: SIP/2.0/UDP 166.34.245.230:54113
From: "3660110" <sip:3660110@166.34.245.230>
To: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>;tag=27D3FCA8-C7F
Date: Sat, 06 Mar 1993 19:10:42 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Max-Forwards: 6
Content-Type: application/sdp
Content-Length: 137
CSeq: 101 ACK
v=0
o=CiscoSystemsSIP-GW-UserAgent 1212 283 IN IP4 166.34.245.230
s=SIP Call
t=0 0
c=IN IP4 166.34.245.230
m=audio 20208 RTP/AVP 0
*Mar 8 17:36:44: HandleUdpSocketReads :Msg enqueued for SPI with IPAddr: 166.34.245.230:54113
*Mar 8 17:36:44: CCSIP-SPI-CONTROL: act_sentsucc_new_message
*Mar 8 17:36:44: CCSIP-SPI-CONTROL: sip_stats_method
*Mar 8 17:36:44: 0x624D8CCC : State change from (STATE_SENT_SUCCESS, SUBSTATE_NONE)
to (STATE_ACTIVE, SUBSTATE_NONE)
*Mar 8 17:36:44: The Call Setup Information is :
    Call Control Block (CCB) : 0x624D8CCC
    State of The Call : STATE_ACTIVE
    TCP Sockets Used : NO
    Calling Number : 3660110
    Called Number : 3660210
    Negotiated Codec : g711lulaw
    Source IP Address (Media): 166.34.245.231
    Source IP Port (Media): 20038
    Destn IP Address (Media): 166.34.245.230
    Destn IP Port (Media): 20208
    Destn SIP Addr (Control) : 166.34.245.230
    Destn SIP Port (Control) : 5060
    Destination Name : 166.34.245.230
*Mar 8 17:36:47: Queued event From SIP SPI to CCAPI/DNS : SIPSPI_EV_CC_CALL_DISCONNECT
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: act_active_disconnect
*Mar 8 17:36:47: Queued event from SIP SPI : SIPSPI_EV_CREATE_CONNECTION
```

## Cisco\_IOS\_Voice\_Troubleshooting\_and\_Monitoring\_--\_Cisco\_SIP\_Gateway\_Troubleshooting

```
*Mar 8 17:36:47: 0x624D8CCC : State change from (STATE_ACTIVE, SUBSTATE_NONE)
to (STATE_ACTIVE, SUBSTATE_CONNECTING)
*Mar 8 17:36:47: REQUEST CONNECTION TO IP:166.34.245.230 PORT:5060
*Mar 8 17:36:47: 0x624D8CCC : State change from (STATE_ACTIVE, SUBSTATE_CONNECTING)
to (STATE_ACTIVE, SUBSTATE_CONNECTING)
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: act_active_connection_created
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: sipSPICheckSocketConnection
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: sipSPICheckSocketConnection: Connid(1)
created to 166.34.245.230:5060, local_port 54835
*Mar 8 17:36:47: Queued event from SIP SPI : SIPSPI_EV_SEND_MESSAGE
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: sip_stats_method
*Mar 8 17:36:47: 0x624D8CCC : State change from (STATE_ACTIVE, SUBSTATE_CONNECTING)
to (STATE_DISCONNECTING, SUBSTATE_NONE)
*Mar 8 17:36:47: Sent:
BYE sip:3660110@166.34.245.230:5060;user=phone SIP/2.0
Via: SIP/2.0/UDP 166.34.245.231:54835
From: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>;tag=27D3FCA8-C7F
To: "3660110" <sip:3660110@166.34.245.230>
Date: Mon, 08 Mar 1993 22:36:44 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
User-Agent: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
Max-Forwards: 6
Timestamp: 731612207
CSeq: 101 BYE
Content-Length: 0
*Mar 8 17:36:47: Received:
SIP/2.0 200 OK
Via: SIP/2.0/UDP 166.34.245.231:54835
From: <sip:3660210@166.34.245.231;user=phone;phone-context=unknown>;tag=27D3FCA8-C7F
To: "3660110" <sip:3660110@166.34.245.230>
Date: Sat, 06 Mar 1993 19:10:50 GMT
Call-ID: ABBAE7AF-823100CE-0-1CCAA69C@172.18.192.194
Server: Cisco VoIP Gateway/ IOS 12.x/ SIP enabled
Timestamp: 731612207
Content-Length: 0
CSeq: 101 BYE
*Mar 8 17:36:47: HandleUdpSocketReads :Msg enqueued for SPI with IPAddr: 166.34.245.230:54113
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: act_disconnecting_new_message
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: sact_disconnecting_new_message_response
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: sipSPICheckResponse
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: sip_stats_status_code
*Mar 8 17:36:47: Roundtrip delay 4 milliseconds for method BYE
*Mar 8 17:36:47: CCSIP-SPI-CONTROL: sipSPICallCleanup
*Mar 8 17:36:47: Queued event from SIP SPI : SIPSPI_EV_CLOSE_CONNECTION
*Mar 8 17:36:47: CLOSE CONNECTION TO CONNID:1
*Mar 8 17:36:47: sipSPIIcpifUpdate :CallState: 4 Playout: 1265 DiscTime:66820800
ConnTime 66820420
*Mar 8 17:36:47: 0x624D8CCC : State change from (STATE_DISCONNECTING, SUBSTATE_NONE)
to (STATE_DEAD, SUBSTATE_NONE)
*Mar 8 17:36:47: The Call Setup Information is :
Call Control Block (CCB) : 0x624D8CCC
State of The Call : STATE_DEAD
TCP Sockets Used : NO
Calling Number : 3660110
Called Number : 3660210
Negotiated Codec : g711ulaw
Source IP Address (Media): 166.34.245.231
Source IP Port (Media): 20038
Destn IP Address (Media): 166.34.245.230
Destn IP Port (Media): 20208
Destn SIP Addr (Control) : 166.34.245.230
Destn SIP Port (Control) : 5060
Destination Name : 166.34.245.230
*Mar 8 17:36:47:
```

## Cisco\_IOS\_Voice\_Troubleshooting\_and\_Monitoring\_--\_Cisco\_SIP\_Gateway\_Troubleshooting

```
Disconnect Cause (CC)      : 16
Disconnect Cause (SIP)     : 200
*Mar  8 17:36:47: udpsock_close_connect: Socket fd: 1 closed for connid 1
with remote port: 5060
```